



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)

# **PCM-DAS16D/12AO**

**ComputerBoards, Inc.**

Revision 2  
March 1999

### **LIFETIME PRODUCT WARRANTY**

Every ComputerBoards, Inc. product is warranted against defects in materials or workmanship for the life of the product, to the original purchaser. Any products found to be defective in material or workmanship will be repaired or replaced promptly.

### **LIFETIME HARSH ENVIRONMENT WARRANTY™**

Any ComputerBoards, Inc. product which is damaged due to misuse may be replaced for only 50% of the current price. I/O boards face some harsh environments, some harsher than the boards are designed to withstand. When that happens, just return the board with an order for its replacement at only 50% of the list price. ComputerBoards does not need to profit from your misfortune. By the way, we will honor this warranty for any other manufacturer's board that we have a replacement for!

### **30 DAY MONEY-BACK GUARANTEE**

Any ComputerBoards, Inc. product may be returned within 30 days of purchase for a full refund of the price paid for the product being returned. If you are not satisfied, or chose the wrong product by mistake, you do not have to keep it. Please call for a RMA number first. No credits or returns accepted without a copy of the original invoice. Some software products are subject to a repackaging fee.

*These warranties are in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness for a particular application. The remedies provided herein are the buyer's sole and exclusive remedies.*

*Neither ComputerBoards, Inc., nor its employees shall be liable for any direct or indirect, special, incidental or consequential damage arising from the use of its products, even if ComputerBoards has been notified in advance of the possibility of such damages.*

### **Notice**

***ComputerBoards, Inc. does not authorize any ComputerBoards, Inc. product for use in life support systems and/or devices without the written approval of the President of ComputerBoards, Inc. Life support devices/systems are devices or systems which, a) are intended for surgical implantation into the body, or b) support or sustain life and whose failure to perform can be reasonably expected to result in injury. ComputerBoards, Inc. products are not designed with the components required, and are not subject to the testing required to ensure a level of reliability suitable for the treatment and diagnosis of people.***

(C) Copyright 1999 ComputerBoards, Inc.

No part of this manual may be reproduced without written permission from ComputerBoards, Inc.

# TABLE OF CONTENTS

<b>1 INTRODUCTION</b>	<b>1</b>
<b>2 WINDOWS 95, 98 INSTALLATION</b>	<b>2</b>
2.1 INSTALL THE InstaCal SOFTWARE PACKAGE	2
2.2 INSTALL THE PCMCIA CARD	2
2.3 RUN InstaCal	3
2.4 TESTING THE INSTALLATION	3
<b>3 WINDOWS 3.X OR DOS INSTALLATION</b>	<b>4</b>
3.1 INSTALL THE InstaCal SOFTWARE PACKAGE	4
3.2 INSTALL THE PCMCIA CARD	4
3.3 RUN InstaCal	5
3.4 TESTING THE INSTALLATION	5
3.5 ABOUT DOS CARD & SOCKET SERVICES	5
<b>4 OPERATING MODES</b>	<b>7</b>
4.1 ANALOG INPUT RESOLUTION & RANGE	7
4.2 CONVERSION SPEED & AMPLIFICATION	7
4.3 TRIGGERING & TRANSFER	7
4.4 A/D PACER CONTROL	8
<b>5 SOFTWARE</b>	<b>9</b>
5.1 PROGRAMMING LANGUAGES	9
5.2 PACKAGED APPLICATIONS PROGRAMS	9
<b>6 ANALOG CONNECTIONS</b>	<b>10</b>
6.1 ANALOG INPUTS	10
6.2 ANALOG OUTPUTS	15
<b>7 I/O CONNECTOR PINOUT</b>	<b>16</b>
<b>8 BOARD ARCHITECTURE</b>	<b>17</b>
8.1 SOFTWARE CALIBRATION	17
8.2 CONTROL REGISTERS	17
<b>APPENDIX A: SPECIFICATIONS</b>	<b>19</b>
<b>APPENDIX B: ELECTRONICS AND INTERFACING</b>	<b>21</b>
B.1 VOLTAGE DIVIDERS	21
B.2 LOW PASS FILTERS	22

# 1 INTRODUCTION

---

---

The Computer Boards PCM-DAS16D/12AO is a multifunction analog and digital I/O card for DOS and Windows compatible computers with PC Card (PCMCIA) type 2 or 3 slots. Based on our popular PCM-DAS16D series, this model adds two channels of analog output. The heart of the board is an analog to digital converter. Analog signals are routed to the A/D via an 8:1 differential multiplexer controlled by a register on the PCM-DAS16. The analog input range is fully software programmable to any of the board's eight ranges. An on board pacer clock, external pacer input or software polling may trigger A/D conversions. Transfers may be via software polling, interrupt service or REP-INSW. A FIFO buffer provides data bus buffering between the A/D circuit and the PCMCIA bus. Four digital I/O lines (set as 4 in or 4 out) provide a means of sensing and controlling discrete events.

---

---

### 2.1 INSTALL THE *InstaCal* SOFTWARE PACKAGE

#### 2.1.1 INTRODUCTION

*InstaCal* is the installation, calibration and test software supplied with your data acquisition / IO hardware. The complete *InstaCal* package is also included with the Universal Library. If you have ordered the Universal Library, use the Universal Library disk set to install *InstaCal*. The installation will create all required files and unpack the various pieces of compressed software. To install *InstaCal*, simply run setup.exe, and follow the on-screen instructions.

#### 2.1.2 INSTALLATION OPTIONS

If you are installing on a Windows 95 or 98 operating system, the "Installation Options" dialog box will allow you to install the 16 bit, the 32 bit or both versions of *InstaCal*. Select the 32 bit version unless you intend to use a 16 bit application or library to control your data acquisition hardware.

If you are installing from the Universal Library disk set, the "Installation Options" dialog box also presents options to install example programs for each language supported. Select the appropriate example programs for the language you will be using.

#### 2.1.3 FILE DEFAULT LOCATION

*InstaCal* will place all appropriate files in "C:\CB." If you change this default location remember where the installed files are placed as you may need to access them later.

#### 2.1.4 INSTALLATION QUESTIONS

At the end of the installation process there will be a series of questions: unless you have knowledge to the contrary, simply accept the default when prompted.

#### 2.1.5 INSTALLATION COMPLETION

After the installation of *InstaCal* is complete you should restart your computer to take advantage of changes made to the system.


---

---

### 2.2 INSTALL THE PCMCIA CARD

Your PCM card is completely plug and play. There are no switches or jumpers to set prior to installation in your computer. Simply follow the steps shown below to install your PCM - hardware.

1. Insert the card into a free PC Card/PCMCIA type II or III slot. You do not have to turn the computer off. The system is designed for power on installation. Shown here is a PCM card case looking into the connector which is inserted into the PCMCIA slot of your computer. The KEY helps to insure that the PCM board is inserted in the correct orientation.



**PCMCIA CARD ORIENTATION - View into PCMCIA connector. The end which goes into the PCMCIA slot.**

2. If the appropriate drivers are already loaded on the PC, the card should be detected, recognized, and configured by Windows and you should hear an insertion beep. If the card is not detected by Windows, go to step 3. To verify the card has been recognized, go to Control Panel\System\Device Manager and the card should now appear under "DAS Component." If your card appears in the list you can now proceed to the "RUN *InstaCal*" section of this manual.

3. If the drivers are not already loaded on the PC, you will be prompted for a driver. If you are not prompted for a driver after inserting the card, go to step 4. The appropriate driver is located on disk 1 of the installation disk set. Insert this disk. Windows should detect the driver file automatically, install it and then the card should be detected by Windows and you should hear an insertion beep. To verify the card has been recognized, go to Control Panel\System\Device Manager and the card should now appear under "DAS Component." If your card appears in the list you can now proceed to the "RUN *InstaCal*" section of this manual.
4. If the card is not detected by Windows and you are not prompted for a driver after inserting the card, check that your computer's 32-bit PCMCIA drivers are enabled. If they are not, enable them and then restart your computer and try the above procedure again.

---

---

## 2.3 RUN *InstaCal*

Run the *InstaCal* program in order to configure the board for run-time use. By configuring the board, you add information to the configuration file, *cb.cfg*, that is used by the Universal Library and other third-party data acquisition packages that use the Universal Library to access the board.

### 2.3.1 RUNNING THE 32 BIT VERSION

You can run the 32 bit version of *InstaCal* by finding the file named "inscal32.exe" in your installation directory and double clicking it. You can also run *InstaCal* by going to your Start Menu then to Programs, then to ComputerBoards, and finally choosing *InstaCal*.

If you have a PCM board inserted in a PCM slot in your computer, *InstaCal* displays a dialog box indicating the device has been detected. Simply click "OK" to proceed with *InstaCal*.

If there are no other boards currently installed by *InstaCal*, then the PCM board will be assigned board number 0. Otherwise it will be assigned the next available board number.

You can now view and change the board configuration by clicking the properties icon or selecting the Install\Configure menu.

### 2.3.2 RUNNING THE 16 BIT VERSION

You can run the 16 bit version of *InstaCal* by finding the file named "instacal.exe" in your installation directory and double clicking it. You can also run *InstaCal* by going to your Start Menu then to Programs, then to ComputerBoards, and finally choosing "InstaCal 16."

If you have a PCM board inserted in a PCM slot in your computer, *InstaCal* displays a dialog box titled "Add PCM Card." Select "Yes." The next dialog box allows you to select a board number. Choose the default (0 if no other cards are already installed) or select a board number.

You can now select the Install menu (using the mouse or the letter "I" on the keyboard) to view or change the configuration of the board.

---

---

## 2.4 TESTING THE INSTALLATION

After you have run the install program, it is time to test the installation. The following section describes the *InstaCal* procedure to test that your board is properly installed.

With *InstaCal* running:

1. Select the board you just installed.
2. Select the "Test" function.

Follow the instructions provided to test for proper board operation.

## 3 WINDOWS 3.X OR DOS INSTALLATION

---

---

### 3.1 INSTALL THE *InstaCal* SOFTWARE PACKAGE

*InstaCal* is the installation, calibration and test software supplied with your data acquisition / IO hardware. The complete *InstaCal* package is also included with the Universal Library. If you have ordered the Universal Library, use the Universal Library disk set to install *InstaCal*. The installation will create all required files and unpack the various pieces of compressed software. To install *InstaCal*, simply run *setup.exe*, and follow the on-screen instructions.

#### 3.1.1 INSTALLATION OPTIONS

If you are installing from the Universal Library disk set, the "Installation Options" dialog box presents options to install libraries and example programs for each language supported. Select the appropriate library version and example programs for the language you will be using.

If your computer does not have the Windows operating system installed (only the DOS operating system is available), install the separate DOS-only *InstaCal* package called "InstaCal for DOS, Universal Library for DOS" available from your vendor.

Computers running Windows 3.x and/or DOS need to use the DOS based Card & Socket Services (CSS) drivers. CSS is included with most newer computers, but if you need to purchase these drivers, they are available from your vendor (order PCM CSS). During the *InstaCal* installation, you will be prompted to indicate whether or not to install CBCLIENT. Respond "Yes." CBCLIENT is used by CSS to configure the PCMCIA data acquisition cards. Remember, if you do not have CSS loaded, install it before attempting to use the PCMCIA card. More information about CSS is available in section 3.5 titled "About DOS Card & Socket Services."

*InstaCal* will place all appropriate files in "C:\CB." If you change this default location remember where the installed files are placed as you may need to access them later. At the end of the installation process there will be a series of questions: unless you have knowledge to the contrary, simply accept the default when prompted.


After the installation of *InstaCal* is complete you should restart your computer to take advantage of changes made to the system.

---

### 3.2 INSTALL THE PCMCIA CARD

Insert the card into a free PCM card slot and wait for the insertion tone (a double beep).

Shown here is a PCM card case looking into the connector which is inserted into the PCMCIA slot of your computer. The KEY helps to insure that the PCM board is inserted in the correct orientation.



**PCMCIA CARD ORIENTATION - View into PCMCIA connector. The end which goes into the PCMCIA slot.**



---

---

### 3.3 RUN *InstaCal*

Run the *InstaCal* program in order to configure the board for run-time use. By configuring the board, you add information to the configuration file, *cb.cfg*, that is used by the Universal Library and other third-party data acquisition packages that use the Universal Library to access the board.

To run *InstaCal* in Windows 3.x, find the file named *InstaCal.exe* in your installation directory or simply double click the *InstaCal.exe* icon.

From DOS, jsut type "Instacal" at the DOS prompt and hit "Enter."

If you have a PCM board inserted in a PCM slot in your computer, *InstaCal* displays a dialog box titled "Add PCM Card." Select "Yes." The next dialog box allows you to select a board number. Choose the default (0 if no other cards are already installed) or select a board number.

You can now select the install menu (using the mouse or the letter "I" on the keyboard) to view or change the configuration of the board.

---

---

### 3.4 TESTING THE INSTALLATION

After you have run the install program and set your base address with *InstaCal*, it is time to test the installation. The following section describes the *InstaCal* procedure to test that your board is properly installed.

With *InstaCal* running, choose the TEST item on the main menu.

- i. Select the board you just installed
- ii. If the choice "Internal Test" is available, then select Internal Test. If not, proceed to "v." below.
- iii. The internal control registers of the board will then be tested. If this test is successful, your board is installed correctly.
- iv. If the Internal Test is completed successfully, you may want to check that the I/O pins are working correctly. To check this select External Test and follow the instruction provided. This will require you to use the shorting wires supplied with the board to connect inputs to outputs for I/O testing. Some external tests may require an external voltage source and ohmmeter. All required equipment and connections will be listed by *InstaCal*.
- v. If the "I/O Test Menu" lists the option "Plot", the select it and make the connections as shown to test your card.

---

---

### 3.5 ABOUT DOS CARD & SOCKET SERVICES

The following section describes Card & Socket Services and should help you determine whether or not you need to install CSS.

Some operating systems, such as Windows 95, include an integrated version of CSS. If you are running such an operating system, do not install DOS CSS unless you have a specific reason to do so.

Card and socket services for your PCM card are on a disk labeled "DOS Card & Socket Services." The software from that disk should be installed if you do not already have CSS support on your PC.

#### 3.5.1 WHAT IS CSS?

CSS is a program that communicates with your computers PCMCIA interface controller and configures it. The PCMCIA interface is configurable, unlike the standard ISA bus you may be familiar with. If you plug a PCMCIA board into a PCMCIA slot and have not yet run CSS, you will have no access to the functions of that PCMCIA board.

#### 3.5.2 DOES CSS USE SYSTEM RESOURCES?

Yes. The CardSoft Card and Socket Services device drivers which are installed in your CONFIG.SYS use about 61K of memory. These files can be installed DEVICEHIGH.

The CBCLIENT.EXE installed in your AUTOEXEC.BAT uses about 10K of memory. The CBCLIENT.EXE program is a TSR (Terminate and Stay Resident). You may modify the program line to LOADHIGH the TSR. We have tested it both high and low with and without Windows and a variety of other applications. We believe it is a safe TSR that will not cause any system problems.

### **3.5.3 HOW DO I KNOW CSS IS INSTALLED AND RUNNING?**

There is a simple test. Just plug in your PCM-card. If CSS is installed and working the computer will beep. You can remove and replace your PCM-card as often as you like and need not power down to do so. The computer should beep each time you insert the PCM-card.

### **3.5.4 WHAT ABOUT CSS FOR MULTIPLE PCM BOARDS?**

Once the current version of CSS is installed, CSS is installed for all PCM boards included in that version of CSS. As new PCM boards become available, they will be added to the CSS and you will want to always have the most recent version of CBCLIENT.EXE installed in the C:\CB directory. Let the installation software do this for you.

You can run multiple PCMCIA boards with the CBCLIENT.EXE CSS, and, if you have another CLIENT program running for other PCMCIA boards, it will not interfere.

---

---

### 4.1 ANALOG INPUT RESOLUTION & RANGE

The 12 bit A/D converter provides a resolution of 1/4096 parts of full scale. The smallest reading of full scale (1 part in 4096) is called a Least Significant Bit (LSB). Accuracy is specified in LSBs. The PCM-DAS16D/12AO is accurate to +/- 1 LSB. Eight different ranges, four unipolar and four bipolar, are fully controlled by software. These are:

<u>Unipolar</u>	<u>1LSB</u>	<u>Bipolar</u>	<u>1LSB</u>
0 to 10V	0.00244V	+/-10V	0.00488V
0 to 5V	0.00122V	+/-5V	0.00244V
0 to 2.5V	0.0006V	+/-2.5V	0.00122V
0 to 1.25V	0.0003V	+/-1.25V	0.0006V

The input range is controlled by a programmable amplifier and is completely software selectable.

---

---

### 4.2 CONVERSION SPEED & AMPLIFICATION

The A/D chip always runs at full speed. The A/D converter and sample & hold circuit captures and digitizes a signal in 10 microseconds (10uS). The conversion speed of the A/D remains constant in all conditions and at all throughput rates. This is important. When you request a sample rate of say 20KHz, the A/D converter is still converting the signal in 10uS. The 20KHz rate comes from the fact that conversions are being initiated only every 50uS.

#### 4.2.1 WHAT FACTORS LIMIT CONVERSION SPEED?

The first is clearly the A/D. A 10uS conversion speed translates to a maximum throughput of 100KHz. The second limiting factor may be the analog front end.

The front-end consists of a multiplexer and a programmable gain amplifier. The speed at which these circuits can switch may also limit the throughput of the A/D board. That is, the rate at which it can acquire, convert and transfer a signal with full accuracy. Accuracy is the key term here. The A/D can always run at full speed, but has the front end settled and captured a true, accurate signal?

#### 4.2.2 WHAT ABOUT INPUT RANGE VS. SPEED?

Here is where the design of the analog front end is critical to maintaining total throughput. The A/D chip has a fixed input range of +/-10V. It is the analog front end that amplifies low level signals and adjusts unipolar signals to match the A/D converter's standard input.

A poorly designed analog front end will show up very quickly in the throughput specifications. If you see that an A/D board has high throughput in only one or two ranges but is slowed greatly at all other ranges, you are seeing the practical implications of a poor front end design. The PCM-DAS16D/12AO achieves 100KHz in all of the eight ranges.

---

---

### 4.3 TRIGGERING & TRANSFER

A Trigger is the event that begins an acquisition/transfer cycle. There are three ways to trigger a PCM-DAS16D/12AO; programmable pacer, software or external. The trigger source is programmable. The programmable pacer is the product of two 16 bit counters dividing a 10MHz or 1MHz wave derived from a 10MHz XTAL which may be used to trigger any number of paced conversions. A single conversion may be triggered by software at any time. External trigger, pacer clock and interrupt signals may also be used to control conversions and synchronize to external events.

Once a conversion is made the sample is placed into a 512 sample FIFO buffer from which it may be retrieved one sample at a time or in blocks via REP-INSW transfers.

### 4.3.1 HOW DO FIFO SIZE AND DESIGN AFFECT THROUGHPUT?

The FIFO buffer stores samples from the A/D converter as they are being converted. When a block of samples is ready and when the PC is ready, the FIFO is emptied into system memory. A properly designed FIFO of the correct size is a requirement for Windows, or samples will be lost at all but the slowest speeds.

Design of the FIFO is critical. Simply having a FIFO is not enough. Most ComputerBoards FIFO designs employ a half-full transfer initiation circuit. When the FIFO is half full, the transfer request is made. Samples continue to fill the second half of the FIFO while the CPU responds to the transfer request and transfers data to system memory.

Some other manufacturer's boards have only a 'FIFO full' circuit. What do you think happens to samples taken after the FIFO is full while waiting for the CPU to begin unloading the FIFO? FIFO size is critical also. We have seen boards with FIFOs as small as 16 samples. The PCM-DAS16D/12AO has a 512 sample FIFO buffer, a size we have determined through extensive testing to be a requirement for real situations.


---

---

## 4.4 A/D PACER CONTROL

Many analog acquisitions can be handled by a simple on-board rate divider created by combining an XTAL with a programmable counter. For those, the on-board 82C54 programmable rate generator supplies the pacing. Some applications require more flexible rate control. The PCM-DAS16 analog conversions may be externally triggered and thereby synchronized with events external to the PC. Conversions may be held off until some external event, such as a not-to-exceed condition is met. Conversions may be externally gated so that samples are taken only when an event of interest is occurring, such as process over normal limits.

Shown here is the A/D pacer clock schematic and the routing of off board trigger signals.



CLOCK, PACER & INTERRUPT CONTROL

In addition to the 8 analog inputs the PCM-DAS16D/12AO has an analog ground, 1 A/D trigger input, 1 interrupt input, 1 gate input, complete access to one 16 bit counter's clock, gate and output lines, access to the A/D pacer's counter output line, and 4 digital output/inputs and four pins for the two analog outputs. A digital ground is in the cable shield clips to either side of the 33 pins of the connector as well as one of the connector pins. Please look at the connector diagram for your board.

### INPUT WARNING!

*Do not exceed the input specifications. There are no socketed or user serviceable parts in a PCM board. Any repair will be expensive. Analog inputs are limited to +/-15V, unlike the higher ratings of ISA boards. If you apply a voltage < -0.5V or greater than 5.5V to a digital input, you will burn out the input transistor.*

*Please turn now to the table of specifications and familiarize yourself with them before connecting any signals.*

After running *InstaCAL* our PCM-DAS16D/12AO is installed and ready for use. Although the PCM-DAS16D/12AO is part of the larger CIO-DAS16 family, there is no correspondence between registers. Software written at the register level for the CIO- DAS16 or PC104-DAS16's will not work with the PCM-DAS16D/12AO.

---

---

### 5.1 PROGRAMMING LANGUAGES

The ComputerBoards UniversalLibrary provides complete access to the PCM-DAS16D/12AO functions from a range of programming languages; both DOS and Windows. If you are planning to write programs, or would like to run the example programs for Visual Basic or any other language, please turn now to the UniversalLibrary manual.

---

---

### 5.2 PACKAGED APPLICATIONS PROGRAMS

Many packaged application programs, such as Labtech Notebook now have drivers for the PCM-DAS16 family. If the package you own does not appear to have drivers for the PCM-DAS16D/12AO please fax the package name and the revision number from the install disks. We will research the package for you and advise by return fax how to obtain the correct drivers.



### 6.1 ANALOG INPUTS

Analog signal connection is one of the most challenging aspects of applying a data acquisition board. If you are an Analog Electrical Engineer then this section is not for you, but if you are like most PC data acquisition users, the best way to connect your analog inputs may not be obvious. Though complete coverage of this topic is well beyond the scope of this manual, the following section provides some explanations and helpful hints regarding these analog input connections. This section is designed to help you achieve the optimum performance from your PCM-DAS16D/12AO series board.

Prior to jumping into actual connection schemes, you should have at least a basic understanding of Single-Ended/Differential inputs and system grounding/isolation. If you are already comfortable with these concepts you may wish to skip to the next section (on wiring configurations).

#### 6.1.1 DIFFERENTIAL INPUTS

Differential inputs measure the voltage between two distinct input signals. Within a certain range (referred to as the common mode range), the measurement is almost independent of signal source to PCM-DAS16D/12AO ground variations. A differential input is also much more immune to EMI than a single-ended one. Most EMI noise induced in one lead is also induced in the other, the input only measures the difference between the two leads, and the EMI common to both is ignored. This effect is a major reason there is twisted pair wire as the twisting assures that both wires are subject to virtually identical external influence. The diagram below shows a typical differential input configuration.



Common Mode Voltage ( $V_{cm}$ ) is ignored by differential input configuration. However, note that  $V_{cm} + V_s$  must remain within the amplifier's common mode range of  $\pm 10V$

#### Differential Input with Common Mode Voltage

Before moving on to the discussion of grounding and isolation, it is important to explain the concepts of common mode, and common mode range (CM Range). Common mode voltage is depicted in the diagram above as  $V_{cm}$ . Though differential inputs measure the voltage between two signals, without (almost) respect to the either signal's voltages relative to ground, there is a limit to how far away from ground either signal can go. Though the PCM-DAS16D/12AO has differential inputs, it will not measure the difference between 100V and 101V as 1 Volt (in fact the 100V would destroy the board!). This limitation or common mode range is depicted graphically in the diagram below. The PCM-DAS16D/12AO common mode range is +/- 10 Volts. Even in differential mode, no input signal can be measured if it is more than 10V from the board's low level ground (LLGND).

### 6.1.2 SYSTEM GROUNDS AND ISOLATION

There are three scenarios possible when connecting your signal source to your PCM-DAS16D/12AO board.

1. The PCM-DAS16D/12AO and the signal source may have the same (or common) ground. This signal source may be connected directly to the PCM-DAS16D/12AO.
2. The PCM-DAS16D/12AO and the signal source may have an offset voltage between their grounds (AC and/or DC). This offset is commonly referred to as **common mode voltage**. Depending on the magnitude of this voltage, it may or may not be possible to connect the PCM-DAS16D/12AO directly to your signal source. We will discuss this topic further in a later section.
3. The PCM-DAS16D/12AO and the signal source may already have **isolated grounds**. This may be the case due to the signals source being isolated from ground, or because the host computer of the PCM-DAS16 board is isolated from ground (or both). In this case the signal source may be connected directly to the PCM-DAS16D/12AO.

### 6.1.3 WHICH SYSTEM DO YOU HAVE?

Try the following experiment. Using a battery powered voltmeter\*, measure the voltage (difference) between the ground signal at your signal source and at your PC. Place one voltmeter probe on the PC ground and the other on the signal source ground. Measure both the AC and DC Voltages.

*\*If you do not have access to a voltmeter, skip the experiment and take a look at the following three sections. You may be able to identify your system type from the descriptions provided.*

If both AC and DC readings are 0.00 volts, you may have a system with common grounds. However, since voltmeters will average out high frequency signals, there is no guarantee. Please refer to the section below titled Common Grounds.

If you measure reasonably stable AC and DC voltages, your system has an offset voltage between the grounds category. This offset is referred to as a Common Mode Voltage. Please be careful to read the following warning and then proceed to the section describing **Common Mode** systems.

#### WARNING

***If either the AC or DC voltage is greater than 10 volts, do not connect the PCM-DAS16D/12AO to this signal source. You are beyond the boards usable common mode range and will need to either adjust your grounding system or add special Isolation signal conditioning to take useful measurements. A ground offset voltage of more than 15 volts will likely damage the PCM-DAS16D/12AO board and possibly your computer.***

***This is such an important point, that we will state it again. If the voltage between the ground of your signal source and your PC is greater than 10 volts, your board will not take useful measurements. If this voltage is greater than 15 volts, it will likely cause damage, and may represent a serious shock hazard! In this case you will need to either reconfigure your system to reduce the ground differentials, or purchase and install special electrical isolation signal conditioning.***

If you cannot obtain a reasonably stable DC voltage measurement between the grounds, or the voltage drifts around considerably, the two grounds are most likely isolated. The easiest way to check for isolation is to change your voltmeter to it's ohm scale and measure the resistance between the two grounds. It is recommended that you turn both systems off prior to taking this resistance measurement. If the measured resistance is more than 100 Kohm, it's a fairly safe bet that your system has electrically **isolated grounds**.

#### **6.1.4 SYSTEMS WITH COMMON GROUNDS**

In the simplest (but perhaps least likely) case, your signal source will have the same ground as the PCM-DAS16D/12AO. This would typically occur when providing power or excitation to your signal source directly from the PCM-DAS16D/12AO. There may be other common ground configurations, but it is important to note that any voltage between the PCM-DAS16D/12AO ground and your signal ground is a potential error voltage if you set up your system based on a common ground assumption.

As a safe rule of thumb, if your signal source or sensor is not connected directly to an LLGND pin on your PCM-DAS16D/12AO, it's best to assume that you do not have a common ground even if your voltmeter measured 0.0 Volts. Configure your system as if there is ground offset voltage between the source and the PCM-DAS16D/12AO. This is especially true if you are using the PCM-DAS16D/12AO at high gains, since ground potentials in the sub millivolt range will be large enough to cause A/D errors, yet will not likely be measured by your hand held voltmeter.

#### **6.1.5 SYSTEMS WITH COMMON MODE (GROUND OFFSET) VOLTAGES**

The most frequently encountered grounding scenario involves grounds that are somehow connected, but have AC and/or DC offset voltages between the PCM-DAS16D/12AO and signal source grounds. This offset voltage may be AC, DC or both and may be caused by a wide array of phenomena including EMI pickup, resistive voltage drops in ground wiring and connections, etc.

#### **6.1.6 SMALL COMMON MODE VOLTAGES**

If the voltage between the signal source ground and PCM-DAS16D/12AO ground is small, the combination of the ground voltage and input signal will not exceed the PCM-DAS16D/12AO's +/-10V common mode range. (i.e. the voltage between grounds, added to the maximum input voltage, stays within +/-10V). This input is compatible with the PCM-DAS16D/12AO and the system may be connected without additional signal conditioning. Fortunately, most systems will fall in this category and have a small voltage differential between grounds.

#### **6.1.7 LARGE COMMON MODE VOLTAGES**

If the ground differential is large enough, the PCM-DAS16D/12AO's +/- 10V common mode range will be exceeded (i.e. the voltage between PCM-DAS16D/12AO and signal source grounds, added to the maximum input voltage you're trying to measure exceeds +/-10V). In this case the PCM-DAS16D/12AO cannot be directly connected to the signal source. You will need to change your system grounding configuration or add isolation signal conditioning. (Please give our technical support group a call to discuss other options.)

#### **NOTE**

Relying on the earth prong of a 120VAC for signal ground connections is not advised.. Different ground plugs may have large and potentially even dangerous voltage differentials. Remember that the ground pins on 120VAC outlets on different sides of the room may only be connected in the basement. This leaves the possibility that the "ground" pins may have a significant voltage differential (especially if the two 120 VAC outlets happen to be on different phases!)

#### **6.1.8 PCM-DAS16D/12AO AND SIGNAL SOURCE ALREADY HAVE ISOLATED GROUNDS**

Some signal sources will already be electrically isolated from the PCM-DAS16D/12AO. The diagram below shows a typical isolated ground system. This is often the case with PCM-based systems as they are frequently battery powered and not tied to any local ground. In addition, the signal source may be battery powered, or fully isolated. Isolated ground systems provide excellent performance, but require some extra effort during connections to assure optimum performance is obtained. Please refer to the following sections for further details.




### 6.1.9 WIRING CONFIGURATIONS

Combining all the grounding and input type possibilities provides us with the following potential connection configurations. The combinations along with our recommendations on usage are shown in the chart below.

The following sections depicts recommended input wiring schemes for each of the possible input configuration/grounding combinations.

#### 6.1.10 COMMON GROUND/DIFFERENTIAL INPUTS


The use of differential inputs to monitor a signal source with a common ground is an acceptable configuration though it requires more wiring and offers fewer channels than selecting a single-ended configuration. The diagram below shows the recommended connections in this configuration.



Signal source and A/D board sharing common ground connected to differential input.

#### 6.1.11 COMMON MODE VOLTAGE < +/-10V/DIFFERENTIAL INPUTS


Systems with varying ground potentials should always be monitored in the differential mode. Care is required to assure that the sum of the input signal and the ground differential (referred to as the common mode voltage) does not exceed the common mode range of the A/D board (+/-10V on the PCM-DAS16D/12AO). The diagram below show recommended connections in this configuration.



Signal source and A/D board with common mode voltage connected to a differential input.

### 6.1.12 COMMON MODE VOLTAGE > +/-10V


The PCM-DAS16D/12AO will not directly monitor signals with common mode voltages greater than +/-10V. You will either need to alter the system ground configuration to reduce the overall common mode voltage, or add isolated signal conditioning between the source and your board.



System with a Large Common Mode Voltage, Connected to a Differential Input

### 6.1.13 ISOLATED GROUNDS/DIFFERENTIAL INPUTS

Optimum performance with isolated signal sources is assured with the use of the differential input setting. The diagram below shows the recommend connections in this configuration.



Already isolated signal source and A/D board connected to a differential input.

---

---

## 6.2 ANALOG OUTPUTS

Analog outputs are simple voltage outputs which can be connected to any device which will record, display or be controlled by a voltage. The PCM-DAS16D/12AO analog outputs can be set to  $\pm 5V$  or  $\pm 10V$  full scale.

The output ranges of the PCM-DAS16D/12AO are set by software. The output ranges may be set within your program and range selection is supported by the Universal Library.

### 6.2.1 CONNECTING DEVICES TO THE ANALOG OUTPUTS

The PCM-DAS16D/12AO analog outputs are single ended. There is an analog ground for each analog output channel. When connecting to the analog output channels you should be sure that LL Gnd on pins 13 and/or 15 are used for Vout return connections.

You should be careful to avoid ground potentials between your external system and your computer board. In addition to avoiding potentials between signal grounds, you must also avoid potentials between signal ground and chassis ground on your computer. If you are using a laptop and are on battery power, the computer is floating with respect to earth ground, but if the laptop is on the charger unit or on wall power, the laptop may be grounded.

Whenever the computer is grounded, you must connect signals so there is no potential between PC ground and signal ground. If there is a potential, it will be added to the signal. For example, if your PCM-DAS16D/12AO is supplying 3.5 volts and there is a potential of -1.5V between the PC and the sensor ground, your device under control will be reading 2.0V instead of 3.5V

### 6.2.2 OUTPUT VOLTAGE RANGES

There are two possible output voltage ranges. Each DAC may be controlled independently, meaning that each DAC may have a different range. The output voltage range is controlled by software and may be selected via the Universal Library. To learn about controlling the outputs of the DACs please consult your software manual, either UniversalLibrary for programmers, or your application user's manual.

The available ranges are:

<u>Range</u>	<u>LSB Step Size</u>
+/-5V	0.00244 V
+/-10V	0.00488 V

## 7 I/O Connector Pinout

---

The I/O connections are made through a 33-pin miniature connector. We recommend you connect your field wiring to our CIO-MINI37 or CIO-TERMINAL screw terminal accessory board which then connects to the PCM card via the PCM-C37/33 cable. The Pinout of the PCM-DAS16D/12AO is shown below.

PIN#	DESIGNATION	PIN#	DESIGNATION
1	CTR 1 out	18	CHO Lo IN
2	CTR 1 gate	19	CHO Hi IN
3	CTR 1 CLK	20	CH1 Lo IN
4	CTR 3 out	21	CH1 Hi IN
5	Ext Trig/Clk	22	CH2 Lo IN
6	CTR 2 Gate	23	CH2 Hi IN
7	Ext INT	24	CH3 Lo IN
8	Dig Gnd	25	CH3 Hi IN
9	DIO 0	26	CH4 Lo IN
10	DIO 1	27	CH4 Hi IN
11	DIO 2	28	CH5 Lo IN
12	DIO 3	29	CH5 Hi IN
13	LL Gnd	30	CH6 Lo IN
14	Vout 0	31	CH6 Hi IN
15	LL Gnd	32	CH7 Lo IN
16	Vout 1	33	CH7 Hi IN
17	LL Gnd		

---

---

### 8.1 SOFTWARE CALIBRATION

If you are using the UniversalLibrary, you can set software calibration factors for offset and gain using the Calibration option of InstaCal. These factors will be applied to readings made by any of the A/D routines called from any of the language libraries of UniversalLibrary.

Choose Calibration from the InstaCal menu, and follow the instructions. Press F1 for help.

A base address register controls the beginning, or 'Base Address' of the I/O addresses occupied by the control registers of the PCM-DAS16D/12AO. In all, 32 addresses are occupied. The base address assigned by Card and Socket Services is stored in the CB.CFG file by Instacal and read by the Universal Library. Please read about installing and using InstaCal.

---

---

### 8.2 CONTROL REGISTERS

Once CSS is installed and a base address has been established, the PCM-DAS16 may be controlled by writing to and reading from the control registers. While it is possible to write your own control routines for the PCM-DAS16, routines have been written and are available in ComputerBoards' Universal Library for DOS and Windows programming languages.

#### NOTE ON REGISTER PROGRAMMING SUPPORT

While the complete register map is explained here, only very limited support for assembly language or direct register programming is available. Register level programming should only be attempted by experienced programmers. We support the use of the PCM-DAS16D/12AO through high level languages using UniversalLibrary and the example programs provided.

#### 8.2.1 MAJOR FUNCTIONS OF THE CONTROL REGISTERS

I/O ADDRESS	PCM-DAS16D/12AO FUNCTION R   W
BASE + 0	A/D Data & Channel   Start A/D
BASE + 2	Digital I/O, Channel Scan Limits
BASE + 4	Interrupt Control & Status, D/A Control
BASE + 6	Input Range and Trigger Method
BASE + 8	Counter 0 Read   Load
BASE + A	Counter 1 Read   Load
BASE + C	Counter 2 Read   Load
BASE + E	None   Counter Control

#### NOTE

*Since digital output control shares the same register as channel scan limits, simultaneous operation of digital output and analog input is not possible when acquiring analog data on more than one channel.*

## 8.2.2 INTERRUPT SOURCE CONTROL

The interrupt source is controlled by three bits.

INT2	INT1	INT0	SOURCE
0	0	1	Pacer - Counter 2
0	1	0	External - Pin 7
0	1	1	FIFO Not Empty
1	0	0	FIFO Half Full
1	0	1	End of Channel Scan

The A/D trigger source is controlled by two bits.

TS1	TS0	SOURCE
0	X	Software Trigger
1	0	Rising Trigger Input, Pin 5
1	1	Pacer - Counter 2

The range of analog input is set by 4 bits.

G3	G2	G1	G0	RANGE
1	0	0	0	+/- 10 V
0	0	0	0	+/- 5 V (A/D Std.)
0	0	0	1	+/- 2.5 V
0	0	1	0	+/- 1.25 V
0	1	0	0	0 to 10 V
0	1	0	1	0 to 5 V
0	1	1	0	0 to 2.5 V
0	1	1	1	0 to 1.25 V

The digital I/O lines may be set as follows via 1 control bit.

LDIR	Bits 3:0
0	Input
1	Output

*Typical for 25°C unless otherwise specified.*

### ANALOG INPUT SECTION

A/D convertor type	ADS7804
Resolution	12 bits
Programmable ranges	$\pm 10V, \pm 5V, \pm 2.5V, \pm 1.25V, 0-10V, 0-5V, 0-2.5V, 0-1.25V$
A/D pacing	Programmable: internal counter or external source (Ext Trig)
A/D Trigger sources	External hardware/software (Ext Trig)
Data transfer	From 512 sample FIFO via REPINSW, interrupt or software polled
Polarity	Bipolar, Unipolar
Number of channels	8 Differential
A/D conversion time	10 $\mu$ s
Throughput (post-process calibration)	100ksamples/sec
Accuracy (software calibrated)	$\pm 1$ LSB
Integral Linearity	$\pm 1$ LSB
Channel crosstalk	$\pm 1$ LSB
Gain drift	160ppm/ $^{\circ}$ C
Zero drift	150ppm/ $^{\circ}$ C
Common Mode Range	$\pm 10V$
CMRR @ 60Hz	-72dB
Input leakage current	200nA
Input impedance	10Mohms
Absolute maximum input voltage	$\pm 15V$

### ANALOG OUTPUT SECTION

D/A convertor type	LTC1446
Resolution	12 bits
Number of channels	2 Voltage Output Single-ended
Ranges	$\pm 10V, \pm 5V$ , each channel independently programmable
Offset error	$\pm 1$ LSB
Gain error	$\pm 1$ LSB
Differential nonlinearity	$\pm 0.5$ LSB max
Integral nonlinearity	$\pm 5$ LSB max, $\pm 2$ LSB typ
Monotonicity	Guaranteed monotonic over temperature
D/A Gain drift	$\pm 0.1$ LSB / $^{\circ}$ C
D/A offset drift	$\pm 15\mu V$ / $^{\circ}$ C
D/A pacing	Software
Data transfer	Software
Throughput (post-process calibration)	System dependent
Slew Rate	0.5 V/ $\mu$ s
Current Drive	$\pm 2$ mA
Output short-circuit duration	Indefinite @12mA
Output coupling	DC
Output impedance	200 ohms open loop
Miscellaneous	Double buffered output latches
Channel crosstalk	$\pm 1$ LSB max
Output inverted (0 code = +FS, 4095 = -FS)	
Noise	< 3 LSBs

## COUNTER SECTION

Counter type 82C54  
Configuration 3 down counters, 16 bits each

### Counter 0

Source: Programmable external (Ctr0 Clk) or 100kHz internal source  
Gate: Available at connector (Ctr0 Gate)  
Output: Available at connector (Ctr0 Out)

### Counter 1 - ADC Pacer Lower Divider

Source: Programmable, 1MHz or 10 MHz internal source  
Gate: Available at connector (Ctr1 Gate), pulled to logic high through 10k resistor  
Output: Chained to Counter 2 Clock

### Counter 2 - ADC Pacer Upper Divider

Source: Counter 1 Output  
Gate: Available at connector (Ext Trig). Programmable enable / disable  
Output: ADC Pacer clock, available at user connector (Ctr2 Out)

Clock input frequency	10Mhz max
High pulse width (clock input)	30ns min
Low pulse width (clock input)	50ns min
Gate width high	50ns min
Gate width low	50ns min
Input low voltage	0.8V max
Input high voltage	2.0V min
Output low voltage	0.4V max
Output high voltage	3.0V min

## DIGITAL I/O SECTION

Digital type	FPGA
Configuration	One port, four bits Programmable as 4 input, or 4 output
Input low voltage	0.8V max
Input high voltage	2.0V min
Output low voltage	(IOL = 4mA) 0.23V max
Output high voltage	(IOH = -4mA) 3.86V min
Absolute maximum input voltage	-0.5V , +5.5V
Interrupts	Programmable: levels 2 - 15
Interrupt enable	Programmable
Interrupt sources	End-of-conversion, FIFO-half-full, external (Ext Int, pin 7)
+5V quiescent	75 mA typical, 105 mA max
+5V during CIS read	90 mA typical, 130 mA max

## ENVIRONMENTAL

Operating temperature range	0 to 60°C
Storage temperature range	-40 to 100°C
Humidity	0 to 90% non-condensing



## B.1 VOLTAGE DIVIDERS

If you wish to measure a signal which varies over a range greater than the input range of a digital input, a voltage divider can drop the voltage of the input signal to the level the digital input can measure.

A voltage divider takes advantage of Ohm's law, which states,


$$\text{Voltage} = \text{Current} * \text{Resistance (commonly } V=IR)$$

and Kirkoff's voltage law which states,

The sum of the voltage drops around a circuit will be equal to the voltage drop for the entire circuit.

Implied in the above is that any variation in the voltage drop for the circuit as a whole will have a proportional variation in all the voltage drops in the circuit.

A voltage divider takes advantage of the fact that the voltage across one of the resistors in a circuit is proportional to the voltage across the total resistance in the circuit.



The trick to using a voltage divider is to choose two resistors with the proper proportions relative to the full scale of the digital input and the maximum signal voltage.

The phenomena of dropping the voltage proportionally is often called attenuation. The formula for attenuation is:

$$\text{Attenuation} = \frac{R1 + R2}{R2}$$

The variable Attenuation is the proportional difference between the signal voltage max and the full scale of the analog input.

$$2 = \frac{10K + 10K}{10K}$$

For example, if the signal varies between 0 and 20 volts and you wish to measure that with an analog input with a full scale range of 0 to 10 volts, the Attenuation is 2:1 or just 2.

$$R1 = (A - 1) * R2$$

For a given attenuation, pick a handy resistor and call it R2, then use this formula to calculate R1.

Digital inputs also make use of voltage dividers, for example, if you wish to measure a digital signal that is at 0 volts when off and 24 volts when on, you cannot connect that directly to the digital inputs. The voltage must be dropped to 5 volts max when on. The Attenuation is 24:5 or 4.8. Use the equation above to find an appropriate R1 if R2 is 1K. Remember that a TTL input is 'on' when the input voltage is greater than 2.5 volts.

**IMPORTANT NOTE:** *The resistors, R1 and R2, are going to dissipate all the power in the divider circuit according to the equation Current = Voltage / Resistance. The higher the value of the resistance (R1 + R2) the less power dissipated by the divider circuit. Here is a simple rule:*

For Attenuation of 5:1 or less, no resistor should be less than 10K.

For Attenuation of greater than 5:1, no resistor should be less than 1K.


The CIO-TERMINAL has the circuitry on board to create custom voltage dividers. The CIO-TERMINAL is a 16" by 4" screw terminal board with two 37 pin D type connectors and 56 screw terminals (12 - 22 AWG). Designed for table top, wall or rack mounting, the board provides prototype, divider circuit, filter circuit and pull-up resistor positions which you may complete with the proper value components for your application.

## B.2 LOW PASS FILTERS

A low pass filter is placed on the signal wires between a signal and an A/D board. It stops frequencies greater than the cut off frequency from entering the A/D board's analog or digital inputs.

The key term in a low pass filter circuit is cut off frequency. The cut of frequency is that frequency above which no variation of voltage with respect to time may enter the circuit. For example, if a low pass filter had a cut off frequency of 30 Hz, the kind of interference associated with line voltage (60Hz) would be filtered out but a signal of 25Hz would be allowed to pass.

Also, in a digital circuit, a low pass filter might be used to de-bounce an input from a momentary contact button pushed by a person.



A low pass filter may be constructed from one resistor (R) and one capacitor (C). The cut off frequency is determined according to the formula:

$$F_c = \frac{1}{2 * \text{Pi} * R * C}$$

$$R = \frac{1}{2 * \text{Pi} * C * F_c}$$

Where Pi = 3.14

## EC Declaration of Conformity

We, ComputerBoards, Inc., declare under sole responsibility that the product:

<u>PCM-DAS16D/12AO</u>	<u>PC CARD Analog I/O interface card</u>
Part Number	Description

to which this declaration relates, meets the essential requirements, is in conformity with, and CE marking has been applied according to the relevant EC Directives listed below using the relevant section of the following EC standards and other normative documents:

**EU EMC Directive 89/336/EEC:** Essential requirements relating to electromagnetic compatibility.

**EU 55022 Class B:** Limits and methods of measurements of radio interference characteristics of information technology equipment.

**EN 50082-1:** EC generic immunity requirements.

**IEC 801-2:** Electrostatic discharge requirements for industrial process measurement and control equipment.

**IEC 801-3:** Radiated electromagnetic field requirements for industrial process measurements and control equipment.

**IEC 801-4:** Electrically fast transients for industrial process measurement and control equipment.

Carl Haapaoja, Director of Quality Assurance

ComputerBoards, Inc.  
16 Commerce Boulevard  
Middleboro, MA 02346  
T:(508) 946-5100  
F: (508)946-9500  
[www.computerboards.com](http://www.computerboards.com)



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)