

Galil Motion Control DMC-4123
Motion Controller



**Limited Availability
Used and in Excellent Condition**

Open Web Page

<https://www.artisanng.com/77314-1>

All trademarks, brandnames, and brands appearing herein are the property of their respective owners.



Your **definitive** source
for quality pre-owned
equipment.

Artisan Technology Group

(217) 352-9330 | sales@artisanng.com | artisanng.com


- Critical and expedited services
- In stock / Ready-to-ship

- We buy your excess, underutilized, and idle equipment
- Full-service, independent repair center

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

DMC-41x3

Manual Rev. 1.3g



Galil Motion Control, Inc.

270 Technology Way
Rocklin, California

916.626.0101
support@galil.com
galil.com

09/2021

Using This Manual

This user manual provides information for proper operation of the DMC-41x3 controller. A separate supplemental manual, the Command Reference, contains a description of the commands available for use with this controller. It is recommended that the user download the latest version of the Command Reference and User Manual from the Galil Website.

<http://galil.com/downloads/manuals-and-data-sheets>

Your DMC-41x3 motion controller has been designed to work with both servo and stepper type motors. Installation and system setup will vary depending upon whether the controller will be used with stepper motors or servo motors. To make finding the appropriate instructions faster and easier, icons will be next to any information that applies exclusively to one type of system. Otherwise, assume that the instructions apply to all types of systems. The icon legend is shown below.



Attention: Pertains to servo motor use.



Attention: Pertains to stepper motor use.



Attention: Pertains to controllers with more than 4 axes.

Please note that many examples are written for the DMC-4143 four-axes controller or the DMC-4183 eight axes controller. Users of the DMC-4133 3-axis controller, DMC-4123 2-axes controller or DMC-4113 1-axis controller should note that the DMC-4133 uses the axes denoted as ABC, the DMC-4123 uses the axes denoted as AB, and the DMC-4113 uses the A-axis only.

Examples for the DMC-4183 denote the axes as A,B,C,D,E,F,G,H. Users of the DMC-4153 5-axes controller. DMC-4163 6-axes controller or DMC-4173, 7-axes controller should note that the DMC-4153 denotes the axes as A,B,C,D,E, the DMC-4163 denotes the axes as A,B,C,D,E,F and the DMC-4173 denotes the axes as A,B,C,D,E,F,G. The axes A,B,C,D may be used interchangeably with X, Y, Z, W.

WARNING	Machinery in motion can be dangerous! It is the responsibility of the user to design effective error handling and safety protection as part of the machinery. Galil shall not be liable or responsible for any incidental or consequential damages
----------------	--

Contents

Contents	iii
Chapter 1 Overview	1
Introduction.....	1
Part Numbers.....	2
Overview of Motor Types.....	6
Overview of External Amplifiers.....	6
Overview of Galil Amplifiers and Drivers.....	7
DMC-41x3 Functional Elements.....	8
Chapter 2 Getting Started	11
Elements You Need.....	11
Installing the DMC, Amplifiers, and Motors.....	12
Chapter 3 Connecting Hardware	20
Overview.....	20
Overview of Optoisolated Inputs.....	20
Optoisolated Input Electrical Information.....	23
Optoisolated Outputs.....	26
TTL Inputs and Outputs.....	30
Analog Inputs.....	32
External Amplifier Interface.....	33
Chapter 4 Software Tools and Communication	38
Introduction.....	38
Controller Response to Commands.....	38
Unsolicited Messages Generated by Controller.....	39
USB and RS-232 Ports.....	39
Ethernet Configuration.....	41
Modbus.....	43
Data Record.....	47
Galil Software.....	51
Creating Custom Software Interfaces.....	51
Chapter 5 Command Basics	52
Introduction.....	52
Command Syntax - ASCII.....	52
Controller Response to DATA.....	53
Interrogating the Controller.....	54
Chapter 6 Programming Motion	56
Overview.....	56
Independent Axis Positioning.....	57
Independent Jogging.....	59
Position Tracking.....	60
Linear Interpolation Mode.....	64
Vector Mode: Linear and Circular Interpolation Motion.....	67
Electronic Gearing.....	74
Electronic Cam.....	77
PVT Mode.....	82
Contour Mode.....	85
Virtual Axis.....	89
Stepper Motor Operation.....	90

Stepper Position Maintenance Mode (SPM).....	92
Dual Loop (Auxiliary Encoder).....	95
Motion Smoothing	97
Homing.....	98
High Speed Position Capture (The Latch Function)	101
Chapter 7 Application Programming	102
Overview.....	102
Program Format.....	102
Executing Programs - Multitasking.....	104
Debugging Programs.....	105
Program Flow Commands.....	106
Mathematical and Functional Expressions.....	121
Variables.....	124
Operands.....	125
Arrays.....	126
Input of Data (Numeric and String).....	129
Output of Data (Numeric and String).....	131
Hardware I/O.....	135
Example Applications.....	139
Using the DMC Editor to Enter Programs (Advanced).....	143
Chapter 8 Hardware & Software Protection	145
Introduction.....	145
Hardware Protection.....	145
Software Protection.....	146
Chapter 9 Troubleshooting	150
Overview.....	150
Chapter 10 Theory of Operation	153
Overview.....	153
Operation of Closed-Loop Systems.....	154
System Modeling.....	155
System Analysis.....	159
System Design and Compensation.....	161
Appendices	164
Electrical Specifications.....	164
Performance Specifications.....	166
Ordering Options.....	167
Power Connector Part Numbers.....	172
Cable Shielding.....	173
Input Current Limitations.....	174
Pin-outs.....	175
Signal Descriptions.....	179
List of Other Publications.....	181
Training Seminars.....	181
Contacting Us.....	182
WARRANTY.....	182
Integrated Components	183
Overview.....	183
A1 – AMP-43040 (-D3040,-D3020)	185
Description.....	185
Electrical Specifications.....	186
Operation.....	187
Error Monitoring and Protection.....	189
A2 – AMP-43140 (-D3140)	191
Description.....	191

Electrical Specifications.....	192
Operation.....	193
A3 – AMP-43240 (-D3240)	194
Description.....	194
Electrical Specifications.....	195
Operation.....	196
Error Monitoring and Protection.....	198
A4 – AMP-43540 (-D3540, -D3520)	200
Description.....	200
Electrical Specifications.....	201
Servo Motor Operation.....	202
Error Monitoring and Protection.....	205
A5 – AMP-43547 (-D3547, -D3527)	207
Description.....	207
Electrical Specifications.....	208
Servo Motor Operation.....	209
Stepper Motor Operation.....	212
Error Monitoring and Protection.....	213
A6 – AMP-43640 (-D3640)	215
Introduction.....	215
Electrical Specifications.....	216
Operation.....	218
A7 – SDM-44040 (-D4040, -D4020)	221
Description.....	221
Electrical Specifications.....	222
Operation.....	223
A8 – SDM-44140 (-D4140)	225
Description.....	225
Electrical Specifications.....	226
Operation.....	227

Chapter 1 Overview

Introduction

The DMC-41x3 Series are Galil's Econo motion controller that is a scaled-down version of the DMC-40x0 Acclerra series controller. The controller series offers many enhanced features compared to prior generation Econo series controllers including high speed communications, non-volatile program memory, faster encoder speeds, and improved cabling for EMI reduction.

Each DMC-41x3 provides two communication channels: a high speed 100BaseT Ethernet connection and a USB programming port. There is an auxiliary RS-232 port that can be used to communicate to external devices such as HMI's. The controllers allow for high-speed servo control up to 15 million encoder counts/sec and step motor control up to 3 million steps per second. Sample rates as low as 62 μ sec per axis are available.

A Flash EEPROM provides non-volatile memory for storing application programs, parameters, arrays and firmware. New firmware revisions are easily upgraded in the field.

The DMC-41x3 is available with up to eight axes in a single stand alone unit. The DMC-4113, 4123, 4133, 4143 are one thru four axes controllers and the DMC-4153, 4163, 4173, 4183 are five thru eight axes controllers. All eight axes have the ability to use Galil's integrated amplifiers or drivers and connections for integrating external devices.

Designed to solve complex motion problems, the DMC-41x3 can be used for applications involving jogging, point-to-point positioning, vector positioning, electronic gearing, multiple move sequences, contouring and a PVT Mode. The controller eliminates jerk by programmable acceleration and deceleration with profile smoothing. For smooth following of complex contours, the DMC-41x3 provides continuous vector feed of an infinite number of linear and arc segments. The controller also features electronic gearing with multiple master axes as well as gantry mode operation.

For synchronization with outside events, the DMC-41x3 provides uncommitted I/O, including 8 optoisolated digital inputs (16 inputs for DMC-4153 thru DMC-4183), 8 optically isolated outputs (16 outputs for DMC-4153 thru DMC-4183), and 8 analog inputs for interface to joysticks, sensors, and pressure transducers. Further I/O is available if the auxiliary encoders are not being used (2 inputs / each axis). Dedicated optoisolated inputs are provided for forward and reverse limits, abort, home, and definable input interrupts.

Commands are sent in ASCII. Additional software is available for automatic-tuning, trajectory viewing on a PC screen, and program development using many environments such as Visual Basic, C, C++ etc. Drivers for Windows XP, Vista and 7 (32 & 64 bit) as well as Linux are available.

Part Numbers

The DMC controller board comes in two sizes, 1-4 axis models (labeled A-D) and 5-8 axis models (labeled E-H). The number of axis is designated by x in the part number DMC-41x3. In addition, Axis A-D and Axis E-H have their own set of axis-specific options that can be ordered. For example, Axis A-D can have a different set of feedback options as Axis E-H even though they reside on the same DMC-41x3 board. The DMC-41x3 can also be ordered with optional internal amplifiers, labeled as AMP or SDM. These amplifiers are “sandwiched” to the back of the DMC-41x3 board. The abstract internal layout of a DMC-41x3 with optional AMP/SDM is shown for 1-4 axis in Figure 1.1.




Figure 1.1: Abstract layout of a 1-4 axis DMC-41x3 and optional internal amp

The 5-8 axis models have room for an additional bank of internal amplifiers as shown in Figure 1.2.




Figure 1.2: Abstract layout of a 5-8 axis DMC-41x3 and optional internal amps

It is important to note that if the DMC-41x3 is ordered *without* optional AMP/SDM options that it can come in either a card or box form factor, ordered as -CARD or -BOXn respectively; where n denotes 4 (for 1-4 axis models) or 8 (for 5-8 axis models). If the DMC-41x3 is ordered *with* an optional AMP/SDM then it *must* be ordered with a -BOXn. Table 1.1 below shows the different form factors and the appropriate part numbers to order them.




Form Factor (example)	Part Number	Description
	-CARD	DMC-41x3, 1-4 axis model ordered with the -CARD option.
	-CARD	DMC-41x3, 5-8 axis model ordered with the -CARD option.
	-BOX4	DMC-41x3, 1-4 axis model ordered with the -BOX4 option. This option is <i>required</i> if the DMC-41x3 is ordered with internal amplifiers, AMP or SDM. This example shows a DMC-41x3 with an internal AMP.
	-BOX8	DMC-41x3, 1-4 axis model ordered with the -BOX8 option. This option is <i>required</i> if the DMC-41x3 is ordered with internal amplifiers, AMP and/or SDM. This example shows a DMC-41x3 with internal AMPs.

Table 1.1: Explanation of different form factor options for the DMC-41x3

The full DMC-41x3 part number is a combination of the DMC controller part number (DMC-41x3), form factor ("-XXXX(Y)), axis-specific options (-ABCD(Y) and -EFGH(Y)), and optional amplifier types (-DXXXX(Y)), where Y is customization options for that specific board or set of axis. The layout of the full DMC-41x3 part number is shown in Figure 1.3 below.




Figure 1.3: Layout of the full DMC-41x3 part number

If the part number is not readily available, you can determine the information by using the 'ID' command. Issuing an 'ID' command when connected to the controller will return your controller's internal hardware configuration.

The placement of the AMP/SDM options is extremely important for 5-8 axis models. Reading the DMC-41x3 part number in Figure 1.3 from left to right, the first AMP/SDM (Axis A-D) will be placed in the AMP(1) spot as shown in Figure 1.2 and the second AMP/SDM (Axis E-H) will be placed in the AMP(2) spot.

Many “Y” options can be ordered *per* board or set of axis if separated by a comma. Please use the DMC-41x3 part number generator to check the validity of all part numbers before ordering:

<http://galil.com/order/part-number-generator/dmc-41x3>

DMC and Form Factor, “DMC-41X3-XXXX(Y)” Options

Option Type	Options	Brief Description	Documentation
X	1, 2, 3, 4, 5, 6, 7, and 8	Number of controller axis	N/A
-XXXX	-CARD	See Table 1.1	See DMC and Form Factor , “DMC-41x3-XXXX(Y)” Options, starting on pg 167
	-BOX4		
	-BOX8		
Y	DIN	DIN Rail Mount clips (-BOXn only)	
	12 VDC	Power Controller with 12 VDC	
	16-bit	16-bit analog inputs	
	4-20mA	4-20mA analog inputs	
	TRES	Encoder terminating resistors	
	ISCNTL	Isolate Controller Power	
	422	RS-422 on Aux Serial Port	
	ETL	ETL Certification	
	MO	Motor off jumpers added	

Table 1.2: Brief list of DMC and Form Factor options

Axis-specific options, “-ABCD(Y) and -EFGH(Y)”

Option Type	Options	Brief Description	Documentation
Y	SER	BiSS and SSI feedback	SER – BiSS and SSI Absolute Encoder Interface, starting on pg 170
	HSRC	500mA Sourcing Outputs	500mA Sourcing Optoisolated Outputs (HSRC), pg 29
	LSNK	25mA Sinking Outputs	25mA Sinking Optoisolated Outputs (LSNK), pg 27
	LSRC	25mA Sourcing Outputs	25mA Sourcing Optoisolated Outputs (LSRC), pg 28

Table 3: Brief list of axis-specific options

It is important to note that 1-4 axis models come with a single bank (Bank 0) of eight optoisolated specified by -ABCD(Y). 5-8 axis models comes with an *additional* bank (Bank 1) of eight optoisolated outputs specified by -EFGH(Y). See Optoisolated Input Electrical Information, pg 23 for further details.

WARNING	If no option is specified, the default optoisolated outputs for -ABCD and -EFGH are 4mA sinking , see 4mA Sinking Optoisolated Outputs (Default), pg 26 for further details.
----------------	---

AMP/SDM, “-DXXXX(Y)” Options

Option Type	Options	Brief Description	Documentation
XXXX	3020/3040	500 W trapazoidal servo drive 2 and 4-axis models	Error: Reference source not found, pg Error: Reference source not found
	3140	20 W brush-type only drive	Error: Reference source not found, pg Error: Reference source not found
	3240	750 W trapazoidal servo drive	Error: Reference source not found, pg Error: Reference source not found
	3520/3540	600 W sinusoidal servo drive 2 and 4-axis models	A4 – AMP-43540 (-D3540, -D3520), pg 202
	3527/3547	600 W sinusoidal servo and microstepping drive	A5 – AMP-43547 (-D3547, -D3527), pg 209
	3640	20 W sinusoidal servo drive	A6 – AMP-43640 (-D3640), pg 217
	4040/4020	1.4 A with 1/16 microstepping drive	A7 – SDM-44040 (-D4040,-D4020), pg 223
	4140	3 A with 1/64 microstepping drive	A8 – SDM-44140 (-D4140), pg 227
Y	ISAMP	Isolates power between amplifiers Two banks of AMP/SDMs required	AMP/SDM, “-DXXXX(Y)” Internal Amplifier Options, starting on pg 170 ¹ Not available for all amplifier options, see the proper documentation.
	SR90	SR-49000 Shunt regulator option	
	SSR	Solid state relay ¹	
	100mA	100mA current -D3140 option only	
	HALLF	Filtered hall inputs	

Table 1.4: Brief list of amplifier options

Overview of Motor Types

The DMC-41x3 can provide the following types of motor control:

1. Standard servo motors with ± 10 volt command signals
2. Step motors with step and direction signals
3. Other actuators such as hydraulics and ceramic motors - For more information, contact Galil.

The user can configure each axis for any combination of motor types, providing maximum flexibility.

Standard Servo Motor with ± 10 Volt Command Signal

The DMC-41x3 achieves superior precision through use of a 16-Bit motor command output DAC and a sophisticated PID filter that features velocity and acceleration feed-forward, an extra pole filter and integration limits.

The controller is configured by the factory for standard servo motor operation. In this configuration, the controller provides an analog signal (± 10 volts) to connect to a servo amplifier. This connection is described in Chapter 2.

Stepper Motor with Step and Direction Signals



The DMC-41x3 can control stepper motors. In this mode, the controller provides two signals to connect to the stepper motor: Step and Direction. For stepper motor operation, the controller does not require an encoder and operates the stepper motor in an open loop fashion. Chapter 2 describes the proper connection and procedure for using stepper motors.

If encoders are available on the stepper motor, Galil's Stepper Position Maintenance Mode may be used for automatic monitoring and correction of the stepper position. See Stepper Position Maintenance Mode (SPM) in Chapter 6 for more information.

Overview of External Amplifiers

The amplifiers should be suitable for the motor and may be linear or pulse-width-modulated. An amplifier may have current feedback, voltage feedback or velocity feedback.

Amplifiers in Current Mode

Amplifiers in current mode should accept an analog command signal in the ± 10 volt range. The amplifier gain should be set such that a +10V command will generate the maximum required current. For example, if the motor peak current is 10A, the amplifier gain should be 1 A/V.

Amplifiers in Velocity Mode

For velocity mode amplifiers, a command signal of 10 volts should run the motor at the maximum required speed. The velocity gain should be set such that an input signal of 10V runs the motor at the maximum required speed.

Stepper Motor Amplifiers



For step motors, the amplifiers should accept step and direction signals.

Overview of Galil Amplifiers and Drivers

With the DMC-41x3 Galil offers a variety of Servo Amplifiers and Stepper Drivers that are integrated into the same enclosure as the controller. Using the Galil Amplifiers and Drivers provides a simple straightforward motion control solution in one box. Instead of having to route a +/-10V motor command signal, or STEP/DIR to some external box, all the wiring is taken care of internally. In addition, Galil's internal amplifiers reside inside the same box as the controller, saving real estate space and the hassle of configuring a separate device.

A full list of amplifier specifications and details can be found in the Integrated Components, starting on pg 183.

DMC-41x3 Functional Elements

The DMC-41x3 circuitry can be divided into the following functional groups as shown in Figure 1.4 and discussed below.




Figure 1.4: DMC-41x3 Functional Elements

Microcomputer Section

The main processing unit of the controller is a specialized Microcomputer with RAM and Flash EEPROM. The RAM provides memory for variables, array elements, and application programs. The flash EEPROM provides non-volatile storage of variables, programs, and arrays. The Flash also contains the firmware of the controller, which is field upgradeable.

Motor Interface

Galil's GL-1800 custom, sub-micron gate array performs quadrature decoding of each encoder at up to 15 MHz. For standard servo operation, the controller generates a ± 10 volt analog signal (16 Bit DAC). For stepper motor operation, the controller generates a step and direction signal.

Communication

The communication interface with the DMC-41x3 consists of high speed 100bT Ethernet and a USB programming port.

General I/O

The DMC-41x3 provides interface circuitry for 8 bi-directional, optoisolated inputs, 8 optoisolated outputs and 8 analog inputs with 12-Bit ADC (16-Bit optional). Unused auxiliary encoder inputs may also be used as additional

inputs (2 inputs / each axis). The general inputs as well as the index pulse can also be used as high speed latches for each axis. A high speed encoder compare output is also provided.

4183

The DMC-4153 through DMC-4183 controller provides an additional 8 optoisolated inputs and 8 optoisolated outputs.

System Elements

As shown in Figure 1.5, the DMC-41x3 is part of a motion control system which includes amplifiers, motors and encoders. These elements are described below.




Figure 1.5: Elements of Servo Systems

Motor

A motor converts current into torque which produces motion. Each axis of motion requires a motor sized properly to move the load at the required speed and acceleration.

The motor may be a step or servo motor and can be brush-type or brushless, rotary or linear. For step motors, the controller can be configured to control full-step, half-step, or microstep drives. An encoder is not required when step motors are used.

Other motors and devices such as Ultrasonic Ceramic motors and voice coils can be controlled with the DMC-41x3.

Amplifier (Driver)

For each axis, the power amplifier converts a ± 10 volt signal from the controller into current to drive the motor. For stepper motors, the amplifier converts step and direction signals into current. The amplifier should be sized properly to meet the power requirements of the motor. For brushless motors, an amplifier that provides electronic commutation is required or the controller must be configured to provide sinusoidal commutation. The amplifiers may be either pulse-width-modulated (PWM) or linear. They may also be configured for operation with or without a tachometer. For current amplifiers, the amplifier gain should be set such that a 10 volt command generates the maximum required current. For example, if the motor peak current is 10A, the amplifier gain should be 1 A/V. For velocity mode amplifiers, 10 volts should run the motor at the maximum speed.

Galil offers amplifiers that are integrated into the same enclosure as the DMC-41x3. See the Integrated section in the Appendices or <http://galil.com/motion-controllers/multi-axis/dmc-41x3> for more information.

Encoder

An encoder translates motion into electrical pulses which are fed back into the controller. The DMC-41x3 accepts feedback from either a rotary or linear encoder. Typical encoders provide two channels in quadrature, known as

MA and MB. This type of encoder is known as a quadrature encoder. Quadrature encoders may be either single-ended (MA and MB) or differential (MA+, MA- and MB+, MB-). The DMC-41x3 decodes either type into quadrature states or four times the number of cycles. Encoders may also have a third channel (or index) for synchronization.

The DMC-41x3 can be ordered with 120 Ω termination resistors installed on the encoder inputs. See the Ordering Options in the Appendix for more information.

The DMC-41x3 can also interface to encoders with pulse and direction signals. Refer to the “CE” command in the command reference for details.

There is no limit on encoder line density; however, the input frequency to the controller must not exceed 3,750,000 full encoder cycles/second (15,000,000 quadrature counts/sec). For example, if the encoder line density is 10,000 cycles per inch, the maximum speed is 375 inches/second. If higher encoder frequency is required, please consult the factory.

The standard encoder voltage level is TTL (0-5v), however, voltage levels up to 12 Volts are acceptable. (If using differential signals, 12 Volts can be input directly to the DMC-41x3. Single-ended 12 Volt signals require a bias voltage input to the complementary inputs).

The DMC-41x3 can accept analog feedback ($\pm 10v$) instead of an encoder for any axis. For more information see the command AF in the command reference.

To interface with other types of position sensors such as absolute encoders, Galil can customize the controller and command set. Please contact Galil to talk to one of our applications engineers about your particular system requirements.

Watch Dog Timer

The DMC-41x3 provides an internal watch dog timer which checks for proper microprocessor operation. The timer toggles the Amplifier Enable Output (AMPEN) which can be used to switch the amplifiers off in the event of a serious DMC-41x3 failure. The AMPEN output is normally high. During power-up and if the microprocessor ceases to function properly, the AMPEN output will go low. The error light will also turn on at this stage. A reset is required to restore the DMC-41x3 to normal operation. Consult the factory for a Return Materials Authorization (RMA) Number if your DMC-41x3 is damaged.

Chapter 2 Getting Started

Elements You Need

For a complete system, Galil recommends the following elements:

1. DMC-41x3 series motion controller
2. Motor Amplifiers (integrated when using Galil amplifiers)
3. Power Supply for controller and amplifiers
4. Brushed or brushless servo motors with encoders or stepper motors
5. Cables for connecting motors and encoders to DMC-41x3
6. PC running Windows 7 or newer (64 bit) or Linux (64 bit)
7. Ethernet cable or straight-through serial cable
8. GDK software

GDK is recommended for first time users of the DMC-41x3. It provides interactive instructions for system connection, tuning, and analysis.

Installing the DMC, Amplifiers, and Motors

Installation of a complete, operational motion control system consists of the following steps:

- | | |
|--|---------------------------------|
| Step 1. Connecting Encoder Feedback, pg 13 | <i>Optional for steppers</i> |
| Step 2a. Wiring Motors to Galil's Internal Amplifiers, pg 14 | <i>Internal Amplifiers only</i> |
| Step 2b. Connecting External Amplifiers and Motors, pg 15 | <i>External Amplifiers only</i> |
| Step 3. Power the Controller, pg 16 | |
| Step 4. Install the Communications Software, pg 17 | |
| Step 5. Establish Communications with Galil Software, pg 17 | |
| Step 6. Motor Setup with GDK Step-By-Step, pg 17 | <i>Internal Amplifiers only</i> |
| Step 7. Setting Safety Features, pg 18 | |
| Step 8. Tune the Servo System, pg 19 | <i>Servo motors only</i> |

WARNING	All wiring procedures and suggestions mentioned in the following sections should be done with the controller in a powered-off state. Failing to do so can cause harm to the user or to the controller.
----------------	--

NOTE	The following instructions are given for Galil products only. If wiring an non-Galil device, follow the instructions provided with that product. Galil shall not be liable or responsible for any incidental or consequential damages that occur to a 3 rd party device.
-------------	---

Step 1. Connecting Encoder Feedback

The type of feedback the controller is capable of interfacing with depends on the additional options ordered for the controller. Table 2.1 shows the different encoder feedback types available for the DMC-41x3 including which options are required. Note that each feedback type has a different configuration command. See the Command Reference for full details on how to properly configure each axis.

NOTE

[GDK's Step-By-Step tool](#) provides an interactive walk-through for configuring motor encoders.

Feedback Type	Configuration Command	ICM/Part Number Required	Connection Location	Firmware Required
Standard Quadrature	CE	Standard on all units	Encoder	Standard
Pulse and Direction	CE	Standard on all units	Encoder	Standard
Analog ¹	AF	Standard on all units (12-bit Standard. 16-bit optional)	Analog	Standard
SSI	SI	SER option	Encoder	-SER
BiSS	SS	SER option	Encoder	-SER
None ²	—	—	—	—
Other	Contact Galil			

Table 2.1: Configuration commands, ICM/Part numbers required for a given feedback type

¹ All wiring/electrical information regarding using analog inputs can be found in Analog Inputs, pg 32.

² Although stepper systems do not require feedback, Galil supports a feedback sensor on each stepper axis. Servo motors require a position sensor.

Different feedback types can be used on the same controller. For instance, one axis could be using standard quadrature and the next could be using SSI. By default, all axes are configured for standard quadrature.

When a stepper motor is used, the auxiliary encoder for the corresponding axis is unavailable for an external connection. If an encoder is used for position feedback with a stepper motor, connect the encoder to the main encoder input corresponding to that axis. The commanded position of the stepper can be interrogated with **TD** and the encoder position can be interrogated with **TP**.

See SER – BiSS and SSI Absolute Encoder Interface, pg 170 for pin-outs and electrical information for SSI and BiSS options.

Encoder pin-outs can be found here:

Jn1 - Encoder 26 pin HD D-Sub Connector (Female), pg 176

Step 2a. Wiring Motors to Galil's Internal Amplifiers

If an external amplifier is being used, proceed to Step 2b. Connecting External Amplifiers and Motors. Table 2.2 below provides a general overview of the connections required for connecting different types of motors to Galil internal amplifiers.

Motor Type	Required Connections
Brushless servo motor	• Power to controller and internal amplifier • Motor power leads to internal amplifiers • Encoder feedback • Hall sensors (Optional for sinusoidal amplifiers)
Brushed servo motor	• Power to controller and internal amplifier • Motor power leads to internal amplifiers • Encoder feedback
Stepper motor	• Power to controller and internal drive • Motor power leads to internal drive • Encoder feedback (optional)

Table 2.2: Synopsis of connections required to connect a motor to Galil's internal amplifiers

Table 2.3 lists each of Galil's internal amplifiers and where to find pin-outs of the amplifier connections and electrical specifications. The commutation method and whether hall sensors are required are also listed.

Amplifier	Commutation	Hall Sensors Required
A1 – AMP-430x0 (-D3040,-D3020), pg 185	Trapezoidal or Brushed	Required for brushless motors
A2 – AMP-43140 (-D3140), pg 193	Brushed	No
A3 – AMP-43240 (-D3240), pg 183	Trapezoidal or Brushed	Required for brushless motors
A4 – AMP-43540 (-D3540, -D3520), pg 202	Sinusoidal or Brushed	Optional for brushless motors
A5 – AMP-43547 (-D3547, -D3527), pg 209	Sinusoidal, Stepper, or Brushed	Optional for brushless motors
A6 – AMP-43640 (-D3640), pg 217	Sinusoidal	Optional for brushless motors
A7 – SDM-44040 (-D4040,-D4020), pg 223	N/A, Stepper	No
A8 – SDM-44140 (-D4140), pg 227	N/A, Stepper	No

Table 2.3: Amplifier documentation location, commutation method(s), and hall sensor requirements for each internal amplifier.

Pin-outs for the hall sensor inputs can be found here:

Jn1 - Encoder 26 pin HD D-Sub Connector (Female), pg 176

Step 2b. Connecting External Amplifiers and Motors

System connection procedures will depend on system components and motor types. Any combination of motor types can be used with the DMC-41x3. There can also be a combination of axes running from Galil integrated amplifiers and drivers and external amplifiers or drivers.

Table 2.4 below shows a brief synopsis of the connections required, the full walkthrough guide is provided below.

Motor Type	Connection Requirements
Servo motors (Brushed and Brushless)	• Power to controller and amplifier • Amplifier Enable • Motor Command • Encoder Feedback • See amplifier documentation for motor connections
Stepper motor	• Power to controller and amplifier • Amplifier enable • Step and Direction lines • Encoder feedback (optional) • See amplifier documentation for motor connections

Table 2.4: Synopsis of connections required to connect an external amplifier

Step A. Connect the motor to the amplifier

Initially do so with no connection to the controller. Consult the amplifier documentation for instructions regarding proper connections. Connect and turn-on the amplifier power supply. If the amplifiers are operating properly, the motor should stand still even when the amplifiers are powered up.

Step B. Connect the amplifier enable signal

Before making any connections from the amplifier to the controller, verify that the ground level of the amplifier is either floating or at the same potential as earth.

WARNING

When the amplifier ground is not isolated from the power line or when it has a different potential than that of the computer ground, serious damage may result to the computer, controller, and amplifier.

If you are not sure about the potential of the ground levels, connect the two ground signals (amplifier ground and earth) by a 10 k Ω resistor and measure the voltage across the resistor. Only if the voltage is zero, connect the two ground signals directly.

The amplifier enable signal is defaulted to 24V, high amp enable sinking (the amplifier enable signal will be high when the controller expects the amplifier to be enabled).

Pin-outs for the amplifier enable signal can be found here:

Jn1 - Encoder 26 pin HD D-Sub Connector (Female), pg 176

For full electrical specifications and wiring diagrams refer to:

External Amplifier Interface, pg 33

Once the amplifier enable signal is correctly wired, issuing an MO will disable the amplifier and an SH will enable it.

Step C. Connect the command signals

The DMC-41x3 has two ways of controlling amplifiers:

1. Using a motor command line ($\pm 10V$ analog output). The motor and the amplifier may be configured in torque or velocity mode. In the torque mode, the amplifier gain should be such that a 10V signal generates the maximum required current. In the velocity mode, a command signal of 10V should run the motor at the maximum required speed.
2. Using step (0-5V) and direction (0-5V toggling line), this is referred to as step/dir for short.

The pin-outs for the command signals can be found here:

Jn1 - Encoder 26 pin HD D-Sub Connector (Female), pg 176

See External Amplifier Interface, pg 33 for full electrical specifications.

Step D. Issue the appropriate configuration commands

The Motor Type (MT) command is used to configure each axis for a stepper or servo motor. The Configure Encoder (CE) command is used to configure the encoder for each axis.

Step 3. Power the Controller

WARNING

Exercise caution with the application of this equipment. Only qualified individuals should attempt to install, set up, and operate this equipment. Never open the controller box when DC power is applied.

Table 2.5 below shows which power connectors are required for powering the system based upon the options ordered. If multiple options are ordered, multiple power connections will be required. Different options may effect which connections and what bus voltages are appropriate. If using an internal amplifier, the ISCNLT – Isolate Controller Power, pg 168 option will require multiple connections, one to power the controller board and another to power the amplifiers. If using two banks of amplifiers, the ISAMP – Isolation of power between each AMP amplifier, pg 171 option will require that the amplifiers are powered independently.

Options Ordered	Controller Power Connector (2-pin Molex on side)	AMP/SDM Power Connector, Axis A-D (6- or 4-pin Molex)	AMP/SDM Power Connector, Axis E-H (6- or 4-pin Molex)
None	X		
ISCNTL ¹	X		
AMP/SDM Axis A-D		X	
AMP/SDM Axis E-H			X
ISAMP ²		X	X

Table 2.5: Available power connectors based upon options ordered

¹ If the ISCNLT option is ordered with an amplifier, the supplies that power the controller and amplifier need to share the same ground.

² If the ISAMP option is not ordered, the amplifiers are sharing power. Their bus voltages and grounds must be from the same source to prevent damage to the controller and amplifiers.

WARNING

Controller or amplifier power should never be plugged in HOT. Always power down the power supply before installing or removing power connector(s) to/from controller or amplifier.

For more information regarding connector type and part numbers see Power Connector Part Numbers, pg 172. The power specifications for the controller are provided in Power Requirements, pg 165 and the power specifications for each amplifier are found under their specific section in the appendix, see Integrated Components, pg 183.

Any emergency stop or disconnect switches should be installed on the AC input to the DC power supply. Relays and/or other switches should not be installed on the DC line between the Galil and the Power supply. An example system is shown in Figure 2.1 with a DMC-4183-D3040-D3040:




Figure 2.1: Wiring for DMC-4183 with Amplifiers

The green power light indicator should go on when power is applied.

Step 4. Install the Communications Software

After applying power to the controller, a PC is used for programming. Galil's development software enables communication between the controller and the host device. The current version of Galil's development software can be found here: <http://galil.com/downloads/software/gdk>

Step 5. Establish Communications with Galil Software

NOTE

[GDK](#)'s Step-By-Step tool provides an interactive and easy to follow guide to setting up a Windows PC for communication with Galil controllers.

GDK will automatically setup the computer for serial communication. For Ethernet communication, see this video for how to configure your NIC card using Windows to connect to a DMC controller:

<http://galil.com/learn/online-videos/basics-galil-design-kit-manager-terminal-and-editor>

See the GDK manual for using the software to communicate: <http://galil.com/sw/pub/all/doc/gdk/man/>

Step 6. Motor Setup with GDK Step-By-Step

NOTE

[GDK](#)'s Step-By-Step tool provides an interactive guide for the automatic set up of brushed, brushless, and stepper motors when using internal amplifiers.

For manual setup instructions, refer to the specific amplifier appendix section which were listed in Table 2.3.

Step 7. Setting Safety Features

Step A. Setting Amplifier Gains

A transconductance (current) amplifier takes a $\pm 10V$ command signal and produces a current in the motor proportional to that signal. This ratio is the amplifier gain (amps/volts) and can be set via the Amplifier Gain (AG) command when using Galil's internal amplifiers. See the AG command in the Command Reference for proper current gain settings for Galil's internal amplifiers.

The Current Loop Gain (AU) command sets the current loop gain for the amplifier and is set based on the bus voltage powering the amplifier as well as the inductance of the motor. Consult the amplifier appendix section or command reference for more details.

Step B. Setting Torque Limits

The Torque Limit (TL) command will limit the output voltage of $\pm 10V$ motor command line. This command should be used to avoid excessive torque and speed when initially setting up a servo system. The Peak Torque Limit (TK) command sets the peak torque limit of the motor output allowing the command line to momentarily exceed TL . See the TL and TK settings in the Command Reference for more information. Amplifier gain needs to be taken into account when setting both TL and TK . For example, if a particular motor has a continuous current rating of 2.0 A and a peak current rating of 5.0 A and the amplifier gain is 0.8A/V, TL and TK can be calculated as follows:

$$TL \text{ setting} = (2.0A)/(0.8A/V) = 2.5V \text{ (} TL \text{ n}=2.5\text{)}$$

$$TK \text{ setting} = (5.0A)/(0.8A/V) = 6.25V \text{ (} TK \text{ n}=6.25\text{)}$$

The user is responsible for determining the relationship between the motor command line and the amplifier torque/velocity using the documentation of the motor and/or amplifier.

Step C. Setting Error Limits

When an Error Limit (ER) and Off-on-Error (OE) is set, the controller will automatically shut down the motors when excess error ($|TE| > ER$) has occurred.

OE requires the amplifier enable signal to be connected from the controller to the amplifier. When using Galil's internal amplifiers, the amplifier enable is already configured. See Step 2b. Connecting External Amplifiers and Motors, pg 15 when using external amplifiers.

Step D. Other Safety Features

This section only provides a brief list of safety features that the DMC can provide. Other features include Encoder Failure Detection (OA, OT, OV), Automatic Subroutines to create an automated response to events such as limit switches toggling ($\#LIMSWI$), large following error ($\#POSERR$), amplifier errors (TA, $\#AMPERR$), and more. For a full list of features and how to program each see Chapter 8 Hardware & Software Protection, pg 145.

Step 8. Tune the Servo System

Adjusting the tuning parameters is required when using servo motors. The controller's default set of PID's are not optimized and should not be used in practice.

For the theory of operation and a full explanation of all the PID and other filter parameters, see Chapter 10 Theory of Operation, pg 153.

For additional tuning resources and guides, see the following Application Notes:

Manual Tuning Methods: <http://www.galil.com/download/application-note/note3413.pdf>

Manual Tuning using the Velocity Zone method: <http://www.galil.com/download/application-note/note5491.pdf>

For information about the Autotuning Tool in GDK: <http://galil.com/sw/pub/all/doc/gdk/man/tuner.html>

Chapter 3 Connecting Hardware

Overview

The DMC-41x3 provides optoisolated digital inputs for **forward limit**, **reverse limit**, **home**, and **abort** signals. The controller also has **8 optoisolated, uncommitted inputs** (for general use) as well as **8 optoisolated outputs** and **8 analog inputs** configured for voltages between ± 10 volts.

4183

Controllers with 5 or more axes have an additional 8 optoisolated inputs and an additional 8 optoisolated outputs.

This chapter describes the inputs and outputs and their proper connection.

Overview of Optoisolated Inputs

Limit Switch Input

The forward limit switch (FLSx) inhibits motion in the forward direction immediately upon activation of the switch. The reverse limit switch (RLSx) inhibits motion in the reverse direction immediately upon activation of the switch. If a limit switch is activated during motion, the controller will make a decelerated stop using the deceleration rate previously set with the SD command. The motor will remain on (in a servo state) after the limit switch has been activated and will hold motor position. The controller can be configured to disable the axis upon the activation of a limit switch, see the OE command in the command reference for further detail.

When a forward or reverse limit switch is activated, the current application program that is running in thread zero will be interrupted and the controller will automatically jump to the #LIMSWI subroutine if one exists. This is a subroutine which the user can include in any motion control program and is useful for executing specific instructions upon activation of a limit switch. Automatic Subroutines for Monitoring Conditions are discussed in Chapter 7 Application Programming.

After a limit switch has been activated, further motion in the direction of the limit switch will not be possible until the logic state of the switch returns back to an inactive state. Any attempt at further motion before the logic state has been reset will result in the following error: “22 - Begin not possible due to limit switch” error.

The operands, _LFx and _LRx, contain the state of the forward and reverse limit switches, respectively (x represents the axis, X, Y, Z, W etc.). The value of the operand is either a ‘0’ or ‘1’ corresponding to the logic state of the limit switch. Using a terminal program, the state of a limit switch can be printed to the screen with the command, MG_LFx or MG_LRx. This prints the value of the limit switch operands for the ‘x’ axis. The logic state of the limit switches can also be interrogated with the TS command. For more details on TS see the Command Reference.

Home Switch Input

Homing inputs are designed to provide mechanical reference points for a motion control application. A transition in the state of a Home input alerts the controller that a particular reference point has been reached by a moving part in the motion control system. A reference point can be a point in space or an encoder index pulse.

The Home input detects any transition in the state of the switch and toggles between logic states 0 and 1 at every transition. A transition in the logic state of the Home input will cause the controller to execute a homing routine specified by the user.

There are three homing routines supported by the DMC-41x3: Find Edge (FE), Find Index (FI), and Standard Home (HM).

The Find Edge routine is initiated by the command sequence: FEX, BGX. The Find Edge routine will cause the motor to accelerate, and then slew at constant speed until a transition is detected in the logic state of the Home input. The direction of the FE motion is dependent on the state of the home switch. High level causes forward motion. The motor will then decelerate to a stop. The acceleration rate, deceleration rate and slew speed are specified by the user, prior to the movement, using the commands AC, DC, and SP. *When using the FE command, it is recommended that a high deceleration value be used so the motor will decelerate rapidly after sensing the Home switch.*

The Find Index routine is initiated by the command sequence: FIX, BGX. Find Index will cause the motor to accelerate to the user-defined slew speed (SP) at a rate specified by the user with the AC command and slew until the controller senses a change in the index pulse signal from low to high. The motor then decelerates to a stop at the rate previously specified by the user with the DC command and then moves back to the index pulse and speed HV. Although Find Index is an option for homing, it is not dependent upon a transition in the logic state of the Home input, but instead is dependent upon a transition in the level of the index pulse signal.

The Standard Homing routine is initiated by the sequence of commands HMX, BGX. Standard Homing is a combination of Find Edge and Find Index homing. Initiating the standard homing routine will cause the motor to slew until a transition is detected in the logic state of the Home input. The motor will accelerate at the rate specified by the command, AC, up to the slew speed. After detecting the transition in the logic state on the Home Input, the motor will decelerate to a stop at the rate specified by the command, DC. After the motor has decelerated to a stop, it switches direction and approaches the transition point at the speed of HV counts/sec. When the logic state changes again, the motor moves forward (in the direction of increasing encoder count) at the same speed, until the controller senses the index pulse. After detection, it decelerates to a stop, moves back to the index, and defines this position as 0. The logic state of the Home input can be interrogated with the command MG_HMX. This command returns a 0 or 1 if the logic state is low or high, respectively. The state of the Home input can also be interrogated indirectly with the TS command.

For examples and further information about Homing, see command HM, FI, FE of the Command Reference and the section entitled Homing in the Programming Motion Section of this manual.

Abort Input

The function of the Abort input is to immediately stop the controller upon transition of the logic state. The ABRT input uses the INCOM pin of the I/O(A-D) connector. For 5-8 axis controllers with two integrated amplifiers, the ABRT input for axes E-H will also use the INCOM pin of the I/O(A-D) connector.

NOTE: The response of the abort input is significantly different from the response of an activated limit switch. When the abort input is activated, the controller stops generating motion commands immediately, whereas the limit switch response causes the controller to make a decelerated stop.

NOTE: The effect of an Abort input is dependent on the state of the off-on-error function (OE Command) for each axis. If the Off-On-Error function is enabled for any given axis, the motor for that axis will be turned off when the abort signal is generated. This could cause the motor to 'coast' to a stop since it is no longer under servo control.

If the Off-On-Error function is disabled, the motor will decelerate to a stop as fast as mechanically possible and the motor will remain in a servo state.

All motion programs that are currently running are terminated when a transition in the Abort input is detected. This can be configured with the CN command. For information see the Command Reference, OE and CN.

ELO (Electronic Lock-Out) Input

Used in conjunction with Galil amplifiers, this input allows the user the shutdown the amplifier at a hardware level. For more detailed information on how specific Galil amplifiers behave when the ELO is triggered, see Integrated in the Appendices. The ELO input uses the INCOM pin of the I/O(A-D) connector (INCOM0). If using a 5-8 axis controller with two integrated amplifiers, the ELO input on the I/O(E-H) connector also uses INCOM0. If either ELO input is triggered, both amplifiers will be shut down at a hardware level.

Reset Input/Reset Button

When the Reset line is triggered the controller will be reset. The reset line and reset button will not master reset the controller unless the MRST jumper is installed during a controller reset. The RST input uses the INCOM pin of the I/O(A-D) connector. For 5-8 axis controllers with two integrated amplifiers, the RST input for axes E-H will also use the INCOM pin of the I/O(A-D) connector.

Uncommitted Digital Inputs

The DMC-41x3 has 8 optoisolated inputs. These inputs can be read individually using the function @ IN[x] where x specifies the input number (1 thru 8). These inputs are uncommitted and can allow the user to create conditional statements related to events external to the controller. For example, the user may wish to have the x-axis motor move 1000 counts in the positive direction when the logic state of DI1 goes high.

The Digital inputs can be used as high speed position latch inputs, see High Speed Position Capture (The Latch Function) for more information.

This can be accomplished by connecting a voltage in the range of +5V to +28V into INCOM0 of the input circuitry from a separate power supply.

4183

Controllers with more than 4 axes have an additional 8 general optoisolated inputs (inputs 9-16). INCOM1 is used for these inputs and is found on the I/O (E-H) D-Sub connector. The grouping is shown in Table 3.1 and Table 3.2.

NOTE: INCOM1 and LSCOM1 for Inputs 9-16 and Limit and Home Switches for axes 5-8 are found on the connectors for the E-H axes. **These are NOT the same INCOM0 and LSCOM0 for axes 1-4.**

Optoisolated Input Electrical Information

Electrical Specifications

INCOM/LSCOM Max Voltage	24 V _{DC}
INCOM/LSCOM Min Voltage	0 V _{DC}
Minimum current to turn on Inputs	1.2 mA
Minimum current to turn off Inputs once activated (hysteresis)	0.5 mA
Maximum current per input ¹	11 mA
Internal resistance of inputs	2.2 kΩ

¹ See the Input Current Limitations section on pg. 174 for more details.

The DMC-41x3's optoisolated inputs are rated to operate with a supply voltage of 5-24 VDC. The optoisolated inputs are powered in banks. For example, INCOM (Bank 0), located on the 44-pin I/O (A-D) D-sub connector, provides power to DI[8:1] (digital inputs), the abort input (ABRT), reset (RST), and electric lock-out (ELO). Table 3.1 shows all the input banks power commons and their corresponding inputs for 1-4 axis controllers and Table 3.2 shows the input banks for 5-8 axis controllers.

Common Signal	Common Signal Location	Powers Inputs Labeled
INCOM (Bank 0)	I/O (A-D) D-Sub Connector	DI[8:1], ABRT, RST, ELO
LSCOM (Bank 0)	I/O (A-D) D-Sub Connector	FLSA, RLSA, HOMA FLSB, RLSB, HOMB FLSC, RLSC, HOMC FLSD, RLSD, HOMD

Table 3.1: 1-4 axis controller INCOM and LSCOM banks and corresponding inputs powered

Common Signal	Common Signal Location	Powers Inputs
INCOM (Bank 0)	I/O (A-D) D-Sub Connector	DI[8:1], ABRT, RST, ELO
LSCOM (Bank 0)	I/O (A-D) D-Sub Connector	FLSA, RLSA, HOMA FLSB, RLSB, HOMB FLSC, RLSC, HOMC FLSD, RLSD, HOMD
INCOM (Bank 1)	I/O (E-H) D-Sub Connector	DI[16:9]
LSCOM (Bank 1)	I/O (E-H) D-Sub Connector	FLSE, RLSE, HOME FLSF, RLSF, HOMF FLSG, RLSG, HOMG FLSH, RLSH, HOMH

Table 3.2: 5-8 axis controller INCOM and LSCOM banks and corresponding inputs powered

The full pin-outs for each bank can be found in the Pin-outs, pg 175.

Wiring the Optoisolated Digital Inputs

To take full advantage of optoisolation, an isolated power supply should be used to provide the voltage at the input common connection. Connecting the ground of the isolated power to the ground of the controller will bypass optoisolation and is not recommended if true optoisolation is desired.

If there is not an isolated supply available, the 5 V_{DC}, 12 V_{DC}, and GND controller references may be used to power INCOM/LSCOM. The current supplied by the controller references are limited, see +5, ±12V Power Output Specifications, pg 165 in the Appendices for electrical specifications. Using the controller reference power completely bypasses optoisolation and is not recommended for most applications.

Banks of inputs can be used as either active high or low. Connecting +V_s to INCOM/LSCOM will configure the inputs for active low as current will flow through the diode when the inputs are pulled to the isolated ground. Connecting the isolated ground to INCOM/LSCOM will configure the inputs for active high as current will flow through the diode when the inputs are pulled up to +V_s.

Figure 3.1 - Figure 3.5 are the optoisolated wiring diagrams for powering INCOM/LSCOM (Bank 0) and INCOM/LSCOM (Bank 1) and their corresponding inputs.




Figure 3.1: Digital Inputs 1-8 (DI[8:1])







Figure 3.2: Digital Inputs 9-16 (DI[16:9])



Optoisolated Outputs

The DMC-41x3 has several different options for the uncommitted digital outputs (labeled as DO). The default outputs are 4mA sinking which are ideal for interfacing to TTL level devices. Additional options include 25mA sinking (lower power sinking, LSNK), 25mA sourcing (low power sourcing, LSRC), and 500mA sourcing outputs (high power sourcing, HSRC). Please refer to your part number to determine which option you have.

The amount of uncommitted, optoisolated outputs the DMC-41x3 has depends on the number of axis. For instance, 1-4 axis models come with a single bank of 8 outputs, Bank 0 (DO[8:1]). 5-8 axis models come with an additional bank of 8 outputs, Bank 1 (DO[16:9]), for a total of 16 outputs.

The wiring pins for Bank 0 are located on J5 - I/O (A-D) 44 pin HD D-Sub Connector (Female) and the pins for wiring Bank 1 are located on J8 - I/O (E-H) 44 pin HD D-Sub Connector (Female). See the Pin-outs in the Appendix for more details.

Wiring diagrams, electrical specifications, and details for each bank and output type are provided below.

4mA Sinking Optoisolated Outputs (Default)

Description

The default outputs of the DMC-41x3 are capable of 4mA and are configured as sinking outputs. The voltage range for the outputs is 5-24 VDC. These outputs should not be used to drive inductive loads directly.

Electrical Specifications

Output PWR Max Voltage	24 V _{DC}
Output PWR Min Voltage	5 V _{DC}
ON Voltage (No Load, Output PWR= 5V _{DC})	0.1 V _{DC}
Max Drive Current per Output	4mA, Sinking

Wiring the 4mA Sinking outputs

With this configuration, the output power supply will be connected to Output PWR (labeled OPnB) and the power supply return will be connected to Output GND (labeled OPnA), where n denotes 0 or 1 referring to Bank 0 and Bank 1 respectively. Note that the load is wired between Output PWR and DO. The wiring diagram for Bank 0 is shown in Figure 3.6 and Bank 1 in Figure 3.7. Refer to Pin-outs in the Appendix for pin-out information.




Figure 3.6: 4mA sinking wiring diagram for Bank 0, DO[8:1]




Figure 3.7: 4mA sinking wiring diagram for Bank 1, DO[16:9]

25mA Sinking Optoisolated Outputs (LSNK)

Description

The 25mA sinking option, referred to as lower power sinking (LSNK), are capable of sinking up to 25mA per output. The voltage range for the outputs is 5-24 VDC. These outputs should not be used to drive inductive loads directly.

Electrical Specifications

Output PWR Max Voltage	24 V _{DC}
Output PWR Min Voltage	5 V _{DC}
ON Voltage (No Load, Output PWR= 5V _{DC})	1.2 V _{DC}
Max Drive Current per Output	25mA, Sinking

Wiring the 25mA Sinking Outputs

When wiring the 25mA sinking outputs, the load is wired in the same fashion as the 4mA sinking outputs: The output power supply will be connected to Output PWR (labeled OPnB) and the power supply return will be connected to Output GND (labeled OPnA), where n denotes 0 or 1 referring to Bank 0 and Bank 1 respectively. Note that the load is wired between Output PWR and DO. The wiring diagram for Bank 0 is shown in Figure 3.8 and Bank 1 in Figure 3.9. Refer to Pin-outs in the Appendix for pin-out information.




Figure 3.8: 25mA sinking wiring diagram for Bank 0, DO[8:1]




Figure 3.9: 25mA sinking wiring diagram for Bank 1, DO[16:9]

25mA Sourcing Optoisolated Outputs (LSRC)

Description

The 25mA sourcing option, referred to as lower power sourcing (LSRC), are capable of sourcing up to 25mA per output. The voltage range for the outputs is 5-24 VDC. These outputs should not be used to drive inductive loads directly.

Electrical Specifications

Output PWR Max Voltage	24 V _{DC}
Output PWR Min Voltage	5 V _{DC}
Max Drive Current per Output	25mA, Sourcing

Wiring the 25mA Sourcing Outputs

With this configuration, the output power supply will be connected to Output PWR (labeled OPnA) and the power supply return will be connected to Output GND (labeled OPnB), where n denotes 0 or 1 referring to Bank 0 and Bank 1 respectively. Note that the load is wired between DO and Output GND. The wiring diagram for Bank 0 is shown in Figure 3.10 and Bank 1 in Figure 3.11. Refer to Pin-outs in the Appendix for pin-out information.




Figure 3.10: 25mA sourcing wiring diagram for Bank 0, DO[8:1]




Figure 3.11: 25mA sourcing wiring diagram for Bank 1, DO[16:9]

500mA Sourcing Optoisolated Outputs (HSRC)

Description

The 500mA sourcing option, referred to as high power sourcing (HSRC), is capable of sourcing up to 500mA per output and up to 3A per **bank**. The voltage range for the outputs is 12-24 V_{DC}. These outputs are capable of driving inductive loads such as solenoids or relays. The outputs are configured for hi-side (sourcing) only.

Electrical Specifications

Output PWR Max Voltage	24 V _{DC}
Output PWR Min Voltage	12 V _{DC}
Max Drive Current per Output	0.5 A (not to exceed 3A per Bank)

Wiring the 500mA Sourcing Optoisolated Outputs

With this configuration, the output power supply will be connected to Output PWR (labeled OPnA) and the power supply return will be connected to Output GND (labeled OPnB), where n denotes 0 or 1 referring to Bank 0 and Bank 1 respectively. Note that the load is wired between DO and Output GND. The wiring diagram for Bank 0 is shown in Figure 3.12 and Bank 1 in Figure 3.13. Refer to Pin-outs in the Appendix for pin-out information.




Figure 3.12: 500mA sourcing wiring diagrams for Bank 0, DO[8:1]




Figure 3.13: 500mA sourcing wiring diagram for Bank 1, DO[16:9]

TTL Inputs and Outputs

Main Encoder Inputs

The main encoder inputs can be configured for quadrature (default) or pulse and direction inputs. This configuration is set through the CE command. The encoder connections are found on the HD D-sub Encoder connectors and are labeled MA+, MA-, MB+, MB-. The '-' (negative) inputs are the differential inputs to the encoder inputs; if the encoder is a single ended 5V encoder, then the negative input should be left floating. If the encoder is a single ended and outputs a 0-12V signal then the negative input should be tied to the 5V line on the DMC-41x3.

When the encoders are setup as step and direction inputs the MA channel will be the step or pulse input, and the MB channel will be the direction input.

The encoder inputs can be ordered with 120 Ω termination resistors installed. See TRES – Encoder Termination Resistors, pg 168 in the Appendix for more information.

Electrical Specifications

Maximum Voltage	12 V _{DC}
Minimum Voltage	-12 V _{DC}
Maximum Frequency (Quadrature)	15 MHz
'+' inputs are internally pulled-up to 5V through a 4.7 k Ω resistor	
'-' inputs are internally biased to ~1.3V	
pulled up to 5V through a 7.1 k Ω resistor	
pulled down to GND through a 2.5 k Ω resistor	

The Auxiliary Encoder Inputs

The auxiliary encoder inputs can be used for general use. For each axis, the controller has one auxiliary encoder and each auxiliary encoder consists of two inputs, channel A and channel B. The auxiliary encoder inputs are mapped to the inputs 81-96. The Aux encoder inputs are not available for any axis that is configured for step and direction outputs (stepper).

Each input from the auxiliary encoder is a differential line receiver and can accept voltage levels between ± 12 V. The inputs have been configured to accept TTL level signals. To connect TTL signals, simply connect the signal to the + input and leave the - input disconnected. For other signal levels, the '-' input should be connected to a

voltage that is $\sim\frac{1}{2}$ of the full voltage range (for example, connect the '-' input to the 5 volts on the Galil if the signal is 0 - 12V logic).

Example:

A DMC-4113 has one auxiliary encoder. This encoder has two inputs (channel A and channel B). Channel A input is mapped to input 81 and Channel B input is mapped to input 82. To use this input for 2 TTL signals, the first signal will be connected to AA+ and the second to AB+. AA- and AB- will be left unconnected. To access this input, use the function @IN[81] and @IN[82].

NOTE: The auxiliary encoder inputs are not available for any axis that is configured for stepper motor.

Electrical Specifications

Maximum Voltage	12 V _{DC}
Minimum Voltage	-12 V _{DC}
'+' inputs are internally pulled-up to 5V through a 4.7kΩ resistor	
'-' inputs are internally biased to $\sim$ 1.3V	
pulled up to 5V through a 7.1kΩ resistor	
pulled down to GND through a 2.5kΩ resistor	

Output Compare

The output compare signal is a TTL output signal and is available on the I/O (A-D) D-Sub connector labeled as CMP. An additional output compare signal is available for 5-8 axes controllers on the I/O (E-H) D-sub connector.

Output compare is controlled by the position of any of the main encoder inputs on the controller. The output can be programmed to produce either a brief, active low pulse (510 nsec) based on an incremental encoder value or to activate once ("one shot") when an axis position has been passed. When setup for a one shot, the output will stay low until the OC command is called again. For further information, see the command OC in the Command Reference.

NOTE	Output compare is not valid with sampled feedback types such as: SSI, BiSS, and Analog
-------------	--

Electrical Specifications

Output Voltage	0 – 5 VDC
Current Output	20 mA Sink/Source

Error Output

The controller provides a TTL signal, ERR, to indicate a controller error condition. When an error condition occurs, the ERR signal will go low and the controller LED will go on. An error occurs because of one of the following conditions:

1. At least one axis has a position error greater than the error limit. The error limit is set by using the command ER.
2. The reset line on the controller is held low or is being affected by noise.
3. There is a failure on the controller and the processor is resetting itself.
4. There is a failure with the output IC which drives the error signal.

The ERR signal is found on the I/O (A-D) D-Sub connector.

4183

For controllers with 5-8 axes, the ERR signal is duplicated on the I/O (E-H) D-Sub connector.

For additional information see Error Light (Red LED) in Chapter 9 Troubleshooting.

Electrical Specifications

Output Voltage	0 – 5 VDC
Current Output	20 mA Sink/Source

Analog Inputs

The DMC-41x3 has eight analog inputs configured for the range between -10V and 10V. The inputs are decoded by a 12-bit A/D decoder giving a voltage resolution of approximately .005V. A 16-bit ADC is available as an option (Ex. *DMC-4123-CARD(-16bit)*). The analog inputs are specified as AN x where x is a number 1 thru 8.

AQ settings

The analog inputs can be set to a range of $\pm 10V$, $\pm 5V$, 0-5V or 0-10V, this allows for increased resolution when the full $\pm 10V$ is not required. The inputs can also be set into a differential mode where analog inputs 2,4,6 and 8 can be set to the negative differential inputs for analog inputs 1,3,5 and 7 respectively. See the AQ command in the command reference for more information.

Electrical Specifications

Input Impedance (12 and 16 bit) –		
	Unipolar (0-5V, 0-10V)	42k Ω
	Bipolar ($\pm 5V$, $\pm 10V$)	31k Ω

External Amplifier Interface

External Stepper Control

The controller provides step and direction (STPn, DIRn) outputs for every axis available on the controller. Step and direction outputs need to be wired with respect to digital ground (GND). See the MT command for more details.

Step and Direction Electrical Specifications

Output Voltage	0 – 5 VDC
Current Output	20 mA Sink/Source

External Servo Control

The DMC-41x3 command voltage ranges between $\pm 10V$ and is output on the motor command line - MCMn (where n is A-H). This signal, along with GND, provides the input to the motor amplifiers. The amplifiers must be sized to drive the motors and load. For best performance, the amplifiers should be configured for a torque (current) mode of operation with no additional compensation. The gain should be set such that a 10 volt input results in the maximum required current.

Motor Command Line Electrical Specifications

Output Voltage	± 10 VDC
Motor Command Output Impedance	500 Ω

The standard configuration of the amplifier enable signal is external voltage with active high amp enable (HAEN) sinking. In other words, the AEN signal will be high when the controller expects the amplifier to be enabled. The polarity and the amplitude can be changed by configuring the Amplifier Enable Circuit on the DMC-41x3.

NOTE: Many amplifiers designate the enable input as 'inhibit'.



Amplifier Enable

This section describes how to configure the DMC-41x3 for different Amplifier Enable configurations.



The default configuration of the amplifier enable signal is external voltage with active high amp enable (HAEN) sinking. In other words, the AEN signal will be high when the controller expects the amplifier to be enabled.

The DMC-41x3 is designed to be easily interfaced to multiple amplifier manufactures. As a result, the amplifier enable circuit for each axis is individually configurable through jumper settings. The user can choose between High-Amp-Enable (HAEN), Low-Amp-Enable (LAEN), 5V logic, 12V logic, external voltage supplies up to 24V, sinking, or sourcing. The different configurations are described below with jumper settings and a basic schematics of the circuit.



+5V HIGH AMP ENABLE SINKING





+12V HIGH AMP ENABLE SINKING





ISOLATED SUPPLY HIGH AMP ENABLE SINKING





+5V HIGH AMP ENABLE SOURCING





+12V HIGH AMP ENABLE SOURCING





ISOLATED SUPPLY HIGH AMP ENABLE SOURCING





+5V LOW AMP ENABLE SINKING





+12V LOW AMP ENABLE SINKING





ISOLATED SUPPLY LOW AMP ENABLE SINKING





+5V LOW AMP ENABLE SOURCING



+12V LOW AMP ENABLE SOURCING



ISOLATED SUPPLY LOW AMP ENABLE SOURCING



Chapter 4 Software Tools and Communication

Introduction

The default configuration DMC-41x3 has one USB port, one RS-232 port and one Ethernet port. The auxiliary RS-232 port is the data term and can be configured with the software command CC. This configuration can be saved using the Burn (BN) instruction. The Ethernet port is a 10/100BASE-T connection that auto-negotiates the speed and half or full duplex.

The GDK software package is available for PC computers running Microsoft Windows or Linux to communicate with the DMC-41x3 controller. This software package has been developed to operate under Windows and Linux, and include all the necessary drivers to communicate to the controller. In addition, gclib, a C based software development communication library, is available which allows users to create their own application interfaces using programming environments such as C/C++, Python, .NET, and Java.

The following sections in this chapter are a description of the communications protocol, and a brief introduction to the software tools and communication techniques used by Galil. At the application level, GDK is the basic development software that the majority of users will need to communicate with the controller, to perform basic setup, and to develop application code (.dmc programs) that is downloaded to the controller. At the Galil API level, gclib is available for users who wish to develop their own custom application programs to communicate to the controller. Custom application programs can utilize API function calls directly to our DLL's. At the driver level, we provide fundamental hardware interface information for users who desire to create their own drivers.

Controller Response to Commands

Most DMC-41x3 instructions are represented by two characters followed by the appropriate parameters. Each instruction must be terminated by a carriage return. Multiple commands may be concatenated by inserting a semicolon between each command.

After the instruction is decoded, the DMC-41x3 returns a response to the port from which the command was generated. If the instruction was valid, the controller returns a colon (:) or the controller will respond with a question mark (?) if the instruction was not valid. For example, the controller will respond to commands which are sent via the USB port back through the USB port, and to commands which are sent via the Ethernet port back through the Ethernet port.

For instructions that return data, such as Tell Position (TP), the DMC-41x3 will return the data followed by a carriage return, line feed and : .

It is good practice to check for : after each command is sent to prevent errors. An echo function is provided to enable associating the DMC-41x3 response with the data sent. The echo is enabled by sending the command EO 1 to the controller.

Unsolicited Messages Generated by Controller

When the controller is executing a program, it may generate responses which will be sent via the USB port or Ethernet handles. This response could be generated as a result of messages using the MG command OR as a result of a command error. These responses are known as unsolicited messages since they are not generated as the direct response to a command.

Messages can be directed to a specific port using the specific Port arguments – see the MG and CF commands in the Command Reference. If the port is not explicitly given or the default is not changed with the CF command, unsolicited messages will be sent to the default port. The default port is the main serial port. When communicating via an Ethernet connection, the unsolicited messages must be sent through a handle that is not the main communication handle from the host. The GDK software automatically establishes this second communication handle.

The controller has a special command, CW, which can affect the format of unsolicited messages. This command is used by Galil Software to differentiate response from the command line and unsolicited messages. The command, CW1 causes the controller to set the high bit of ASCII characters to 1 of all unsolicited characters. This may cause characters to appear garbled to some terminals. This function can be disabled by issuing the command, CW2. For more information, see the CW command in the Command Reference.

USB and RS-232 Ports

The USB port by default is an interpreted serial communication port for the DMC-41x3 and will receive and respond to DMC commands. The RS232 (DB9) port is the auxiliary port by default, and is used to connect to external devices that do not use DMC code, such as bar code readers or other RS232 sensors and displays. The controller can read and write generic data but the user must write their own communication routines. A full description of the USB and RS232 default configuration settings can be found in the following sections.

The US command (Rev D firmware or greater) can reverse the main and auxiliary port such that the RS232 port would interpret DMC commands and the USB port would be available for generic data. The following are several points to consider when switching the USB and RS232 ports with US.

- A null modem cable is required for interfacing to the RS232 port. Baud rates are set via the controller's jumpers.
- Firmware cannot be loaded from the RS232 port. The user must switch back to USB mode to load firmware via serial. Ethernet firmware updates are supported in both modes.
- When using the USB port in swapped mode, the remote device must interface to the USB to serial converter on the controller. On a PC this is done with a device driver. The USB to serial UART is an FT232 from FTDI.

See the US command in the command reference for further detail. Contact Galil if a permanent swap is required. Several options are available.

USB Port

The USB port on the DMC-41x3 is a USB to serial converter. It should be setup for 115.2kB, 8 Data bits, No Parity, 1 Stop Bit and Flow Control set for Hardware. The baud rate can be changed to 19200 baud by installing the 19.2 jumper on JP1, but this configuration is only recommended if a slower baud rate is required from the host

communication. The USB port on the DMC-41x3 is a Female Type B USB port. The standard cable when communicating to a PC will be a Male Type A – Male Type B USB cable.

When connected to a PC, the USB connection will be available as a new serial port connection (ex. with GDK “COM3 115200”).

The USB port is not recommended when using the GDK Scope. In this case the Ethernet connection is advised for higher performance.

Baud Rate Selection

JP1 JUMPER SETTINGS	
19.2	BAUD RATE
ON	19200
OFF (recommended)	115200

USB Driver

The USB port on the DMC-41x3 utilizes a USB to serial converter. The driver for this device is expected to be loaded automatically upon connection of the controller in most OS's. If the driver does not load, or is not installed automatically, it can be downloaded from the mfg website here:

<http://www.ftdichip.com/Drivers/VCP.htm>

RS-232 Port

The main purpose of the auxiliary RS232 port is to connect to external devices that cannot use DMC code to communicate. It is important to note that the Aux port is not an interpreted port and cannot receive DMC Galil commands directly. Instead, use CI, #COMINT, and the P2 operands to handle received data on this port.

NOTE: If you are connecting the RS-232 auxiliary port to a terminal or any device which is a DATASET, it is necessary to use a connector adapter, which changes a dataset to a dataterm. This cable is also known as a 'null' modem cable.

CC Command

The CC, or Configure Communications command, configures the auxiliary ports properties including: Baud rate, handshaking, enable/disabled port, and echo. See the CC command in the Command Reference for a full description and command syntax.

If the CC command is configured for hardware handshaking it is required to use the RTS and CTS lines. The RTS line will go high whenever the DMC-41x3 is not ready to receive additional characters. The CTS line will inhibit the DMC-41x3 from sending additional characters. Note, the CTS line goes high for inhibit.

RS-422 Configuration

The DMC-41x3 can be ordered with the auxiliary port configured for RS-422 communication. RS-422 communication is a differentially driven serial communication protocol that should be used when long distance serial communication is required in an application.

For more information see RS-422 – Auxiliary Serial Port Serial Communication in the in Appendix.

Ethernet Configuration

Communication Protocols

The Ethernet is a local area network through which information is transferred in units known as packets. Communication protocols are necessary to dictate how these packets are sent and received. The DMC-41x3 supports two industry standard protocols, TCP/IP and UDP/IP. The controller will automatically respond in the format in which it is contacted.

TCP/IP is a "connection" protocol. The master, or client, connects to the slave, or server, through a series of packet handshakes in order to begin communicating. Each packet sent is acknowledged when received. If no acknowledgment is received, the information is assumed lost and is resent.

Unlike TCP/IP, UDP/IP does not require a "connection". If information is lost, the controller does not return a colon or question mark. Because UDP does not provide for lost information, the sender must re-send the packet.

It is recommended that the motion control network containing the controller and any other related devices be placed on a "closed" network. If this recommendation is followed, UDP/IP communication to the controller may be utilized instead of a TCP connection. With UDP there is less overhead, resulting in higher throughput. Also, there is no need to reconnect to the controller with a UDP connection. Because handshaking is built into the Galil communication protocol through the use of colon or question mark responses to commands sent to the controller, the TCP handshaking is not required.

Packets must be limited to 512 data bytes (including UDP/TCP IP Header) or less. Larger packets could cause the controller to lose communication.

NOTE: In order not to lose information in transit, the user must wait for the controller's response before sending the next packet.

Addressing

There are three levels of addresses that define Ethernet devices. The first is the MAC or hardware address. This is a unique and permanent 6 byte number. No other device will have the same MAC address. The DMC-41x3 MAC address is set by the factory and the last two bytes of the address are the serial number of the board. To find the Ethernet MAC address for a DMC-41x3 unit, use the TH command. A sample is shown here with a unit that has a serial number of 3:

Sample MAC Ethernet Address: 00-50-4C-38-00-03

The second level of addressing is the IP address. This is a 32-bit (or 4 byte) number that usually looks like this: 192.168.15.1. The IP address is constrained by each local network and must be assigned locally. Assigning an IP address to the DMC-41x3 controller can be done in a number of ways.

The first method for setting the IP address is using a DHCP server. The DH command controls whether the DMC-41x3 controller will get an IP address from the DHCP server. If the unit is set to DH1 (default) and there is a DHCP server on the network, the controller will be dynamically assigned an IP address from the server. Setting the board to DH0 will prevent the controller from being assigned an IP address from the server.

The second method to assign an IP address is to use the BOOT-P utility via the Ethernet connection. The BOOT-P functionality is only enabled when DH is set to 0. Either a BOOT-P server on the internal network or the Galil software may be used. When opening the Galil Software, it will respond with a list of all DMC-41x3's and other controllers on the network that do not currently have IP addresses. The user must select the board and the software will assign the specified IP address to it. This address will be burned into the controller (BN) internally to save the IP address to the non-volatile memory.

NOTE: if multiple boards are on the network – use the serial numbers to differentiate them.

CAUTION	Be sure that there is only one BOOT-P or DHCP server running. If your network has DHCP or BOOT-P running, it may automatically assign an IP address to the DMC controller upon linking it to the network. In order to ensure that the IP address is correct, please contact your system administrator before connecting the I/O board to the Ethernet network.
----------------	--

The third method for setting an IP address is to send the IA command through the USB port. (Note: The IA command is only valid if DH0 is set). The IP address may be entered as a 4 byte number delimited by commas (industry standard uses periods) or a signed 32 bit number (e.g. IA 124,51,29,31 or IA 2083724575). Type in BN to save the IP address to the DMC-41x3 non-volatile memory.

NOTE: Galil strongly recommends that the IP address selected is not one that can be accessed across the Gateway. The Gateway is an application that controls communication between an internal network and the outside world.

The third level of Ethernet addressing is the UDP or TCP port number. The Galil board does not require a specific port number. The port number is established by the client or master each time it connects to the DMC-41x3 board. Typical port numbers for applications are:

Port 23: Telnet

Port 502: Modbus

Communicating with Multiple Devices

The DMC-41x3 is capable of supporting multiple masters and slaves. The masters may be multiple PC's that send commands to the controller. The slaves are typically peripheral I/O devices that receive commands from the controller.

NOTE: The term "Master" is equivalent to the internet "client". The term "Slave" is equivalent to the internet "server".

An Ethernet handle is a communication resource within a device. The DMC-41x3 can have a maximum of 8 Ethernet handles open at any time. When using TCP/IP, each master or slave uses an individual Ethernet handle. In UDP/IP, one handle may be used for all the masters, but each slave uses one. (Pings and ARPs do not occupy handles.) If all 8 handles are in use and a 9th master tries to connect, it will be sent a "reset packet" that generates the appropriate error in its windows application.

NOTE: There are a number of ways to reset the controller. Hardware reset (push reset button or power down controller) and software resets (through Ethernet or USB by entering RS).

When the Galil controller acts as the master, the IH command is used to assign handles and connect to its slaves. The IP address may be entered as a 4 byte number separated with commas (industry standard uses periods) or as a signed 32 bit number. A port number may also be specified, but if it is not, it will default to 1000. The protocol (TCP/IP or UDP/IP) to use must also be designated at this time. Otherwise, the controller will not connect to the slave. (Ex. IHB=151,25,255,9<179>2 This will open handle #2 and connect to the IP address 151.25.255.9, port 179, using TCP/IP)

Which devices receive what information from the controller depends on a number of things. If a device queries the controller, it will receive the response unless it explicitly tells the controller to send it to another device. If the command that generates a response is part of a downloaded program, the response will route to whichever port is specified as the default (unless explicitly told to go to another port with the CF command). To designate a specific destination for the information, add {Eh} to the end of the command. (Ex. MG{EC}"Hello" will send the message "Hello" to handle #3. TP,,,{EF} will send the z axis position to handle #6.)

Multicasting

A multicast may only be used in UDP/IP and is similar to a broadcast (where everyone on the network gets the information) but specific to a group. In other words, all devices within a specified group will receive the information that is sent in a multicast. There can be many multicast groups on a network and are differentiated by their multicast IP address. To communicate with all the devices in a specific multicast group, the information can be sent to the multicast IP address rather than to each individual device IP address. All Galil controllers belong to a default multicast address of 239.255.19.56. The controller's multicast IP address can be changed by using the `IA> u` command.

Using Third Party Software

Galil supports DHCP, ARP, BOOT-P, and Ping which are utilities for establishing Ethernet connections. DHCP is a protocol used by networked devices (clients) to obtain the parameters necessary for operation in an Internet Protocol network. ARP is an application that determines the Ethernet (hardware) address of a device at a specific IP address. BOOT-P is an application that determines which devices on the network do not have an IP address and assigns the IP address you have chosen to it. Ping is used to check the communication between the device at a specific IP address and the host computer.

The DMC-41x3 can communicate with a host computer through any application that can send TCP/IP or UDP/IP packets. A good example of this is Telnet, a utility that comes with most Windows systems.

Modbus

An additional protocol layer is available for speaking to I/O devices. Modbus is an RS-485 protocol that packages information in binary packets that are sent as part of a TCP/IP packet. In this protocol, each slave has a 1 byte slave address. The DMC-41x3 can use a specific slave address or default to the handle number. The port number for Modbus is 502. The DMC-41x3 can fill the role of either a Modbus master or Modbus slave.

The Modbus protocol has a set of commands called function codes. The DMC-41x3 supports the 10 major function codes as a Modbus Master:

Function Code	Definition
01	Read Coil Status (Read Bits)
02	Read Input Status (Read Bits)
03	Read Holding Registers (Read Words)
04	Read Input Registers (Read Words)
05	Force Single Coil (Write One Bit)
06	Preset Single Register (Write One Word)
07	Read Exception Status (Read Error Code)
15	Force Multiple Coils (Write Multiple Bits)
16	Preset Multiple Registers (Write Words)
17	Report Slave ID

The DMC-41x3 supports 2 major function codes as a Modbus Slave:

Function Code	Definition
03	Read Holding Registers (Read Words)
16	Preset Multiple Registers (Write Words)

A Modbus master has the ability to read and write array data on the DMC-41x3¹ acting as a slave (up to 1000 elements are available). Each element is accessible as a 16-bit unsigned integer (Modbus register 1xxx) or as a 32-bit floating point number (Modbus registers 2xxx). The ability to write to the slaves array table is enabled by setting the ME command (ME is not needed to read array data). See the DMC-41x3 Command Reference for further details.

¹ Only DMC-41x3 firmware revisions Rev 1.2c and later support Modbus slave capability via the ME command.

The DMC-41x3 provides three levels of Modbus communication. The first level allows the user to create a raw packet and receive raw data. It uses the MBh command with a function code of -1. The format of the command is

MBh = -1, len, array[] where len is the number of bytes
array[] is the array with the data

The second level incorporates the Modbus structure. This is necessary for sending configuration and special commands to an I/O device. The formats vary depending on the function code that is called. For more information refer to the Command Reference.

The third level of Modbus communication uses standard Galil commands. Once the slave has been configured, the commands that may be used are @IN[], @AN[], SB, CB, OB, and AO. For example, AO 2020,8.2 would tell I/O number 2020 to output 8.2 volts.

If a specific slave address is not necessary, the I/O number to be used can be calculated with the following:

$$\text{I/O Number} = (\text{HandleNum} * 1000) + ((\text{Module}-1) * 4) + (\text{BitNum}-1)$$

Where HandleNum is the handle number from 1 (A) to 8 (8). Module is the position of the module in the rack from 1 to 16. BitNum is the I/O point in the module from 1 to 4.

Modbus Examples

Example #1

DMC-4143 connected as a Modbus master to a RIO-47120 via Modbus. The DMC-4143 will set or clear all 16 of the RIO's digital outputs

1. Begin by opening a connection to the RIO which in our example has IP address 192.168.1.120

IHB=192,168,1,120<502>2 (Issued to DMC-4143)

2. Dimension an array to store the commanded values. Set array element 0 equal to 170 and array element 1 equal to 85. (array element 1 configures digital outputs 15-8 and array element 0 configures digital outputs 7-0)

```
DM myarray[2]
myarray[0] = 170      (which is 10101010 in binary)
myarray[1] = 85       (which is 01010101 in binary)
```

3. a) Send the appropriate MB command. Use function code 15. Start at output 0 and set/clear all 16 outputs based on the data in myarray[]

```
MBB=,15,0,16,myarray[]
```

3. b) Set the outputs using the SB command.

SB2001:SB2003:SB2005:SB2007:SB2008:SB2010:SB2012:SB2014:

Results:

Both steps 3a and 3b will result in outputs being activated as below. The only difference being that step 3a will set and clear all 16 bits where as step 3b will only set the specified bits and will have no affect on the others.

Bit Number	Status
0	0
1	1
2	0
3	1
4	0
5	1
6	0
7	1

Bit Number	Status
8	1
9	0
10	1
11	0
12	1
13	0
14	1
15	0

Example #2

DMC-4143 connected as a Modbus master to a 3rd party PLC. The DMC-4143 will read the value of analog inputs 3 and 4 on the PLC located at addresses 40006 and 40008 respectively. The PLC stores values as 32-bit floating point numbers which is common.

1. Begin by opening a connection to the PLC which has an IP address of 192.168.1.10 in our example

```
IHB=192,168,1,10<502>2
```

2. Dimension an array to store the results

```
DM myanalog[4]
```

3. Send the appropriate MB command. Use function code 4 (as specified per the PLC). Start at address 40006. Retrieve 4 modbus registers (2 modbus registers per 1 analog input, as specified by the PLC)

```
MBB=,4,40006,4,myanalog[]
```

Results:

Array elements 0 and 1 will make up the 32 bit floating point value for analog input 3 on the PLC and array elements 2 and 3 will combine for the value of analog input 4.

```
myanalog[0]=16412=0x401C
myanalog[1]=52429=0xCCCC
myanalog[2]=49347=0xC0C3
myanalog[3]=13107=0x3333
```

Analog input 3 = 0x401CCCCD = 2.45V

Analog input 4 = 0xC0C33333 = -6.1V

Example #3

DMC-4143 connected as a Modbus master to a hydraulic pump. The DMC-4143 will set the pump pressure by writing to an analog output on the pump located at Modbus address 30000 and consisting of 2 Modbus registers forming a 32 bit floating point value.

1. Begin by opening a connection to the pump which has an IP address of 192.168.1.100 in our example

```
IHB=192,168,1,100<502>2
```

2. Dimension and fill an array with values that will be written to the PLC

```
DM pump[2]
```

```
pump[0]=16531=0x4093  
pump[1]=13107=0x3333
```

3. Send the appropriate MB command. Use function code 16. Start at address 30000 and write to 2 registers using the data in the array pump[]

```
MBB=,16,30000,2,pump[]
```

Results:

Analog output will be set to 0x40933333 which is 4.6V

Data Record

The DMC-41x3 can provide a binary block of status information with the use of the `QR` and `DR` commands. These commands, along with the `QZ` command can be very useful for accessing complete controller status. The `QR` command will return 4 bytes of header information and specific blocks of information as specified by the command arguments:

`QR ABCDEFGHST`

Each argument corresponds to a block of information according to the Data Record Map below. If no argument is given, the entire data record map will be returned. Note that the data record size will depend on the number of axes.

The following is the byte map for the binary data.

Data Record Map Key	
Acronym	Meaning
UB	Unsigned byte
UW	Unsigned word
SW	Signed word
SL	Signed long
UL	Unsigned long

General Controller Information and Status

ADDR	TYPE	ITEM	ADDR	TYPE	ITEM
00	UB	1 st Byte of Header	30-31	SW	Reserved
01	UB	2 nd Byte of Header	32-33	SW	Reserved
02	UB	3 rd Byte of Header	34-35	SW	Reserved
03	UB	4 th Byte of Header	36-37	SW	Reserved
04-05	UW	sample number	38-39	SW	Reserved
06	UB	general input block 0 (inputs 1-8)	40-41	SW	Reserved
07	UB	general input block 1 (inputs 9-16)	42	UB	Ethernet Handle A Status
08	UB	general input block 2 (inputs 17-24)	43	UB	Ethernet Handle B Status
09	UB	general input block 3 (inputs 25-32)	44	UB	Ethernet Handle C Status
10	UB	general input block 4 (inputs 33-40)	45	UB	Ethernet Handle D Status
11	UB	general input block 5 (inputs 41-48)	46	UB	Ethernet Handle E Status
12	UB	general input block 6 (inputs 49-56)	47	UB	Ethernet Handle F Status
13	UB	general input block 7 (inputs 57-64)	48	UB	Ethernet Handle G Status
14	UB	general input block 8 (inputs 65-72)	49	UB	Ethernet Handle H Status
15	UB	general input block 9 (inputs 73-80)	50	UB	error code
16	UB	general output block 0 (outputs 1-8)	51	UB	thread status – see bit field map below
17	UB	general output block 1 (outputs 9-16)	52-55	UL	Amplifier Status
18	UB	general output block 2 (outputs 17-24)	56-59	UL	Segment Count for Contour Mode
19	UB	general output block 3 (outputs 25-32)	60-61	UW	Buffer space remaining – Contour Mode
20	UB	general output block 4 (outputs 33-40)	62-63	UW	segment count of coordinated move for S plane
21	UB	general output block 5 (outputs 41-48)	64-65	UW	coordinated move status for S plane – see bit field map below
22	UB	general output block 6 (outputs 49-56)	66-69	SL	distance traveled in coordinated move for S plane
23	UB	general output block 7 (outputs 57-64)	70-71	UW	Buffer space remaining – S Plane
24	UB	general output block 8 (outputs 65-72)	72-73	UW	segment count of coordinated move for T plane
25	UB	general output block 9 (outputs 73-80)	74-75	UW	Coordinated move status for T plane – see bit field map below
26-27	SW	Reserved	76-79	SL	distance traveled in coordinated move for T plane
28-29	SW	Reserved	80-81	UW	Buffer space remaining – T Plane

Axis Information

ADDR	TYPE	ITEM	ADDR	TYPE	ITEM
82-83	UW	A axis status – see bit field map below	226-227	UW	E axis status – see bit field map below
84	UB	A axis switches – see bit field map below	228	UB	E axis switches – see bit field map below
85	UB	A axis stop code	229	UB	E axis stop code
86-89	SL	A axis reference position	230-233	SL	E axis reference position
90-93	SL	A axis motor position	234-237	SL	E axis motor position
94-97	SL	A axis position error	238-241	SL	E axis position error
98-101	SL	A axis auxiliary position	242-245	SL	E axis auxiliary position
102-105	SL	A axis velocity	246-249	SL	E axis velocity
106-109	SL	A axis torque	250-253	SL	E axis torque
110-111	SW or UW ¹	A axis analog input	254-255	SW or UW ¹	E axis analog input
112	UB	A Hall Input Status	256	UB	E Hall Input Status
113	UB	Reserved	257	UB	Reserved
114-117	SL	A User defined variable (ZA)	258-261	SL	E User defined variable (ZA)
118-119	UW	B axis status – see bit field map below	262-263	UW	F axis status – see bit field map below
120	UB	B axis switches – see bit field map below	264	UB	F axis switches – see bit field map below
121	UB	B axis stop code	265	UB	F axis stop code
122-125	SL	B axis reference position	266-269	SL	F axis reference position
126-129	SL	B axis motor position	270-273	SL	F axis motor position
130-133	SL	B axis position error	274-277	SL	F axis position error
134-137	SL	B axis auxiliary position	278-281	SL	F axis auxiliary position
138-141	SL	B axis velocity	282-285	SL	F axis velocity
142-145	SL	B axis torque	286-289	SL	F axis torque
146-147	SW or UW ¹	B axis analog input	290-291	SW or UW ¹	F axis analog input
148	UB	B Hall Input Status	292	UB	F Hall Input Status
149	UB	Reserved	293	UB	Reserved
150-153	SL	B User defined variable (ZA)	294-297	SL	F User defined variable (ZA)
154-155	UW	C axis status – see bit field map below	298-299	UW	G axis status – see bit field map below
156	UB	C axis switches – see bit field map below	300	UB	G axis switches – see bit field map below
157	UB	C axis stop code	301	UB	G axis stop code
158-161	SL	C axis reference position	302-305	SL	G axis reference position
162-165	SL	C axis motor position	306-309	SL	G axis motor position
166-169	SL	C axis position error	310-313	SL	G axis position error
170-173	SL	C axis auxiliary position	314-317	SL	G axis auxiliary position
174-177	SL	C axis velocity	318-321	SL	G axis velocity
178-181	SL	C axis torque	322-325	SL	G axis torque
182-183	SW or UW ¹	C axis analog input	326-327	SW or UW ¹	G axis analog input
184	UB	C Hall Input Status	328	UB	G Hall Input Status
185	UB	Reserved	329	UB	Reserved
186-189	SL	C User defined variable (ZA)	330-333	SL	G User defined variable (ZA)
190-191	UW	D axis status – see bit field map below	334-335	UW	H axis status – see bit field map below
192	UB	D axis switches – see bit field map below	336	UB	H axis switches – see bit field map below
193	UB	D axis stop code	337	UB	H axis stop code
194-197	SL	D axis reference position	338-341	SL	H axis reference position
198-201	SL	D axis motor position	342-345	SL	H axis motor position
202-205	SL	D axis position error	346-349	SL	H axis position error
206-209	SL	D axis auxiliary position	350-353	SL	H axis auxiliary position
210-213	SL	D axis velocity	354-357	SL	H axis velocity
214-217	SL	D axis torque	358-361	SL	H axis torque
218-219	SW or UW ¹	D axis analog input	362-363	SW or UW ¹	H axis analog input
220	UB	D Hall Input Status	364	UB	H Hall Input Status
221	UB	Reserved	365	UB	Reserved
222-225	SL	D User defined variable (ZA)	366-369	SL	H User defined variable (ZA)

¹ Will be either a Signed Word or Unsigned Word depending upon AQ setting. See AQ in the Command Reference for more information.

Data Record Bit Field Maps

Header Information - Byte 0, 1 of Header:

BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8
1	N/A	N/A	N/A	N/A	I Block Present in Data Record	T Block Present in Data Record	S Block Present in Data Record
BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
H Block Present in Data Record	G Block Present in Data Record	F Block Present in Data Record	E Block Present in Data Record	D Block Present in Data Record	C Block Present in Data Record	B Block Present in Data Record	A Block Present in Data Record

Bytes 2, 3 of Header:

Bytes 2 and 3 make a word which represents the Number of bytes in the data record, including the header.

Byte 2 is the low byte and byte 3 is the high byte

NOTE: The header information of the data records is formatted in little endian (reversed network byte order).

Thread Status (1 Byte)

BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
Thread 7 Running	Thread 6 Running	Thread 5 Running	Thread 4 Running	Thread 3 Running	Thread 2 Running	Thread 1 Running	Thread 0 Running

Coordinated Motion Status for S or T Plane (2 Byte)

BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8
Move in Progress	N/A	N/A	N/A	N/A	N/A	N/A	N/A

BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
N/A	N/A	Motion is slewing	Motion is stopping due to ST or Limit Switch	Motion is making final decel.	N/A	N/A	N/A

Axis Status (1 Word)

BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8
Move in Progress	Mode of Motion PA or PR	Mode of Motion PA only	(FE) Find Edge in Progress	Home (HM) in Progress	1 st Phase of HM complete	2 nd Phase of HM complete or FI command issued	Mode of Motion Coord. Motion

BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
Negative Direction Move	Mode of Motion Contour	Motion is slewing	Motion is stopping due to ST of Limit Switch	Motion is making final decel.	Latch is armed	3rd Phase of HM in Progress	Motor Off

Axis Switches (1 Byte)

BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
Latch Occurred	State of Latch Input	N/A	N/A	State of Forward Limit	State of Reverse Limit	State of Home Input	Stepper Mode

Amplifier Status (4 Bytes)

BIT 31	BIT 30	BIT 29	BIT 28	BIT 27	BIT 26	BIT 25	BIT 24
N/A	N/A	N/A	N/A	N/A	N/A	ELO Active (Axis E-H)	ELO Active (Axis A-D)

BIT 23	BIT 22	BIT 21	BIT 20	BIT 19	BIT 18	BIT 17	BIT 16
Peak Current H-axis	Peak Current G-axis	Peak Current F-axis	Peak Current E-axis	Peak Current D-axis	Peak Current C-axis	Peak Current B-axis	Peak current A-axis

BIT 15	BIT 14	BIT 13	BIT 12	BIT 11	BIT 10	BIT 9	BIT 8
Hall Error H-axis	Hall Error G-axis	Hall Error F-axis	Hall Error E-axis	Hall Error D-axis	Hall Error C-axis	Hall Error B-axis	Hall Error A-axis

BIT 7	BIT 6	BIT 5	BIT 4	BIT 3	BIT 2	BIT 1	BIT 0
Under Voltage Axis (E-H)	Over Temp. Axis (E-H)	Over Voltage Axis (E-H)	Over Current Axis (E-H)	Under Voltage Axis (A-D)	Over Temp. Axis (A-D)	Over Voltage Axis (A-D)	Over Current Axis (A-D)

Notes Regarding Velocity and Torque Information

The velocity information that is returned in the data record is 64 times larger than the value returned when using the command TV (Tell Velocity). See command reference for more information about TV.

The Torque information is represented as a number in the range of ± 32767 . Maximum negative torque is -32767. Maximum positive torque is 32767. Zero torque is 0.

QZ Command

The QZ command can be very useful when using the QR command, since it provides information about the controller and the data record. The QZ command returns the following 4 bytes of information.

BYTE #	INFORMATION
0	Number of axes present
1	number of bytes in general block of data record
2	number of bytes in coordinate plane block of data record
3	Number of Bytes in each axis block of data record

Galil Software

Galil provides a variety of software tools available to make communication and configuration easier for the user. Galil's latest generation software is available on the Galil website at:

<http://galil.com/downloads/software>

Creating Custom Software Interfaces

Galil provides programming tools so that users can develop their own custom software interfaces to a Galil controller. For new applications, Galil recommends the current generation communication libraries located on the Galil Website:

<http://galil.com/downloads/api>

Please visit the API examples page under the Learn section for details on getting started developing custom software interfaces for Galil controllers:

<http://galil.com/learn/api-examples>

Chapter 5 Command Basics

Introduction

The DMC-41x3 provides over 100 commands for specifying motion and machine parameters. Commands are included to initiate action, interrogate status and configure the digital filter. These commands are sent in ASCII.

The DMC-41x3 instruction set is BASIC-like and easy to use. Instructions consist of two uppercase letters that correspond phonetically with the appropriate function. For example, the instruction BG begins motion, and ST stops the motion.

Commands can be sent "live" over the communications port for immediate execution by the DMC-41x3, or an entire group of commands can be downloaded into the DMC-41x3 memory for execution at a later time. Combining commands into groups for later execution is referred to as Applications Programming and is discussed in the following chapter.

This section describes the DMC-41x3 instruction set and syntax. A summary of commands as well as a complete listing of all DMC-41x3 instructions is included in the *Command Reference*.

<http://galil.com/downloads/manuals-and-data-sheets>

Command Syntax - ASCII

DMC-41x3 instructions are represented by two ASCII upper case characters followed by applicable arguments. A space may be inserted between the instruction and arguments. A semicolon or <return> is used to terminate the instruction for processing by the DMC-41x3 command interpreter.

NOTE: If you are using a Galil terminal program, commands will not be processed until an <return> command is given. This allows the user to separate many commands on a single line and not begin execution until the user gives the <return> command.

NOTE	All DMC commands are two-letters sent in upper case!
-------------	--

For example, the command

`PR 4000 <return>`

`Position relative`

Implicit Notation

PR is the two character instruction for position relative. 4000 is the argument which represents the required position value in counts. The <return> terminates the instruction. The space between PR and 4000 is optional.

For specifying data for the A,B,C and D axes, commas are used to separate the axes. If no data is specified for an axis, a comma is still needed as shown in the examples below. If no data is specified for an axis, the previous value is maintained.

To view the current values for each command, type the command followed by a ? for each axis requested.

PR 1000	Specify A only as 1000
PR ,2000	Specify B only as 2000
PR ,,3000	Specify C only as 3000
PR,,,4000	Specify D only as 4000
PR 2000, 4000,6000, 8000	Specify A,B,C and D
PR ,8000,,9000	Specify B and D only
PR ?,?,?/?	Request A,B,C,D values
PR ,?	Request B value only

Explicit Notation

The DMC-41x3 provides an alternative method for specifying data. Here data is specified individually using a single axis specifier such as A, B, C or D. An equals sign is used to assign data to that axis. For example:

PRA=1000	Specify a position relative movement for the A axis of 1000
ACB=200000	Specify acceleration for the B axis as 200000

Instead of data, some commands request action to occur on an axis or group of axes. For example, ST AB stops motion on both the A and B axes. Commas are not required in this case since the particular axis is specified by the appropriate letter A, B, C or D. If no parameters follow the instruction, action will take place on all axes. Here are some examples of syntax for requesting action:

BG A	Begin A only
BG B	Begin B only
BG ABCD	Begin all axes
BG BD	Begin B and D only
BG	Begin all axes

4183

For controllers with 5 or more axes, the axes are referred to as A,B,C,D,E,F,G,H. The specifiers X,Y,Z,W and A,B,C,D may be used interchangeably.

BG ABCDEFGH	Begin all axes
BG D	Begin D only

Coordinated Motion with more than 1 axis

When requesting action for coordinated motion, the letter S or T is used to specify the coordinated motion. This allows for coordinated motion to be setup for two separate coordinate systems. Refer to the CA command in the Command Reference for more information on specifying a coordinate system. For example:

BG S	Begin coordinated sequence, S
BG TD	Begin coordinated sequence, T, and D axis

Controller Response to DATA

The DMC-41x3 returns a : for valid commands and a ? for invalid commands.

For example, if the command BG is sent in lower case, the DMC-41x3 will return a ?.

:bg	invalid command, lower case
-----	-----------------------------

? DMC-41x3 returns a ?

When the controller receives an invalid command the user can request the error code. The error code will specify the reason for the invalid command response. To request the error code type the command TC1. For example:

?TC1	Tell Code command
1 Unrecognized command	Returned response

There are many reasons for receiving an invalid command response. The most common reasons are: unrecognized command (such as typographical entry or lower case), command given at improper time (such as during motion), or a command out of range (such as exceeding maximum speed). A complete listing of all codes is listed in the TC command in the Command Reference section.

Interrogating the Controller

Interrogation Commands

The DMC-41x3 has a set of commands that directly interrogate the controller. When the command is entered, the requested data is returned in decimal format on the next line followed by a carriage return and line feed. The format of the returned data can be changed using the Position Format (PF), Variable Format (VF) and Leading Zeros (LZ) command. See Chapter 7 Application Programming and the Command Reference.

Summary of Interrogation Commands

RP	Report Command Position
RL	Report Latch
^R^V	Firmware Revision Information
SC	Stop Code
TA	Tell Amplifier Error
TB	Tell Status
TC	Tell Error Code
TD	Tell Dual Encoder
TE	Tell Error
TI	Tell Input
TP	Tell Position
TR	Trace
TS	Tell Switches
TT	Tell Torque
TV	Tell Velocity

For example, the following example illustrates how to display the current position of the X axis:

TP A	Tell position A
0	Controllers Response
TP AB	Tell position A and B
0,0	Controllers Response

Interrogating Current Commanded Values.

Most commands can be interrogated by using a question mark (?) as the axis specifier. Type the command followed by a ? for each axis requested.

PR ?, ?, ?, ?	Request A,B,C,D values
PR , ?	Request B value only

The controller can also be interrogated with operands.

Operands

Most DMC-41x3 commands have corresponding operands that can be used for interrogation. Operands must be used inside of valid DMC expressions. For example, to display the value of an operand, the user could use the command:

MG `operand' where 'operand' is a valid DMC operand

All of the command operands begin with the underscore character (_). For example, the value of the current position on the A axis can be assigned to the variable 'V' with the command:

V=_TPA

The Command Reference denotes all commands which have an equivalent operand as "Operand Usage". Also, see description of operands in Chapter 7 Application Programming.

Command Summary

For a complete command summary, see *Command Reference* manual.

<http://galil.com/download/comref/com4103/index.html>

Chapter 6 Programming Motion

Overview

The DMC-41x3 provides several modes of motion, including independent positioning and jogging, coordinated motion, electronic cam motion, and electronic gearing. Each one of these modes is discussed in the following sections.

The DMC-4113 are single axis controllers and use X-axis motion only. Likewise, the DMC-4123 use X and Y, the DMC-4133 use X,Y, and Z, and the DMC-4143 use X,Y,Z, and W. The DMC-4153 use A,B,C,D, and E. The DMC-4163 use A,B,C,D,E, and F. The DMC-4173 use A,B,C,D,E,F, and G. The DMC-4183 use the axes A,B,C,D,E,F,G, and H.

The example applications described below will help guide you to the appropriate mode of motion.

4183

For controllers with 5 or more axes, the specifiers, ABCDEFGH, are used. XYZ and W may be interchanged with ABCD.

EXAMPLE APPLICATION	MODE OF MOTION	COMMANDS
Absolute or relative positioning where each axis is independent and follows prescribed velocity profile.	Independent Axis Positioning	PA, PR, SP, AC, DC
Velocity control where no final endpoint is prescribed. Motion stops on Stop command.	Independent Jogging	JG, AC, DC, ST
Absolute positioning mode where absolute position targets may be sent to the controller while the axis is in motion.	Position Tracking	PA, AC, DC, SP, PT
Motion Path described as incremental position points versus time.	Contour Mode	CM, CD, DT
Motion Path described as incremental position, velocity and delta time	PVT Mode	PV, BT
2 to 8 axis coordinated motion where path is described by linear segments.	Linear Interpolation Mode	LM, LI, LE, VS, VR, VA, VD
2-D motion path consisting of arc segments and linear segments, such as engraving or quilting.	Vector Mode: Linear and Circular Interpolation Motion	VM, VP, CR, VS, VR, VA, VD, VE
Third axis must remain tangent to 2-D motion path, such as knife cutting.	Vector Mode: Linear and Circular Interpolation Motion with Tangent Motion:	VM, VP, CR, VS, VA, VD, TN, VE
Electronic gearing where slave axes are scaled to master axis which can move in both directions.	Electronic Gearing	GA, GD, _GP, GR, GM (if gantry)
Master/slave where slave axes must follow a master such as conveyer speed.	Electronic Gearing and Ramped Gearing	GA, GD, _GP, GR

Moving along arbitrary profiles or mathematically prescribed profiles such as sine or cosine trajectories.	Contour Mode	CM, CD, DT
Teaching or Record and Play Back	Contour Mode with Teach (Record and Play-Back)	CM, CD, DT, RA, RD, RC
Backlash Correction	Dual Loop (Auxiliary Encoder)	DV
Following a trajectory based on a master encoder position	Electronic Cam	EA, EM, EP, ET, EB, EG, EQ
Smooth motion while operating in independent axis positioning	Motion Smoothing	IT
Smooth motion while operating in vector or linear interpolation positioning	Motion Smoothing	IT
Smooth motion while operating with stepper motors	Stepper Motion Smoothing	KS
Gantry - two axes are coupled by gantry	Electronic Gearing - Example - Gantry Mode	GR, GM

Independent Axis Positioning

In this mode, motion between the specified axes is independent, and each axis follows its own profile. The user specifies the desired absolute position (PA) or relative position (PR), slew speed (SP), acceleration ramp (AC), and deceleration ramp (DC), for each axis. On begin (BG), the DMC-41x3 profiler generates the corresponding trapezoidal or triangular velocity profile and position trajectory. The controller determines a new command position along the trajectory every sample period until the specified profile is complete. Motion is complete when the last position command is sent by the DMC-41x3 profiler. Note: The actual motor motion may not be complete when the profile has been completed, however, the next motion command may be specified.

The Begin (BG) command can be issued for all axes either simultaneously or independently. XYZ or W axis specifiers are required to select the axes for motion. When no axes are specified, this causes motion to begin on all axes.

The speed (SP) and the acceleration (AC) can be changed at any time during motion, however, the deceleration (DC) and position (PR or PA) cannot be changed until motion is complete. Remember, motion is complete when the profiler is finished, not when the actual motor is in position. The Stop command (ST) can be issued at any time to decelerate the motor to a stop before it reaches its final position.

An incremental position movement (IP) may be specified during motion as long as the additional move is in the same direction. Here, the user specifies the desired position increment, n. The new target is equal to the old target plus the increment, n. Upon receiving the IP command, a revised profile will be generated for motion towards the new end position. The IP command does not require a begin. Note: If the motor is not moving, the IP command is equivalent to the PR and BG command combination.

Command Summary - Independent Axis

COMMAND	DESCRIPTION
PR x, y, z, w	Specifies relative distance
PA x, y, z, w	Specifies absolute position
SP x, y, z, w	Specifies slew speed
AC x, y, z, w	Specifies acceleration rate
DC x, y, z, w	Specifies deceleration rate
BG XYZW	Starts motion
ST XYZW	Stops motion before end of move
IP x, y, z, w	Changes position target
IT x, y, z, w	Time constant for independent motion smoothing
AM XYZW	Trippoint for profiler complete
MC XYZW	Trippoint for "in position"

The lower case specifiers (x,y,z,w) represent position values for each axis.

The DMC-41x3 also allows use of single axis specifiers such as PRY=2000

Operand Summary - Independent Axis

OPERAND	DESCRIPTION
ACx	Return acceleration rate for the axis specified by 'x'
DCx	Return deceleration rate for the axis specified by 'x'
SPx	Returns the speed for the axis specified by 'x'
PAX	Returns current destination if 'x' axis is moving, otherwise returns the current commanded position if in a move.
PRx	Returns current incremental distance specified for the 'x' axis

Example - Absolute Position Movement

```

PA 10000,20000      Specify absolute X,Y position
AC 1000000,1000000  Acceleration for X,Y
DC 1000000,1000000  Deceleration for X,Y
SP 50000,30000      Speeds for X,Y
BG XY               Begin motion

```

Example - Multiple Move Sequence

Required Motion Profiles:

X-Axis	500 counts	Position
	20000 count/sec	Speed
	500000 counts/sec ²	Acceleration
Y-Axis	1000 counts	Position
	10000 count/sec	Speed
	500000 counts/sec ²	Acceleration
Z-Axis	100 counts	Position
	5000 counts/sec	Speed
	500000 counts/sec	Acceleration

This example will specify a relative position movement on X, Y and Z axes. The movement on each axis will be separated by 20 msec Figure 6.1 shows the velocity profiles for the X,Y and Z axis.

```

#A                Begin Program
PR 2000,500,100   Specify relative position movement of 2000, 500 and 100 counts for X,Y and Z axes.
SP 20000,10000,5000 Specify speed of 20000, 10000, and 5000 counts / sec
AC 500000,500000,500000 Specify acceleration of 500000 counts / sec2 for all axes
DC 500000,500000,500000 Specify deceleration of 500000 counts / sec2 for all axes
BG X              Begin motion on the X axis
WT 20             Wait 20 msec
BG Y              Begin motion on the Y axis
WT 20             Wait 20 msec
BG Z              Begin motion on Z axis
EN               End Program

```




Figure 6.1: Velocity Profiles of XYZ

Notes on Figure 6.1: The X and Y axis have a ‘trapezoidal’ velocity profile, while the Z axis has a ‘triangular’ velocity profile. The X and Y axes accelerate to the specified speed, move at this constant speed, and then decelerate such that the final position agrees with the command position, PR. The Z axis accelerates, but before the specified speed is achieved, must begin deceleration such that the axis will stop at the commanded position. All 3 axes have the same acceleration and deceleration rate, hence, the slope of the rising and falling edges of all 3 velocity profiles are the same.

Independent Jogging

The jog mode of motion is very flexible because speed, direction and acceleration can be changed during motion. The user specifies the jog speed (JG), acceleration (AC), and the deceleration (DC) rate for each axis. The direction of motion is specified by the sign of the JG parameters. When the begin command is given (BG), the motor accelerates up to speed and continues to jog at that speed until a new speed or stop (ST) command is issued. If the jog speed is changed during motion, the controller will make a accelerated (or decelerated) change to the new speed.

An instant change to the motor position can be made with the use of the IP command. Upon receiving this command, the controller commands the motor to a position which is equal to the specified increment plus the current position. This command is useful when trying to synchronize the position of two motors while they are moving.

Note that the controller operates as a closed-loop position controller while in the jog mode. The DMC-41x3 converts the velocity profile into a position trajectory and a new position target is generated every sample period. This method of control results in precise speed regulation with phase lock accuracy.

Command Summary - Jogging

COMMAND	DESCRIPTION
AC x, y, z, w	Specifies acceleration rate
BG XYZW	Begins motion
DC x, y, z, w	Specifies deceleration rate
IP x, y, z, w	Increments position instantly
IT x, y, z, w	Time constant for independent motion smoothing
JG $\pm x, y, z, w$	Specifies jog speed and direction
ST XYZW	Stops motion

Parameters can be set with individual axes specifiers such as JGY=2000 (set jog speed for Y axis to 2000).

Operand Summary - Independent Axis

OPERAND	DESCRIPTION
ACx	Return acceleration rate for the axis specified by 'x'
DCx	Return deceleration rate for the axis specified by 'x'
SPx	Returns the jog speed for the axis specified by 'x'
TVx	Returns the actual velocity of the axis specified by 'x' (averaged over 0.25 sec)

Example - Jog in X only

Jog X motor at 50000 count/s. After X motor is at its jog speed, begin jogging Z in reverse direction at 25000 count/s.

```
#A
AC 20000,,20000      Specify X,Z acceleration of 20000 counts / sec^2
DC 20000,,20000      Specify X,Z deceleration of 20000 counts / sec^2
JG 50000,,-25000     Specify jog speed and direction for X and Z axis
BG X                  Begin X motion
AS X                  Wait until X is at speed
BG Z                  Begin Z motion
EN
```

Example - Joystick Jogging

The jog speed can also be changed using an analog input such as a joystick. Assume that for a 10 Volt input the speed must be 50000 counts/sec.

```
#JOY                  Label
JG0                    Set in Jog Mode
BGX                     Begin motion
#B                      Label for loop
V1 =@AN[1]             Read analog input
VEL=V1*50000/10         Compute speed
JG VEL                  Change JG speed
JP #B                   Loop
```

Position Tracking

The Galil controller may be placed in the position tracking mode to support changing the target of an absolute position move on the fly. New targets may be given in the same direction or the opposite direction of the current position target. The controller will then calculate a new trajectory based upon the new target and the acceleration, deceleration, and speed parameters that have been set. The motion profile in this mode is trapezoidal. There is not a set limit governing the rate at which the end point may be changed, however at the standard TM rate, the controller updates the position information at the rate of 1msec. The controller generates a profiled point every other sample, and linearly interpolates one sample between each profiled point. Some examples of applications that may use this mode are satellite tracking, missile tracking, random pattern polishing of mirrors or lenses, or any application that requires the ability to change the endpoint without completing the previous move.

The PA command is typically used to command an axis or multiple axes to a specific absolute position. For some applications such as tracking an object, the controller must proceed towards a target and have the ability to change the target during the move. In a tracking application, this could occur at any time during the move or at regularly scheduled intervals. For example if a robot was designed to follow a moving object at a specified distance and the path of the object wasn't known the robot would be required to constantly monitor the motion of the object that it was following. To remain within a specified distance it would also need to constantly update the position target it is moving towards. Galil motion controllers support this type of motion with the position tracking mode. This mode will allow scheduled or random updates to the current position target on the fly. Based on the new target the controller will either continue in the direction it is heading, change the direction it is moving, or decelerate to a stop.

The position tracking mode shouldn't be confused with the contour mode. The contour mode allows the user to generate custom profiles by updating the reference position at a specific time rate. In this mode, the position can be updated randomly or at a fixed time rate, but the velocity profile will always be trapezoidal with the parameters specified by AC, DC, and SP. Updating the position target at a specific rate will not allow the user to create a custom profile.

The following example will demonstrate the possible different motions that may be commanded by the controller in the position tracking mode. In this example, there is a host program that will generate the absolute position targets. The absolute target is determined based on the current information the host program has gathered on the object that it is tracking. The position tracking mode does allow for all of the axes on the controller to be in this mode, but for the sake of discussion, it is assumed that the robot is tracking only in the X dimension.

The controller must be placed in the position tracking mode to allow on the fly absolute position changes. This is performed with the PT command. To place the X axis in this mode, the host would issue PT1 to the controller if both X and Y axes were desired the command would be PT 1,1. The next step is to begin issuing PA command to the controller. The BG command isn't required in this mode, the SP, AC, and DC commands determine the shape of the trapezoidal velocity profile that the controller will use.

Example - Motion 1:

The host program determines that the first target for the controller to move to is located at 5000 encoder counts. The acceleration and deceleration should be set to 150,000 counts/sec² and the velocity is set to 50,000 counts/sec. The command sequence to perform this is listed below.

```
#EX1
PT 1; '      Place the X axis in Position tracking mode
AC 150000; '  Set the X axis acceleration to 150000 counts/sec2
DC 150000; '  Set the X axis deceleration to 150000 counts/sec2
SP 50000; '   Set the X axis speed to 50000 counts/sec
PA 5000; '    Command the X axis to absolute position 5000 encoder counts
EN
```

The output from this code can be seen in Figure 6.2, a screen capture from the GDK scope.




Figure 6.2: Position vs Time (msec) - Motion 1

Example - Motion 2:

The previous step showed the plot if the motion continued all the way to 5000, however partway through the motion, the object that was being tracked changed direction, so the host program determined that the actual target position should be 2000 counts at that time. Figure 6.2 shows what the position profile would look like if the move was allowed to complete to 5000 counts. The position was modified when the robot was at a position of 4200 counts (Figure 6.3). Note that the robot actually travels to a distance of almost 5000 counts before it turns around. This is a function of the deceleration rate set by the DC command. When a direction change is

commanded, the controller decelerates at the rate specified by the DC command. The controller then ramps the velocity in up to the value set with SP in the opposite direction traveling to the new specified absolute position. In Figure 6.3 the velocity profile is triangular because the controller doesn't have sufficient time to reach the set speed of 50000 counts/sec before it is commanded to change direction.

The below code is used to simulate this scenario:

```
#EX2
PT 1;' Place the X axis in Position tracking mode
AC 150000;' Set the X axis acceleration to 150000 counts/sec2
DC 150000;' Set the X axis deceleration to 150000 counts/sec2
SP 50000;' Set the X axis speed to 50000 counts/sec
PA 5000;' Command the X axis to abs position 5000 encoder counts
MF 4200
PA 2000;' Change end point position to position 2000
EN
```




Figure 6.3: Position and Velocity vs Time(msec) for Motion 2

Example - Motion 3:

In this motion, the host program commands the controller to begin motion towards position 5000, changes the target to -2000, and then changes it again to 8000. Figure 6.4 shows the plot of position vs. time and velocity vs. time. Below is the code that is used to simulate this scenario:

```
#EX3
PT 1;' Place the X axis in Position tracking mode
AC 150000;' Set the X axis acceleration to 150000 counts/sec2
DC 150000;' Set the X axis deceleration to 150000 counts/sec2
SP 50000;' Set the X axis speed to 50000 counts/sec
PA 5000;' Command the X axis to abs position 5000 encoder counts
WT 300
PA -2000;' Change end point position to -2000
WT 200
PA 8000;' Change end point position to 8000
EN
```

Figure 6.5 demonstrates the use of motion smoothing (IT) on the velocity profile in this mode. The jerk in the system is also affected by the values set for AC and DC.




Figure 6.4: Position and Velocity vs Time (msec) for Motion 3




Figure 6.5: Position and Velocity vs Time (msec) for Motion 3 with IT 0.1

Note the controller treats the point where the velocity passes through zero as the end of one move, and the beginning of another move. IT is allowed, however it will introduce some time delay.

Trippoints

Most trippoints are valid for use while in the position tracking mode. There are a few exceptions to this; the AM and MC commands may not be used while in this mode. It is recommended that AR, MF, MR, or AP be used, as they involve motion in a specified direction, or the passing of a specific absolute position.

Command Summary – Position Tracking Mode

COMMAND	DESCRIPTION
AC n,n,n,n,n,n,n,n	Acceleration settings for the specified axes
AP n,n,n,n,n,n,n,n	trippoint that holds up program execution until an absolute position has been reached
DC n,n,n,n,n,n,n,n	Deceleration settings for the specified axes
MF n,n,n,n,n,n,n,n	trippoint to hold up program execution until n number of counts have passed in the forward direction. Only one axis at a time may be specified.
MR n,n,n,n,n,n,n,n	trippoint to hold up program execution until n number of counts have passed in the reverse direction. Only one axis at a time may be specified.
PT n,n,n,n,n,n,n,n	Command used to enter and exit the Trajectory Modification Mode
PA n,n,n,n,n,n,n,n	Command Used to specify the absolute position target
SP n,n,n,n,n,n,n,n	Speed settings for the specified axes

Linear Interpolation Mode

The DMC-41x3 provides a linear interpolation mode for 2 or more axes. In linear interpolation mode, motion between the axes is coordinated to maintain the prescribed vector speed, acceleration, and deceleration along the specified path. The motion path is described in terms of incremental distances for each axis. An unlimited number of incremental segments may be given in a continuous move sequence, making the linear interpolation mode ideal for following a piece-wise linear path. There is no limit to the total move length.

The LM command selects the Linear Interpolation mode and axes for interpolation. For example, LM YZ selects only the Y and Z axes for linear interpolation.

When using the linear interpolation mode, the LM command only needs to be specified once unless the axes for linear interpolation change.

Specifying Linear Segments

The command LI x,y,z,w or LI a,b,c,d,e,f,g,h specifies the incremental move distance for each axis. This means motion is prescribed with respect to the current axis position. Up to 511 incremental move segments may be given prior to the Begin Sequence (BGS) command. Once motion has begun, additional LI segments may be sent to the controller.

The clear sequence (CS) command can be used to remove LI segments stored in the buffer prior to the start of the motion. To stop the motion, use the instructions STS or AB. The command, ST, causes a decelerated stop. The command, AB, causes an instantaneous stop and aborts the program, and the command AB1 aborts the motion only.

The Linear End (LE) command must be used to specify the end of a linear move sequence. This command tells the controller to decelerate to a stop following the last LI command. If an LE command is not given, an Abort AB1 must be used to abort the motion sequence.

It is the responsibility of the user to keep enough LI segments in the DMC-41x3 sequence buffer to ensure continuous motion. If the controller receives no additional LI segments and no LE command, the controller will stop motion instantly at the last vector. There will be no controlled deceleration. LM? or _LM returns the available spaces for LI segments that can be sent to the buffer. 511 returned means the buffer is empty and 511 LI segments can be sent. A zero means the buffer is full and no additional segments can be sent. As long as the buffer is not full, additional LI segments can be sent at PC bus speeds.

The instruction _CS returns the segment counter. As the segments are processed, _CS increases, starting at zero. This function allows the host computer to determine which segment is being processed.

Additional Commands

The commands VS n, VA n, and VD n are used to specify the vector speed, acceleration and deceleration. The DMC-41x3 computes the vector speed based on the axes specified in the LM mode. For example, LM XYZ designates linear interpolation for the X,Y and Z axes. The vector speed for this example would be computed using the equation:

$VS2=XS2+YS2+ZS2$, where XS, YS and ZS are the speed of the X,Y and Z axes.

The controller always uses the axis specifications from LM, not LI, to compute the speed.

IT is used to set the S-curve smoothing constant for coordinated moves. The command AV n is the 'After Vector' trippoint, which halts program execution until the vector distance of n has been reached.

An Example of Linear Interpolation Motion:

#LMOVE	label
DP 0,0	Define position of X and Y axes to be 0
LMXY	Define linear mode between X and Y axes.
LI 5000,0	Specify first linear segment
LI 0,5000	Specify second linear segment
LE	End linear segments
VS 4000	Specify vector speed
BGS	Begin motion sequence
AV 4000	Set trippoint to wait until vector distance of 4000 is reached
VS 1000	Change vector speed
AV 5000	Set trippoint to wait until vector distance of 5000 is reached
VS 4000	Change vector speed
EN	Program end

In this example, the XY system is required to perform a 90° turn. In order to slow the speed around the corner, we use the AV 4000 trippoint, which slows the speed to 1000 count/s. Once the motors reach the corner, the speed is increased back to 4000 counts/s.

Specifying Vector Speed for Each Segment

The instruction VS has an immediate effect and, therefore, must be given at the required time. In some applications, such as CNC, it is necessary to attach various speeds to different motion segments. This can be done by two functions: < n and > m

For example: LI x,y,z,w < n > m

The first command, < n, is equivalent to commanding VS_n at the start of the given segment and will cause an acceleration toward the new commanded speeds, subjects to the other constraints.

The second function, > m, requires the vector speed to reach the value m at the end of the segment. Note that the function > m may start the deceleration within the given segment or during previous segments, as needed to meet the final speed requirement, under the given values of VA and VD.

Note, however, that the controller works with one > m command at a time. As a consequence, one function may be masked by another. For example, if the function >100000 is followed by >5000, and the distance for deceleration is not sufficient, the second condition will not be met. The controller will attempt to lower the speed to 5000, but will reach that at a different point.

As an example, consider the following program.

#ALT	Label for alternative program
DP 0,0	Define Position of X and Y axis to be 0
LMXY	Define linear mode between X and Y axes.
LI 4000,0 <4000>1000	Specify first linear segment with a vector speed of 4000 and end speed 1000
LI 1000,1000<4000>1000	Specify second linear segment with a vector speed of 4000 and end speed 1000
LI 0,5000<4000>1000	Specify third linear segment with a vector speed of 4000 and end speed 1000
LE	End linear segments
BGS	Begin motion sequence
EN	Program end

Changing Feed Rate:

The command VR n allows the feed rate, VS, to be scaled between 0 and 10 with a resolution of .0001. This command takes effect immediately and causes VS to be scaled. VR also applies when the vector speed is specified with the '<' operator. This is a useful feature for feed rate override. VR does not ratio the accelerations. For example, VR .5 results in the specification VS 2000 to be divided in half.

Command Summary - Linear Interpolation

COMMAND	DESCRIPTION
LM XYZW	Specify axes for linear interpolation
LM ABCDEFGH	(same) controllers with 5 or more axes
LM?	Returns number of available spaces for linear segments in DMC-41x3 sequence buffer. Zero means buffer full. 511 means buffer empty.
LI x,y,z,w<n	Specify incremental distances relative to current position, and assign vector speed n.
LI a,b,c,d,e,f,g,h<n	
VS n	Specify vector speed
VA n	Specify vector acceleration
VD n	Specify vector deceleration
VR n	Specify the vector speed ratio
BGS	Begin Linear Sequence
CS	Clear sequence
LE	Linear End- Required at end of LI command sequence
LE?	Returns the length of the vector (resets after 2147483647)
AMS	Trippoint for After Sequence complete
AV n	Trippoint for After Relative Vector distance, n
IT	S curve smoothing constant for vector moves

Operand Summary - Linear Interpolation

OPERAND	DESCRIPTION
_AV	Return distance traveled
_CS	Segment counter - returns number of the segment in the sequence, starting at zero.
_LE	Returns length of vector (resets after 2147483647)
_LM	Returns number of available spaces for linear segments in DMC-41x3 sequence buffer. Zero means buffer full. 511 means buffer empty.
_VPm	Return the absolute coordinate of the last data point along the trajectory. (m=X,Y,Z or W or A,B,C,D,E,F,G or H)

To illustrate the ability to interrogate the motion status, consider the first motion segment of our example, #LMOVE, where the X axis moves toward the point X=5000. Suppose that when X=3000, the controller is interrogated using the command 'MG _AV'. The returned value will be 3000. The value of _CS, _VPX and _VPY will be zero.

Now suppose that the interrogation is repeated at the second segment when Y=2000. The value of _AV at this point is 7000, _CS equals 1, _VPX=5000 and _VPY=0.

Example - Linear Move

Make a coordinated linear move in the ZW plane. Move to coordinates 40000,30000 counts at a vector speed of 100000 counts/sec and vector acceleration of 1000000 counts/sec².

LM ZW	Specify axes for linear interpolation
LI , , 40000, 30000	Specify ZW distances
LE	Specify end move
VS 100000	Specify vector speed
VA 1000000	Specify vector acceleration
VD 1000000	Specify vector deceleration
BGS	Begin sequence

Note that the above program specifies the vector speed, VS, and not the actual axis speeds VZ and VW. The axis speeds are determined by the controller from:

$$VS = \sqrt{VZ^2 + VW^2}$$

The result is shown in Figure 6.6.




Figure 6.6: Linear Interpolation

Example - Multiple Moves

This example makes a coordinated linear move in the XY plane. The Arrays VX and VY are used to store 750 incremental distances which are filled by the program #LOAD.

#LOAD	Load Program
DM VX [750],VY [750]	Define Array
COUNT=0	Initialize Counter
N=0	Initialize position increment
#LOOP	LOOP
VX [COUNT]=N	Fill Array VX
VY [COUNT]=N	Fill Array VY
N=N+10	Increment position
COUNT=COUNT+1	Increment counter
JP #LOOP,COUNT<750	Loop if array not full
#A	Label
LM XY	Specify linear mode for XY
COUNT=0	Initialize array counter
#LOOP2;JP#LOOP2,_LM=0	If sequence buffer full, wait
JS#C,COUNT=500	Begin motion on 500 th segment
LI VX [COUNT],VY [COUNT]	Specify linear segment
COUNT=COUNT+1	Increment array counter
JP #LOOP2,COUNT<750	Repeat until array done
LE	End Linear Move
AMS	After Move sequence done
MG "DONE"	Send Message
EN	End program
#C;BGS;EN	Begin Motion Subroutine

Vector Mode: Linear and Circular Interpolation Motion

The DMC-41x3 allows a long 2-D path consisting of linear and arc segments to be prescribed. Motion along the path is continuous at the prescribed vector speed even at transitions between linear and circular segments. The

DMC-41x3 performs all the complex computations of linear and circular interpolation, freeing the host PC from this time intensive task.

The coordinated motion mode is similar to the linear interpolation mode. Any pair of two axes may be selected for coordinated motion consisting of linear and circular segments. In addition, a third axis can be controlled such that it remains tangent to the motion of the selected pair of axes. Note that only one pair of axes can be specified for coordinated motion at any given time.

The command VM m,n,p where 'm' and 'n' are the coordinated pair and p is the tangent axis (Note: the commas which separate m,n and p are not necessary). For example, VM XWZ selects the XW axes for coordinated motion and the Z-axis as the tangent.

Specifying the Coordinate Plane

The DMC-41x3 allows for 2 separate sets of coordinate axes for linear interpolation mode or vector mode. These two sets are identified by the letters S and T.

To specify vector commands the coordinate plane must first be identified. This is done by issuing the command CAS to identify the S plane or CAT to identify the T plane. All vector commands will be applied to the active coordinate system until changed with the CA command.

Specifying Vector Segments

The motion segments are described by two commands; VP for linear segments and CR for circular segments. Once a set of linear segments and/or circular segments have been specified, the sequence is ended with the command VE. This defines a sequence of commands for coordinated motion. Immediately prior to the execution of the first coordinated movement, the controller defines the current position to be zero for all movements in a sequence. Note: This 'local' definition of zero does not affect the absolute coordinate system or subsequent coordinated motion sequences.

The command, VP x,y specifies the coordinates of the end points of the vector movement with respect to the starting point. Non-sequential axis do not require comma delimitation. The command, CR r,q,d define a circular arc with a radius r, starting angle of q, and a traversed angle d. The notation for q is that zero corresponds to the positive horizontal direction, and for both q and d, the counter-clockwise (CCW) rotation is positive.

Up to 511 segments of CR or VP may be specified in a single sequence and must be ended with the command VE. The motion can be initiated with a Begin Sequence (BGS) command. Once motion starts, additional segments may be added.

The Clear Sequence (CS) command can be used to remove previous VP and CR commands which were stored in the buffer prior to the start of the motion. To stop the motion, use the instructions STS or AB1. ST stops motion at the specified deceleration. AB1 aborts the motion instantaneously.

The Vector End (VE) command must be used to specify the end of the coordinated motion. This command requires the controller to decelerate to a stop following the last motion requirement. If a VE command is not given, an Abort (AB1) must be used to abort the coordinated motion sequence.

It is the responsibility of the user to keep enough motion segments in the DMC-41x3 sequence buffer to ensure continuous motion. If the controller receives no additional motion segments and no VE command, the controller will stop motion instantly at the last vector. There will be no controlled deceleration. LM? or _LM returns the available spaces for motion segments that can be sent to the buffer. 511 returned means the buffer is empty and 511 segments can be sent. A zero means the buffer is full and no additional segments can be sent. As long as the buffer is not full, additional segments can be sent at PC bus speeds.

The operand _CS can be used to determine the value of the segment counter.

Additional commands

The commands VS n, VA n and VD n are used for specifying the vector speed, acceleration, and deceleration.

IT is the s curve smoothing constant used with coordinated motion.

Specifying Vector Speed for Each Segment:

The vector speed may be specified by the immediate command VS. It can also be attached to a motion segment with the instructions

VP x,y < n > m

CR r,θ,δ < n > m

The first command, < n, is equivalent to commanding VS n at the start of the given segment and will cause an acceleration toward the new commanded speeds, subjects to the other constraints.

The second function, > m, requires the vector speed to reach the value m at the end of the segment. Note that the function > m may start the deceleration within the given segment or during previous segments, as needed to meet the final speed requirement, under the given values of VA and VD.

Note, however, that the controller works with one > m command at a time. As a consequence, one function may be masked by another. For example, if the function >100000 is followed by >5000, and the distance for deceleration is not sufficient, the second condition will not be met. The controller will attempt to lower the speed to 5000, but will reach that at a different point.

Changing Feed Rate:

The command VR n allows the feed rate, VS, to be scaled between 0 and 10 with a resolution of .0001. This command takes effect immediately and causes VS scaled. VR also applies when the vector speed is specified with the '<' operator. This is a useful feature for feed rate override. VR does not ratio the accelerations. For example, VR 0.5 results in the specification VS 2000 to be divided by two.

Compensating for Differences in Encoder Resolution:

By default, the DMC-41x3 uses a scale factor of 1:1 for the encoder resolution when used in vector mode. If this is not the case, the command, ES can be used to scale the encoder counts. The ES command accepts two arguments which represent the number of counts for the two encoders used for vector motion. The smaller ratio of the two numbers will be multiplied by the higher resolution encoder. For more information, see ES command in the Command Reference.

Trippoints:

The AV n command is the After Vector trippoint, which waits for the vector relative distance of n to occur before executing the next command in a program.

Tangent Motion:

Several applications, such as cutting, require a third axis (i.e. a knife blade), to remain tangent to the coordinated motion path. To handle these applications, the DMC-41x3 allows one axis to be specified as the tangent axis. The VM command provides parameter specifications for describing the coordinated axes and the tangent axis.

VM m, n, p

m,n specifies coordinated axes p specifies tangent axis such as X,Y,Z,W p=N turns off tangent axis

Before the tangent mode can operate, it is necessary to assign an axis via the VM command and define its offset and scale factor via the TN m,n command. m defines the scale factor in counts/degree and n defines the tangent position that equals zero degrees in the coordinated motion plane. The operand _TN can be used to return the initial position of the tangent axis.

Example:

Assume an XY table with the Z-axis controlling a knife. The Z-axis has a 2000 quad counts/rev encoder and has been initialized after power-up to point the knife in the +Y direction. A 180° circular cut is desired, with a radius of 3000, center at the origin and a starting point at (3000,0). The motion is CCW, ending at (-3000,0). Note that the 0° position in the XY plane is in the +X direction. This corresponds to the position -500 in the Z-axis, and defines the offset. The motion has two parts. First, X,Y and Z are driven to the starting point, and later, the cut is performed. Assume that the knife is engaged with output bit 0.

#EXAMPLE	Example program
VM XYZ	XY coordinate with Z as tangent
TN 2000/360,-500	2000/360 counts/degree, position -500 is 0 degrees in XY plane
CR 3000,0,180	3000 count radius, start at 0 and go to 180 CCW
VE	End vector
CB0	Disengage knife
PA 3000,0,_TN	Move X and Y to starting position, move Z to initial tangent position
BG XYZ	Start the move to get into position
AM XYZ	When the move is complete
SB0	Engage knife
WT50	Wait 50 msec for the knife to engage
BGS	Do the circular cut
AMS	After the coordinated move is complete
CB0	Disengage knife
MG "ALL DONE"	
EN	End program

Command Summary - Coordinated Motion Sequence

COMMAND	DESCRIPTION
VM m,n	Specifies the axes for the planar motion where m and n represent the planar axes and p is the tangent axis.
VP m,n	Return coordinate of last point, where m=X,Y,Z or W.
CR r, θ , δ <n>m	Specifies arc segment where r is the radius, Θ is the starting angle and $\Delta\Theta$ is the travel angle. Positive direction is CCW.
VS s,t	Specify vector speed or feed rate of sequence.
VA s,t	Specify vector acceleration along the sequence.
VD s,t	Specify vector deceleration along the sequence.
VR s,t	Specify vector speed ratio
BGST	Begin motion sequence, S or T
CSST	Clear sequence, S or T
AV s,t	Trippoint for After Relative Vector distance.
AMST	Holds execution of next command until Motion Sequence is complete.
TN m,n	Tangent scale and offset.
ES m,n	Ellipse scale factor.
IT s,t	S curve smoothing constant for coordinated moves
LM?	Return number of available spaces for linear and circular segments in DMC-41x3 sequence buffer. Zero means buffer is full. 511 means buffer is empty.
CAS or CAT	Specifies which coordinate system is to be active (S or T)

Operand Summary - Coordinated Motion Sequence

OPERAND	DESCRIPTION
VPM	The absolute coordinate of the axes at the last intersection along the sequence.
AV	Distance traveled.
LM	Number of available spaces for linear and circular segments in DMC-41x3 sequence buffer. Zero means buffer is full. 511 means buffer is empty.
CS	Segment counter - Number of the segment in the sequence, starting at zero.
VE	Vector length of coordinated move sequence.

When AV is used as an operand, _AV returns the distance traveled along the sequence.

The operands _VPX and _VPY can be used to return the coordinates of the last point specified along the path.

Example:

Traverse the path shown in Figure 6.7. Feed rate is 20000 counts/sec. Plane of motion is XY

VM XY	Specify motion plane
VS 20000	Specify vector speed
VA 1000000	Specify vector acceleration
VD 1000000	Specify vector deceleration
VP -4000,0	Segment AB
CR 1500,270,-180	Segment BC
VP 0,3000	Segment CD
CR 1500,90,-180	Segment DA
VE	End of sequence
BGS	Begin Sequence

The resulting motion starts at the point A and moves toward points B, C, D, A. Suppose that we interrogate the controller when the motion is halfway between the points A and B.

The value of _AV is 2000

The value of _CS is 0

_VPX and _VPY contain the absolute coordinate of the point A

Suppose that the interrogation is repeated at a point, halfway between the points C and D.

The value of _AV is $4000+1500\pi+2000=10,712$

The value of _CS is 2

_VPX,_VPY contain the coordinates of the point C




Figure 6.7: The Required Path

Vector Mode - Mathematical Analysis

The terms of coordinated motion are best explained in terms of the vector motion. The vector velocity, V_s , which is also known as the feed rate, is the vector sum of the velocities along the X and Y axes, V_x and V_y .

$$V_s = \sqrt{V_x^2 + V_y^2}$$

The vector distance is the integral of V_s , or the total distance traveled along the path. To illustrate this further, suppose that a string was placed along the path in the X-Y plane. The length of that string represents the distance traveled by the vector motion.

The vector velocity is specified independently of the path to allow continuous motion. The path is specified as a collection of segments. For the purpose of specifying the path, define a special X-Y coordinate system whose origin is the starting point of the sequence. Each linear segment is specified by the X-Y coordinate of the final point expressed in units of resolution, and each circular arc is defined by the arc radius, the starting angle, and the angular width of the arc. The zero angle corresponds to the positive direction of the X-axis and the CCW direction

of rotation is positive. Angles are expressed in degrees, and the resolution is 1/256th of a degree. For example, the path shown in Figure 6.8 is specified by the instructions:

```
VP 0,10000
CR 10000, 180, -90
VP 20000, 20000
```




Figure 6.8: X-Y Motion Path

The first line describes the straight line vector segment between points A and B. The next segment is a circular arc, which starts at an angle of 180° and traverses -90°. Finally, the third line describes the linear segment between points C and D. Note that the total length of the motion consists of the segments:

A-B	Linear	10000 units
B-C	Circular	$\frac{R \Delta\theta 2\pi}{360} = 15708$
C-D	Linear	10000
Total		35708 counts

In general, the length of each linear segment is

$$L_k = \sqrt{X_k^2 + Y_k^2}$$

Where X_k and Y_k are the changes in X and Y positions along the linear segment. The length of the circular arc is

$$L_k = R_k |\Delta\Theta_k| 2\pi/360$$

The total travel distance is given by

$$D = \sum_{k=1}^n L_k$$

The velocity profile may be specified independently in terms of the vector velocity and acceleration.

For example, the velocity profile corresponding to the path of Figure 6.8 may be specified in terms of the vector speed and acceleration.

```
VS 100000
VA 2000000
```

The resulting vector velocity is shown in Figure 6.9.




Figure 6.9: Vector Velocity Profile

The acceleration time, T_a , is given by

$$T_a = \frac{VS}{VA} = \frac{100000}{2000000} = 0.05s$$

The slew time, T_s , is given by

$$T_s = \frac{D}{VS} - T_a = \frac{35708}{100000} - 0.05 = 0.307s$$

The total motion time, T_t , is given by:

$$T_t = \frac{D}{VS} + T_a = 0.407s$$

The velocities along the X and Y axes are such that the direction of motion follows the specified path, yet the vector velocity fits the vector speed and acceleration requirements.

For example, the velocities along the X and Y axes for the path shown in Figure 6.8 are given in Figure 6.10.

Figure 6.10 shows the vector velocity. It also indicates the position point along the path starting at A and ending at D. Between the points A and B, the motion is along the Y axis. Therefore,

$$V_y = V_s$$

and

$$V_x = 0$$

Between the points B and C, the velocities vary gradually and finally, between the points C and D, the motion is in the X direction.




Figure 6.10: Vector and Axes Velocities

Electronic Gearing

This mode allows up to 8 axes to be electronically geared to some master axes. The masters may rotate in both directions and the geared axes will follow at the specified gear ratio. The gear ratio may be different for each axis and changed during motion.

The command GA XYZW or GA ABCDEFGH specifies the master axes. GR x,y,z,w specifies the gear ratios for the slaves where the ratio may be a number between ± 127.9999 with a fractional resolution of .0001. There are two modes: standard gearing and gantry mode. The gantry mode (enabled with the command GM) allows the gearing to stay enabled even if a limit is hit or an ST command is issued. GR 0,0,0,0 turns off gearing in both modes.

The command GM x,y,z,w select the axes to be controlled under the gantry mode. The parameter 1 enables gantry mode, and 0 disables it.

GR causes the specified axes to be geared to the actual position of the master. The master axis is commanded with motion commands such as PR, PA or JG.

When the master axis is driven by the controller in the jog mode or an independent motion mode, it is possible to define the master as the command position of that axis, rather than the actual position. The designation of the commanded position master is by the letter, C. For example, GACX indicates that the gearing is the commanded position of X.

An alternative gearing method is to synchronize the slave motor to the commanded vector motion of several axes performed by GAS. For example, if the X and Y motor form a circular motion, the Z axis may move in proportion to the vector move. Similarly, if X,Y and Z perform a linear interpolation move, W can be geared to the vector move.

Electronic gearing allows the geared motor to perform a second independent or coordinated move in addition to the gearing. For example, when a geared motor follows a master at a ratio of 1:1, it may be advanced an additional distance with PR or JG commands or VP or LI coordinated commands.

Ramped Gearing

In some applications, especially when the master is traveling at high speeds, it is desirable to have the gear ratio ramp gradually to minimize large changes in velocity on the slave axis when the gearing is engaged. For example if the master axis is already traveling at 500,000 counts/sec and the slave will be geared at a ratio of 1:1 when the gearing is engaged, the slave will instantly develop following error, and command maximum current to the motor. This can be a large shock to the system. For many applications it is acceptable to slowly ramp the engagement of gearing over a greater time frame. Galil allows the user to specify an interval of the master axis over which the gearing will be engaged. For example, the same master X axis in this case travels at 500,000 counts/sec, and the gear ratio is 1:1, but the gearing is slowly engaged over 30,000 counts of the master axis, greatly diminishing the initial shock to the slave axis. Figure 6.11 below shows the velocity vs. time profile for instantaneous gearing. Figure 6.12 shows the velocity vs. time profile for the gradual gearing engagement.




Figure 6.11: Velocity counts/sec vs. Time (msec) Instantaneous Gearing Engagement




Figure 6.12: Velocity (counts/sec) vs. Time (msec) Ramped Gearing

The slave axis for each figure is shown on the bottom portion of the figure; the master axis is shown on the top portion. The shock to the slave axis will be significantly less in Figure 6.12 than in Figure 6.11. The ramped gearing does have one consequence. There isn't a true synchronization of the two axes, until the gearing ramp is complete. The slave will lag behind the true ratio during the ramp period. If exact position synchronization is required from the point gearing is initiated, then the position must be commanded in addition to the gearing. The controller keeps track of this position phase lag with the `_GP` operand. The following example will demonstrate how the command is used.

Example – Electronic Gearing Over a Specified Interval

Objective Run two geared motors at speeds of 1.132 and -.045 times the speed of an external master. Because the master is traveling at high speeds, it is desirable for the speeds to change slowly.

Solution: Use a DMC-4133 controller where the Z-axis is the master and X and Y are the geared axes. We will implement the gearing change over 6000 counts (3 revolutions) of the master axis.

MO Z	Turn Z off, for external master
GA Z, Z	Specify Z as the master axis for both X and Y.
GD 6000, 6000	Specify ramped gearing over 6000 counts of the master axis.
GR 1.132, -.045	Specify gear ratios

Question: What is the effect of the ramped gearing?

Answer: Below, in the example titled Electronic Gearing, gearing would take effect immediately. From the start of gearing if the master traveled 6000 counts, the slaves would travel 6792 counts and 270 counts.

Using the ramped gearing, the slave will engage gearing gradually. Since the gearing is engaged over the interval of 6000 counts of the master, the slave will only travel ~3396 counts and ~135 counts respectively. The difference between these two values is stored in the _GPn operand. If exact position synchronization is required, the IP command is used to adjust for the difference.

Command Summary - Electronic Gearing

COMMAND	DESCRIPTION
GA n	Specifies master axes for gearing where: n = X,Y,Z or W or A,B,C,D,E,F,G,H for main encoder as master n = CX,CY,CZ, CW or CA, CB,CC,CD,CE,CF,CG,CH for commanded position. n = DX,DY,DZ or DW or DA, DB, DC, DD, DE, DF,DG,DH for auxiliary encoders n = S or T for gearing to coordinated motion.
GD a,b,c,d,e,f,g,h	Sets the distance the master will travel for the gearing change to take full effect.
_GPn	This operand keeps track of the difference between the theoretical distance traveled if gearing changes took effect immediately, and the distance traveled since gearing changes take effect over a specified interval.
GR a,b,c,d,e,f,g,h	Sets gear ratio for slave axes. 0 disables electronic gearing for specified axis.
GM a,b,c,d,e,f,g,h	X = 1 sets gantry mode, 0 disables gantry mode
MR x,y,z,w	Trippoint for reverse motion past specified value. Only one field may be used.
MF x,y,z,w	Trippoint for forward motion past specified value. Only one field may be used.

Example - Simple Master Slave

Master axis moves 10000 counts at slow speed of 100000 counts/sec. Y is defined as the master. X,Z,W are geared to master at ratios of 5,-.5 and 10 respectively.

GA Y, , Y, Y	Specify master axes as Y
GR 5, , -.5, 10	Set gear ratios
PR , 10000	Specify Y position
SP , 100000	Specify Y speed
BGY	Begin motion

Example - Electronic Gearing

Objective: Run two geared motors at speeds of 1.132 and -0.045 times the speed of an external master. The master is driven at speeds between 0 and 1800 RPM (2000 counts/rev encoder).

Solution: Use a DMC-4133 controller, where the Z-axis is the master and X and Y are the geared axes.

MO Z	Turn Z off, for external master
GA Z, Z	Specify Z as the master axis for both X and Y.
GR 1.132, -.045	Specify gear ratios

Now suppose the gear ratio of the X-axis is to change on-the-fly to 2. This can be achieved by commanding:

GR 2	Specify gear ratio for X axis to be 2
------	---------------------------------------

Example - Gantry Mode

In applications where both the master and the follower are controlled by the DMC-41x3 controller, it may be desired to synchronize the follower with the commanded position of the master, rather than the actual position. This eliminates the coupling between the axes which may lead to oscillations.

For example, assume that a gantry is driven by two axes, X,Y, on both sides. This requires the gantry mode for strong coupling between the motors. The X-axis is the master and the Y-axis is the follower. To synchronize Y with the commanded position of X, use the instructions:

GA, CX	Specify the commanded position of X as master for Y.
GR, 1	Set gear ratio for Y as 1:1
GM, 1	Set gantry mode
PR 3000	Command X motion
BG X	Start motion on X axis

You may also perform profiled position corrections in the electronic gearing mode. Suppose, for example, that you need to advance the slave 10 counts. Simply command

IP ,10	Specify an incremental position movement of 10 on Y axis.
--------	---

Under these conditions, this IP command is equivalent to:

PR, 10	Specify position relative movement of 10 on Y axis
BGY	Begin motion on Y axis

Often the correction is quite large. Such requirements are common when synchronizing cutting knives or conveyor belts.

Example - Synchronize two conveyor belts with trapezoidal velocity correction

GA, X	Define X as the master axis for Y.
GR, 2	Set gear ratio 2:1 for Y
PR, 300	Specify correction distance
SP, 5000	Specify correction speed
AC, 100000	Specify correction acceleration
DC, 100000	Specify correction deceleration
BGY	Start correction

Electronic Cam

The electronic cam is a motion control mode which enables the periodic synchronization of several axes of motion. Up to 7 axes can be slaved to one master axis. The master axis encoder must be input through a main encoder port.

The electronic cam is a more general type of electronic gearing which allows a table-based relationship between the axes. It allows synchronizing all the controller axes. For example, the DMC-4183 controllers may have one master and up to seven slaves.

To illustrate the procedure of setting the cam mode, consider the cam relationship for the slave axis Y, when the master is X. Such a graphic relationship is shown in Figure 6.13.

Step 1. Selecting the master axis

The first step in the electronic cam mode is to select the master axis. This is done with the instruction

EAp where p = X,Y,Z,W,E,F,G,H

p is the selected master axis

For the given example, since the master is x, we specify EAX

Step 2. Specify the master cycle and the change in the slave axis (or axes).

In the electronic cam mode, the position of the master is always expressed modulo one cycle. In this example, the position of x is always expressed in the range between 0 and 6000. Similarly, the slave position is also redefined such that it starts at zero and ends at 1500. At the end of a cycle when the master is 6000 and the slave is 1500, the positions of both x and y are redefined as zero. To specify the master cycle and the slave cycle change, we use the instruction EM.

EM x,y,z,w

where x,y,z,w specify the cycle of the master and the total change of the slaves over one cycle.

The cycle of the master is limited to 8,388,607 whereas the slave change per cycle is limited to 2,147,483,647. If the change is a negative number, the absolute value is specified. For the given example, the cycle of the master is 6000 counts and the change in the slave is 1500. Therefore, we use the instruction:

```
EM 6000,1500
```

Step 3. Specify the master interval and starting point.

Next we need to construct the ECAM table. The table is specified at uniform intervals of master positions. Up to 256 intervals are allowed. The size of the master interval and the starting point are specified by the instruction:

```
EP m,n
```

where m is the interval width in counts, and n is the starting point.

For the given example, we can specify the table by specifying the position at the master points of 0, 2000, 4000 and 6000. We can specify that by

```
EP 2000,0
```

Step 4. Specify the slave positions.

Next, we specify the slave positions with the instruction

```
ET[n]=x,y,z,w
```

where n indicates the order of the point.

The value, n, starts at zero and may go up to 256. The parameters x,y,z,w indicate the corresponding slave position. For this example, the table may be specified by

```
ET[0]=,0  
ET[1]=,3000  
ET[2]=,2250  
ET[3]=,1500
```

This specifies the ECAM table.

Step 5. Enable the ECAM

To enable the ECAM mode, use the command

```
EB n
```

where n=1 enables ECAM mode and n=0 disables ECAM mode.

Step 6. Engage the slave motion

To engage the slave motion, use the instruction

```
EG x,y,z,w
```

where x,y,z,w are the master positions at which the corresponding slaves must be engaged.

If the value of any parameter is outside the range of one cycle, the cam engages immediately. When the cam is engaged, the slave position is redefined, modulo one cycle.

Step 7. Disengage the slave motion

To disengage the cam, use the command

```
EQ x,y,z,w
```

where x,y,z,w are the master positions at which the corresponding slave axes are disengaged.




Figure 6.13: Electronic Cam Example

This disengages the slave axis at a specified master position. If the parameter is outside the master cycle, the stopping is instantaneous.

To illustrate the complete process, consider the cam relationship described by the equation:

$$Y = 0.5 * X + 100 \sin (0.18 * X)$$

where X is the master, with a cycle of 2000 counts.

The cam table can be constructed manually, point by point, or automatically by a program. The following program includes the set-up.

The instruction EAX defines X as the master axis. The cycle of the master is

2000. Over that cycle, Y varies by 1000. This leads to the instruction EM 2000,1000.

Suppose we want to define a table with 100 segments. This implies increments of 20 counts each. If the master points are to start at zero, the required instruction is EP 20,0.

The following routine computes the table points. As the phase equals $0.18X$ and X varies in increments of 20, the phase varies by increments of 3.6° . The program then computes the values of Y according to the equation and assigns the values to the table with the instruction $ET[N] = Y$.

INSTRUCTION	INTERPRETATION
#SETUP	Label
EAX	Select X as master
EM 2000,1000	Cam cycles
EP 20,0	Master position increments
N = 0	Index
#LOOP	Loop to construct table from equation
P = N*3.6	Note $3.6 = 0.18 * 20$
S = @SIN [P]*100	Define sine position
Y = N*10+S	Define slave position
ET [N] =, Y	Define table
N = N+1	
JP #LOOP, N<=100	Repeat the process
EN	

Now suppose that the slave axis is engaged with a start signal, input 1, but that both the engagement and disengagement points must be done at the center of the cycle: $X = 1000$ and $Y = 500$. This implies that Y must be driven to that point to avoid a jump.

This is done with the program:

INSTRUCTION	INTERPRETATION
#RUN	Label
EB1	Enable cam
PA,500	starting position
SP,5000	Y speed
BGY	Move Y motor
AM	After Y moved
AI1	Wait for start signal
EG,1000	Engage slave
AI - 1	Wait for stop signal
EQ,1000	Disengage slave
EN	End

Command Summary - Electronic CAM

Command	Description
EA p	Specifies master axes for electronic cam where: p = X,Y,Z or W or A,B,C,D,E,F,G,H for main encoder as master or M or N a for virtual axis master
EB n	Enables the ECAM
EC n	ECAM counter - sets the index into the ECAM table
EG x, y, z, w	Engages ECAM
EM x, y, z, w	Specifies the change in position for each axis of the CAM cycle
EP m, n	Defines CAM table entry size and offset
EQ m, n	Disengages ECAM at specified position
ET [n]	Defines the ECAM table entries
EW	Widen Segment (see Application Note #2444)
EY	Set ECAM cycle count

Operand Summary - Electronic CAM

Command	Description
EB	Contains State of ECAM
EC	Contains current ECAM index
EGx	Contains ECAM status for each axis
EM	Contains size of cycle for each axis
EP	Contains value of the ECAM table interval
EQx	Contains ECAM status for each axis
EY	Set ECAM cycle count

Example - Electronic CAM

The following example illustrates a cam program with a master axis, Z, and two slaves, X and Y.

INSTRUCTION

```
#A; V1=0
PA 0,0;BGXY;AMXY
EA Z
EM 0,0,4000
EP400,0
ET[0]=0,0
ET[1]=0,0
ET[2]=120,60
ET[3]=240,120
ET[4]=360,180
ET[5]=360,180
ET[6]=360,180
ET[7]=240,120
ET[8]=120,60
ET[9]=0,0
ET[10]=0,0
EB 1
JGZ=4000
EG 0,0
BGZ
#LOOP; JP#LOOP, V1=0
EQ2000,2000
MF,, 2000
ST Z
EB 0
EN
```

INTERPRETATION

Label; Initialize variable
Go to position 0,0 on X and Y axes
Z axis as the Master for ECAM
Change for Z is 4000, zero for X, Y
ECAM interval is 400 counts with zero start
When master is at 0 position; 1st point.
2nd point in the ECAM table
3rd point in the ECAM table
4th point in the ECAM table
5th point in the ECAM table
6th point in the ECAM table
7th point in the ECAM table
8th point in the ECAM table
9th point in the ECAM table
10th point in the ECAM table
Starting point for next cycle
Enable ECAM mode
Set Z to jog at 4000
Engage both X and Y when Master = 0
Begin jog on Z axis
Loop until the variable is set
Disengage X and Y when Master = 2000
Wait until the Master goes to 2000
Stop the Z axis motion
Exit the ECAM mode
End of the program

The above example shows how the ECAM program is structured and how the commands can be given to the controller. Figure 6.14 shows the GDK scope capture of the ECAM profile. This shows how the motion will be seen during the ECAM cycles. The first trace is for the A axis, the second trace shows the cycle on the B axis and the third trace shows the cycle of the C axis.




Figure 6.14: ECAM cycle with Z axis as master

PVT Mode

The DMC-41x3 controller now supports a mode of motion referred to as “PVT.” This mode allows arbitrary motion profiles to be defined by position, velocity and time individually on all 8 axes. This motion is designed for systems where the load must traverse a series of coordinates with no discontinuities in velocity. By specifying the target position, velocity and time to achieve those parameters the user has control over the velocity profile. Taking advantage of the built in buffering the user can create virtually any profile including those with infinite path lengths.

Specifying PVT Segments

PVT segments must be entered one axis at a time using the PVn command. The PV command includes the target distance to be moved and target velocity to be obtained over the specified timeframe. Positions are entered as relative moves, similar to the standard PR command, in units of encoder counts and velocity is entered in counts/second. The controller will interpolate the motion profile between subsequent PV commands using a 3rd order polynomial equation. During a PV segment, jerk is held constant, and accelerations, velocities, and positions will be calculated every other sample.

Motion will not begin until a BT command is issued, much like the standard BG command. This means that the user can fill the PVT buffer for each axis prior to motion beginning. The BT command will ensure that all axes begin motion simultaneously. It is not required for the “t” value for each axis to be the same, however if they are then the axes will remain coordinated. Each axis has a 255 segment buffer. This buffer is a FIFO and the available space can be queried with the operand _PVn. As the buffer empties the user can add more PVT segments.

Exiting PVT Mode

To exit PVT mode the user must send the segment command PVn=0,0,0. This will exit the mode once the segment is reached in the buffer. To avoid an abrupt stop the user should slow the motion to a zero velocity prior to executing this command. The controller will instantly command a zero velocity once a PVn=0,0,0 is executed. In addition, a ST command will also exit PVT mode. Motion will come to a controlled stop using the DC value for deceleration. The same controlled stop will occur if a limit switch is activated in the direction of motion. As a result, the controller will be switched to a jog mode of motion.

Error Conditions and Stop Codes

If the buffer is allowed to empty while in PVT mode then the profiling will be aborted and the motor will come to a controlled stop on that axis with a deceleration specified by the DC command. Also, PVT mode will be exited and the stop code will be set to 32. During normal operation of PVT mode the stop code will be 30. If PVT mode is exited normally (PVn=0,0,0), then the stop code will be set to 31.

Additional PVT Information

It is the users’ responsibility to enter PVT data that the system’s mechanics and power system can respond to in a reasonable manner. Because this mode of motion is not constrained by the AC, DC or SP values, if a large velocity or position is entered with a short period to achieve it, the acceleration can be very high, beyond the capabilities of the system, resulting in excessive position error. The position and velocity at the end of the segment are guaranteed to be accurate but it is important to remember that the required path to obtain the position and velocity in the specified time may be different based on the PVT values. Mismatched values for PVT can result in different interpolated profiles than expected but the final velocity and position will be accurate.

The “t” value is entered in samples, which will depend on the TM setting. With the default TM of 1000, one sample is 976us. This means that a “t” value of 1024 will yield one second of motion. The velocity value, “v” will always be in units of counts per second, regardless of the TM setting.

Command Summary – PVT

COMMAND	DESCRIPTION
PVa = p, v, t	Specifies the segment of axis 'a' for a incremental PVT segment of 'p' counts, an end speed of 'v' counts/sec in a total time of 't' samples.
_PVa	Contains the number of PV segments available in the PV buffer for a specified axes.
BT	Begin PVT mode
_BTa	Contains the number PV segments that have executed

PVT Examples

Parabolic Velocity Profile

In this example we will assume that the user wants to start from zero velocity, accelerate to a maximum velocity of 1000 counts/second in 1 second and then back down to 0 counts/second within an additional second. The velocity profile would be described by the following equation and shown in Figure 6.15.

$$v(t) = -1000(t-1)^2 + 1000$$




Figure 6.15: Parabolic Velocity Profile

To accomplish this we need to calculate the desired velocities and change in positions. In this example we will assume a delta time of ¼ of a second, which is 256 samples (1024 samples = 1 second with the default TM of 1000).

Velocity(counts/second)	Position(counts)
$v(t) = -1000(t-1)^2 + 1000$	$p(t) = \int (-1000(t-1)^2 + 1000)dt$
$v(.25) = 437.5$	$p(0 \text{ to } .25) = 57$
$v(.5) = 750$	$p(.25 \text{ to } .5) = 151$
$v(.75) = 937.5$	$p(.5 \text{ to } .75) = 214$
$v(1) = 1000$	$p(.75 \text{ to } 1) = 245$
$v(1.25) = 937.5$	$p(1 \text{ to } 1.25) = 245$
$v(1.5) = 750$	$p(1.25 \text{ to } 1.5) = 214$
$v(1.75) = 437.5$	$p(1.5 \text{ to } 1.75) = 151$
$v(2) = 0$	$p(1.75 \text{ to } 2) = 57$

The DMC program is shown below and the results can be seen in Figure 6.16.

INSTRUCTION

```
#PVT
PVX = 57,437,256
PVX = 151,750,256
PVX = 214,937,256
PVX = 245,1000,256
PVX = 245,937,256
PVX = 214,750,256
PVX = 151,437,256
PVX = 57,0,256
PVX = 0,0,0
BTX
EN
```

INTERPRETATION

```
Label
Incremental move of 57 counts in 256 samples with a final velocity of 437 counts/sec
Incremental move of 151 counts in 256 samples with a final velocity of 750 counts/sec
Incremental move of 214 counts in 256 samples with a final velocity of 937 counts/sec
Incremental move of 245 counts in 256 samples with a final velocity of 1000 counts/sec
Incremental move of 245 counts in 256 samples with a final velocity of 937 counts/sec
Incremental move of 214 counts in 256 samples with a final velocity of 750 counts/sec
Incremental move of 151 counts in 256 samples with a final velocity of 437 counts/sec
Incremental move of 57 counts in 256 samples with a final velocity of 0 counts/sec
Termination of PVT buffer
Begin PVT
```




Figure 6.16: Actual Velocity and Position vs Time of Parabolic Velocity Profile

Multi-Axis Coordinated Move

Many applications require moving two or more axes in a coordinated move yet still require smooth motion at the same time. These applications are ideal candidates for PVT mode.

In this example we will have a 2 dimensional stage that needs to follow a specific profile. The application requires that the certain points be met however the path between points is not important. Smooth motion between points is critical.

X-axis	Y-axis
500	500
1500	5000
2500	4000
3300	4200
7300	3300

The resultant DMC program is shown below. The position points are dictated by the application requirements and the velocities and times were chosen to create smooth yet quick motion. For example, in the second segment the B axis is slowed to 0 at the end of the move in anticipation of reversing direction during the next segment.

INSTRUCTION

```
#PVT
PVA = 500,2000,500
```

INTERPRETATION

```
Label
1st point in Figure 6.21 - A axis
```

PVB = 500,5000,500	1 st point in Figure 6.21 - B axis
PVA = 1000,4000,1200	2 nd point in Figure 6.21 - A axis
PVB = 4500,0,1200	2 nd point in Figure 6.21 - B axis
PVA = 1000,4000,750	3 rd point in Figure 6.21 - A axis
PVB = -1000,1000,750	3 rd point in Figure 6.21 - B axis
BTAB	Begin PVT mode for A and B axes
PVA = 800,10000,250	4 th point in Figure 6.21 - A axis
PVB = 200,1000,250	4 th point in Figure 6.21 - B axis
PVA = 4000,0,1000	5 th point in Figure 6.21 - A axis
PVB = -900,0,1000	5 th point in Figure 6.21 - B axis
PVA = 0,0,0	Termination of PVT buffer for A axis
PVB = 0,0,0	Termination of PVT buffer for B axis
EN	

NOTE: The BT command is issued prior to filling the PVT buffers and additional PV commands are added during motion for demonstration purposes only. The BT command could have been issued at the end of all the PVT points in this example.

The resultant X vs. Y position graph is shown in Figure 6.17, with the specified PVT points enlarged.




Figure 6.17: X vs Y Commanded Positions for Multi-Axis Coordinated Move

Contour Mode

The DMC-41x3 also provides a contouring mode. This mode allows any arbitrary position curve to be prescribed for 1 to 8 axes. This is ideal for following computer generated paths such as parabolic, spherical or user-defined profiles. The path is not limited to straight line and arc segments and the path length may be infinite.

Specifying Contour Segments

The Contour Mode is specified with the command, CM. For example, CMXZ specifies contouring on the X and Z axes. Any axes that are not being used in the contouring mode may be operated in other modes.

A contour is described by position increments which are described with the command, CD x,y,z,w over a time interval, DT n. The parameter, n, specifies the time interval. The time interval is defined as 2ⁿ sample period (1 ms for TM1000), where n is a number between 1 and 8. The controller performs linear interpolation between the specified increments, where one point is generated for each sample. If the time interval changes for each segment, use CD x,y,z,w=n where n is the new DT value.

Consider, for example, the trajectory shown in Figure 6.18. The position X may be described by the points:

Point 1	X=0 at T=0ms
Point 2	X=48 at T=4ms

Point 3 X=288 at T=12ms
Point 4 X=336 at T=28ms

The same trajectory may be represented by the increments

Increment 1	DX=48	Time=4	DT=2
Increment 2	DX=240	Time=8	DT=3
Increment 3	DX=48	Time=16	DT=4

When the controller receives the command to generate a trajectory along these points, it interpolates linearly between the points. The resulting interpolated points include the position 12 at 1 msec, position 24 at 2 msec, etc.

The programmed commands to specify the above example are:

#A	
CMX	Specifies X axis for contour mode
CD 48=2	Specifies first position increment and time interval, 2 ² ms
CD 240=3	Specifies second position increment and time interval, 2 ³ ms
CD 48=4	Specifies the third position increment and time interval, 2 ⁴ ms
CD 0=0	End Contour buffer
#Wait;JP#Wait,_CM<>511	Wait until path is done
EN	




Figure 6.18: The Required Trajectory

Additional Commands

_CM gives the amount of space available in the contour buffer (511 maximum). Zero parameters for DT followed by zero parameters for CD will exit the contour mode.

If no new data record is found and the controller is still in the contour mode, the controller waits for new data. No new motion commands are generated while waiting. If bad data is received, the controller responds with a ?.

Specifying a -1 for the DT or as the time interval in the CD command will pause the contour buffer.

Issuing the CM command will clear the contour buffer.

Command Summary - Contour Mode

COMMAND	DESCRIPTION
CM XYZW	Specifies which axes for contouring mode. Any non-contouring axes may be operated in other modes.
CM ABCDEFGH	Contour axes for DMC-4183
CD x,y,z,w	Specifies position increment over time interval. Range is $\pm 32,000$. CD 0,0,0...=0 ends the contour buffer. This is much like the LE or VE commands.
CD a,b,c,d,e,f,g,h	Position increment data for DMC-4183
DT n	Specifies time interval 2 ⁿ sample periods (1 ms for TM1000) for position increment, where n is an integer between 1 and 8. Zero ends contour mode. If n does not change, it does not need to be specified with each CD.
_CM	Amount of space left in contour buffer (511 maximum)

General Velocity Profiles

The Contour Mode is ideal for generating any arbitrary velocity profiles. The velocity profile can be specified as a mathematical function or as a collection of points.

The design includes two parts: Generating an array with data points and running the program.

Generating an Array - An Example

Consider the velocity and position profiles shown in Figure 6.19. The objective is to rotate a motor a distance of 6000 counts in 120 ms. The velocity profile is sinusoidal to reduce the jerk and the system vibration. If we describe the position displacement in terms of A counts in B milliseconds, we can describe the motion in the following manner:

$$\omega = \frac{A}{B} (1 - \cos(2\pi/B))$$
$$X = \frac{AT}{B} - \frac{A}{2\pi} \sin(2\pi/B)$$

Note: ω is the angular velocity; X is the position; and T is the variable, time, in milliseconds.

In the given example, A=6000 and B=120, the position and velocity profiles are:

$$X = 50T - (6000/2\pi) \sin(2\pi T/120)$$

Note that the velocity, ω , in count/ms, is

$$\omega = 50 [1 - \cos 2\pi T/120]$$




Figure 6.19: Velocity Profile with Sinusoidal Acceleration

The DMC-41x3 can compute trigonometric functions. However, the argument must be expressed in degrees. Using our example, the equation for X is written as:

$$X = 50T - 955 \sin 3T$$

A complete program to generate the contour movement in this example is given below. To generate an array, we compute the position value at intervals of 8 ms. This is stored at the array POS. Then, the difference between the positions is computed and is stored in the array DIF. Finally the motors are run in the contour mode.

Contour Mode Example

INSTRUCTION	INTERPRETATION
#POINTS	Program defines X points
DM POS[16]	Allocate memory
DM DIF[15]	
C=0	Set initial conditions, C is index
T=0	T is time in ms
#A	
V1=50*T	
V2=3*T	Argument in degrees

V3=-955*@SIN[V2]+V1	Compute position
V4=@INT[V3]	Integer value of V3
POS[C]=V4	Store in array POS
T=T+8	
C=C+1	
JP #A,C<16	
#B	
C=0	Program to find position differences
#C	
D=C+1	
DIF[C]=POS[D]-POS[C]	Compute the difference and store
C=C+1	
JP #C,C<15	
#RUN	Program to run motor
CMX	Contour Mode
DT3	8 millisecond intervals
C=0	
#E	
CD DIF[C]	Contour Distance is in DIF
C=C+1	
JP #E,C<15	
CD 0=0	End contour buffer
#Wait;JP#Wait,_CM<>511	Wait until path is done
EN	End the program

Teach (Record and Play-Back)

Several applications require teaching the machine a motion trajectory. Teaching can be accomplished using the DMC-41x3 automatic array capture feature to capture position data. The captured data may then be played back in the contour mode. The following array commands are used:

DM C[n]	Dimension array
RA C[]	Specify array for automatic record (up to 4 for DMC-4143)
RD _TPX	Specify data for capturing (such as _TPX or _TPZ)
RC n,m	Specify capture time interval where n is 2 ⁿ sample periods (1 ms for TM1000), m is number of records to be captured
RC? or _RC	Returns a 1 if recording

Record and Playback Example:

#RECORD	Begin Program
DM XPOS[501]	Dimension array with 501 elements
RA XPOS[]	Specify automatic record
RD _TPX	Specify X position to be captured
MOX	Turn X motor off
RC2	Begin recording; 4 msec interval (at TM1000)
#A;JP#A,_RC=1	Continue until done recording
#COMPUTE	Compute DX
DM DX[500]	Dimension Array for DX
C=0	Initialize counter
#L	Label
D=C+1	
DELTA=XPOS[D]-XPOS[C]	Compute the difference
DX[C]=DELTA	Store difference in array
C=C+1	Increment index
JP #L,C<500	Repeat until done
#PLAYBCK	Begin Playback
CMX	Specify contour mode
DT2	Specify time increment
I=0	Initialize array counter
#B	Loop counter
CD DX[I]; I=I+1	Specify contour data I=I+1 Increment array counter
JP #B,I<500	Loop until done
CD 0=0	End countour buffer
#Wait;JP#Wait,_CM<>511	Wait until path is done
EN	End program

For additional information about automatic array capture, see Automatic Data Capture into Arrays in Chapter 7.

Virtual Axis

The DMC-41x3 controller has two additional virtual axes designated as the M and N axes. These axes have no encoder and no DAC. However, they can be commanded by the commands:

AC, DC, JG, SP, PR, PA, BG, IT, GA, VM, VP, CR, ST, DP, RP

The main use of the virtual axes is to serve as a virtual master in ECAM modes, and to perform an unnecessary part of a vector mode. These applications are illustrated by the following examples.

ECAM Master Example

Suppose that the motion of the XY axes is constrained along a path that can be described by an electronic cam table. Further assume that the ecam master is not an external encoder but has to be a controlled variable.

This can be achieved by defining the N axis as the master with the command EAN and setting the modulo of the master with a command such as EMN= 4000. Next, the table is constructed. To move the constrained axes, simply command the N axis in the jog mode or with the PR and PA commands.

For example,

PAN = 2000
BGN

will cause the XY axes to move to the corresponding points on the motion cycle.

Sinusoidal Motion Example

The x axis must perform a sinusoidal motion of 10 cycles with an amplitude of 1000 counts and a frequency of 20 Hz.

This can be performed by commanding the X and N axes to perform circular motion. Note that the value of VS must be

$$VS=2\pi * R * F$$

where R is the radius, or amplitude and F is the frequency in Hz.

Set VA and VD to maximum values for the fastest acceleration.

INSTRUCTION	INTERPRETATION
VMXN	Select Axes
VA 68000000	Maximum Acceleration
VD 68000000	Maximum Deceleration
VS 125664	VS for 20 Hz
CR 1000, -90, 3600	Ten Cycles
VE	
BGS	

Stepper Motor Operation

When configured for stepper motor operation, several commands are interpreted differently than from servo mode. The following describes operation with stepper motors.

Specifying Stepper Motor Operation

Stepper motor operation is specified by the command MT. The argument for MT is as follows:

- 2 specifies a stepper motor with active low step output pulses
- 2 specifies a stepper motor with active high step output pulses
- 2.5 specifies a stepper motor with active low step output pulses and reversed direction
- 2.5 specifies a stepper motor with active high step output pulse and reversed direction

Stepper Motor Smoothing

The command, KS, provides stepper motor smoothing. The effect of the smoothing can be thought of as a simple Resistor-Capacitor (single pole) filter. The filter occurs after the motion profiler and has the effect of smoothing out the spacing of pulses for a more smooth operation of the stepper motor. Use of KS is most applicable when operating in full step or half step operation. KS will cause the step pulses to be delayed in accordance with the time constant specified.

When operating with stepper motors, you will always have some amount of stepper motor smoothing, KS. Since this filtering effect occurs after the profiler, the profiler may be ready for additional moves before all of the step pulses have gone through the filter. It is important to consider this effect since steps may be lost if the controller is commanded to generate an additional move before the previous move has been completed. See the discussion below, Monitoring Generated Pulses vs. Commanded Pulses.

The general motion smoothing command, IT, can also be used. The purpose of the command, IT, is to smooth out the motion profile and decrease 'jerk' due to acceleration.

Monitoring Generated Pulses vs. Commanded Pulses

For proper controller operation, it is necessary to make sure that the controller has completed generating all step pulses before making additional moves. This is most particularly important if you are moving back and forth. For example, when operating with servo motors, the trippoint AM (After Motion) is used to determine when the motion profiler is complete and is prepared to execute a new motion command. However when operating in stepper mode, the controller may still be generating step pulses when the motion profiler is complete. This is


caused by the stepper motor smoothing filter, KS. To understand this, consider the steps the controller executes to generate step pulses:

First, the controller generates a motion profile in accordance with the motion commands.

Second, the profiler generates pulses as prescribed by the motion profile. The pulses that are generated by the motion profiler can be monitored by the command, RP (Reference Position). RP gives the absolute value of the position as determined by the motion profiler. The command, DP, can be used to set the value of the reference position. For example, DP 0, defines the reference position of the X axis to be zero.

Third, the output of the motion profiler is filtered by the stepper smoothing filter. This filter adds a delay in the output of the stepper motor pulses. The amount of delay depends on the parameter which is specified by the command, KS. As mentioned earlier, there will always be some amount of stepper motor smoothing.

Fourth, the output of the stepper smoothing filter is buffered and is available for input to the stepper motor driver. The pulses which are generated by the smoothing filter can be monitored by the command, TD (Tell Dual). TD gives the absolute value of the position as determined by actual output of the buffer. The command, DP sets the value of the step count register as well as the value of the reference position. For example, DP 0, defines the reference position of the X axis to be zero.



Motion Complete Trippoint

When used in stepper mode, the MC command will hold up execution of the proceeding commands until the controller has generated the same number of steps out of the step count register as specified in the commanded position. The MC trippoint (Motion Complete) is generally more useful than AM trippoint (After Motion) since the step pulses can be delayed from the commanded position due to stepper motor smoothing.

Using an Encoder with Stepper Motors

An encoder may be used on a stepper motor to check the actual motor position with the commanded position. If an encoder is used, it must be connected to the main encoder input. Note: The auxiliary encoder is not available while operating with stepper motors. The position of the encoder can be interrogated by using the command, TP. The position value can be defined by using the command, DE.

Note: Closed loop operation with a stepper motor is not possible.

Command Summary - Stepper Motor Operation

COMMAND	DESCRIPTION
DE	Define Encoder Position (When using an encoder)
DP	Define Reference Position and Step Count Register
IT	Motion Profile Smoothing - Independent Time Constant
KS	Stepper Motor Smoothing
MT	Motor Type (2,-2,2.5 or -2.5 for stepper motors)
RP	Report Commanded Position
TD	Report number of step pulses generated by controller
TP	Tell Position of Encoder

Operand Summary - Stepper Motor Operation

OPERAND	DESCRIPTION
DEx	Contains the value of the step count register for the 'x' axis
DPx	Contains the value of the main encoder for the 'x' axis
ITx	Contains the value of the Independent Time constant for the 'x' axis
KSx	Contains the value of the Stepper Motor Smoothing Constant for the 'x' axis
MTx	Contains the motor type value for the 'x' axis
RPx	Contains the commanded position generated by the profiler for the 'x' axis
TDx	Contains the value of the step count register for the 'x' axis
TPx	Contains the value of the main encoder for the 'x' axis

Stepper Position Maintenance Mode (SPM)

The Galil controller can be set into the Stepper Position Maintenance (SPM) mode to handle the event of stepper motor position error. The mode looks at position feedback from the main encoder and compares it to the commanded step pulses. The position information is used to determine if there is any significant difference between the commanded and the actual motor positions. If such error is detected, it is updated into a command value for operator use. In addition, the SPM mode can be used as a method to correct for friction at the end of a microstepping move. This capability provides closed-loop control at the application program level. SPM mode can be used with Galil and non-Galil step drives.

SPM mode is configured, executed, and managed with seven commands. This mode also utilizes the #POSERR automatic subroutine allowing for automatic user-defined handling of an error event.

Internal Controller Commands (user can query):

QS Error Magnitude (pulses)

User Configurable Commands (user can query & change):

OE Profiler Off-On Error
YA Step Drive Resolution (pulses / full motor step)
YB Step Motor Resolution (full motor steps / revolution)
YC Encoder Resolution (counts / revolution)
YR Error Correction (pulses)
YS Stepper Position Maintenance enable, status

A pulse is defined by the resolution of the step drive being used. Therefore, one pulse could be a full step, a half step or a microstep.

When a Galil controller is configured for step motor operation, the step pulse output by the controller is internally fed back to the auxiliary encoder register. For SPM the feedback encoder on the stepper will connect to the main encoder port. Enabling the SPM mode on a controller with YS=1 executes an internal monitoring of the auxiliary and main encoder registers for that axis or axes. Position error is then tracked in step pulses between these two registers (QS command).

$$QS = TD - \frac{TP \times YA \times YB}{YC}$$

Where TD is the auxiliary encoder register(step pulses) and TP is the main encoder register(feedback encoder). Additionally, YA defines the step drive resolution where YA = 1 for full stepping or YA = 2 for half stepping. The full range of YA is up to YA = 9999 for microstepping drives.

Error Limit

The value of QS is internally monitored to determine if it exceeds a preset limit of three full motor steps. Once the value of QS exceeds this limit, the controller then performs the following actions:

1. The motion is maintained or is stopped, depending on the setting of the OE command. If OE=0 the axis stays in motion, if OE=1 the axis is stopped.
2. YS is set to 2, which causes the automatic subroutine labeled #POSERR to be executed.

Correction

A correction move can be commanded by assigning the value of QS to the YR correction move command. The correction move is issued only after the axis has been stopped. After an error correction move has completed and QS is less than three full motor steps, the YS error status bit is automatically reset back to 1; indicating a cleared error.

Example: SPM Mode Setup

The following code demonstrates what is necessary to set up SPM mode for a full step drive, a half step drive, and a 1/64th microstepping drive for an axis with a 1.8° step motor and 4000 count/rev encoder. Note the necessary difference is with the YA command.

Full-Stepping Drive, X axis:

```
#SETUP
OE1;          Set the profiler to stop axis upon error
KS16;         Set step smoothing
MT-2;         Motor type set to stepper
YA1;          Step resolution of the full-step drive
YB200;        Motor resolution (full steps per revolution)
YC4000;       Encoder resolution (counts per revolution)
SHX;          Enable axis
WT50;         Allow slight settle time
YS1;          Enable SPM mode
```

Half-Stepping Drive, X axis:

```
#SETUP
OE1;          Set the profiler to stop axis upon error
KS16;         Set step smoothing
MT-2;         Motor type set to stepper
YA2;          Step resolution of the half-step drive
YB200;        Motor resolution (full steps per revolution)
YC4000;       Encoder resolution (counts per revolution)
SHX;          Enable axis
WT50;         Allow slight settle time
YS1;          Enable SPM mode
```

1/64th Step Microstepping Drive, X axis:

```
#SETUP
OE1;          Set the profiler to stop axis upon error
KS16;         Set step smoothing
MT-2;         Motor type set to stepper
YA64;         Step resolution of the microstepping drive
YB200;        Motor resolution (full steps per revolution)
YC4000;       Encoder resolution (counts per revolution)
SHX;          Enable axis
WT50;         Allow slight settle time
YS1;          Enable SPM mode
```

Example: Error Correction

The following code demonstrates what is necessary to set up SPM mode for the X axis, detect error, stop the motor, correct the error, and return to the main code. The drive is a full step drive, with a 1.8° step motor and 4000 count/rev encoder.

```
#setup
OE 1; '          Set the profiler to stop axis upon error
KS 16; '         Set step smoothing
MT -2,-2,-2,-2; ' Motor type set to stepper
YA 2; '          Step resolution of the drive
YB 200; '        Motor resolution (full steps per revolution)
YC 4000; '        Encoder resolution (counts per revolution)
SH A; '          Enable axis
WT 100; '         Allow slight settle time

#motion; '        Perform motion
SP 512; '         Set the speed
PR 1000; '        Prepare mode of motion
BG A; '          Begin motion
EN               End of program subroutine

REM When error occurs, the axis will stop due to OE1. In
REM #POSERR, query the status YS and the error QS, correct,
REM and return to the main code.

#POSERR; '        Automatic subroutine is called when _YS=2
WT 100; '         Wait helps user see the correction
spsave=_SPA; '    Save current speed setting
JP #return,_YSA<>2; ' Return to thread zero if invalid error
SP64; '           Set slow speed setting for correction
MG "ERROR= ",_QSA
YRA=_QSA; '       Else, error is valid, use QS for correction
MC A; '           Wait for motion to complete
MG "CORRECTED, ERROR NOW= ",_QSX
WT 100; '         Wait helps user see the correction

#return
SPA=spsave; '     Return the speed to previous setting
RE 0; '           Return from #POSERR
```

Example: Friction Correction

The following example illustrates how the SPM mode can be useful in correcting for X axis friction after each move when conducting a reciprocating motion. The drive is a 1/64th microstepping drive with a 1.8° step motor and 4000 count/rev encoder.

```
#SETUP;          Set the profiler to continue upon error
KS16;            Set step smoothing
MT-2,-2,-2,-2;  Motor type set to stepper
YA64;            Step resolution of the microstepping drive
YB200;           Motor resolution (full steps per revolution)
YC4000;          Encoder resolution (counts per revolution)
SHX;             Enable axis
WT50;            Allow slight settle time
YS1;             Enable SPM mode
```

#MOTION;	Perform motion
SP16384;	Set the speed
PR10000;	Prepare mode of motion
BGX;	Begin motion
MCX	
JS#CORRECT;	Move to correction
#MOTION2	
SP16384;	Set the speed
PR-10000;	Prepare mode of motion
BGX;	Begin motion
MCX	
JS#CORRECT;	Move to correction
JP#MOTION	
#CORRECT;	Correction code
SPX=_SPX	
#LOOP;	Save speed value
SP2048;	Set a new slow correction speed
WT100;	Stabilize
JP#END, @ABS[_Q SX]<10;	End correction if error is within defined tolerance
YRX=_Q SX;	Correction move
MCX	
WT100;	Stabilize
JP#LOOP;	Keep correcting until error is within tolerance
#END;	End #CORRECT subroutine, returning to code
SPX=SPX	
EN	

Dual Loop (Auxiliary Encoder)

The DMC-41x3 provides an interface for a second encoder for each axis except for axes configured for stepper motor operation and axis used in circular compare. When used, the second encoder is typically mounted on the motor or the load, but may be mounted in any position. The most common use for the second encoder is backlash compensation, described below.

The second encoder may be a standard quadrature type, or it may provide pulse and direction. The controller also offers the provision for inverting the direction of the encoder rotation. The main and the auxiliary encoders are configured with the CE command. The command form is CE x,y,z,w (or a,b,c,d,e,f,g,h for controllers with more than 4 axes) where the parameters x,y,z,w each equal the sum of two integers m and n. m configures the main encoder and n configures the auxiliary encoder.

Using the CE Command

m=	Main Encoder	n=	Second Encoder
0	Normal quadrature	0	Normal quadrature
1	Pulse & direction	4	Pulse & direction
2	Reverse quadrature	8	Reversed quadrature
3	Reverse pulse & direction	12	Reversed pulse & direction

For example, to configure the main encoder for reversed quadrature, m=2, and a second encoder of pulse and direction, n=4, the total is 6, and the command for the X axis is:

CE 6

Additional Commands for the Auxiliary Encoder

The command, DE x,y,z,w, can be used to define the position of the auxiliary encoders. For example,

DE 0,500,-30,300

sets their initial values. The positions of the auxiliary encoders may be interrogated with the command, DE?. For example:

DE ?,?,?

returns the value of the X and Z auxiliary encoders.

The auxiliary encoder position may be assigned to variables with the instructions

V1= _DEX

The command, TD XYZW, returns the current position of the auxiliary encoder.

The command, DV 1,1,1,1, configures the auxiliary encoder to be used for backlash compensation.

Backlash Compensation

There are two methods for backlash compensation using the auxiliary encoders:

1. Continuous dual loop
2. Sampled dual loop

To illustrate the problem, consider a situation in which the coupling between the motor and the load has a backlash. To compensate for the backlash, position encoders are mounted on both the motor and the load.

The continuous dual loop combines the two feedback signals to achieve stability. This method requires careful system tuning, and depends on the magnitude of the backlash. However, once successful, this method compensates for the backlash continuously.

The second method, the sampled dual loop, reads the load encoder only at the end point and performs a correction. This method is independent of the size of the backlash. However, it is effective only in point-to-point motion systems which require position accuracy only at the endpoint.

Continuous Dual Loop - Example

Connect the load encoder to the main encoder port and connect the motor encoder to the dual encoder port. The dual loop method splits the filter function between the two encoders. It applies the KP (proportional) and KI (integral) terms to the position error, based on the load encoder, and applies the KD (derivative) term to the motor encoder. This method results in a stable system.

The dual loop method is activated with the instruction DV (Dual Velocity), where

DV 1,1,1,1

activates the dual loop for the four axes and

DV 0,0,0,0

disables the dual loop.

NOTE: that the dual loop compensation depends on the backlash magnitude, and in extreme cases will not stabilize the loop. The proposed compensation procedure is to start with KP=0, KI=0 and to maximize the value of KD under the condition DV1. Once KD is found, increase KP gradually to a maximum value, and finally, increase KI, if necessary.

Sampled Dual Loop - Example

In this example, we consider a linear slide which is run by a rotary motor via a lead screw. Since the lead screw has a backlash, it is necessary to use a linear encoder to monitor the position of the slide. For stability reasons, it is best to use a rotary encoder on the motor.

Connect the rotary encoder to the X-axis and connect the linear encoder to the auxiliary encoder of X. Assume that the required motion distance is one inch, and that this corresponds to 40,000 counts of the rotary encoder and 10,000 counts of the linear encoder.

The design approach is to drive the motor a distance, which corresponds to 40,000 rotary counts. Once the motion is complete, the controller monitors the position of the linear encoder and performs position corrections.

This is done by the following program.

INSTRUCTION	INTERPRETATION
#DUALOOP	Label
CE 0	Configure encoder
DE0	Set initial value
PR 40000	Main move
BGX	Start motion
#correct	Correction loop
AMX	Wait for motion completion
V1=10000-_DEX	Find linear encoder error
V2=-_TEX/4+V1	Compensate for motor error
JP#END,@ABS[V2]<2	Exit if error is small
PR V2*4	Correction move
BGX	Start correction
JP#correct	Repeat
#END	
EN	

Motion Smoothing

The DMC-41x3 controller allows the smoothing of the velocity profile to reduce the mechanical vibration of the system.

Trapezoidal velocity profiles have acceleration rates which change abruptly from zero to maximum value. The discontinuous acceleration results in jerk which causes vibration. The smoothing of the acceleration profile leads to a continuous acceleration profile and reduces the mechanical shock and vibration.

Using the IT Command:



When operating with servo motors, motion smoothing can be accomplished with the IT command. This command filters the acceleration and deceleration functions to produce a smooth velocity profile. The resulting velocity profile, has continuous acceleration and results in reduced mechanical vibrations.

The smoothing function is specified by the following commands:

IT x,y,z,w Independent time constant

The command, IT, is used for smoothing independent moves of the type JG, PR, PA and to smooth vector moves of the type VM and LM.

The smoothing parameters, x,y,z,w and n are numbers between 0 and 1 and determine the degree of filtering. The maximum value of 1 implies no filtering, resulting in trapezoidal velocity profiles. Smaller values of the smoothing parameters imply heavier filtering and smoother moves.

The following example illustrates the effect of smoothing. Figure 6.20 shows the trapezoidal velocity profile and the modified acceleration and velocity.

Note that the smoothing process results in longer motion time.

Example - Smoothing

PR 20000	Position
AC 100000	Acceleration
DC 100000	Deceleration
SP 5000	Speed
IT .5	Filter for smoothing
BG X	Begin




Figure 6.20: Trapezoidal velocity and smooth velocity profiles

Using the KS Command (Step Motor Smoothing):



When operating with step motors, motion smoothing can be accomplished with the command, KS. The KS command smooths the frequency of step motor pulses. Similar to the command IT, this produces a smooth velocity profile.

The step motor smoothing is specified by the following command:

KS x, y, z, w where x,y,z,w is an integer from 0.5 to 128 and represents the amount of smoothing

The smoothing parameters, x,y,z,w and n are numbers between 0.5 and 128 and determine the degree of filtering. The minimum value of 0.5 implies the least filtering, resulting in trapezoidal velocity profiles. Larger values of the smoothing parameters imply heavier filtering and smoother moves.

Note that KS is valid only for step motors.

Homing

The Find Edge (FE) and Home (HM) instructions may be used to home the motor to a mechanical reference. This reference is connected to the Home input line. The HM command initializes the motor to the encoder index pulse in addition to the Home input. The configure command (CN) is used to define the polarity of the home input.




Figure 6.21: Required XY Points

The Find Edge (FE) instruction is useful for initializing the motor to a home switch. The home switch is connected to the Homing Input. When the Find Edge command and Begin is used, the motor will accelerate up to the slew speed and slew until a transition is detected on the Homing line. The motor will then decelerate to a stop. A high deceleration value must be input before the find edge command is issued for the motor to decelerate rapidly after sensing the home switch. The Home (HM) command can be used to position the motor on the index pulse after the home switch is detected. This allows for finer positioning on initialization. The HM command and BG command causes the following sequence of events to occur.

Stage 1:

Upon begin, the motor accelerates to the slew speed specified by the JG or SP commands. The direction of its motion is determined by the state of the homing input. If `_HMX` reads 1 initially, the motor will go in the reverse direction first (direction of decreasing encoder counts). If `_HMX` reads 0 initially, the motor will go in the forward direction first. CN is the command used to define the polarity of the home input. With CN,-1 (the default value) a normally open switch will make `_HMX` read 1 initially, and a normally closed switch will make `_HMX` read zero. Furthermore, with CN,1 a normally open switch will make `_HMX` read 0 initially, and a normally closed switch will make `_HMX` read 1. Therefore, the CN command will need to be configured properly to ensure the correct direction of motion in the home sequence.

Upon detecting the home switch changing state, the motor begins decelerating to a stop.

NOTE: The direction of motion for the FE command also follows these rules for the state of the home input.

Stage 2:

The motor then traverses at HV counts/sec in the opposite direction of Stage 1 until the home switch toggles again. If Stage 3 is in the opposite direction of Stage 2, the motor will stop immediately at this point and change direction. If Stage 2 is in the same direction as Stage 3, the motor will never stop, but will smoothly continue into Stage 3.

Stage 3:

The motor traverses forward at HV counts/sec until the encoder index pulse is detected. The motor then decelerates to a stop and goes back to the index.

The DMC-41x3 defines the home position as the position at which the index was detected and sets the encoder reading at this point to zero.

The 4 different motion possibilities for the home sequence are shown in the following table.

Switch Type	CN Setting	Initial <code>_HMX</code> state	Direction of Motion		
			Stage 1	Stage 2	Stage 3
Normally Open	CN,-1	1	Reverse	Forward	Forward
Normally Open	CN,1	0	Forward	Reverse	Forward
Normally Closed	CN,-1	0	Forward	Reverse	Forward
Normally Closed	CN,1	1	Reverse	Forward	Forward

Example: Homing

Instruction

#HOME

CN, -1

AC 1000000

Interpretation

Label

Configure the polarity of the home input

Acceleration Rate

DC 1000000	Deceleration Rate
SP 5000	Speed for Home Search
HM	Home
BG	Begin Motion
AM	After Complete
MG "AT HOME"	Send Message
EN	End

Figure 6.22 shows the velocity profile from the homing sequence of the example program above. For this profile, the switch is normally closed and CN,-1.




Figure 6.22: Homing Sequence for Normally Closed Switch and CN,-1

Example: Find Edge

#EDGE	Label
AC 2000000	Acceleration rate
DC 2000000	Deceleration rate
SP 8000	Speed
FE	Find edge command
BG	Begin motion
AM	After complete
MG "FOUND HOME"	Send message
DP 0	Define position as 0
EN	End

Command Summary - Homing Operation

COMMAND	DESCRIPTION
FE XYZW	Find Edge Routine. This routine monitors the Home Input
FI XYZW	Find Index Routine - This routine monitors the Index Input
HM XYZW	Home Routine - This routine combines FE and FI as Described Above
SC XYZW	Stop Code
TS XYZW	Tell Status of Switches and Inputs

Operand Summary - Homing Operation

Operand	Description
HMx	Contains the value of the state of the Home Input
SCx	Contains stop code
TSx	Contains status of switches and inputs

High Speed Position Capture (The Latch Function)

Often it is desirable to capture the position precisely for registration applications. Position capture can be programmed to latch on either a corresponding input (see Table 6.1) or on the index pulse for that axis. The position can be captured for either the main or auxiliary encoder within 25 microseconds of an high-to-low transition.

Input 1	A-axis latch	Input 9	E-axis latch
Input 2	B-axis latch	Input 10	F-axis latch
Input 3	C-axis latch	Input 11	G-axis latch
Input 4	D-axis latch	Input 12	H-axis latch

Table 6.1: Inputs and corresponding axis latch

NOTE	Latching is not valid with sampled feedback types such as: SSI, BiSS, and Analog
-------------	--

To insure a position capture within 25 microseconds, the input signal must be a transition from high to low. Low to high transitions may have greater delay.

The software commands, AL and RL, are used to arm the latch and report the latched position respectively. The latch must be re-armed after each latching event. See the Command Reference for more details on these commands.

Chapter 7 Application Programming

Overview

The DMC-41x3 provides a powerful programming language that allows users to customize the controller for their particular application. Programs can be downloaded into the DMC-41x3 memory freeing the host computer for other tasks. However, the host computer can send commands to the controller at any time, even while a program is being executed. Only ASCII commands can be used for application programming.

In addition to standard motion commands, the DMC-41x3 provides commands that allow the DMC-41x3 to make its own decisions. These commands include conditional jumps, event triggers and subroutines. For example, the command JP#LOOP, n<10 causes a jump to the label #LOOP if the variable n is less than 10.

For greater programming flexibility, the DMC-41x3 provides user-defined variables, arrays and arithmetic functions. For example, with a cut-to-length operation, the length can be specified as a variable in a program which the operator can change as necessary.

The following sections in this chapter discuss all aspects of creating applications programs. The program memory size is 80 characters x 4000 lines.

Program Format

A DMC-41x3 program consists of DMC instructions combined to solve a machine control application. Action instructions, such as starting and stopping motion, are combined with Program Flow instructions to form the complete program. Program Flow instructions evaluate real-time conditions, such as elapsed time or motion complete, and alter program flow accordingly.

Each DMC-41x3 instruction in a program must be separated by a delimiter. Valid delimiters are the semicolon (;) or carriage return. The semicolon is used to separate multiple instructions on a single program line where the maximum number of instructions on a line is limited by 80 characters. A carriage return enters the final command on a program line.

Using Labels in Programs

All DMC-41x3 programs must begin with a label and end with an End (EN) statement. Labels start with the pound (#) sign followed by a maximum of seven characters. The first character must be a letter; after that, numbers are permitted. Spaces are not permitted in a label.

The maximum number of labels which may be defined is 510.

Valid labels

```
#BEGIN  
#SQUARE
```

```
#X1
#BEGIN1
```

Invalid labels

```
#1Square
#123
```

A Simple Example Program:

#START	Beginning of the Program
PR 10000,20000	Specify relative distances on X and Y axes
BG XY	Begin Motion
AM	Wait for motion complete
WT 2000	Wait 2 sec
JP #START	Jump to label START
EN	End of Program

The above program moves X and Y 10000 and 20000 units. After the motion is complete, the motors rest for 2 seconds. The cycle repeats indefinitely until the stop command is issued.

Special Labels

The DMC-41x3 have some special labels, which are used to define input interrupt subroutines, limit switch subroutines, error handling subroutines, and command error subroutines. See section on _____

#AMPERR	Label for Amplifier error routine
#AUTO	Label that will automatically run upon the controller exiting a reset (power-on)
#AUTOERR	Label that will automatically run if there is an EEPROM error out of reset
#CMDERR	Label for incorrect command subroutine
#COMINT	Label for Communications Interrupt (See CC Command)
#ININT	Label for Input Interrupt subroutine (See II Command)
#LIMSWI	Label for Limit Switch subroutine
#MCTIME	Label for timeout on Motion Complete trippoint
#POSERR	Label for excess Position Error subroutine
#TCPERR	Label for errors over a TCP connection (error code 123)

Commenting Programs

Using the command, NO or Apostrophe (')

The DMC-41x3 provides a command, NO, for commenting programs or single apostrophe. This command allows the user to include up to 78 characters on a single line after the NO command and can be used to include comments from the programmer as in the following example:

```
#PATH
\ 2-D CIRCULAR PATH
VMXY
\ VECTOR MOTION ON X AND Y
VS 10000
\ VECTOR SPEED IS 10000
VP -4000,0
\ BOTTOM LINE
CR 1500,270,-180
\ HALF CIRCLE MOTION
VP 0,3000
\ TOP LINE
CR 1500,90,-180
\ HALF CIRCLE MOTION
VE
\ END VECTOR SEQUENCE
BGS
\ BEGIN SEQUENCE MOTION
EN
\ END OF PROGRAM
```

NOTE: The NO command is an actual controller command. Therefore, inclusion of the NO commands will require process time by the controller.

Difference between NO and ' using the GDK software

The GDK software will treat an apostrophe (') command different from an NO when the compression algorithm is activated upon a program download (line > 80 characters or program memory > 4000 lines). In this case the software will remove all (') comments as part of the compression and it will download all NO comments to the controller.

Executing Programs - Multitasking

The DMC-41x3 can run up to 8 independent programs simultaneously. These programs are called threads and are numbered 0 through 7, where 0 is the main thread. Multitasking is useful for executing independent operations such as PLC functions that occur independently of motion.

The main thread differs from the others in the following ways:

1. When input interrupts are implemented for limit switches, position errors or command errors, the subroutines are executed as thread 0.

To begin execution of the various programs, use the following instruction:

```
XQ #A, n
```

Where n indicates the thread number. To halt the execution of any thread, use the instruction

```
HX n
```

where n is the thread number.

Note that both the XQ and HX commands can be performed by an executing program.

The example below produces a waveform on Output 1 independent of a move.

#TASK1	Task1 label
AT0	Initialize reference time
CB1	Clear Output 1
#LOOP1	Loop1 label
AT 10	Wait 10 msec from reference time
SB1	Set Output 1
AT -40	Wait 40 msec from reference time, then initialize reference
CB1	Clear Output 1
JP #LOOP1	Repeat Loop1
#TASK2	Task2 label
XQ #TASK1, 1	Execute Task1
#LOOP2	Loop2 label
PR 1000	Define relative distance
BGX	Begin motion
AMX	After motion done
WT 10	Wait 10 msec
JP #LOOP2, @IN[2]=1	Repeat motion unless Input 2 is low
HX	Halt all tasks

The program above is executed with the instruction XQ #TASK2,0 which designates TASK2 as the main thread (i.e. Thread 0). #TASK1 is executed within TASK2.

Debugging Programs

The DMC-41x3 provides commands and operands which are useful in debugging application programs. These commands include interrogation commands to monitor program execution, determine the state of the controller and the contents of the controllers program, array, and variable space. Operands also contain important status information which can help to debug a program.

Trace Commands

The trace command causes the controller to send each line in a program to the host computer immediately prior to execution. Tracing is enabled with the command, TR1. TR0 turns the trace function off. Note: When the trace function is enabled, the line numbers as well as the command line will be displayed as each command line is executed.

NOTE: When the trace function is enabled, the line numbers as well as the command line will be displayed as each command line is executed.

Error Code Command

When there is a program error, the DMC-41x3 halts the program execution at the point where the error occurs. To display the last line number of program execution, issue the command, MG_ED.

The user can obtain information about the type of error condition that occurred by using the command, TC1. This command reports back a number and a text message which describes the error condition. The command, TC0 or TC, will return the error code without the text message. For more information about the command, TC, see the Command Reference.

Stop Code Command

The status of motion for each axis can be determined by using the stop code command, SC. This can be useful when motion on an axis has stopped unexpectedly. The command SC will return a number representing the motion status. See the command reference for further information.

RAM Memory Interrogation Commands

For debugging the status of the program memory, array memory, or variable memory, the DMC-41x3 has several useful commands. The command, DM ?, will return the number of array elements currently available. The command, DA ?, will return the number of arrays which can be currently defined. For example, a standard DMC-14113 will have a maximum of 24000 array elements in up to 30 arrays. If an array of 100 elements is defined, the command DM ? will return the value 15900 and the command DA ? will return 29.

To list the contents of the variable space, use the interrogation command LV (List Variables). To list the contents of array space, use the interrogation command, LA (List Arrays). To list the contents of the Program space, use the interrogation command, LS (List). To list the application program labels only, use the interrogation command, LL (List Labels).

Operands

In general, all operands provide information which may be useful in debugging an application program. Below is a list of operands which are particularly valuable for program debugging. To display the value of an operand, the message command may be used. For example, since the operand, _ED contains the last line of program execution, the command MG_ED will display this line number.

- _ED contains the last line of program execution. Useful to determine where program stopped.
- _DL contains the number of available labels.
- _UL contains the number of available variables.
- _DA contains the number of available arrays.
- _DM contains the number of available array elements.
- _AB contains the state of the Abort Input
- _LFx contains the state of the forward limit switch for the 'x' axis
- _LRx contains the state of the reverse limit switch for the 'x' axis

Debugging Example:

The following program has an error. It attempts to specify a relative movement while the X-axis is already in motion. When the program is executed, the controller stops at line 003. The user can then query the controller using the command, TC1. The controller responds with the corresponding explanation:

Download Code	
#A	Program Label
PR1000	Position Relative 1000
BGX	Begin
PR5000	Position Relative 5000
EN	End
From Terminal	
:XQ #A	Execute #A
?003 PR5000	Error on Line 3
:TC1	Tell Error Code
?7 Command not valid while running.	Command not valid while running
	Change the BGX line to BGX;AMX and re-download the program.
:XQ #A	Execute #A

Program Flow Commands

The DMC-41x3 provides instructions to control program flow. The controller program sequencer normally executes program instructions sequentially. The program flow can be altered with the use of event triggers, trippoints, and conditional jump statements.

Event Triggers & Trippoints

To function independently from the host computer, the DMC-41x3 can be programmed to make decisions based on the occurrence of an event. Such events include waiting for motion to be complete, waiting for a specified amount of time to elapse, or waiting for an input to change logic levels.

The DMC-41x3 provides several event triggers that cause the program sequencer to halt until the specified event occurs. Normally, a program is automatically executed sequentially one line at a time. When an event trigger instruction is decoded, however, the actual program sequence is halted. The program sequence does not continue until the event trigger is "tripped". For example, the motion complete trigger can be used to separate two move sequences in a program. The commands for the second move sequence will not be executed until the motion is complete on the first motion sequence. In this way, the controller can make decisions based on its own status or external events without intervention from a host computer.

DMC-41x3 Event Triggers

Command	Function
AM X Y Z W or S (A B C D E F G H)	Halts program execution until motion is complete on the specified axes or motion sequence(s). AM with no parameter tests for motion complete on all axes. This command is useful for separating motion sequences in a program.
AD X or Y or Z or W (A or B or C or D or E or F or G or H)	Halts program execution until position command has reached the specified relative distance from the start of the move. Only one axis may be specified at a time.
AR X or Y or Z or W (A or B or C or D or E or F or G or H)	Halts program execution until after specified distance from the last AR or AD command has elapsed. Only one axis may be specified at a time.
AP X or Y or Z or W (A or B or C or D or E or F or G or H)	Halts program execution until after absolute position occurs. Only one axis may be specified at a time.
MF X or Y or Z or W (A or B or C or D or E or F or G or H)	Halts program execution until after forward motion reached absolute position. Only one axis may be specified. If position is already past the point, then MF will trip immediately. Will function on geared axis or aux. inputs.
MR X or Y or Z or W (A or B or C or D or E or F or G or H)	Halts program execution until after reverse motion reached absolute position. Only one axis may be specified. If position is already past the point, then MR will trip immediately. Will function on geared axis or aux. inputs.
MC X or Y or Z or W (A or B or C or D or E or F or G or H)	Halts program execution until after the motion profile has been completed and the encoder has entered or passed the specified position. TW x,y,z,w sets timeout to declare an error if not in position. If timeout occurs, then the trippoint will clear and the stop code will be set to 99. An application program will jump to label #MCTIME.
AI ±n	Halts program execution until after specified input is at specified logic level. n specifies input line. Positive is high logic level, negative is low level. n=1 through 8 for DMC-4113, 4123, 4133, 4143. n=1 through 16 for DMC-4153, 4163, 4173, 4183. Also n= 17-48
AS X Y Z W S (A B C D E F G H)	Halts program execution until specified axis has reached its slew speed.
AT ±n,m	For m=omitted or 0, halts program execution until n msec from reference time. AT 0 sets reference. AT n waits n msec from reference. AT -n waits n msec from reference and sets new reference after elapsed time. For m=1. Same functionality except that n is number of samples rather than msec
AV n	Halts program execution until specified distance along a coordinated path has occurred.
WT n,m	For m=omitted or 0, halts program execution until specified time in msec has elapsed. For m=1. Same functionality except that n is number of samples rather than msec.

Event Trigger Examples:

Event Trigger - Multiple Move Sequence

The AM trippoint is used to separate the two PR moves. If AM is not used, the controller returns a ? for the second PR command because a new PR cannot be given until motion is complete.

#TWOMOVE; '	Label
PR 2000; '	Position Command
BGX; '	Begin Motion
AMX; '	Wait for Motion Complete
PR 4000; '	Next Position Move
BGX; '	Begin 2 nd move
EN; '	End program

Event Trigger - Set Output after Distance

Set output bit 1 after a distance of 1000 counts from the start of the move. The accuracy of the trippoint is the speed multiplied by the sample period.

#SETBIT; '	Label
SP 10000; '	Speed is 10000
PA 20000; '	Specify Absolute position
BGX; '	Begin motion
AD 1000; '	Wait until 1000 counts
SB1; '	Set output bit 1
EN; '	End program

Event Trigger - Repetitive Position Trigger

To set the output bit every 10000 counts during a move, the AR trippoint is used as shown in the next example.

#TRIP; '	Label
JG 50000; '	Specify Jog Speed
BGX;n=0; '	Begin Motion
#REPEAT; '	# Repeat Loop
AR 10000; '	Wait 10000 counts
TPX; '	Tell Position
SB1; '	Set output 1
WT50; '	Wait 50 msec
CB1; '	Clear output 1
n=n+1; '	Increment counter
JP #REPEAT,n<5; '	Repeat 5 times
STX; '	Stop
EN; '	End

Event Trigger - Start Motion on Input

This example waits for input 1 to go low and then starts motion. Note: The AI command actually halts execution of the program until the input occurs. If you do not want to halt the program sequences, you can use the Input Interrupt function (II) or use a conditional jump on an input, such as JP#GO,@IN[1] = 1.

#INPUT; '	Program Label
AI-1; '	Wait for input 1 low
PR 10000; '	Position command
BGX; '	Begin motion
EN; '	End program

Event Trigger - Set output when At speed

#ATSPEED; '	Program Label
JG 50000; '	Specify jog speed
AC 10000; '	Acceleration rate
BGX; '	Begin motion
ASX; '	Wait for at slew speed 50000
SB1; '	Set output 1
EN; '	End program

Event Trigger - Change Speed along Vector Path

The following program changes the feed rate or vector speed at the specified distance along the vector. The vector distance is measured from the start of the move or from the last AV command.

#VECTOR; '	Label
VMXY;VS 5000; '	Coordinated path
VP 10000,20000; '	Vector position
VP 20000,30000; '	Vector position
VE; '	End vector
BGS; '	Begin sequence
AV 5000; '	After vector distance
VS 1000; '	Reduce speed
EN; '	End

Event Trigger - Multiple Move with Wait

This example makes multiple relative distance moves by waiting for each to be complete before executing new moves.

#MOVES; '	Label
PR 12000; '	Distance
SP 20000; '	Speed
AC 100000; '	Acceleration
BGX; '	Start Motion
AD 10000; '	Wait a distance of 10,000 counts
SP 5000; '	New Speed
AMX; '	Wait until motion is completed
WT 200; '	Wait 200 ms
PR -10000; '	New Position
SP 30000; '	New Speed
AC 150000; '	New Acceleration
BGX; '	Start Motion
EN; '	End

Define Output Waveform Using AT

The following program causes Output 1 to be high for 10 msec and low for 40 msec. The cycle repeats every 50 msec.

#OUTPUT; '	Program label
AT0; '	Initialize time reference
SB1; '	Set Output 1
#LOOP; '	Loop
AT 10; '	After 10 msec from reference,
CB1; '	Clear Output 1
AT -40; '	Wait 40 msec from reference and reset reference
SB1; '	Set Output 1
JP #LOOP; '	Loop
EN; '	End Program

Using AT/WT with non-default TM rates

By default both WT and AT are defined to hold up program execution for 'n' number of milliseconds (WT n or AT n). The second field of both AT and WT can be used to have the program execution be held-up for 'n' number of samples rather than milliseconds. For example WT 400 or WT 400,0 will hold up program execution for 400 msec regardless of what is set for TM. By contrast WT 400,1 will hold up program execution for 400 samples. For the default TM of 1000 the servo update rate is 976us per sample, so the difference between WT n,0 and WT n,1 is minimal. The difference comes when the servo update rate is changed. With a low servo update rate, it is often useful to be able to time loops based upon samples rather than msec, and this is where the “unscaled” WT and AT are useful. For example:

#MAIN; '	Label
TM 250; '	250us update rate
#MOVE; '	Label
PRX=1000; '	Position Relative Move
BGX; '	Begin Motion
MCX; '	Wait for motion to complete
WT 2,1; '	Wait 2 samples (500us)
SB1; '	Set bit 1
EN; '	End Program

In the above example, without using an unscaled WT, the output would either need to be set directly after the motion was complete, or 2 ms after the motion was complete. By using WT n,1 and a lower TM, greater delay resolution was achieved.

Conditional Jumps

The DMC-41x3 provides Conditional Jump (JP) and Conditional Jump to Subroutine (JS) instructions for branching to a new program location based on a specified condition. The conditional jump determines if a condition is satisfied and then branches to a new location or subroutine. Unlike event triggers, the conditional jump instruction does not halt the program sequence. Conditional jumps are useful for testing events in real-time. They allow the controller to make decisions without a host computer. For example, the DMC-41x3 can decide between two motion profiles based on the state of an input line.

Command Format - JP and JS

FORMAT:	DESCRIPTION
JS destination, logical condition	Jump to subroutine if logical condition is satisfied
JP destination, logical condition	Jump to location if logical condition is satisfied

The destination is a program line number or label where the program sequencer will jump if the specified condition is satisfied. Note that the line number of the first line of program memory is 0. The comma designates "IF". The logical condition tests two operands with logical operators.

Logical operators:

OPERATOR	DESCRIPTION
<	less than
>	greater than
=	equal to
<=	less than or equal to
>=	greater than or equal to
<>	not equal

Conditional Statements

The conditional statement is satisfied if it evaluates to any value other than zero. The conditional statement can be any valid DMC-41x3 numeric operand, including variables, array elements, numeric values, functions, keywords, and arithmetic expressions. If no conditional statement is given, the jump will always occur.

Examples:

Number	v1=6
Numeric Expression	v1=v7*6 @ABS[v1]>10
Array Element	v1<count[2]
Variable	v1<v2
Internal Variable	_TPX=0 _TVX>500
I/O	v1>@AN[2] @IN[1]=0

Multiple Conditional Statements

The DMC-41x3 will accept multiple conditions in a single jump statement. The conditional statements are combined in pairs using the operands "&" and "|". The "&" operand between any two conditions, requires that both statements must be true for the combined statement to be true. The "|" operand between any two conditions, requires that only one statement be true for the combined statement to be true.

NOTE: Each condition must be placed in parentheses for proper evaluation by the controller. In addition, the DMC-41x3 executes operations from left to right. See Mathematical and Functional Expressions for more information.

For example, using variables named v1, v2, v3 and v4:

```
JP #TEST, ((v1<v2) & (v3<v4))
```

In this example, this statement will cause the program to jump to the label #TEST if v1 is less than v2 and v3 is less than v4. To illustrate this further, consider this same example with an additional condition:

```
JP #TEST, ((v1<v2) & (v3<v4)) | (v5<v6)
```

This statement will cause the program to jump to the label #TEST under two conditions; 1. If v1 is less than v2 and v3 is less than v4. OR 2. If v5 is less than v6.

Using the JP Command:

If the condition for the JP command is satisfied, the controller branches to the specified label or line number and continues executing commands from this point. If the condition is not satisfied, the controller continues to execute the next commands in sequence.

Conditional	Meaning
JP #Loop, count<10	Jump to #Loop if the variable, count, is less than 10
JS #MOVE2, @IN[1]=1	Jump to subroutine #MOVE2 if input 1 is logic level high. After the subroutine MOVE2 is executed, the program sequencer returns to the main program location where the subroutine was called.
JP #BLUE, @ABS[v2]>2	Jump to #BLUE if the absolute value of variable, v2, is greater than 2
JP #C, v1*v7<=v8*v2	Jump to #C if the value of v1 times v7 is less than or equal to the value of v8*v2
JP#A	Jump to #A

Example Using JP command:

Move the X motor to absolute position 1000 counts and back to zero ten times. Wait 100 msec between moves.

#BEGIN	Begin Program
count=10	Initialize loop counter
#LOOP	Begin loop
PA 1000	Position absolute 1000
BGX	Begin move
AMX	Wait for motion complete
WT 100	Wait 100 msec
PA 0	Position absolute 0
BGX	Begin move
AMX	Wait for motion complete
WT 100	Wait 100 msec
count=count-1	Decrement loop counter
JP #LOOP, count>0	Test for 10 times thru loop
EN	End Program

Using If, Else, and Endif Commands

The DMC-41x3 provides a structured approach to conditional statements using IF, ELSE and ENDIF commands.

Using the IF and ENDIF Commands

An IF conditional statement is formed by the combination of an IF and ENDIF command. The IF command has as it's arguments one or more conditional statements. If the conditional statement(s) evaluates true, the command interpreter will continue executing commands which follow the IF command. If the conditional statement evaluates false, the controller will ignore commands until the associated ENDIF command is executed OR an ELSE command occurs in the program (see discussion of ELSE command below).

NOTE: An ENDIF command must always be executed for every IF command that has been executed. It is recommended that the user not include jump commands inside IF conditional statements since this causes re-direction of command execution. In this case, the command interpreter may not execute an ENDIF command.

Using the ELSE Command

The ELSE command is an optional part of an IF conditional statement and allows for the execution of command only when the argument of the IF command evaluates False. The ELSE command must occur after an IF command

and has no arguments. If the argument of the IF command evaluates false, the controller will skip commands until the ELSE command. If the argument for the IF command evaluates true, the controller will execute the commands between the IF and ELSE command.

Nesting IF Conditional Statements

The DMC-41x3 allows for IF conditional statements to be included within other IF conditional statements. This technique is known as 'nesting' and the DMC-41x3 allows up to 255 IF conditional statements to be nested. This is a very powerful technique allowing the user to specify a variety of different cases for branching.

Command Format - IF, ELSE and ENDIF

Format:	Description
IF conditional statement(s)	Execute commands proceeding IF command (up to ELSE command) if conditional statement(s) is true, otherwise continue executing at ENDIF command or optional ELSE command.
ELSE	Optional command. Allows for commands to be executed when argument of IF command evaluates not true. Can only be used with IF command.
ENDIF	Command to end IF conditional statement. Program must have an ENDIF command for every IF command.

Example using IF, ELSE and ENDIF:

#TEST	Begin Main Program "TEST"
II,,3	Enable input interrupts on input 1 and input 2
MG "WAITING FOR INPUT 1, INPUT 2"	Output message
#LOOP	Label to be used for endless loop
JP #LOOP	Endless loop
EN	End of main program
#ININT	Input Interrupt Subroutine
IF (@IN[1]=0)	IF conditional statement based on input 1
IF (@IN[2]=0)	2 nd IF conditional statement executed if 1 st IF conditional true
MG "INPUT 1 AND INPUT 2 ARE ACTIVE"	Message to be executed if 2 nd IF conditional is true
ELSE	ELSE command for 2 nd IF conditional statement
MG "ONLY INPUT 1 IS ACTIVE"	Message to be executed if 2 nd IF conditional is false
ENDIF	End of 2 nd conditional statement
ELSE	ELSE command for 1 st IF conditional statement
MG "ONLY INPUT 2 IS ACTIVE"	Message to be executed if 1 st IF conditional statement is false
ENDIF	End of 1 st conditional statement
#WAIT	Label to be used for a loop
JP#WAIT, (@IN[1]=0) (@IN[2]=0)	Loop until both input 1 and input 2 are not active
RIO	End Input Interrupt Routine without restoring trippoints

Subroutines

A subroutine is a group of instructions beginning with a label and ending with an end command (EN). Subroutines are called from the main program with the jump subroutine instruction JS, followed by a label or line number, and conditional statement. Up to 16 subroutines can be nested. After the subroutine is executed, the program sequencer returns to the program location where the subroutine was called unless the subroutine stack is manipulated as described in the following section.

Example:

An example of a subroutine to draw a square 500 counts per side is given below. The square is drawn at vector position 1000,1000.

#M	Begin Main Program
CB1	Clear Output Bit 1 (pick up pen)
VP 1000,1000;LE;BGS	Define vector position; move pen
AMS	Wait for after motion trippoint
SBl	Set Output Bit 1 (put down pen)
JS #Square;CB1	Jump to square subroutine
EN	End Main Program
#Square	Square subroutine
v1=500;JS #L	Define length of side
v1=-v1;JS #L	Switch direction
EN	End subroutine
#L;PR v1,v1;BGX	Define X,Y; Begin X
AMX;BGY;AMY	After motion on X, Begin Y
EN	End subroutine

Stack Manipulation

It is possible to manipulate the subroutine stack by using the ZS command. Every time a JS instruction, interrupt or automatic routine (such as #POSERR or #LIMSWI) is executed, the subroutine stack is incremented by 1. Normally the stack is restored with an EN instruction. Occasionally it is desirable not to return back to the program line where the subroutine or interrupt was called. The ZS1 command clears 1 level of the stack. This allows the program sequencer to continue to the next line. The ZS0 command resets the stack to its initial value. For example, if a limit occurs and the #LIMSWI routine is executed, it is often desirable to restart the program sequence instead of returning to the location where the limit occurred. To do this, give a ZS command at the end of the #LIMSWI routine.

Auto-Start Routine

The DMC-41x3 has a special label for automatic program execution. A program which has been saved into the controller's non-volatile memory can be automatically executed upon power up or reset by beginning the program with the label #AUTO. The program must be saved into non-volatile memory using the command, BP.

Automatic Subroutines for Monitoring Conditions

Often it is desirable to monitor certain conditions continuously without tying up the host or DMC-41x3 program sequences. The controller can monitor several important conditions in the background. These conditions include checking for the occurrence of a limit switch, a defined input, position error, or a command error. Automatic monitoring is enabled by inserting a special, predefined label in the applications program. The pre-defined labels are:

SUBROUTINE	DESCRIPTION
#LIMSWI	Limit switch on any axis goes low
#ININT	Input specified by II goes low
#POSERR	Position error exceeds limit specified by ER
#MCTIME	Motion Complete timeout occurred. Timeout period set by TW command
#CMDERR	Bad command given
#AUTO	Automatically executes on power up
#AUTOERR	Automatically executes when a checksum is encountered during #AUTO start-up. Check error condition with _RS. bit 0 for variable checksum error bit 1 for parameter checksum error bit 2 for program checksum error bit 3 for master reset error (there should be no program)
#AMPERR	Error from internal Galil amplifier

For example, the #POSERR subroutine will automatically be executed when any axis exceeds its position error limit. The commands in the #POSERR subroutine could decode which axis is in error and take the appropriate action. In another example, the #ININT label could be used to designate an input interrupt subroutine. When the specified input occurs, the program will be executed automatically.

NOTE: An application program must be running for #CMDERR to function.

Example - Limit Switch:

This program prints a message upon the occurrence of a limit switch. Note, for the #LIMSWI routine to function, the DMC-41x3 must be executing an applications program from memory. This can be a very simple program that does nothing but loop on a statement, such as #LOOP;JP #LOOP;EN. Motion commands, such as JG 5000 can still be sent from the PC even while the “dummy” applications program is being executed.

#LOOP	Dummy Program
JP #LOOP;EN	Jump to Loop
#LIMSWI	Limit Switch Label
MG "LIMIT OCCURRED"	Print Message
RE	Return to main program
	Download Program
:XQ #LOOP	Execute Dummy Program
:JG 5000	Jog
:BGX	Begin Motion

Now, when a forward limit switch occurs on the X axis, the #LIMSWI subroutine will be executed.

Notes regarding the #LIMSWI Routine:

- 1) The RE command is used to return from the #LIMSWI subroutine.
- 2) The #LIMSWI subroutine will be re-executed if the limit switch remains active.

The #LIMSWI routine is only executed when the motor is being commanded to move.

Example - Position Error

#LOOP	Dummy Program
JP #LOOP;EN	Loop
#POSERR	Position Error Routine
V1= TEX	Read Position Error
MG "EXCESS POSITION ERROR"	Print Message
MG "ERROR=",V1=	Print Error
RE	Return from Error
	Download program
:XQ #LOOP	Execute Dummy Program
:JG 100000	Jog at High Speed
:BGX	Begin Motion

Example - Input Interrupt

#A	Label
II1	Input Interrupt on 1
JG 30000,,,60000	Jog
BGXW	Begin Motion
#LOOP;JP#LOOP;EN	Loop
#ININT	Input Interrupt
STXW;AM	Stop Motion
#TEST;JP #TEST, @IN[1]=0	Test for Input 1 still low
JG 30000,,,60000	Restore Velocities
BGXW	Begin motion
RI0	Return from interrupt routine to Main Program and do not re-enable trippoints

Example - Motion Complete Timeout

#BEGIN	Begin main program
TW 1000	Set the time out to 1000 ms
PA 10000	Position Absolute command
BGX	Begin motion
MCX	Motion Complete trippoint
EN	End main program
#MCTIME	Motion Complete Subroutine
MG "X fell short"	Send out a message
EN	End subroutine

This simple program will issue the message "X fell short" if the X axis does not reach the commanded position within 1 second of the end of the profiled move.

Example - Command Error

#BEGIN	Begin main program
speed = 2000	Set variable for speed
JG speed;BGX;	Begin motion
#LOOP	
JG speed;WT100	Update Jog speed based upon speed variable
JP #LOOP	
EN	End main program
#CMDERR	Command error utility
JP#DONE, _ED<>2	Check if error on line 2
JP#DONE, _TC<>6	Check if out of range
MG "SPEED TOO HIGH"	Send message
MG "TRY AGAIN"	Send message
ZS1	Adjust stack
JP #BEGIN	Return to main program
#DONE	End program if other error
ZS0	Zero stack
EN	End program

The above program prompts the operator to enter a jog speed. If the operator enters a number out of range (greater than 8 million), the #CMDERR routine will be executed prompting the operator to enter a new number.

In multitasking applications, there is an alternate method for handling command errors from different threads. Using the XQ command along with the special operands described below allows the controller to either skip or retry invalid commands.

OPERAND	FUNCTION
_ED1	Returns the number of the thread that generated an error
_ED2	Retry failed command (operand contains the location of the failed command)
_ED3	Skip failed command (operand contains the location of the command after the failed command)

The operands are used with the XQ command in the following format:

XQ _ED2 (or _ED3),_ED1,1

Where the ",1" at the end of the command line indicates a restart; therefore, the existing program stack will not be removed when the above format executes.

The following example shows an error correction routine which uses the operands.

Example - Command Error w/Multitasking

#A	Begin thread 0 (continuous loop)
JP #A	
EN	End of thread 0
#B	Begin thread 1
N=-1	Create new variable
KP N	Set KP to value of N, an invalid value
TY	Issue invalid command
EN	End of thread 1
#CMDERR	Begin command error subroutine
IF _TC=6	If error is out of range (KP -1)
N=1	Set N to a valid number
XQ _ED2,_ED1,1	Retry KP N command
ENDIF	
IF _TC=1	If error is invalid command (TY)
XQ _ED3,_ED1,1	Skip invalid command
ENDIF	
EN	End of command error routine

Example - Communication Interrupt

A DMC-4113 is used to move the A axis back and forth from 0 to 10000. This motion can be paused, resumed and stopped via input from an auxiliary port terminal.

#BEGIN	Label for beginning of program
CC 9600,0,1,0	Setup communication configuration for auxiliary serial port
CI 2	Setup communication interrupt for auxiliary serial port
MG {P2}"Type 0 to stop motion"	Message out of auxiliary port
MG {P2}"Type 1 to pause motion"	Message out of auxiliary port
MG {P2}"Type 2 to resume motion"	Message out of auxiliary port
rate=2000	Variable to remember speed
SPA=rate	Set speed of A axis motion
#LOOP	Label for Loop
PAA=10000	Move to absolute position 10000
BGA	Begin Motion on A axis
AMA	Wait for motion to be complete
PAA=0	Move to absolute position 0
BGA	Begin Motion on A axis
AMA	Wait for motion to be complete
JP #LOOP	Continually loop to make back and forth motion
EN	End main program
#COMINT	Interrupt Routine
JP #STOP,P2CH="0"	Check for S (stop motion)
JP #PAUSE,P2CH="1"	Check for P (pause motion)
JP #RESUME,P2CH="2"	Check for R (resume motion)
EN1,1	Do nothing
#STOP	Routine for stopping motion
STA;ZS;EN	Stop motion on A axis; Zero program stack; End Program
#PAUSE	Routine for pausing motion
rate=_SPA	Save current speed setting of A axis motion
SPA=0	Set speed of A axis to zero (allows for pause)
EN1,1	Re-enable trippoint and communication interrupt
#RESUME	Routine for resuming motion
SPA=rate	Set speed on A axis to original speed
EN1,1	Re-enable trippoint and communication interrupt

For additional information, see section on Using Communication Interrupt.

Example – Ethernet Communication Error

This simple program executes in the DMC-41x3 and indicates (via the serial port) when a communication handle fails. By monitoring the serial port, the user can re-establish communication if needed.

```
#LOOP
JP#LOOP
EN
#TCPERR
MG {P1}_IA4

RE
```

Simple program loop

Ethernet communication error auto routine
Send message to serial port indicating which handle did not receive proper acknowledgment.

Example – Amplifier Error

The program below will execute upon the detection of an error from an internal Galil Amplifier. The bits in TA1 will be set for all axes that have an invalid hall state even if BR1 is set for those axes, this is handled with the mask variable shown in the code below.

```
#AMPERR
REM mask out axes that are in brushed mode for _TA1
mask=(_BRH*128)+(_BRG*64)+(_BRF*32)+(_BRE*16)+(_BRD*8)+(_BRC*4)+(_BRB*2)+_BRA
mask=@COM[mask]
mask=(_TA1&mask)&$0000FFFF)
REM amplifier error status
MG"A-ER TA0",_TA0
MG"A-ER TA1",mask
MG"A-ER TA2",_TA2
MG"A-ER TA3",_TA3
WT5000
REM the sum of the amperr bits should be 0 with no amplifier error
er=_TA0+mask+_TA2+_TA3
JP#AMPERR,er0
REM Notify user amperr has cleared
MG"AMPERR RESOLVED"
WT3000
RE
```

JS Subroutine Stack Variables (^a, ^b, ^c, ^d, ^e, ^f, ^g, ^h)

There are 8 variables that may be passed on the subroutine stack when using the JS command. Passing values on the stack is advanced DMC programming, and is recommended for experienced DMC programmers familiar with the concept of passing arguments by value and by reference.

Notes:

1. Passing parameters has no type checking, so it is important to exercise good programming style when passing parameters. See examples below for recommended syntax.
2. Do not use spaces in expressions containing ^.
3. Global variables MUST be assigned prior to any use in subroutines where variables are passed by reference.
4. Please refer to the JS command in the controller's command reference for further important information.

Example: A Simple Adding Function

```
#Add
JS#SUM(1,2,3,4,5,6,7,8)          ;' call subroutine, pass values
MG_JS                            ;' print return value
EN
'

#SUM                              ;NO(^a,^b,^c,^d,^e,^f,^g,^h) syntax note for use
EN,,(^a+^b+^c+^d+^e+^f+^g+^h)    ;' return sum

:Executed program from program1.dmc
36.0000
```

Example: Variable, and an Important Note about Creating Global Variables

```
#Var
value=5                                ;'a value to be passed by reference
global=8                              ;'a global variable
JS#SUM(&value,1,2,3,4,5,6,7)           ;'note first arg passed by reference
MG value                             ;'message out value after subroutine.
MG _JS                               ;'message out returned value
EN
'

#SUM                                  ;NO(* ^a,^b,^c,^d,^e,^f,^g)
^a=^b+^c+^d+^e+^f+^g+^h+global
EN,,^a
'notes:
'do not use spaces when working with ^
'If using global variables, they MUST be created before the subroutine is run
```

Executed program from program2.dmc

```
36.0000
36.0000
```

Example: Working with Arrays

```
#Array
DM speeds[8]
DM other[256]
JS#zeroAry("speeds",0)                ;'zero out all buckets in speeds[]
JS#zeroAry("other",0)                ;'zero out all buckers in other[]
EN
'

#zeroAry                             ;NO(array ^a, ^b) zeros array starting at index ^b
^a[^b]=0
^b=^b+1
JP#zeroAry, (^b<^a[-1])              ;'[-1] returns the length of an array
EN
```

Example: Abstracting Axes

```
#Axes
JS#runMove(0,10000,1000,100000,100000)
MG "Position:",_JS
EN
'

#runMove                             ;NO(axis ^a, PR ^b, SP ^c, AC ^d, DC ^e) Profile movement for axis
~a=^a                                ;'~a is global, so use carefully in subroutines
                                     ;'try one variable axis a-h for each thread A-H

PR~a=^b
SP~a=^c
AC~a=^d
DC~a=^e
BG~a
MC~a
EN,,_TP~a
```

Example: Local Scope

```
#Local
JS#POWER(2,2)
MG_JS
JS#POWER(2,16)
MG_JS
JS#POWER(2,-8)
MG_JS
,

#POWER          ;NO(base ^a,exponent^b) Returns base^exponent power. ± integer only
^c=1            ;'unpassed variable space (^c-^h) can be used as local scope variables
IF ^b=0         ;'special case, exponent = 0
  EN,,1
ENDIF
IF ^b<0         ;'special case, exponent < 0, invert result
  ^d=1
  ^b=@ABS[^b]
ELSE
  ^d=0
ENDIF
#PWRHLPR
^c=^c*^a
^b=^b-1
JP#PWRHLPR,^b>0
IF ^d=1         ;'if inversion required
  ^c=(1/^c)
ENDIF
EN,,^c

Executed program from program1.dmc
4.0000
65536.0000
0.0039
```

Example: Recursion

```
'although the stack depth is only 16, Galil DMC code does support recursion
JS#AxsInfo(0)
MG{Z2.0}"Recursed through ",_JS," stacks"
EN
,

#AxsInfo          ;NO(axis ^a) List info for axes
~h=^a
^b=(^a+$41)*$1000000 ;'convert to Galil String
MG^b{S1}, " Axis: "{N}
MG{F8.0}"Position: ",_TP~h," Error:",_TE~h," Torque:",_TT~h{F1.4}
IF ^a=7           ;'recursion exit condition
  EN,,1
ENDIF
JS#AxsInfo(^a + 1) ;'stack up recursion
EN,,_JS+1         ;' as recursion closes, add up stack depths

Executed program from program1.dmc
A Axis: Position: 00029319 Error: 00001312 Torque: 9.9982
B Axis: Position: -00001612 Error: 00000936 Torque: 1.7253
C Axis: Position: 00001696 Error:-00001076 Torque:-1.9834
D Axis: Position: -00002020 Error: 00001156 Torque: 2.1309
E Axis: Position: 00000700 Error:-00001300 Torque:-2.3963
F Axis: Position: 00000156 Error:-00000792 Torque:-1.4599
G Axis: Position: -00002212 Error: 00001732 Torque: 3.1926
H Axis: Position: 00002665 Error:-00001721 Torque:-3.1723
Recursed through 8 stacks
```

General Program Flow and Timing information

This section will discuss general programming flow and timing information for Galil programming.

REM vs. NO or ' comments

There are 2 ways to add comments to a .dmc program. REM statements or NO/ ' comments. The main difference between the 2 is that REM statements are stripped from the program upon download to the controller and NO or ' comments are left in the program. In most instances the reason for using REM statements instead of NO or ' is to save program memory. The other benefit to using REM commands comes when command execution of a loop, thread or any section of code is critical. Although they do not take much time, NO and ' comments still take time to process. So when command execution time is critical, REM statements should be used. The 2 examples below demonstrate the difference in command execution of a loop containing comments.

The GDK software will treat an apostrophe (') comment different from an NO when the compression algorithm is activated upon a program download (line > 80 characters or program memory > 4000 lines). In this case the software will remove all (') comments as part of the compression and it will download all NO comments to the controller.

Note: Actual processing time will vary depending upon number of axes, communication activity, number of threads currently executing etc.

```
#a
i=0;'initialize a counter
t= TIME;' set an initial time reference
#loop
NO this comment takes time to process
'this comment takes time to process
i=i+1;'this comment takes time to process
JP#loop,i<1000
MG TIME-t;'display number of samples from initial time reference
EN
```

When executed on a DMC-4123, the output from the above program returned a 116, which indicates that it took 116 samples (TM 1000) to process the commands from 't=TIME' to 'MG TIME-t'. This is about 114ms ±2ms.

Now when the comments inside of the #loop routine are changed into REM statements (a REM statement must always start on a new line), the processing is greatly reduced.

When executed on the same DMC-4123, the output from the program shown below returned a 62, which indicates that it took 62 samples to process the commands from 't=TIME' to 'MG TIME-t'. This is about 60ms ±2ms, and about 50% faster than when the comments were downloaded to the controller.

```
#a
i=0;'initialize a counter
t= TIME;' set an initial time reference
#loop
REM this comment is removed upon download and takes no time to process
REM this comment is removed upon download and takes no time to process
i=i+1
REM this comment is removed upon download and takes no time to process
JP#loop,i<1000
MG TIME-t;'display number of samples from initial time reference
EN
```

WT vs AT and coding deterministic loops

The main difference between WT and AT is that WT will hold up execution of the next command for the specified time from the execution of the WT command, AT will hold up execution of the next command for the specified time from the last time reference set with the AT command.

```

#A
AT0;'set initial AT time reference
WT 1000,1;'wait 1000 samples
t1=TIME
AT 4000,1;'wait 4000 samples from last time reference
t2=TIME-t1
REM in the above scenario, t2 will be ~3000 because AT 4000,1 will have
REM paused program execution from the time reference of AT0
REM since the WT 1000,1 took 1000 samples, there was only 3000 samples left
REM of the "4000" samples for AT 4000,1
MG t,t2;'this should output 1000,3000
EN;'End program

```

Where the functionality of the operation of the AT command is very useful is when it is required to have a deterministic loop operating on the controller. These instances range from writing PLC-type scan threads to writing custom control algorithms. The key to having a deterministic loop time is to have a trippoint that will wait a specified time independent of the time it took to execute the loop code. In this definition, the AT command is a perfect fit. The below code is an example of a PLC-type scan thread that runs at a 500ms loop rate. A typical implementation would be to run this code in a separate thread (ex XQ#plcscan,2).

```

REM this code will set output 3 high if
REM inputs 1 and 2 are high, and input 3 is low
REM else output 3 will be low
REM if input 4 is low, output 1 will be high
REM and ouput 3 will be low regardless of the
REM states of inputs 1,2 or 3
#plcscan
AT0;'set initial time reference
#scan
REM mask inputs 1-4
ti= TI0&$F
REM variables for bit 1 and bit 3
b1=0;b3=0
REM if input 4 is high set bit 1 and clear bit 3
REM ti&8 - gets 4th bit, if 4th bit is high result = 8
IF ti&8=8;b1=1;ELSE
REM ti&7 get lower 3 bits, if 011 then result = 3
IF ti&7=3;b3=1;ENDIF;ENDIF
REM set output bits 1 and 3 accordingly
REM set outputs at the end for a PLC scan
OB1,b1;OB3,b3
REM wait 500ms (for 500 samples use AT-500,1)
REM the '-' will reset the time reference
AT-500
JP#scan

```

Mathematical and Functional Expressions

Mathematical Operators

For manipulation of data, the DMC-41x3 provides the use of the following mathematical operators:

Operator	Function
+	Addition
-	Subtraction
*	Multiplication
/	Division
%	Modulus
&	Logical And (Bit-wise)
	Logical Or (On some computers, a solid vertical line appears as a broken line)
()	Parenthesis

Mathematical operations are executed from left to right. Calculations within parentheses have precedence.

Examples:

speed = 7.5*V1/2	The variable, speed, is equal to 7.5 multiplied by V1 and divided by 2
count = count+2	The variable, count, is equal to the current value plus 2.
result = _TPX- (@COS[45]*40)	Puts the position of X - 28.28 in result. 40 * cosine of 45° is 28.28
temp = @IN[1]&@IN[2]	temp is equal to 1 only if Input 1 and Input 2 are high

Mathematical Operation Precision and Range

The controller stores non-integers in a fixed point representation (not floating point). Numbers are stored as 4 bytes of integer and 2 bytes of fraction within the range of $\pm 2,147,483,647.9999$. The smallest number representable (and thus the precision) is $1/65536$ or approximately 0.000015.

Example:

Using basic mathematics it is known that $1.4*(80,000) = 112,000$. However, using a basic terminal, a DMC controller would calculate the following:

:var= 1.4*80000;'	Storing the result of 1.4*80000 in var
:MG var;'	Prints variable "var" to screen
111999.5117	
:	

The reason for this error relies in the precision of the controller. 1.4 must be stored to the nearest multiple of $1/65536$, which is $91750/65536 = 1.3999$. Thus, $(91750/65536)*80000 = 111999.5117$ and reveals the source of the error.

By ignoring decimals and multiplying by integers first (since they carry no error), and then adding the decimal back in by dividing by a factor of 10 will allow the user to avoid any errors caused by the limitations of precision of the controller. Continuing from the example above:

:var= 14*80000;'	Ignore decimals
:MG var;'	Print result
1120000.0000	
:var= var/10;'	Divide by 10 to add in decimal
:MG var;'	Print correct result
112000.0000	
:	

Bit-Wise Operators

The mathematical operators & and | are bit-wise operators. The operator, &, is a Logical And. The operator, |, is a Logical Or. These operators allow for bit-wise operations on any valid DMC-41x3 numeric operand, including variables, array elements, numeric values, functions, keywords, and arithmetic expressions. The bit-wise operators may also be used with strings. This is useful for separating characters from an input string. When using the input command for string input, the input variable will hold up to 6 characters. These characters are combined into a single value which is represented as 32 bits of integer and 16 bits of fraction. Each ASCII character is represented as one byte (8 bits), therefore the input variable can hold up to six characters. The first character of the string will be placed in the top byte of the variable and the last character will be placed in the lowest significant byte of the fraction. The characters can be individually separated by using bit-wise operations as illustrated in the following example:

#TEST	Begin main program
len="123456"	Set len to a string value
Flen=@FRAC[len]	Define variable 'Flen' as fractional part of variable 'len'
Flen=\$10000*Flen	Shift Flen by 32 bits (IE - convert fraction, Flen, to integer)
len1=(Flen&\$00FF)	Mask top byte of Flen and set this value to variable 'len1'
len2=(Flen&\$FF00)/\$100	Let variable, 'len2' = top byte of Flen
len3=len&\$000000FF	Let variable, 'len3' = bottom byte of len
len4=(len&\$0000FF00)/\$100	Let variable, 'len4' = second byte of len
len5=(len&\$00FF0000)/\$10000	Let variable, 'len5' = third byte of len
len6=(len&\$FF000000)/\$1000000	Let variable, 'len6' = fourth byte of len
MG len6 {S4}	Display 'len6' as string message of up to 4 chars
MG len5 {S4}	Display 'len5' as string message of up to 4 chars
MG len4 {S4}	Display 'len4' as string message of up to 4 chars
MG len3 {S4}	Display 'len3' as string message of up to 4 chars
MG len2 {S4}	Display 'len2' as string message of up to 4 chars
MG len1 {S4}	Display 'len1' as string message of up to 4 chars
EN	

This program will accept a string input of up to 6 characters, parse each character, and then display each character. Notice also that the values used for masking are represented in hexadecimal (as denoted by the preceding '\$'). For more information, see section Sending Messages.

To illustrate further, if the user types in the string "TESTME" at the input prompt, the controller will respond with the following:

T	Response from command MG len6 {S4}
E	Response from command MG len5 {S4}
S	Response from command MG len4 {S4}
T	Response from command MG len3 {S4}
M	Response from command MG len2 {S4}
E	Response from command MG len1 {S4}

Functions

FUNCTION	DESCRIPTION
@SIN[n]	Sine of n (n in degrees, with range of -32768 to 32767 and 16-bit fractional resolution)
@COS[n]	Cosine of n (n in degrees, with range of -32768 to 32767 and 16-bit fractional resolution)
@TAN[n]	Tangent of n (n in degrees, with range of -32768 to 32767 and 16-bit fractional resolution)
@ASIN* [n]	Arc Sine of n, between -90° and +90°. Angle resolution in 1/64000 degrees.
@ACOS* [n]	Arc Cosine of n, between 0 and 180°. Angle resolution in 1/64000 degrees.
@ATAN* [n]	Arc Tangent of n, between -90° and +90°. Angle resolution in 1/64000 degrees
@COM[n]	1's Complement of n
@ABS[n]	Absolute value of n
@FRAC[n]	Fraction portion of n
@INT[n]	Integer portion of n
@RND[n]	Round of n (Rounds up if the fractional part of n is .5 or greater)
@SQR[n]	Square root of n (Accuracy is ±.004)
@IN[n]	Return digital input at general input n (where n starts at 1)
@OUT[n]	Return digital output at general output n (where n starts at 1)
@AN[n]	Return analog input at general analog in n (where n starts at 1)

*Note that these functions are multi-valued. An application program may be used to find the correct band.

Functions may be combined with mathematical expressions. The order of execution of mathematical expressions is from left to right and can be over-ridden by using parentheses.

Examples:

v1=@ABS[V7]	The variable, v1, is equal to the absolute value of variable v7.
v2=5*@SIN[pos]	The variable, v2, is equal to five times the sine of the variable, pos.
v3=@IN[1]	The variable, v3, is equal to the digital value of input 1.
v4=2*(5+@AN[5])	The variable, v4, is equal to the value of analog input 5 plus 5, then multiplied by 2.

Variables

For applications that require a parameter that is variable, the DMC-41x3 provides 510 variables. These variables can be numbers or strings. A program can be written in which certain parameters, such as position or speed, are defined as variables. The variables can later be assigned by the operator or determined by program calculations. For example, a cut-to-length application may require that a cut length be variable.

Example:

<code>posx=5000</code>	Assigns the value of 5000 to the variable posx
<code>PR posx</code>	Assigns variable posx to PR command
<code>JG rpmY*70</code>	Assigns variable rpmY multiplied by 70 to JG command.

Programmable Variables

The DMC-41x3 allows the user to create up to 510 variables. Each variable is defined by a name which can be up to eight characters. The name must start with an alphabetic character; however, numbers are permitted in the rest of the name. Spaces are not permitted. Variable names should not be the same as DMC-41x3 instructions. For example, PR is not a good choice for a variable name.

NOTE: It is generally a good idea to use lower-case variable names so there is no confusion between Galil commands and variable names.

Examples of valid and invalid variable names are:

Valid Variable Names

```
posx
posl
speedz
```

Invalid Variable Names

```
RealLongName ; 'Cannot have more than 8 characters
123          ; 'Cannot begin variable name with a number
speed Z      ; 'Cannot have spaces in the name
```

Assigning Values to Variables:

Assigned values can be numbers, internal variables and keywords, functions, controller parameters and strings. The range for numeric variable values is 4 bytes of integer (231) followed by two bytes of fraction ($\pm 2,147,483,647.9999$).

Numeric values can be assigned to programmable variables using the equal sign.

Any valid DMC-41x3 function can be used to assign a value to a variable. For example, `v1=@ABS[v2]` or `v2=@IN[1]`. Arithmetic operations are also permitted.

To assign a string value, the string must be in quotations. String variables can contain up to six characters which must be in quotation.

Examples:

<code>posX=_TPX</code>	Assigns returned value from TPX command to variable posx.
<code>speed=5.75</code>	Assigns value 5.75 to variable speed
<code>input=@IN[2]</code>	Assigns logical value of input 2 to variable input
<code>v2=v1+v3*v4</code>	Assigns the value of v1 plus v3 times v4 to the variable v2.
<code>var="CAT"</code>	Assign the string, CAT, to var
<code>MG var{S3}</code>	Displays the variable var – (CAT)

Assigning Variable Values to Controller Parameters

Variable values may be assigned to controller parameters such as SP or PR.

<code>PR v1</code>	Assign v1 to PR command
--------------------	-------------------------

Displaying the value of variables at the terminal

Variables may be sent to the screen using the format, variable=. For example, v1= , returns the value of the variable v1.

Example - Using Variables for Joystick

The example below reads the voltage of an X-Y joystick and assigns it to variables vX and vY to drive the motors at proportional velocities, where:

10 Volts = 3000 rpm = 200000 c/sec

Speed/Analog input = 200000/10 = 20000

#JOYSTIK	Label
JG 0,0	Set in Jog mode
BGXY	Begin Motion
AT0	Set AT time reference
#LOOP	Loop
vX=@AN[1]*20000	Read joystick X
vY=@AN[2]*20000	Read joystick Y
JG vX,vY	Jog at variable vX,vY
AT-4	Wait 4ms from last time reference, creates a deterministic loop time
JP#LOOP	Repeat
EN	End

Operands

Operands allow motion or status parameters of the DMC-41x3 to be incorporated into programmable variables and expressions. Most DMC commands have an equivalent operand - which are designated by adding an underscore (_) prior to the DMC-41x3 command. The command reference indicates which commands have an associated operand.

Status commands such as Tell Position return actual values, whereas action commands such as KP or SP return the values in the DMC-41x3 registers. The axis designation is required following the command.

Examples of Internal Variables:

posX=_TPX	Assigns value from Tell Position X to the variable posX.
deriv=_KDZ*2	Assigns value from KDZ multiplied by two to variable, deriv.
JP #LOOP,_TEX>5	Jump to #LOOP if the position error of X is greater than 5
JP #ERROR,_TC=1	Jump to #ERROR if the error code equals 1.

Operands can be used in an expression and assigned to a programmable variable, but they cannot be assigned a value. For example: _KDX=2 is invalid.

Special Operands (Keywords)

The DMC-41x3 provides a few additional operands which give access to internal variables that are not accessible by standard DMC-41x3 commands.

Keyword	Function
BGn	*Returns a 1 if motion on axis 'n' is complete, otherwise returns 0.
BN	*Returns serial # of the board.
DA	*Returns the number of arrays available
DL	*Returns the number of available labels for programming
DM	*Returns the available array memory
HMn	*Returns status of Home Switch (equals 0 or 1)
LFn	Returns status of Forward Limit switch input of axis 'n' (equals 0 or 1)
LRX	Returns status of Reverse Limit switch input of axis 'n' (equals 0 or 1)
UL	*Returns the number of available variables
TIME	Free-Running Real Time Clock (off by 2.4% - Resets with power-on). Note: TIME does not use an underscore character (_) as other keywords.

* - These keywords have corresponding commands while the keywords _LF, _LR, and TIME do not have any associated commands. All keywords are listed in the Command Reference.

Examples of Keywords:

v1=_LFX	Assign v1 the logical state of the Forward Limit Switch on the X-axis
v3=TIME	Assign v3 the current value of the time clock
v4=_HMW	Assign v4 the logical state of the Home input on the W-axis

Arrays

For storing and collecting numerical data, the DMC-41x3 provides array space for 24000 elements. The arrays are one dimensional and up to 30 different arrays may be defined. Each array element has a numeric range of 4 bytes of integer (2^{31}) followed by two bytes of fraction ($\pm 2,147,483,647.9999$).

Arrays can be used to capture real-time data, such as position, torque and analog input values. In the contouring mode, arrays are convenient for holding the points of a position trajectory in a record and playback application.

Defining Arrays

An array is defined with the command DM. The user must specify a name and the number of entries to be held in the array. An array name can contain up to eight characters, starting with an alphabetic character. The number of entries in the defined array is enclosed in [].

Example:

DM posx[7]	Defines an array names 'posx' with seven entries
DM speed[100]	Defines an array named speed with 100 entries
DA posx[]	Frees array space

Assignment of Array Entries

Like variables, each array element can be assigned a value. Assigned values can be numbers or returned values from instructions, functions and keywords.

Array elements are addressed starting at count 0. For example the first element in the 'posx' array (defined with the DM command, DM posx[7]) would be specified as posx[0].

Values are assigned to array entries using the equal sign. Assignments are made one element at a time by specifying the element number with the associated array name.

NOTE: Arrays must be defined using the command, DM, before assigning entry values.

Examples:

DM speed[10]	Dimension speed Array
speed[0]=7650.2	Assigns the first element of the array, 'speed' the value 7650.2
speed[0]=	Returns array element value
posx[9]=_TPX	Assigns the 10 th element of the array 'posx' the returned value from the tell position command.
con[1]=@COS[pos]*2	Assigns the second element of the array 'con' the cosine of the variable POS multiplied by 2.
timer[0]=TIME	Assigns the first element of the array timer the returned value of the TIME keyword.

Using a Variable to Address Array Elements

An array element number can also be a variable. This allows array entries to be assigned sequentially using a counter.

Example:

#A	Begin Program
count=0;DM pos[10]	Initialize counter and define array
#LOOP	Begin loop
WT 10	Wait 10 msec
pos[count]=_TPX	Record position into array element
pos[count]=	Report position
count=count+1	Increment counter
JP #LOOP,count<10	Loop until 10 elements have been stored
EN	End Program

The above example records 10 position values at a rate of one value per 10 msec. The values are stored in an array named 'pos'. The variable, 'count', is used to increment the array element counter. The above example can also be executed with the automatic data capture feature described below.

Uploading and Downloading Arrays to On Board Memory

The GDK software is recommended for downloading and uploading array data from the controller. The Gclib programming library also provides function calls for downloading and uploading array data from the controller to/from a buffer or a file.

Arrays may also be uploaded and downloaded using the QU and QD commands.

```
QU array[,start,end,delim
QD array[,start,end
```

where array is an array name such as A[].

start is the first element of array (default=0)

end is the last element of array (default=last element)

delim specifies whether the array data is separated by a comma (delim=1) or a carriage return (delim=0).

The file is terminated using <control>Z, <control>Q, <control>D or \.

Automatic Data Capture into Arrays

The DMC-41x3 provides a special feature for automatic capture of data such as position, position error, inputs or torque. This is useful for teaching motion trajectories or observing system performance. Up to eight types of data can be captured and stored in eight arrays. The capture rate or time interval may be specified. Recording can be done as a one time event or as a circular continuous recording.

Command Summary - Automatic Data Capture

Command	Description
RA n[],m[],o[],p[]	Selects up to eight arrays for data capture. The arrays must be defined with the DM command.
RD type1,type2,type3,type4	Selects the type of data to be recorded, where type1, type2, type3, and type 4 represent the various types of data (see table below). The order of data type is important and corresponds with the order of n,m,o,p arrays in the RA command.
RC n,m	The RC command begins data collection. Sets data capture time interval where n is an integer between 1 and 8 and designates 2 ⁿ msec between data. m is optional and specifies the number of elements to be captured. If m is not defined, the number of elements defaults to the smallest array defined by DM. When m is a negative number, the recording is done continuously in a circular manner. _RD is the recording pointer and indicates the address of the next array element. n=0 stops recording.
RC?	Returns a 0 or 1 where, 0 denotes not recording, 1 specifies recording in progress

Data Types for Recording:

Data type	Description
TIME	Controller time as reported by the TIME command
_AFn	Analog input (n=X,Y,Z,W,E,F,G,H, for AN inputs 1-8)
_DEX	2 nd encoder position (dual encoder)
_NOX	Status bits
_OP	Output
_RLX	Latched position
_RPX	Commanded position
_SCX	Stop code
_TEX	Position error
_TI	Inputs
_TPX	Encoder position
_TSX	Switches (only bit 0-4 valid)
_TTX	Torque (reports digital value ±32544)

NOTE: X may be replaced by Y,Z or W for capturing data on other axes.

Operand Summary - Automatic Data Capture

_RC	Returns a 0 or 1 where, 0 denotes not recording, 1 specifies recording in progress
_RD	Returns address of next array element.

Example - Recording into An Array

During a position move, store the X and Y positions and position error every 2 msec.

#RECORD	Begin program
DM XPOS[300],YPOS[300]	Define X,Y position arrays
DM XERR[300],YERR[300]	Define X,Y error arrays
RA XPOS[],XERR[],YPOS[],YERR[]	Select arrays for capture
RD _TPX,_TEX,_TPY,_TEY	Select data types
PR 10000,20000	Specify move distance
RC1	Start recording now, at rate of 2 msec
BG XY	Begin motion
#A;JP #A,_RC=1	Loop until done
MG "DONE"	Print message
EN	End program
#PLAY	Play back
N=0	Initial Counter
JP# DONE,N>300	Exit if done
N=	Print Counter
X POS[N]=	Print X position
Y POS[N]=	Print Y position
XERR[N]=	Print X error
YERR[N]=	Print Y error
N=N+1	Increment Counter
#DONE	Done
EN	End Program

De-allocating Array Space

Array space may be de-allocated using the DA command followed by the array name. DA*[0] deallocates all the arrays.

Input of Data (Numeric and String)

NOTE: The IN command has been removed from the DMC-41x3 firmware. Variables should be entered by sending data directly from the host application.

Sending Data from a Host

The DMC-41x3 can accept ASCII strings from a host. This is the most common way to send data to the controller such as setting variables to numbers or strings. Any variable can be stored in a string format up to 6 characters by simply specifying defining that variable to the string value with quotes, for example:

varS = "STRING"

Will assign the variable 'varS' to a string value of "STRING".

To assign a variable a numerical value, the direct number is used, for example:

varN = 123456

Will assign the variable 'varN' to a number of 123,456.

All variables on the DMC-41x3 controller are stored with 4 bytes of integer and 2 bytes of fractional data.

Operator Data Entry Mode

The Operator Data Entry Mode provides for un-buffered data entry through the auxiliary RS-232 port. In this mode, the DMC-41x3 provides a buffer for receiving characters. This mode may only be used when executing an applications program.

The Operator Data Entry Mode may be specified for Port 2 only. This mode may be exited with the \ or <escape> key.

NOTE: Operator Data Entry Mode cannot be used for high rate data transfer.

Set the third field of the CC command to one to set the Operator Data Entry Mode.

To capture and decode characters in the Operator Data Mode, the DMC-41x3 provides special the following keywords:

Keyword	Function
P2CH	Contains the last character received
P2ST	Contains the received string
P2NM	Contains the received number
P2CD	Contains the status code: -1 mode disabled 0 nothing received 1 received character, but not <enter> 2 received string, not a number 3 received number

NOTE: The value of P2CD returns to zero after the corresponding string or number is read.

These keywords may be used in an applications program to decode data and they may also be used in conditional statements with logical operators.

Example

Instruction	Interpretation
JP #LOOP, P2CD< >3	Checks to see if status code is 3 (number received)
JP #P, P2CH="V"	Checks if last character received was a V
PR P2NM	Assigns received number to position
JS #XAXIS, P2ST="X"	Checks to see if received string is X

Using Communication Interrupt

The DMC-41x3 provides a special interrupt for communication allowing the application program to be interrupted by input from the user. The interrupt is enabled using the CI command. The syntax for the command is CI n:

n = 0	Don't interrupt Port 2
n = 1	Interrupt on <enter> Port 2
n = 2	Interrupt on any character Port 2
n = -1	Clear any characters in buffer

The #COMINT label is used for the communication interrupt. For example, the DMC-41x3 can be configured to interrupt on any character received on Port 2. The #COMINT subroutine is entered when a character is received and the subroutine can decode the characters. At the end of the routine the EN command is used. EN,1 will re-enable the interrupt and return to the line of the program where the interrupt was called, EN will just return to the line of the program where it was called without re-enabling the interrupt. As with any automatic subroutine, a program must be running in thread 0 at all times for it to be enabled.

Example

A DMC-41x3 is used to jog the A and B axis. This program automatically begins upon power-up and allows the user to input values from the main serial port terminal. The speed of either axis may be changed during motion by specifying the axis letter followed by the new speed value. An S stops motion on both axes.

Instruction	Interpretation
#AUTO	Label for Auto Execute
speedA=10000	Initial A speed
speedB=10000	Initial B speed
CI 2	Set Port 2 for Character Interrupt
JG speedA, speedB	Specify jog mode speed for A and B axis
BGXY	Begin motion
#PRINT	Routine to print message to terminal
MG{P2}"TO CHANGE SPEEDS"	Print message
MG{P2}"TYPE A OR B"	
MG{P2}"TYPE S TO STOP"	
#JOGLOOP	Loop to change Jog speeds
JG speedA, speedB	Set new jog speed
JP #JOGLOOP	
EN	End of main program
#COMINT	Interrupt routine
JP #A, P2CH="A"	Check for A
JP #B, P2CH="B"	Check for B
JP #C, P2CH="S"	Check for S
ZS1;CI2;JP#JOGLOOP	Jump if not X,Y,S
#A;JS#NUM	
speedX=val	New X speed
ZS1;CI2;JP#PRINT	Jump to Print
#B;JS#NUM	
speedY=val	New Y speed
ZS1;CI2;JP#PRINT	Jump to Print
#C;ST;AMX;CI-1	Stop motion on S
MG{^8}, "THE END"	
ZS;EN,1	End-Re-enable interrupt
#NUM	Routine for entering new jog speed
MG "ENTER", P2CH{S}, "AXIS SPEED" {N}	Prompt for value
#NUMLOOP; CI-1	Check for enter

#NMLP	Routine to check input from terminal
JP #NMLP, P2CD<2	Jump to error if string
JP #ERROR, P2CD=2	Read value
val=P2NM	
EN	End subroutine
#ERROR;CI-1	Error Routine
MG "INVALID-TRY AGAIN"	Error message
JP #NMLP	
EN	End

Output of Data (Numeric and String)

Numerical and string data can be output from the controller using several methods. The message command, MG, can output string and numerical data. Also, the controller can be commanded to return the values of variables and arrays, as well as other information using the interrogation commands (the interrogation commands are described in chapter 5).

Sending Messages

Messages may be sent to the bus using the message command, MG. This command sends specified text and numerical or string data from variables or arrays to the screen.

Text strings are specified in quotes and variable or array data is designated by the name of the variable or array. For example:

```
MG "The Final Value is", result
```

In addition to variables, functions and commands, responses can be used in the message command. For example:

```
MG "Analog input is", @AN[1]
MG "The Position of A is", _TPA
```

Specifying the Port for Messages:

The port can be specified with the specifier, {P1} for the main USB {P2} for auxiliary serial port, or {En} for the Ethernet port.

```
MG {P2} "Hello World"           Sends message to Auxiliary Port
```

Formatting Messages

String variables can be formatted using the specifier, {Sn} where n is the number of characters, 1 thru 6. For example:

```
MG STR {S3}
```

This statement returns 3 characters of the string variable named STR.

Numeric data may be formatted using the {Fn.m} expression following the completed MG statement. {\$n.m} formats data in HEX instead of decimal. The actual numerical value will be formatted with n characters to the left of the decimal and m characters to the right of the decimal. Leading zeros will be used to display specified format.

For example:

```
MG "The Final Value is", result {F5.2}
```

If the value of the variable result is equal to 4.1, this statement returns the following:

```
The Final Value is 00004.10
```

If the value of the variable result is equal to 999999.999, the above message statement returns the following:

```
The Final Value is 99999.99
```

The message command normally sends a carriage return and line feed following the statement. The carriage return and the line feed may be suppressed by sending {N} at the end of the statement. This is useful when a text string needs to surround a numeric value.

Example:

```
#A
JG 50000;BGA;ASA
MG "The Speed is", _TVA {F5.0} {N}
MG "counts/sec"
EN
```

When #A is executed, the above example will appear on the screen as:

The Speed is 50000 counts/sec

Using the MG Command to Configure Terminals

The MG command can be used to configure a terminal. Any ASCII character can be sent by using the format {^n} where n is any integer between 1 and 255.

Example:

```
MG {^07} {^255}
```

sends the ASCII characters represented by 7 and 255 to the bus.

Summary of Message Functions

function	description
" "	Surrounds text string
{Fn.m}	Formats numeric values in decimal n digits to the left of the decimal point and m digits to the right
{P1}, {P2} or {E}	Send message to Main Serial Port, Auxiliary Serial Port or Ethernet Port
{\$n.m}	Formats numeric values in hexadecimal
{^n}	Sends ASCII character specified by integer n
{N}	Suppresses carriage return/line feed
{Sn}	Sends the first n characters of a string variable, where n is 1 thru 6.

Displaying Variables and Arrays

Variables and arrays may be sent to the screen using the format, variable= or array[x]=. For example, v1= returns the value of v1.

Example - Printing a Variable and an Array element

Instruction	Interpretation
#DISPLAY	Label
DM posA[7]	Define Array posA with 7 entries
PR 1000	Position Command
BGX	Begin
AMX	After Motion
v1=_TPA	Assign Variable v1
posA[1]=_TPA	Assign the first entry
v1=	Print v1

Interrogation Commands

The DMC-41x3 has a set of commands that directly interrogate the controller. When these command are entered, the requested data is returned in decimal format on the next line followed by a carriage return and line feed. The

format of the returned data can be changed using the Position Format (PF), and Leading Zeros (LZ) command. For a complete description of interrogation commands, see [Chapter 5](#).

Using the PF Command to Format Response from Interrogation Commands

The command, PF, can change format of the values returned by theses interrogation commands:

BL ?	LE ?
DE ?	PA ?
DP ?	PR ?
EM ?	TN ?
FL ?	VE ?
IP ?	TE
TP	

The numeric values may be formatted in decimal or hexadecimal with a specified number of digits to the right and left of the decimal point using the PF command.

Position Format is specified by:

PF m.n

where m is the number of digits to the left of the decimal point (0 thru 10) and n is the number of digits to the right of the decimal point (0 thru 4) A negative sign for m specifies hexadecimal format.

Hex values are returned preceded by a \$ and in 2's complement. Hex values should be input as signed 2's complement, where negative numbers have a negative sign. The default format is PF 10.0.

If the number of decimal places specified by PF is less than the actual value, a nine appears in all the decimal places.

Example

Instruction	Interpretation
:DP21	Define position
:TPA	Tell position
0000000021	Default format
:PF4	Change format to 4 places
:TPA	Tell position
0021	New format
:PF-4	Change to hexadecimal format
:TPA	Tell Position
\$0015	Hexadecimal value
:PF2	Format 2 places
:TPA	Tell Position
99	Returns 99 if position greater than 99

Adding Leading Zeros from Response to Interrogation Commands

The leading zeros on data returned as a response to interrogation commands can be added by the use of the command, LZ. The LZ command is set to a default of 1.

LZ0	Disables the LZ function
TP	Tell Position Interrogation Command
-0000000009, 0000000005	Response (With Leading Zeros)
LZ1	Enables the LZ function
TP	Tell Position Interrogation Command
-9, 5	Response (Without Leading Zeros)

Local Formatting of Response of Interrogation Commands

The response of interrogation commands may be formatted locally. To format locally, use the command, {Fn.m} or {\$n.m} on the same line as the interrogation command. The symbol F specifies that the response should be

returned in decimal format and \$ specifies hexadecimal. n is the number of digits to the left of the decimal, and m is the number of digits to the right of the decimal.

TP {F2.2}	Tell Position in decimal format 2.2
-05.00, 05.00, 00.00, 07.00	Response from Interrogation Command
TP {\$4.2}	Tell Position in hexadecimal format 4.2
FFFB.00,\$0005.00,\$0000.00,\$0007.00	Response from Interrogation Command

Formatting Variables and Array Elements

The Variable Format (VF) command is used to format variables and array elements. The VF command is specified by:

VF m.n

where m is the number of digits to the left of the decimal point (0 thru 10) and n is the number of digits to the right of the decimal point (0 thru 4).

A negative sign for m specifies hexadecimal format. The default format for VF is VF 10.4

Hex values are returned preceded by a \$ and in 2's complement.

Instruction	Interpretation
v1=10	Assign v1
v1=	Return v1
:0000000010.0000	Response - Default format
VF2.2	Change format
v1=	Return v1
:10.00	Response - New format
VF-2.2	Specify hex format
v1=	Return v1
\$0A.00	Response - Hex value
VF1	Change format
v1=	Return v1
:9	Response - Overflow

Local Formatting of Variables

PF and VF commands are global format commands that affect the format of all relevant returned values and variables. Variables may also be formatted locally. To format locally, use the command, {Fn.m} or {\$n.m} following the variable name and the '=' symbol. F specifies decimal and \$ specifies hexadecimal. n is the number of digits to the left of the decimal, and m is the number of digits to the right of the decimal.

Instruction	Interpretation
v1=10	Assign v1
v1=	Return v1
:0000000010.0000	Default Format
v1={F4.2}	Specify local format
:0010.00	New format
v1={\$4.2}	Specify hex format
: \$000A.00	Hex value
v1="ALPHA"	Assign string "ALPHA" to v1
v1={S4}	Specify string format first 4 characters
:ALPH	

The local format is also used with the MG command.

Converting to User Units

Variables and arithmetic operations make it easy to input data in desired user units such as inches or RPM.

The DMC-41x3 position parameters such as PR, PA and VP have units of quadrature counts. Speed parameters such as SP, JG and VS have units of counts/sec. Acceleration parameters such as AC, DC, VA and VD have units of counts/sec². The controller interprets time in milliseconds.

All input parameters must be converted into these units. For example, an operator can be prompted to input a number in revolutions. A program could be used such that the input number is converted into counts by multiplying it by the number of counts/revolution.

Instruction	Interpretation
#RUN	Label
MG "ENTER # OF REVOLUTIONS";n1=-1	Prompt for revs
#rev;JP#rev,n1=-1	Wait until user enters new value for n1
PR n1*2000	Convert to counts
MG "ENTER SPEED IN RPM";s1=-1	Prompt for RPMs
#spd;JP#spd,s1=-1	Wait for user to enter new value for s1
SP s1*2000/60	Convert to counts/sec
MG "ENTER ACCEL IN RAD/SEC2";a1=-1	Prompt for ACCEL
#acc;JP#acc,a1=-1	Wait for user to enter new value for a1
AC a1*2000/(2*3.14)	Convert to counts/sec ²
BG	Begin motion
EN	End program

Hardware I/O

Digital Outputs

The DMC-41x3 has an 8-bit uncommitted output port, the DMC-4153 through DMC-4183 has an additional 8 outputs. Each bit on the output port may be set and cleared with the software instructions SB (Set Bit) and CB (Clear Bit), or OB (define output bit).

Example- Set Bit and Clear Bit

Instruction	Interpretation
SB6	Sets bit 6 of output port
CB4	Clears bit 4 of output port

Example- Output Bit

The Output Bit (OB) instruction is useful for setting or clearing outputs depending on the value of a variable, array, input or expression. Any non-zero value results in a set bit.

Instruction	Interpretation
OB1, POS	Set Output 1 if the variable POS is non-zero. Clear Output 1 if POS equals 0.
OB 2, @IN [1]	Set Output 2 if Input 1 is high. If Input 1 is low, clear Output 2.
OB 3, @IN [1] & @IN [2]	Set Output 3 only if Input 1 and Input 2 are high.
OB 4, COUNT [1]	Set Output 4 if element 1 in the array COUNT is non-zero.

The output port can be set by specifying an 16-bit word using the instruction OP (Output Port). This instruction allows a single command to define the state of the entire 16-bit output port, where bit 0 is output 1, bit1 is output2 and so on. A 1 designates that the output is on.

Example- Output Port

Instruction	Interpretation
OP6	Sets outputs 2 and 3 of output port to high. All other bits are 0. ($2^1 + 2^2 = 6$)
OP0	Clears all bits of output port to zero
OP 255	Sets all bits of output port to one. ($2^0 + 2^1 + 2^2 + 2^3 + 2^4 + 2^5 + 2^6 + 2^7$)

The output port is useful for setting relays or controlling external switches and events during a motion sequence.

Example - Turn on output after move

Instruction	Interpretation
#OUTPUT	Label
PR 2000	Position Command
BG	Begin
AM	After move
SB1	Set Output 1
WT 1000	Wait 1000 msec
CB1	Clear Output 1
EN	End

Digital Inputs

The general digital inputs are accessed by using the @IN[n] function or the TI command. The @IN[n] function returns the logic level of the specified input, n, where n is a number 1 through 16.

Example - Using Inputs to control program flow

Instruction	Interpretation
JP #A,@IN[1]=0	Jump to A if input 1 is low
JP #B,@IN[2]=1	Jump to B if input 2 is high
AI 7	Wait until input 7 is high
AI -6	Wait until input 6 is low

Example - Start Motion on Switch

Motor A must turn at 4000 counts/sec when the user flips a panel switch to on. When panel switch is turned to off position, motor A must stop turning.

Solution: Connect panel switch to input 1 of DMC-41x3. High on input 1 means switch is in on position.

Instruction	Interpretation
#S;JG 4000	Set speed
AI 1;BGA	Begin after input 1 goes high
AI -1;STA	Stop after input 1 goes low
AMA;JP #S	After motion, repeat
EN	

The Auxiliary Encoder Inputs

The auxiliary encoder inputs can be used for general use. For each axis, the controller has one auxiliary encoder and each auxiliary encoder consists of two inputs, channel A and channel B. The auxiliary encoder inputs are mapped to the inputs 81-96.

Each input from the auxiliary encoder is a differential line receiver and can accept voltage levels between ± 12 volts. The inputs have been configured to accept TTL level signals. To connect TTL signals, simply connect the signal to the + input and leave the - input disconnected. For other signal levels, the - input should be connected to a voltage that is $\frac{1}{2}$ of the full voltage range (for example, connect the - input to 5 volts if the signal is a 0 - 12 volt logic).

Example:

A DMC-4113 has one auxiliary encoder. This encoder has two inputs (channel A and channel B). Channel A input is mapped to input 81 and Channel B input is mapped to input 82. To use this input for 2 TTL signals, the first signal

will be connected to AA+ and the second to AB+. AA- and AB- will be left unconnected. To access this input, use the function @IN[81] and @IN[82].

NOTE: The auxiliary encoder inputs are not available for any axis that is configured for stepper motor.

Input Interrupt Function

The DMC-41x3 provides an input interrupt function which causes the program to automatically execute the instructions following the #ININT label. This function is enabled using the II m,n,o command. The m specifies the beginning input and n specifies the final input in the range. The parameter o is an interrupt mask. If m and n are unused, o contains a number with the mask. For example, II,,5 enables inputs 1 and 3.

A low input on any of the specified inputs will cause automatic execution of the #ININT subroutine. The Return from Interrupt (RI) command is used to return from this subroutine to the place in the program where the interrupt had occurred.

Important: Use the RI command (not EN) to return from the #ININT subroutine.

Example - Input Interrupt

Instruction	Interpretation
#A	Label #A
II 1	Enable input 1 for interrupt function
JG 30000,-20000	Set speeds on A and B axes
BG AB	Begin motion on A and B axes
#B	Label #B
TP AB	Report A and B axes positions
WT 1000	Wait 1000 milliseconds
JP #B	Jump to #B
EN	End of program
#ININT	Interrupt subroutine
MG "Interrupt has occurred"	Displays the message
ST AB	Stops motion on A and B axes
#LOOP;JP #LOOP,@IN[1]=0	Loop until Interrupt cleared
JG 15000,10000	Specify new speeds
WT 300	Wait 300 milliseconds
BG AB	Begin motion on A and B axes
RI	Return from Interrupt subroutine

Jumping back to main program with #ININT

To jump back to the main program using the JP command, the RI command must be issued in a subroutine and then the ZS command must be issued prior to the JP command. See Application Note # 2418 for more information.

<http://galil.com/download/application-note/note2418.pdf>

Analog Inputs

The DMC-41x3 provides eight analog inputs. The value of these inputs in volts may be read using the @AN[n] function where n is the analog input 1 through 8. The resolution of the Analog-to-Digital conversion is 12 bits (16-bit ADC is available as an option). Analog inputs are useful for reading special sensors such as temperature, tension or pressure.

The following examples show programs which cause the motor to follow an analog signal. The first example is a point-to-point move. The second example shows a continuous move.

Example - Position Follower (Point-to-Point)

Objective - The motor must follow an analog signal. When the analog signal varies by 10V, motor must move 10000 counts.

Method: Read the analog input and command A to move to that point.

Instruction	Interpretation
#POINTS	Label
SP 7000	Speed
AC 80000;DC 80000	Acceleration
#LOOP	
VP=@AN[1]*1000	Read and analog input, compute position
PA VP	Command position
BGA	Start motion
AMA	After completion
JP #LOOP	Repeat
EN	End

Example - Position Follower (Continuous Move)

Method: Read the analog input, compute the commanded position and the position error. Command the motor to run at a speed in proportions to the position error.

Instruction	Interpretation
#CONT	Label
AC 80000;DC 80000	Acceleration rate
JG 0	Start job mode
BGX	Start motion
#LOOP	
vp=@AN[1]*1000	Compute desired position
ve=vp-_TPA	Find position error
vel=ve*20	Compute velocity
JG vel	Change velocity
JP #LOOP	Change velocity
EN	End

Example – Low Pass Digital Filter for the Analog inputs

Because the analog inputs on the Galil controller can be used to close a position loop, they have a very high bandwidth and will therefore read noise that comes in on the analog input. Often when an analog input is used in a motion control system, but not for closed loop control, the higher bandwidth is not required. In this case a simple digital filter may be applied to the analog input, and the output of the filter can be used for in the motion control application. This example shows how to apply a simple single pole low-pass digital filter to an analog input. This code is commonly run in a separate thread (XQ#filt,1 – example of executing in thread 1).

```
#filt
REM an1 = filtered output. Use this instead of @AN[1]
an1=@AN[1];'set initial value
REM k1+k2=1 this condition must be met
REM use division of m/2^n for elimination of round off
REM increase k1 = less filtering
REM increase k2 = more filtering
k1=32/64;k2=32/64
AT0;'set initial time reference
#loop
REM calculate filtered output and then way 2 samples from last
REM time reference (last AT-2,1 or AT0)
an1=(k1*@AN[1])+(k2*an1);AT-2,1
JP#loop
```

Example Applications

Wire Cutter

An operator activates a start switch. This causes a motor to advance the wire a distance of 10". When the motion stops, the controller generates an output signal which activates the cutter. Allowing 100 ms for the cutting completes the cycle.

Suppose that the motor drives the wire by a roller with a 2" diameter. Also assume that the encoder resolution is 1000 lines per revolution. Since the circumference of the roller equals 2π inches, and it corresponds to 4000 quadrature, one inch of travel equals:

$$4000/2\pi = 637 \text{ count/inch}$$

This implies that a distance of 10 inches equals 6370 counts, and a slew speed of 5 inches per second, for example, equals 3185 count/sec.

The input signal may be applied to I1, for example, and the output signal is chosen as output 1. The motor velocity profile and the related input and output signals are shown in Figure 7.1.

The program starts at a state that we define as #A. Here the controller waits for the input pulse on I1. As soon as the pulse is given, the controller starts the forward motion.

Upon completion of the forward move, the controller outputs a pulse for 20 ms and then waits an additional 80 ms before returning to #A for a new cycle.

INSTRUCTION	FUNCTION
#A	Label
AI1	Wait for input 1
PR 6370	Distance
SP 3185	Speed
BGX	Start Motion
AMX	After motion is complete
SB1	Set output bit 1
WT 20	Wait 20 ms
CB1	Clear output bit 1
WT 80	Wait 80 ms
JP #A	Repeat the process




Figure 7.1: Motor Velocity and the Associated Input/Output signals

X-Y Table Controller

An X-Y-Z system must cut the pattern shown in Figure 7.2. The X-Y table moves the plate while the Z-axis raises and lowers the cutting tool.

The solid curves in Figure 7.2 indicate sections where cutting takes place. Those must be performed at a feed rate of 1 inch per second. The dashed line corresponds to non-cutting moves and should be performed at 5 inch per second. The acceleration rate is 0.1 g.

The motion starts at point A, with the Z-axis raised. An X-Y motion to point B is followed by lowering the Z-axis and performing a cut along the circle. Once the circular motion is completed, the Z-axis is raised and the motion continues to point C, etc.

Assume that all of the 3 axes are driven by lead screws with 10 turns-per-inch pitch. Also assume encoder resolution of 1000 lines per revolution. This results in the relationship:

$$1 \text{ inch} = 40,000 \text{ counts}$$

and the speeds of

$$1 \text{ in/sec} = 40,000 \text{ count/sec}$$

$$5 \text{ in/sec} = 200,000 \text{ count/sec}$$

an acceleration rate of 0.1g equals

$$0.1g = 38.6 \text{ in/s}^2 = 1,544,000 \text{ count/s}^2$$

Note that the circular path has a radius of 2" or 80000 counts, and the motion starts at the angle of 270° and traverses 360° in the CW (negative direction). Such a path is specified with the instruction

CR 80000,270,-360

Further assume that the Z must move 2" at a linear speed of 2" per second. The required motion is performed by the following instructions:

INSTRUCTION	FUNCTION
#A	Label
VM XY	Circular interpolation for XY
VP 160000,160000	Positions
VE	End Vector Motion
VS 200000	Vector Speed
VA 1544000	Vector Acceleration
BGS	Start Motion
AMS	When motion is complete
PR, , -80000	Move Z down
SP, , 80000	Z speed
BGZ	Start Z motion
AMZ	Wait for completion of Z motion
CR 80000,270,-360	Circle
VE	
VS 40000	Feed rate
BGS	Start circular move
AMS	Wait for completion
PR, , 80000	Move Z up
BGZ	Start Z move
AMZ	Wait for Z completion
PR -21600	Move X
SP 20000	Speed X
BGX	Start X
AMX	Wait for X completion
PR, , -80000	Lower Z
BGZ	
AMZ	
CR 80000,270,-360	Z second circle move
VE	
VS 40000	
BGS	
AMS	
PR, , 80000	Raise Z
BGZ	
AMZ	

```

VP -37600,-16000      Return XY to start
VE
VS 200000
BGS
AMS
EN

```




Figure 7.2: Motor Velocity and the Associated Input/Output signals

Speed Control by Joystick

The speed of a motor is controlled by a joystick. The joystick produces a signal in the range between -10V and +10V. The objective is to drive the motor at a speed proportional to the input voltage.

Assume that a full voltage of 10 Volts must produce a motor speed of 3000 rpm with an encoder resolution of 1000 lines or 4000 count/rev. This speed equals:

$$3000 \text{ rpm} = 50 \text{ rev/sec} = 200000 \text{ count/sec}$$

The program reads the input voltage periodically and assigns its value to the variable VIN. To get a speed of 200,000 ct/sec for 10 volts, we select the speed as:

$$\text{Speed} = 20000 \times \text{VIN}$$

The corresponding velocity for the motor is assigned to the VEL variable.

Instruction

```

#A
JG0
BGX
#B
VIN=@AN[1]
VEL=VIN*20000
JG VEL
JP #B
EN

```

Position Control by Joystick

This system requires the position of the motor to be proportional to the joystick angle. Furthermore, the ratio between the two positions must be programmable. For example, if the control ratio is 5:1, it implies that when the joystick voltage is 5 Volts, corresponding to 1028 counts, the required motor position must be 5120 counts. The variable V3 changes the position ratio.

INSTRUCTION	FUNCTION
#A	Label
V3=5	Initial position ratio
DP0	Define the starting position
JG0	Set motor in jog mode as zero
BGX	Start
#B	
VIN=@AN[1]	Read analog input
V2=V1*V3	Compute the desired position
V4=V2- _TPX- _TEX	Find the following error
V5=V4*20	Compute a proportional speed
JG V5	Change the speed
JP #B	Repeat the process
EN	End

Backlash Compensation by Sampled Dual-Loop

The continuous dual loop, enabled by the DV1 function is an effective way to compensate for backlash. In some cases, however, when the backlash magnitude is large, it may be difficult to stabilize the system. In those cases, it may be easier to use the sampled dual loop method described below.

This design example addresses the basic problems of backlash in motion control systems. The objective is to control the position of a linear slide precisely. The slide is to be controlled by a rotary motor, which is coupled to the slide by a lead screw. Such a lead screw has a backlash of 4 micron, and the required position accuracy is for 0.5 micron.

The basic dilemma is where to mount the sensor. If you use a rotary sensor, you get a 4 micron backlash error. On the other hand, if you use a linear encoder, the backlash in the feedback loop will cause oscillations due to instability.

An alternative approach is the dual-loop, where we use two sensors, rotary and linear. The rotary sensor assures stability (because the position loop is closed before the backlash) whereas the linear sensor provides accurate load position information. The operation principle is to drive the motor to a given rotary position near the final point. Once there, the load position is read to find the position error and the controller commands the motor to move to a new rotary position which eliminates the position error.

Since the required accuracy is 0.5 micron, the resolution of the linear sensor should preferably be twice finer. A linear sensor with a resolution of 0.25 micron allows a position error of ± 2 counts.

The dual-loop approach requires the resolution of the rotary sensor to be equal or better than that of the linear system. Assuming that the pitch of the lead screw is 2.5mm (approximately 10 turns per inch), a rotary encoder of 2500 lines per turn or 10,000 count per revolution results in a rotary resolution of 0.25 micron. This results in equal resolution on both linear and rotary sensors.

To illustrate the control method, assume that the rotary encoder is used as a feedback for the X-axis, and that the linear sensor is read and stored in the variable LINPOS. Further assume that at the start, both the position of X and the value of LINPOS are equal to zero. Now assume that the objective is to move the linear load to the position of 1000.

The first step is to command the X motor to move to the rotary position of 1000. Once it arrives we check the position of the load. If, for example, the load position is 980 counts, it implies that a correction of 20 counts must be made. However, when the X-axis is commanded to be at the position of 1000, suppose that the actual position is only 995, implying that X has a position error of 5 counts, which will be eliminated once the motor settles. This implies that the correction needs to be only 15 counts, since 5 counts out of the 20 would be corrected by the X-axis. Accordingly, the motion correction should be:

$$\text{Correction} = \text{Load Position Error} - \text{Rotary Position Error}$$

The correction can be performed a few times until the error drops below ± 2 counts. Often, this is performed in one correction cycle.

Example:

INSTRUCTION	FUNCTION
#A	Label
DPO	Define starting positions as zero
LINPOS=0	
PR 1000	Required distance
BGX	Start motion
#B	
AMX	Wait for completion
WT 50	Wait 50 msec
LINPOS = _DEX	Read linear position
ERR=1000-LINPOS-_TEX	Find the correction
JP #C, @ABS[ERR]<2	Exit if error is small
PR ERR	Command correction
BGX	
JP #B	Repeat the process
#C	
EN	

Using the DMC Editor to Enter Programs (Advanced)

The GDK software package provides an editor and utilities that allow the upload and download of DMC programs to the motion controller. In most instances the user will use Galil software or a host application to download programs to the Galil controller rather than using the ED command.

Application programs for the DMC-41x3 may also be created and edited locally using the DMC-41x3 when using a program such as hyper-terminal or telnet.

The DMC-41x3 provides a line Editor for entering and modifying programs. The Edit mode is entered with the ED instruction. (Note: The ED command can only be given when the controller is in the non-edit mode, which is signified by a colon prompt).

In the Edit Mode, each program line is automatically numbered sequentially starting with 000. If no parameter follows the ED command, the editor prompter will default to the last line of the last program in memory. If desired, the user can edit a specific line number or label by specifying a line number or label following ED.

ED	Puts Editor at end of last program
:ED 5	Puts Editor at line 5
:ED #BEGIN	Puts Editor at label #BEGIN

Line numbers appear as 000,001,002 and so on. Program commands are entered following the line numbers. Multiple commands may be given on a single line as long as the total number of characters doesn't exceed 80 characters per line.

While in the Edit Mode, the programmer has access to special instructions for saving, inserting and deleting program lines. These special instructions are listed below:

Edit Mode Commands

<RETURN>

Typing the return key causes the current line of entered instructions to be saved. The editor will automatically advance to the next line. Thus, hitting a series of <RETURN> will cause the editor to advance a series of lines. Note, changes on a program line will not be saved unless a <return> is given.

<cntrl>P

The <cntrl>P command moves the editor to the previous line.

<cntrl>I

The <cntrl>I command inserts a line above the current line. For example, if the editor is at line number 2 and <cntrl>I is applied, a new line will be inserted between lines 1 and 2. This new line will be labeled line 2. The old line number 2 is renumbered as line 3.

<cntrl>D

The <cntrl>D command deletes the line currently being edited. For example, if the editor is at line number 2 and <cntrl>D is applied, line 2 will be deleted. The previous line number 3 is now renumbered as line number 2.

<cntrl>Q

The <cntrl>Q quits the editor mode. In response, the DMC-41x3 will return a colon.

After the Edit session is over, the user may list the entered program using the LS command. If no operand follows the LS command, the entire program will be listed. The user can start listing at a specific line or label using the operand n. A command and new line number or label following the start listing operand specifies the location at which listing is to stop.

Example:

Instruction	Interpretation
:LS	List entire program
:LS 5	Begin listing at line 5
:LS 5,9	List lines 5 thru 9
:LS #A,9	List line label #A thru line 9
:LS #A, #A +5	List line label #A and additional 5 lines

Chapter 8 Hardware & Software Protection

Introduction

The DMC-41x3 provides several hardware and software features to check for error conditions and to inhibit the motor on error. These features help protect the various system components from damage.

WARNING: Machinery in motion can be dangerous! It is the responsibility of the user to design effective error handling and safety protection as part of the machine. Since the DMC-41x3 is an integral part of the machine, the engineer should design his overall system with protection against a possible component failure on the DMC-41x3. Galil shall not be liable or responsible for any incidental or consequential damages.

Hardware Protection

The DMC-41x3 includes hardware input and output protection lines for various error and mechanical limit conditions. These include:

Output Protection Lines

Amp Enable

This signal goes low when the motor off command is given, when the position error exceeds the value specified by the Error Limit (ER) command, or when off-on-error condition is enabled (OE1) and the abort command is given. Each axis amplifier has separate amplifier enable lines. This signal also goes low when the watch-dog timer is activated, or upon reset.

NOTE: The standard configuration of the AEN signal is high amp enable (HAEN). Both the polarity and the amplitude can be changed. To make these changes, see section entitled Amplifier Enable in Chapter 3..

Error Output

The error output is a TTL signal which indicates an error condition in the controller. This signal is available on the interconnect module as ERR. When the error signal is low, this indicates an error condition and the Error Light on the controller will be illuminated. For details on the reasons why the error output would be active see Error Light (Red LED) in Chapter 9.

Input Protection Lines

General Abort

A low input stops commanded motion instantly without a controlled deceleration. For any axis in which the Off-On-Error function is enabled, the amplifiers will be disabled. This could cause the motor to 'coast' to a stop. If the Off-On-Error function is not enabled, the motor will instantaneously stop and servo at the current position. The Off-On-Error function is further discussed in this chapter.

The Abort input by default will also halt program execution; this can be changed by changing the 5th field of the CN command. See the CN command in the command reference for more information.

Selective Abort

The controller can be configured to provide an individual abort for each axis. Activation of the selective abort signal will act the same as the Abort Input but only on the specific axis. To configure the controller for selective abort, issue the command CN,,,1. This configures the inputs 5,6,7,8,13,14,15,16 to act as selective aborts for axes A,B,C,D,E,F,G,H respectively.

ELO (Electronic Lock Out)

Used in conjunction with Galil amplifiers, this input allows the user the shutdown the amplifier at a hardware level. For more detailed information on how specific Galil amplifiers behave when the ELO is triggered, see Integrated in the Appendices. If using a 5-8 axis controller with two integrated amplifiers, the ELO input on the A-D connector should be used. If an ELO is sensed both amplifiers will act on it, and shut down at a hardware level.

Forward Limit Switch

Low input inhibits motion in forward direction. If the motor is moving in the forward direction when the limit switch is activated, the motion will decelerate and stop. In addition, if the motor is moving in the forward direction, the controller will automatically jump to the limit switch subroutine, #LIMSWI (if such a routine has been written by the user). The CN command can be used to change the polarity of the limit switches. The OE command can also be configured so that the axis will be disabled upon the activation of a limit switch.

Reverse Limit Switch

Low input inhibits motion in reverse direction. If the motor is moving in the reverse direction when the limit switch is activated, the motion will decelerate and stop. In addition, if the motor is moving in the reverse direction, the controller will automatically jump to the limit switch subroutine, #LIMSWI (if such a routine has been written by the user). The CN command can be used to change the polarity of the limit switches. The OE command can also be configured so that the axis will be disabled upon the activation of a limit switch.

Software Protection

The DMC-41x3 provides a programmable error limit as well as encoder failure detection. It is recommended that both the position error and encoder failure detection be used when running servo motors with the DMC-41x3. Along with position error and encoder failure detection, then DMC-41x3 has the ability to have programmable software limit.

Position Error

The error limit can be set for any number between 0 and 2147483647 using the ER n command. The default value for ER is 16384.

Example:

ER 200,300,400,500

Set X-axis error limit for 200, Y-axis error limit to 300, Z-axis error limit to 400 counts, W-axis error limit to 500 counts

ER, 1, , 10

Set Y-axis error limit to 1 count, set W-axis error limit to 10 counts.

The units of the error limit are quadrature counts. The error is the difference between the command position and actual encoder position. If the absolute value of the error exceeds the value specified by ER, the controller will generate several signals to warn the host system of the error condition. These signals include:

Signal or Function	State if Error Occurs
#POSERR	Jumps to automatic excess position error subroutine
Error Light	Turns on
OE Function	Shuts motor off if OE1 or OE3
AEN Output Line	Switches to Motor Off state

The Jump on Condition statement is useful for branching on a given error within a program. The position error of X,Y,Z and W can be monitored during execution using the TE command.

Encoder Failure detection

The encoder failure detection on the controller operates based upon two factors that are user settable, a threshold of motor command output (OV), a time above that threshold (OT) in which there is no more than 4 counts of change on the encoder input for that axis. The encoder failure detection is activated with the OA command. When an encoder failure is detected and OA is set to 1 for that axis, the same conditions will occur as a position error.

Conditions for proper operation of Encoder Failure detection

- The axis must have a non-zero KI setting order to detect an encoder failure when the axis is not profiling.
- The IL command must be set to a value greater than the OV setting
- The TL command must be set to a value greater than the OV setting

Example:

The A axis is setup with the following settings for encoder failure detection:

```
OA 1
OT 500
OV 3
OE 1
ER 1000
```

The A axis is commanded to move 300 counts, but the B channel on the encoder has failed and no longer operates. Because the ER setting is greater than the commanded move, the error will not be detected by using the OE and ER commands, but this condition will be detected as an encoder failure. When the axis is commanded to move a 300 counts, the position error will cause the motor command voltage to be increased to a value that will be greater than the OV value, 3 volts in this case. Once the motor command output is greater than the OV threshold for more than the 500ms defined by the OT command AND there has been less than 4 counts of change on the encoder, then the controller will turn off that axis due to an encoder failure. The motor will have moved some distance during this operation, but it will be shut down before a full runaway condition occurs.

Using Encoder Failure to detect a hard stop or stalled motor

The encoder failure detection can also be used to detect when an axis is up against a hard stop. In this scenario the motor command will be commanded above the OV threshold, but because the motor is not moving the controller will detect this scenario as an encoder failure.

Programmable Position Limits

The DMC-41x3 provides programmable forward and reverse position limits. These are set by the BL and FL software commands. Once a position limit is specified, the DMC-41x3 will not accept position commands beyond the limit. Motion beyond the limit is also prevented.

Example:

DP0,0,0	Define Position
BL -2000,-4000,-8000	Set Reverse position limit
FL 2000,4000,8000	Set Forward position limit
JG 2000,2000,2000	Jog
BG XYZ	Begin

(motion stops at forward limits)

Off-On-Error

The DMC-41x3 controller has a built in function which can turn off the motors under certain error conditions. This function is known as 'Off-On-Error'. To activate the OE function for each axis, specify 1, 2 or 3 for that axis. To disable this function, specify 0 for the axes. When this function is enabled, the specified motor will be disabled under the following 3 conditions:

1. The position error for the specified axis exceeds the limit set with the command, ER
2. A hardware limit is reached
3. The abort command is given
4. The abort input is activated with a low signal.

NOTE: If the motors are disabled while they are moving, they may 'coast' to a stop because they are no longer under servo control.

To re-enable the system, use the Reset (RS) or Servo Here (SH) command.

Examples:

OE 1,1,1,1	Enable off-on-error for X,Y,Z and W
OE 0,1,0,1	Enable off-on-error for Y and W axes and disable off-on-error for X and Z axes
OE 2,3	Enable off-on-error for limit switch for the X axis, and position error (or abort input) and limit switch for the Y axis

Automatic Error Routine

The #POSERR label causes the statements following to be automatically executed if error on any axis exceeds the error limit specified by ER, a encoder failure is detected, or the abort input is triggered. The error routine must be closed with the RE command. The RE command returns from the error subroutine to the main program.

NOTE: The Error Subroutine will be entered again unless the error condition is cleared.

Example:

#A;JP #A;EN	"Dummy" program
#POSERR	Start error routine on error
MG "error"	Send message
SB 1	Fire relay
STX	Stop motor
AMX	After motor stops
SHX	Servo motor here to clear error
RE	Return to main program

Limit Switch Routine

The DMC-41x3 provides forward and reverse limit switches which inhibit motion in the respective direction. There is also a special label for automatic execution of a limit switch subroutine. The #LIMSWI label specifies the start of the limit switch subroutine. This label causes the statements following to be automatically executed if any limit switch is activated and that axis motor is moving in that direction. The RE command ends the subroutine.

The state of the forward and reverse limit switches may also be tested during the jump-on-condition statement. The _LR condition specifies the reverse limit and _LF specifies the forward limit. X,Y,Z, or W following LR or LF specifies the axis. The CN command can be used to configure the polarity of the limit switches.

Limit Switch Example:

#A; JP #A; EN	Dummy Program
#LIMSWI	Limit Switch Utility
V1= _LFX	Check if forward limit
V2= _LRX	Check if reverse limit
JP#LF, V1=0	Jump to #LF if forward
JP#LR, V2=0	Jump to #LR if reverse
JP#END	Jump to end
#LF	#LF
MG "FORWARD LIMIT"	Send message
STX; AMX	Stop motion
PR-1000; BGX; AMX	Move in reverse
JP#END	End
#LR	#LR
MG "REVERSE LIMIT"	Send message
STX; AMX	Stop motion
PR1000; BGX; AMX	Move forward
#END	End
RE	Return to main program

Chapter 9 Troubleshooting

Overview

The following discussion may help you get your system to work.

Potential problems have been divided into groups as follows:

1. Installation
2. Stability and Compensation
3. Operation
4. Error Light (Red LED)

The various symptoms along with the cause and the remedy are described in the following tables.

Installation

SYMPTOM	DIAGNOSIS	CAUSE	REMEDY
Motor runs away with no connections from controller to amplifier input.	Adjusting offset causes the motor to change speed.	1. Amplifier has an internal offset.	Adjust amplifier offset. Amplifier offset may also be compensated by use of the offset configuration on the controller (see the OF command).
		2. Damaged amplifier.	Replace amplifier.
Motor is enabled even when MO command is given	The SH command disables the motor	1. The amplifier requires the a different Amplifier Enable setting on the Interconnect Module	Refer to Chapter 3 or contact Galil.
Unable to read main or auxiliary encoder input.	The encoder does not work when swapped with another encoder input.	1. Wrong encoder connections.	Check encoder wiring. For single ended encoders (CHA and CHB only) do not make any connections to the CHA- and CHB- inputs.
		2. Encoder is damaged	Replace encoder
		3. Encoder configuration incorrect.	Check CE command
Unable to read main or auxiliary encoder input.	The encoder works correctly when swapped with another encoder input.	1. Wrong encoder connections.	Check encoder wiring. For single ended encoders (MA+ and MB+ only) do not make any connections to the MA- and MB- inputs.
		2. Encoder configuration incorrect.	Check CE command
		3. Encoder input or controller is damaged	Contact Galil
Encoder Position Drifts	Swapping cables fixes the problem	1. Poor Connections / intermittent cable	Review all connections and connector contacts.

Encoder Position Drifts	Significant noise can be seen on MA+ and / or MB+ encoder signals	1. Noise	Shield encoder cables Avoid placing power cables near encoder cables Avoid Ground Loops Use differential encoders Use $\pm 12V$ encoders
-------------------------	---	----------	--

Stability

SYMPTOM	DIAGNOSIS	CAUSE	REMEDY
Servo motor runs away when the loop is closed.	Reversed Motor Type corrects situation (MT -1)	Wrong feedback polarity.	Reverse Motor or Encoder Wiring (remember to set Motor Type back to default value: MT 1)
Motor oscillates.		Too high gain or too little damping.	Decrease KI and KP. Increase KD.

Operation

SYMPTOM	DIAGNOSIS	CAUSE	REMEDY
Controller rejects commands.	Response of controller from TC1 diagnoses error.	Anything	Correct problem reported by TC1
Motor Doesn't Move	Response of controller from TC1 diagnoses error.	Anything	Correct problem reported by SC

Error Light (Red LED)

The red error LED has multiple meanings for Galil controllers. Here is a list of reasons the error light will come on and possible solutions:

Under Voltage

If the controller is not receiving enough voltage to power up.

Under Current

If the power supply does not have enough current, the red LED will cycle on and off along with the green power LED.

Position Error

If any axis that is set up as a servo (MT command) has a position error value (TE) that exceeds the error limit (ER) - the error light will come on to signify there is an axis that has exceeded the position error limit. Use a DP*=0 to set all encoder positions to zero or a SH (Servo Here) command to eliminate position error.

Invalid Firmware

If the controller is interrupted during a firmware update or an incorrect version of firmware is installed - the error light will come on. The prompt will show up as a greater than sign ">" instead of the standard colon ":" prompt. Use GDK software to install the correct version of firmware to fix this problem.

Self Test

During the first few seconds of power up, it is normal for the red LED to turn on while it is performing a self test. If the self test detects a problem such as corrupted memory or damaged hardware - the error light will stay on to signal a problem with the board. To fix this problem, a Master Reset may be required. The Master Reset will set

the controller back to factory default conditions so it is recommended that all motor and I/O cables be removed for safety while performing the Master Reset. Cables can be plugged back in after the correct settings have been loaded back to the controller (when necessary). To perform a Master Reset - find the jumper location labeled MR or MRST on the controller and put a jumper across the two pins. Power up with the jumper installed. The Self-Test will take slightly longer - up to 5seconds. After the error light shuts off, it is safe to power down and remove the Master Reset jumper. If performing a Master Reset does not get rid of the error light, the controller may need to be sent back to the factory to be repaired. Contact Galil for more information.

Chapter 10 Theory of Operation

Overview

The following discussion covers the operation of motion control systems. A typical motion control system consists of the elements shown in Figure 10.1.




Figure 10.1: Elements of Servo Systems

The operation of such a system can be divided into three levels , the levels are:

1. Closing the Loop
2. Motion Profiling
3. Motion Programming

The first level, the closing of the loop, assures that the motor follows the commanded position. This is done by closing the position loop using a sensor. The operation at the basic level of closing the loop involves the subjects of modeling, analysis, and design. These subjects will be covered in the following discussions.

The motion profiling is the generation of the desired position function. This function, $R(t)$, describes where the motor should be at every sampling period. Note that the profiling and the closing of the loop are independent functions. The profiling function determines where the motor should be and the closing of the loop forces the motor to follow the commanded position

The highest level of control is the motion program. This can be stored in the host computer or in the controller. This program describes the tasks in terms of the motors that need to be controlled, the distances and the speed.

The three levels of control may be viewed as different levels of management. The top manager, the motion program, may specify the following instruction, for example.

```
PR 6000,4000
SP 20000,20000
AC 200000,00000
BG X
AD 2000
BG Y
EN
```

This program corresponds to the velocity profiles shown in Figure 10.2. Note that the profiled positions show where the motors must be at any instant of time.

Finally, it remains up to the servo system to verify that the motor follows the profiled position by closing the servo loop.

The following section explains the operation of the servo system. First, it is explained qualitatively, and then the explanation is repeated using analytical tools for those who are more theoretically inclined.




Figure 10.2: Velocity and Position Profiles

Operation of Closed-Loop Systems

To understand the operation of a servo system, we may compare it to a familiar closed-loop operation, adjusting the water temperature in the shower. One control objective is to keep the temperature at a comfortable level, say 90 degrees F. To achieve that, our skin serves as a temperature sensor and reports to the brain (controller). The brain compares the actual temperature, which is called the feedback signal, with the desired level of 90 degrees F. The difference between the two levels is called the error signal. If the feedback temperature is too low, the error is positive, and it triggers an action which raises the water temperature until the temperature error is reduced sufficiently.

The closing of the servo loop is very similar. Suppose that we want the motor position to be at 90 degrees. The motor position is measured by a position sensor, often an encoder, and the position feedback is sent to the controller. Like the brain, the controller determines the position error, which is the difference between the commanded position of 90 degrees and the position feedback. The controller then outputs a signal that is proportional to the position error. This signal produces a proportional current in the motor, which causes a motion until the error is reduced. Once the error becomes small, the resulting current will be too small to overcome the friction, causing the motor to stop.

The analogy between adjusting the water temperature and closing the position loop carries further. We have all learned the hard way, that the hot water faucet should be turned at the “right” rate. If you turn it too slowly, the temperature response will be slow, causing discomfort. Such a slow reaction is called over-damped response.

The results may be worse if we turn the faucet too fast. The overreaction results in temperature oscillations. When the response of the system oscillates, we say that the system is unstable. Clearly, unstable responses are bad when we want a constant level.

What causes the oscillations? The basic cause for the instability is a combination of delayed reaction and high gain. In the case of the temperature control, the delay is due to the water flowing in the pipes. When the human reaction is too strong, the response becomes unstable.

Servo systems also become unstable if their gain is too high. The delay in servo systems is between the application of the current and its effect on the position. Note that the current must be applied long enough to cause a significant effect on the velocity, and the velocity change must last long enough to cause a position change. This delay, when coupled with high gain, causes instability.

This motion controller includes a special filter which is designed to help the stability and accuracy. Typically, such a filter produces, in addition to the proportional gain, damping and integrator. The combination of the three functions is referred to as a PID filter.

The filter parameters are represented by the three constants K_P , K_I and K_D , which correspond to the proportional, integral and derivative term respectively.

The damping element of the filter acts as a predictor, thereby reducing the delay associated with the motor response.

The integrator function, represented by the parameter K_I , improves the system accuracy. With the K_I parameter, the motor does not stop until it reaches the desired position exactly, regardless of the level of friction or opposing torque.

The integrator also reduces the system stability. Therefore, it can be used only when the loop is stable and has a high gain.

The output of the filter is applied to a digital-to-analog converter (DAC). The resulting output signal in the range between +10 and -10 Volts is then applied to the amplifier and the motor.

The motor position, whether rotary or linear is measured by a sensor. The resulting signal, called position feedback, is returned to the controller for closing the loop.

The following section describes the operation in a detailed mathematical form, including modeling, analysis and design.

System Modeling

The elements of a servo system include the motor, driver, encoder and the controller. These elements are shown in Figure 10.3. The mathematical model of the various components is given below.




Figure 10.3: Functional Elements of a Motion Control System

Motor-Amplifier

The motor amplifier may be configured in three modes:

1. Voltage Drive
2. Current Drive
3. Velocity Loop

The operation and modeling in the three modes is as follows:

Voltage Drive

The amplifier is a voltage source with a gain of K_v [V/V]. The transfer function relating the input voltage, V , to the motor position, P , is

$$P/V = K_v / [K_t S (ST_m + 1) (ST_e + 1)]$$

where

$$T_m = RJ / K_t^2 \quad [s]$$

and

$$T_e = L / R \quad [s]$$

and the motor parameters and units are

K_t	Torque constant [Nm/A]
R	Armature Resistance Ω
J	Combined inertia of motor and load [kg m ²]
L	Armature Inductance [H]

When the motor parameters are given in English units, it is necessary to convert the quantities to MKS units. For example, consider a motor with the parameters:

$$K_t = 14.16 \text{ oz} \cdot \text{in}/\text{A} = 0.1 \text{ Nm}/\text{A}$$

$$R = 2 \Omega$$

$$J = 0.0283 \text{ oz} \cdot \text{in} \cdot \text{s}^2 = 2 \cdot 10^{-4} \text{ kg} \cdot \text{m}^2$$

$$L = 0.004 \text{ H}$$

Then the corresponding time constants are

$$T_m = 0.04 \text{ sec}$$

and

$$T_e = 0.002 \text{ sec}$$

Assuming that the amplifier gain is $K_v = 4$, the resulting transfer function is

$$P/V = 40 / [s(0.04s+1)(0.002s+1)]$$

Current Drive

The current drive generates a current I , which is proportional to the input voltage, V , with a gain of K_a . The resulting transfer function in this case is

$$P/V = K_a K_t / Js^2$$

where K_t and J are as defined previously. For example, a current amplifier with $K_a = 2 \text{ A}/\text{V}$ with the motor described by the previous example will have the transfer function:

$$P/V = 1000/s^2 \text{ [rad/V]}$$

If the motor is a DC brushless motor, it is driven by an amplifier that performs the commutation. The combined transfer function of motor amplifier combination is the same as that of a similar brush motor, as described by the previous equations.

Velocity Loop

The motor driver system may include a velocity loop where the motor velocity is sensed by a tachometer and is fed back to the amplifier. Such a system is illustrated in Figure 10.4. Note that the transfer function between the input voltage V and the velocity ω is:

$$\omega / V = [K_a K_t / Js] / [1 + K_a K_t K_g / Js] = 1 / [K_g (sT_1 + 1)]$$

where the velocity time constant, T_1 , equals

$$T_1 = J / K_a K_t K_g$$

This leads to the transfer function

$$P/V = 1 / [K_g s(sT_1 + 1)]$$






Figure 10.4: Elements of velocity loops

The resulting functions derived above are illustrated by the block diagram of Figure 10.5.

VOLTAGE SOURCE



CURRENT SOURCE



VELOCITY LOOP




Figure 10.5: Mathematical model of the motor and amplifier in three operational modes

Encoder

The encoder generates N pulses per revolution. It outputs two signals, Channel A and B, which are in quadrature. Due to the quadrature relationship between the encoder channels, the position resolution is increased to $4N$ quadrature counts/rev.

The model of the encoder can be represented by a gain of

$$K_f = 4N/2\pi \quad [\text{count/rad}]$$

For example, a 1000 lines/rev encoder is modeled as

$$K_f = 638$$

DAC

The DAC or D-to-A converter converts a 16-bit number to an analog voltage. The input range of the numbers is 65536 and the output voltage range is $\pm 10\text{V}$ or 20V . Therefore, the effective gain of the DAC is

$$K = 20/65536 = 0.0003 \text{ [V/count]}$$

Digital Filter

The digital filter has three element in series: PID, low-pass and a notch filter. The transfer function of the filter. The transfer function of the filter elements are:

$$\text{PID} \quad D(z) = \frac{K(Z-A)}{Z} + \frac{CZ}{Z-1}$$

$$\text{Low-pass} \quad L(z) = \frac{1-B}{Z-B}$$

$$\text{Notch} \quad N(z) = \frac{(Z-z)(Z-z)}{(Z-p)(Z-p)}$$

The filter parameters, K, A, C and B are selected by the instructions KP, KD, KI and PL, respectively. The relationship between the filter coefficients and the instructions are:

$$\begin{aligned} K &= (KP + KD) \\ A &= KD/(KP + KD) \\ C &= KI \\ B &= PL \end{aligned}$$

The PID and low-pass elements are equivalent to the continuous transfer function $G(s)$.

$$G(s) = (P + sD + I/s) \cdot a / (s + a)$$

where,

$$\begin{aligned} P &= KP \\ D &= T \cdot KD \\ I &= KI/T \end{aligned}$$

$$a = \frac{1}{T} \ln \left(\frac{1}{B} \right)$$

where T is the sampling period, and B is the pole setting

For example, if the filter parameters of the DMC-41x3 are

$$\begin{aligned} KP &= 16 \\ KD &= 144 \\ KI &= 2 \\ PL &= 0.75 \\ T &= 0.001 \text{ s} \end{aligned}$$

the digital filter coefficients are

$K = 160$
 $A = 0.9$
 $C = 2$
 $a = 250 \text{ rad/s}$

and the equivalent continuous filter, $G(s)$, is

$$G(s) = [16 + 0.144s + 2000/s] \cdot 250 / (s+250)$$

The notch filter has two complex zeros, z and $\bar{z}$, and two complex poles, p and $\bar{p}$.

The effect of the notch filter is to cancel the resonance affect by placing the complex zeros on top of the resonance poles. The notch poles, P and p , are programmable and are selected to have sufficient damping. It is best to select the notch parameters by the frequency terms. The poles and zeros have a frequency in Hz, selected by the command NF. The real part of the poles is set by NB and the real part of the zeros is set by NZ.

The most simple procedure for setting the notch filter, identify the resonance frequency and set NF to the same value. Set NB to about one half of NF and set NZ to a low value between zero and 5.

ZOH

The ZOH, or zero-order-hold, represents the effect of the sampling process, where the motor command is updated once per sampling period. The effect of the ZOH can be modeled by the transfer function

$$H(s) = 1/(1+sT/2)$$

If the sampling period is $T = 0.001$, for example, $H(s)$ becomes:

$$H(s) = 2000/(s+2000)$$

However, in most applications, $H(s)$ may be approximated as one.

This completes the modeling of the system elements. Next, we discuss the system analysis.

System Analysis

To analyze the system, we start with a block diagram model of the system elements. The analysis procedure is illustrated in terms of the following example.

Consider a position control system with the DMC-41x3 controller and the following parameters:

$K_t = 0.1$	Nm/A	Torque constant
$J = 2 \cdot 10^{-4}$	kg.m ²	System moment of inertia
$R = 2$	Ω	Motor resistance
$K_a = 4$	Amp/Volt	Current amplifier gain
$K_P = 12.5$		Digital filter gain
$K_D = 245$		Digital filter zero
$K_I = 0$		No integrator
$N = 500$	Counts/rev	Encoder line density
$T = 1$	ms	Sample period

The transfer function of the system elements are:

Motor

$$M(s) = P/I = K_t/Js^2 = 500/s^2 \text{ [rad/A]}$$

Amp

$$K_a = 4 \text{ [Amp/V]}$$

DAC

$$K_d = 0.0003 \text{ [V/count]}$$

Encoder

$$K_f = 4N/2\pi = 318 \text{ [count/rad]}$$

ZOH

$$2000/(s+2000)$$

Digital Filter

$$K_P = 12.5, K_D = 245, T = 0.001$$

Therefore,

$$D(z) = 1030 (z-0.95)/Z$$

Accordingly, the coefficients of the continuous filter are:

$$P = 50$$

$$D = 0.98$$

The filter equation may be written in the continuous equivalent form:

$$G(s) = 50 + 0.98s = 0.098 (s+51)$$

The system elements are shown in Figure 10.6.




Figure 10.6: Mathematical model of the control system

The open loop transfer function, $A(s)$, is the product of all the elements in the loop.

$$A(s) = 390,000 (s+51)/[s^2(s+2000)]$$

To analyze the system stability, determine the crossover frequency, ω_c at which $A(j\omega_c)$ equals one. This can be done by the Bode plot of $A(j\omega_c)$, as shown in Figure 10.7.




Figure 10.7: Bode plot of the open loop transfer function

For the given example, the crossover frequency was computed numerically resulting in 200 rad/s.

Next, we determine the phase of $A(s)$ at the crossover frequency.

$$A(j200) = 390,000 (j200+51)/[(j200)^2 \cdot (j200 + 2000)]$$

$$\alpha = \text{Arg}[A(j200)] = \tan^{-1}(200/51) - 180^\circ - \tan^{-1}(200/2000)$$

$$\alpha = 76^\circ - 180^\circ - 6^\circ = -110^\circ$$

Finally, the phase margin, PM, equals

$$\text{PM} = 180^\circ + \alpha = 70^\circ$$

As long as PM is positive, the system is stable. However, for a well damped system, PM should be between 30° and 45° . The phase margin of 70° given above indicated over-damped response.

Next, we discuss the design of control systems.

System Design and Compensation

The closed-loop control system can be stabilized by a digital filter, which is preprogrammed in the DMC-41x3 controller. The filter parameters can be selected by the user for the best compensation. The following discussion presents an analytical design method.

The Analytical Method

The analytical design method is aimed at closing the loop at a crossover frequency, ω_c , with a phase margin PM. The system parameters are assumed known. The design procedure is best illustrated by a design example.

Consider a system with the following parameters:

$K_t = 0.2$	Nm/A	Torque constant
$J = 2 \times 10^{-4}$	kg.m ²	System moment of inertia
$R = 2$	Ω	Motor resistance
$K_a = 2$	Amp/Volt	Current amplifier gain
$N = 1000$	Counts/rev	Encoder line density

The DAC of the DMC-41x3 outputs $\pm 10V$ for a 16-bit command of ± 32768 counts.

The design objective is to select the filter parameters in order to close a position loop with a crossover frequency of $\omega_c = 500$ rad/s and a phase margin of 45 degrees.

The first step is to develop a mathematical model of the system, as discussed in the previous system.

Motor

$$M(s) = P/I = K_t/Js^2 = 1000/s^2$$

Amp

$$K_a = 2 \quad [\text{Amp/V}]$$

DAC

$$K_d = 10/32768 = .0003$$

Encoder

$$K_f = 4N/2\pi = 636$$

ZOH

$$H(s) = 2000/(s+2000)$$

Compensation Filter

$$G(s) = P + sD$$

The next step is to combine all the system elements, with the exception of $G(s)$, into one function, $L(s)$.

$$L(s) = M(s) K_a K_d K_f H(s) = 3.17 \cdot 10^6 / [s^2(s+2000)]$$

Then the open loop transfer function, $A(s)$, is

$$A(s) = L(s) G(s)$$

Now, determine the magnitude and phase of $L(s)$ at the frequency $\omega_c = 500$.

$$L(j500) = 3.17 \cdot 10^6 / [(j500)^2 (j500+2000)]$$

This function has a magnitude of

$$|L(j500)| = 0.00625$$

and a phase

$$\text{Arg}[L(j500)] = -180^\circ - \tan^{-1}[500/2000] = -194^\circ$$

$G(s)$ is selected so that $A(s)$ has a crossover frequency of 500 rad/s and a phase margin of 45 degrees. This requires that

$$\begin{aligned} |A(j500)| &= 1 \\ \text{Arg}[A(j500)] &= -135^\circ \end{aligned}$$

However, since

$$A(s) = L(s) G(s)$$

then it follows that $G(s)$ must have magnitude of

$$|G(j500)| = |A(j500)/L(j500)| = 160$$

and a phase

$$\arg[G(j500)] = \arg[A(j500)] - \arg[L(j500)] = -135^\circ + 194^\circ = 59^\circ$$

In other words, we need to select a filter function $G(s)$ of the form

$$G(s) = P + sD$$

so that at the frequency $\omega_c = 500$, the function would have a magnitude of 160 and a phase lead of 59 degrees.

These requirements may be expressed as:

$$|G(j500)| = |P + (j500D)| = 160$$

and

$$\arg[G(j500)] = \tan^{-1}[500D/P] = 59^\circ$$

The solution of these equations leads to:

$$\begin{aligned} P &= 160 \cos 59^\circ = 82.4 \\ 500D &= 160 \sin 59^\circ = 137 \end{aligned}$$

Therefore,

$$D = 0.274$$

and

$$G = 82.4 + 0.274s$$

The function G is equivalent to a digital filter of the form:

$$D(z) = KP + KD(1-z^{-1})$$

where

$$P = KP$$

$$D = KD \cdot T$$

and

$$KD = D/T$$

Assuming a sampling period of $T=1\text{ms}$, the parameters of the digital filter are:

$$KP = 82.4$$

$$KD = 274$$

The DMC-41x3 can be programmed with the instruction:

$$KP \ 82.4$$

$$KD \ 274$$

In a similar manner, other filters can be programmed. The procedure is simplified by the following table, which summarizes the relationship between the various filters.

Equivalent Filter Form - DMC-41x3

Digital	$D(z) = [K(z-A/z) + Cz/(z-1)] \cdot (1-B)/(Z-B)$
---------	--

$$KP, KD, KI, PLK = (KP + KD)$$

$$A = KD/(KP+KD)$$

$$C = KI$$

$$B = PL$$

Digital	$D(z) = [KP + KD(1-z^{-1}) + KI/2(1-z^{-1})] \cdot (1-PL)/(Z-PL)$
---------	---

Continuous	$G(s) = (P + Ds + I/s) \cdot a/(s+a)$
------------	---------------------------------------

PID, T	$P = KP$
--------	----------

$$D = T \cdot KD$$

$$I = KI / T$$

$$a = 1/T \ln(1/PL)$$

Appendices

Electrical Specifications

NOTE	Electrical specifications are only valid once controller is out of reset.
-------------	---

Servo Control

Motor command line	±10 V analog signal Resolution: 16-bit DAC or 0.0003 volts 3 mA maximum. Output impedance – 500 Ω
Main and auxiliary encoder inputs	TTL compatible, but can accept up to ±12 volts Quadrature phase on CHA, CHB Single-ended or differential Maximum A, B edge rate: 15 MHz Minimum IDX pulse width: 39 nsec

Stepper Control

STPn (Step)	TTL (0-5 volts) level at 50% duty cycle. 3,000,000 pulses/sec maximum frequency
DIRn (Direction)	TTL (0-5 volts)

Input / Output

Opto-isolated Inputs: DI[16:1]*, Limit switches, home, abort, reset	2.2 kΩ in series with opto-isolator Active high or low requires at least 1mA to activate. Once activated, the input requires the current to go below 0.5mA. All Limit Switch and Home inputs use one common voltage (LSCOM) which can accept up to 24 volts. Voltages above 24 volts require an additional resistor. ≥ 1 mA = ON; ≤ 0.5 mA = OFF *[8:1] for 1-4 axes models, [16:1] for 5-8 axes models
Analog Inputs: AI[8:1]	±10 volts 12-Bit Analog-to-Digital converter 16-bit optional
Digital Outputs: DO[16:1]*	4mA sinking (25mA sinking/sourcing and 500mA sourcing options) *[8:1] for 1-4 axes models, [16:1] for 5-8 axes models
Auxiliary Inputs as Uncommitted Inputs: DI[96:81]*	The auxiliary pins can be used as uncommitted inputs and are assigned to the following bits: - Axis A: DI81, DI82 - Axis B: DI83, DI84 - Axis C: DI85, DI86 - Axis D: DI87, DI88 - Axis E: DI89, DI90 - Axis F: DI91, DI92 - Axis G: DI93, DI94 - Axis H: DI95, DI96 These inputs have the same specifications as listed above for encoder inputs. *The number of auxiliary inputs is dependent on the number of axes ordered

Power Requirements

20-80 V _{DC}	10 W at 25° C
-----------------------	---------------

+5, ±12V Power Output Specifications

Output Voltage	Tolerance	Max Current Output
+5V	±5%	1.1A
+12V	±5%	40mA
-12V	±5%	40mA

Performance Specifications

Minimum Servo Loop Update Time	
DMC-4113	125 μ sec
DMC-4123	125 μ sec
DMC-4133	250 μ sec
DMC-4143	250 μ sec
DMC-4153	375 μ sec
DMC-4163	375 μ sec
DMC-4173	500 μ sec
DMC-4183	500 μ sec
Position Accuracy	± 1 quadrature count
Velocity Accuracy	
Long Term	Phase-locked, better than 0.005%
Short Term	System dependent
Position Range	± 2147483647 counts per move
Velocity Range	Up to 15,000,000 counts/sec servo; 3,000,000 pulses/sec-stepper
Velocity Resolution	2 counts/sec
Motor Command Resolution	16 bit or 0.0003 V
Variable Range	± 2 billion
Variable Resolution	1×10^{-4}
Number of Variables	510
Array Size	24000 elements, 30 arrays
Program Size	4000 lines x 80 characters

Ordering Options

Overview

The DMC-41x3 can be ordered in many different configurations and with different options. This section provides information regarding the different options available on the DMC-41x3 motion controller, axis-specific options, and internal amplifiers. For information on pricing and how to order your controller with these options, see our DMC-41x3 part number generator on our website.

<http://galil.com/order/part-number-generator/dmc-41x3>

DMC and Form Factor , “DMC-41x3-XXXX(Y)” Options

The following options are the “-XXXX” form factor options that determine how the DMC-41x3 product will be delivered. See TABLE for example images.

CARD

This is the default option if none is specified and no internal amplifier is being used. If an internal amplifier is being used, the BOXn (where n stands for 4 or 8) option is required.

Part number ordering example: DMC-4153-CARD

BOX4, BOX8

The BOX4 or BOX8 option on the DMC-41x3 provides a metal enclosure for the controller. BOX4 is the box for the 1-4 axis controllers, the BOX8 is for 5-8 axis controllers. The BOXn option is required when using Galil internal amplifiers and is recommended for any application that requires CE certification.

Part number ordering example: DMC-4113-BOX4

The following options are the “Y” configuration options that can be added to the DMC part number. Often, multiple Y-options can be ordered per board as long as they're separated by a comma:

DIN – DIN Rail Mounting

The DIN option on the DMC-41x3 motion controller provides DIN rail mounts on the base of the controller. This will allow the controller to be mounted to any standard DIN rail. Requires BOX4 or BOX8 option.

Part number ordering example: DMC-4113-BOX4-DIN

12V – Power Controller with 12VDC

The 12V option allows the controller to be powered with a regulated 12V supply. The tolerance of the 12V input must be within $\pm 5\%$. If ordered with an internal amplifier, the 12V will automatically be upgraded to the ISCNTL option, see ISCNTL – Isolate Controller Power, pg 168. The controller will be powered through the 2-pin Molex connector on the front face of the controller. Molex connector part numbers and power connector pin-outs can be found here: Power Connector Part Numbers, pg 172.

Part number ordering example: DMC-4113-CARD(12V)

-16 bit – 16 bit Analog Inputs

The -16 bit option provides 16 bit analog inputs on the DMC-41x3 motion controller. The standard resolution of the analog inputs is 12 bits.

Part number ordering example: DMC-4113-CARD(-16bit)

4-20mA – 4-20mA analog inputs

The 4-20mA option converts all 8 analog inputs into 4-20mA analog inputs. This is accomplished by installing 475Ω precision resistors between the analog inputs and ground. When using this option the analog inputs should be configured for 0-10V analog inputs using the AQ command (AQ n,4). The equation for calculating the current is:

$$I_{ma} = 2.105 V$$

Where I_{ma} = current in mA

V = Voltage reading from DMC-41x3

Part number ordering example:

DMC-4113-CARD(4-20mA)

TRES – Encoder Termination Resistors

The TRES option provides termination resistors on all of the main and auxiliary encoder inputs on the DMC-41x3 motion controller. The termination resistors are 120 Ω, and are placed between the positive and negative differential inputs on the Main A, B, Index channels as well as the Auxiliary A and B channels as in Figure A.1.




Figure A.1: Encoder Inputs with -TRES option

NOTE: Single ended encoders will not operate correctly with the termination resistors installed. If a combination of differential encoder inputs with termination resistors and single ended encoders is required on the same controller, contact Galil directly.

Part number ordering example:

DMC-4113-CARD(TRES)

ISCNTL – Isolate Controller Power

The ISCNTL option isolates the power input for the controller from the power input of the amplifiers. With this option, the power is brought in through the 2 pin Molex connector on the front face of the controller. This option is only valid when Galil amplifiers are ordered with the DMC-41x3. Molex connector part numbers and power connector pin-outs can be found here: Power Connector Part Numbers, pg 172

Part number ordering example:

DMC-4113-BOX4(ISCNTL)-D3020

RS-422 – Auxiliary Serial Port Serial Communication

The default serial configuration for the DMC-41x3 is to have RS-232 communication on the Aux (P2) serial port. The controller can be ordered to have RS-422 for this port. RS-422 communication is a differentially driven serial communication protocol that should be used when long distance serial communication is required in an application.

See the JP1 - Jumper Description for DMC-41x3 section for termination resistor options for CTS and RXD signals.

RS-422-Auxiliary Port

Standard connector and cable when DMC-41x3 is ordered with RS-422 Option.

Pin	Signal
1	CTS-
2	RXD-
3	TXD-
4	RTS-
5	GND
6	CTS+
7	RXD+
8	TXD+
9	RTS+

Part number ordering example: DMC-4113-CARD(P2422)

ETL – ETL Certified DMC-41x3

The DMC-41x3 can be ordered in a configuration that is ETL listed. ETL Mark is shown in Figure A.2.



Figure A.2: ETL Mark with (ETL) Option

Part number ordering example: DMC-4143-BOX4(ETL)

MO – Motor Off Jumpers Installed

When a jumper is installed on the “MO” pins, the controller will be powered up in the “motor off” state. This option will cause jumper to be installed at the factory.

Part number ordering example: DMC-4123-BOX4(MO)-D3520

INVELO – Inverted ELO (Electronic Lock-Out) Logic

This option will invert the logic for the ELO input. With this option, current flowing through the ELO circuit (normally closed) is normal operation and will allow Galil internal amplifiers to be powered. An open circuit or no current flowing will activate the ELO and cut power to the amplifier. If a 5 thru 8 axis unit is ordered, the inverted logic will apply to both amplifiers.

Part number ordering example: DMC-4123-BOX4(INVELO)-D3520

Axis-specific, “-ABDC(Y), -EFGH(Y)” Options

The following options are the “Y” configuration options that can be added to the axis-specific part numbers. Often, multiple Y-options can be ordered per bank of 4 axis as long as they're separated by a comma.

SER – BiSS and SSI Absolute Encoder Interface

The DMC-41x3 controller can be configured to support BiSS and SSI encoders. See the SS and SI commands in the DMC-41x3 Command Reference (<http://galil.com/download/comref/com4103/index.html>). Pin-out information is shown below:

Jn1 - Encoder 26 pin HD D-Sub Connector (SER option)

Pin #	Label	Description	Pin #	Label	Description
1	HALC	Hall C	14	FLS	Forward Limit Switch Input
2	AEN	Amplifier Enable	15	AB+	Data + (Dn+ or SLO+)
3	DIR	Direction	16	MI-	I- Index Pulse Input
4	HOM	Home	17	MB+	B+ Main Encoder Input
5	LSCOMn	Limit Switch Common ²	18	GND	Digital Ground ¹
6	AA-	Clock - (Cn- or MA-)	19	MCMD	Motor Command
7	MI+	I+ Index Pulse Input	20	ENBL+	Amp Enable Power
8	MA-	A- Main Encoder Input	21	HALA	Hall A
9	+5V	+5V	22	RLS	Reverse Limit Switch Input
10	GND	Digital Ground ¹	23	AB-	Data - (Dn- or SLO-)
11	ENBL-	Amp Enable Return	24	AA+	Clock + (Cn+ or MA+)
12	HALB	Hall B	25	MB-	B- Main Encoder Input
13	STP	Step	26	MA+	A+ Main Encoder Input

¹ Only one ground pin must be connected to the encoders digital ground signal.

² LSCOMn on JA1, JB1, JC1 and JD1 is common to LSCOM0 on J5
LSCOMn on JE1, JF1, JG1 and JH1 is common to LSCOM1 on J8

LSNK – 25mA Sinking Outputs

The LSNK option modifies the digital outputs on the DMC-41x3 to be capable of sinking up to 25mA per output. For detailed information see the 25mA Sinking Optoisolated Outputs (LSNK) section in Chapter 3 Connecting Hardware.

Part number ordering example: DMC-4113-CARD-ABCD(LSNK)

LSRC – 25mA Sourcing Outputs

The LSRC option modifies the digital outputs on the DMC-41x3 to be capable of sourcing up to 25mA per output. For detailed information see the 25mA Sourcing Optoisolated Outputs (LSRC) section in Chapter 3 Connecting Hardware.

Part number ordering example: DMC-4113-CARD-ABCD(LSRC)

HSRC – 500mA Sourcing Outputs

The HSRC option modifies the digital outputs on the DMC-41x3 to be capable of sourcing up to 500mA per output. For detailed information see the 500mA Sourcing Optoisolated Outputs (HSRC) section in Chapter 3 Connecting Hardware.

Part number ordering example: DMC-4113-CARD-ABCD(HSRC)

AMP/SDM, “-DXXXX(Y)” Internal Amplifier Options

The following options are the “Y” configuration options that can be added to the -DXXXX(Y) amplifier part number. Often, multiple Y-options can be ordered per board as long as they're separated by a comma.

ISAMP – Isolation of power between each AMP amplifier

The ISAMP option separates the power pass-through between the Axes 1-4 amplifier and the Axes 5-8 amplifier. This allows the 2 internal amplifiers to be powered at separate voltages.

If the ISCNLT option is NOT ordered on the DMC-41x3, the amplifier with the higher bus voltage will automatically power the controller. The amplifier with the higher voltage, and the voltage level does not have to be specified during time of purchase as long as the voltage falls within the range of 20-80VDC.

This option is only valid on the 5-8 Axes amplifier board.

Part number ordering example: DMC-4183-BOX8-D3040-D3040-ISAMP

SR90 – SR-49000 Shunt Regulator Option

The SR-49000 is a shunt regulator for the DMC-41x3 controller and internal amplifiers. This option is highly recommended for any application where there is a large inertial load, or a gravitational load. To calculate if your system requires a Shunt Regulator, see Application Note #5448: “Shunt Regulator Operation” linked below:

<http://galil.com/download/application-note/note5448.pdf>

The SR-49000 is installed inside the box of the DMC-41x3 controller, so it does not effect the form of the unit.

As a functional example, -SR90 shunt regulator activates when the voltage supplied to the amplifier rises above 90V. When activated, the power from the power supply is dissipated through a 5 Ω , 20W power resistor.

When used a 5-8 axis controller with two internal amplifiers, the -SR90 option can protect both internal amplifiers. However, with an -ISAMP (ISAMP – Isolation of power between each AMP amplifier) option, the -SR90 option will only protect the first four axis with internal amplifiers.

Part number ordering example: DMC-4143-BOX4-D3040-SR90

SSR – Solid State Relay Option for AMP-43140

The SSR option configures the AMP-43140 (-D3140) with Solid State Relays on the motor power leads that are engaged and disengaged when the amplifier is enabled and disabled. See the -SSR Option in the AMP-43140 section of the Appendix for more information.

This option is only valid with the AMP-43140.

Part number ordering example: DMC-4143-BOX4-D3140(SSR)

100mA – 100mA Maximum Current output for AMP-43140

The 100mA option configures the AMP-43140 (-D3140) for 10mA/V gain with a maximum current output of 100mA. This option is only valid with the AMP-43140.

Part number ordering example: DMC-4143-BOX4(ISCNLT)-D3140(100mA)

HALLF – Filtered Hall Sensor Inputs

The HALLF option will place a capacitor between the hall input and digital GND to filter unwanted noise. This results in cleaner, more reliable hall sensor reads. The HALLF option is only available for Galil's internal PWM amplifiers.

Part number ordering example: DMC-4143-BOX4-D3040(HALLF)

Power Connector Part Numbers

Overview

The DMC-41x3 uses Molex Mini-Fit, Jr.™ Receptacle Housing connectors for connecting DC Power to the Amplifiers, Controller, and Motors. This section gives the specifications of these connectors. For information specific to your Galil amplifier or driver, refer to the specific amplifier/driver in the [Integrated Components](#) section.

Molex Part Numbers

There are 3 different Molex connectors used with the DMC-41x3. The type of connectors on any given controller will be determined by the Amplifiers/Drivers that were ordered. Below are tables indicating the type of Molex Connectors used and the specific part numbers used on each Amplifier or Driver. For more information on the connectors, go to <http://www.molex.com/>

On Board Connector	Common Mating Connectors*	Crimp Part Number	Type
MOLEX# 39-31-0060	MOLEX# 39-01-2065	MOLEX# 44476-3112	6 Position
MOLEX# 39-31-0040	MOLEX# 39-01-2045	MOLEX# 44476-3112	4 Position
MOLEX# 39-31-0020	MOLEX# 39-01-2025	MOLEX# 44476-3112	2 Position

*The mating connectors listed are not the only mating connectors available from Molex. See <http://www.molex.com/> for the full list of available mating connectors.

Galil Amplifier / Driver		On Board Connector	Type
None		MOLEX# 39-31-0020	2 Position
AMP-43040	Power	MOLEX# 39-31-0060	6 Position
	Motor	MOLEX# 39-31-0040	4 Position
AMP-43140	Power	MOLEX# 39-31-0040	4 Position
	Motor	MOLEX# 39-31-0020	2 Position
SDM-44040	Power	MOLEX# 39-31-0060	6 Position
	Motor	MOLEX# 39-31-0040	4 Position
SMD-44140	Power	MOLEX# 39-31-0060	6 Position
	Motor	MOLEX# 39-31-0040	4 Position

Cable Shielding

Electrical noise can negatively impact system performance by affecting different machine components. For example, it can cause the incorrect reporting of digital input states or position data. One simple and effective way to mitigate electrical noise is to add a shield around the encoder and motor phase cables. For proper shielding, the shield's drain wire should be terminated on only one side of the cable. The following diagrams illustrate the best means of achieving this with the DMC-4103, with the expectation that the controller's baseplate is mounted to something with a secure connection to Earth Ground.

Figure A.3 shows how to connect the encoder cable's shield drain wire. This side of the cable should then go to the controller's 26 pin encoder connector, making a connection to Earth Ground.




Figure A.3: Drain wire of the encoder cable shield

Figure A.4 shows how to connect the drain wire to the motor phase shield.




Figure A.4: Drain wire of the motor phase shield

The motor phase drain wire is fastened to Earth ground on the controller box, shown in Figure A.5.




Figure A.5: Ring terminal of motor phase drain wire connected to box of DMC-4143

For more information on the theory behind electrical noise and its different sources, see Application Note #5438, <https://www.galil.com/download/application-note/note5438.pdf>

Input Current Limitations

The current for an optoisolated input shall not exceed 11mA. Some applications may require the use of an external resistor (R) to limit the amount of current for an input. These external resistors can be placed in series between the inputs and their power supply (Vs). To determine if an additional resistor (R) is required, follow Equation A1 below for guidance.

$$1\text{ mA} < \frac{V_s}{R + 2200\ \Omega} < 11\text{ mA}$$

Equation A1: Current limitation requirements for each input.

Pin-outs

J5 - I/O (A-D) 44 pin HD D-Sub Connector (Female)

Pin#	Label	Description	Pin#	Label	Description	Pin#	Label	Description
1	ERR	Error Output	16	RST	Reset Input	31	GND	Digital Ground
2	DI1	Digital Input 1/ A latch	17	INCOM0	Input Common (DI 1-8)	32	DI2	Digital Input 2 / B latch
3	DI4	Digital Input 4 / D latch	18	DI3	Digital Input 3 / C latch	33	DI5	Digital Input 5
4	DI7	Digital Input 7	19	DI6	Digital Input 6	34	DI8	Digital Input 8
5	ELO	Electronic Lock Out	20	ABRT	Abort Input	35	GND	Digital Ground
6	LSCOM0	Limit Switch Com (A-D)	21	N/C	No Connect	36	FLSA	Forward Limit Switch A
7	HOMA	Home Switch A	22	RLSA	Reverse Limit Switch A	37	FLSB	Forward Limit Switch B
8	HOMB	Home Switch B	23	RLSB	Reverse Limit Switch B	38	FLSC	Forward Limit Switch C
9	HOMC	Home Switch C	24	RLSC	Reverse Limit Switch C	39	FLSD	Forward Limit Switch D
10	HOMD	Home Switch D	25	RLSD	Reverse Limit Switch D	40	GND	Digital Ground
11	OP0A	Output GND/PWR (Bank 0)	26	OP0A	Output GND/PWR (Bank 0)	41	DO1	Digital Output 1
12	DO3	Digital Output 3	27	DO2	Digital Output 2	42	DO4	Digital Output 4
13	DO6	Digital Output 6	28	DO5	Digital Output 5	43	DO7	Digital Output 7
14	OP0B	Output PWR/GND (Bank 0)	29	DO8	Digital Output 8	44	CMP	Output Compare (A-D)
15	+5V	+5V	30	+5V	+5V			

J8 - I/O (E-H) 44 pin HD D-Sub Connector (Female)

For DMC-4153 thru DMC-4183 controllers only.

Pin#	Label	Description	Pin#	Label	Description	Pin#	Label	Description
1	ERR	Error Output	16	RST*	Reset Input	31	GND	Digital Ground
2	DI9	Digital Input 9 / E latch	17	INCOM1	Input Common (DI 9-16)	32	DI10	Digital Input 10 / F latch
3	DI12	Digital Input 12/H latch	18	DI11	Digital Input 11 / G latch	33	DI13	Digital Input 13
4	DI15	Digital Input 15	19	DI14	Digital Input 14	34	DI16	Digital Input 16
5	ELO*	Electronic Lock Out	20	ABRT*	Abort Input	35	GND	Digital Ground
6	LSCOM1	Limit Switch Com (E-H)	21	N/C	No Connect	36	FLSE	Forward Limit Switch E
7	HOME	Home Switch E	22	RLSE	Reverse Limit Switch E	37	FLSF	Forward Limit Switch F
8	HOMF	Home Switch F	23	RLSF	Reverse Limit Switch F	38	FLSG	Forward Limit Switch G
9	HOMG	Home Switch G	24	RLSG	Reverse Limit Switch G	39	FLSH	Forward Limit Switch H
10	HOMH	Home Switch H	25	RLSH	Reverse Limit Switch H	40	GND	Digital Ground
11	OP1A	Output GND/PWR (Bank 1)	26	OP1A	Output GND/PWR (Bank 1)	41	DO9	Digital Output 9
12	DO11	Digital Output 11	27	DO10	Digital Output 10	42	DO12	Digital Output 12
13	DO14	Digital Output 14	28	DO13	Digital Output 13	43	DO15	Digital Output 15
14	OP1B	Output PWR/GND (Bank 1)	29	DO16	Digital Output 16	44	CMP	Output Compare (E-H)
15	+5V	+5V	30	+5V	+5V			

* ABRT, RST and ELO use INCOM0

Jn1 - Encoder 26 pin HD D-Sub Connector (Female)

Pin #	Label	Description	Pin #	Label	Description
1	HALC	Hall C	14	FLS	Forward Limit Switch Input
2	AEN	Amplifier Enable	15	AB+	B+ Aux Encoder Input
3	DIR	Direction	16	MI-	I- Index Pulse Input
4	HOM	Home	17	MB+	B+ Main Encoder Input
5	LSCOMn	Limit Switch Common*	18	GND	Digital Ground
6	AA-	A- Aux Encoder Input	19	MCMD	Motor Command
7	MI+	I+ Index Pulse Input	20	ENBL+	Amp Enable Power
8	MA-	A- Main Encoder Input	21	HALA	Hall A
9	+5V	+5V	22	RLS	Reverse Limit Switch Input
10	GND	Digital Ground	23	AB-	B- Aux Encoder Input
11	ENBL-	Amp Enable Return	24	AA+	A+ Aux Encoder Input
12	HALB	Hall B	25	MB-	B- Main Encoder Input
13	STP	Step	26	MA+	A+ Main Encoder Input

* LSCOMn on JA1, JB1, JC1 and JD1 is common to LSCOM0 on J5
LSCOMn on JE1, JF1, JG1 and JH1 is common to LSCOM1 on J8

J4 - Analog 15 pin D-sub Connector (Male)

Pin #	Label	Description
1	AGND	Analog Ground
2	AI1	Analog Input 1
3	AI3	Analog Input 3
4	AI5	Analog Input 5
5	AI7	Analog Input 7
6	AGND	Analog Ground
7	-12V	-12V
8	+5V	+5V
9	AGND	Analog Ground
10	AI2	Analog Input 2
11	AI4	Analog Input 4
12	AI6	Analog Input 6
13	AI8	Analog Input 8
14	N/C	No Connect
15	+12V	+12V

JPn1 - Amplifier Enable Jumper Description for DMC-41x3

Jumper	Label	Function (If jumpered)
Q and P	1	Sink/Source Selection
	2	Sink/Source Selection
	3	Sink/Source Selection
	4	HAEN/LAEN Selection
	5	5V/12V/External Power Selection
	6	5V/12V/External Power Selection

NOTE: See Amplifier Enable in Chapter 3 for detailed information.

J1 – Ethernet (RJ45)

Pin #	Signal
1	TXP
2	TXN
3	RXP
4	NC
5	NC
6	RXN
7	NC
8	NC

The Ethernet connection is Auto MDIX, 100bT/10bT.

J2 – USB

The USB port on the DMC-41x3 is a Female Type B USB port. The standard cable when communicating to a PC will be a Male Type A – Male Type B USB cable.

J3 – RS-232 Auxiliary Port (Female)

Standard connector and cable, 9Pin

Pin #	Signal
1	NC
2	RXD
3	TXD
4	NC
5	GND
6	NC
7	RTS
8	CTS
9	NC (5V with APWR Jumper)

J3 - RS-422-Auxiliary Port (Non-Standard Option)

Standard connector and cable when DMC-41x3 is ordered with RS-422 Option. For detailed information on the RS-422 option see RS-422 – Auxiliary Serial Port Serial Communication in the Appendices.

Pin #	Signal
1	CTS-
2	RXD-
3	TXD-
4	RTS-
5	GND
6	CTS+
7	RXD+
8	TXD+
9	RTS+

JP1 - Jumper Description for DMC-41x3

Label	Function (If jumpered)
ARXD	RS-422 Option Only: Connects a 120 Ω Termination resistor between the differential "Receive" inputs on the Aux Serial port. Pins 2 and 7 on RS-422 Auxiliary Port.
ACTS	RS-422 Option Only: Connects a 120 Ω Termination resistor between the differential "Clear To Send" inputs on the Aux Serial port. Pins 1 and 6 on RS-422 Auxiliary Port.
APWR	Connects 5V to pin 9 on the Aux serial port connector (J3)
OPT	Reserved
MO	When controller is powered on or reset, Amplifier Enable lines will be in a Motor Off state. A SH will be required to re-enable the motors.
19.2K	Baud Rate setting – see table below
UPGD	Applied for recovery from a failed firmware upgrade.
MRST	Master Reset enable. Returns controller to factory default settings and erases EEPROM. Requires power-on or RESET to be activated.

Note: The ARXD and ACTS jumpers should be installed for single-drop RS-422. For multi-drop, the jumpers should be installed on the last device.

Baud Rate Jumper Settings

19.2	BAUD RATE
ON	19200
OFF	115200 (Recommended)

Signal Descriptions

Inputs

Encoder, MA+, MB+	Position feedback from incremental encoder with two channels in quadrature, CHA and CHB. The encoder may be analog or TTL. Any resolution encoder may be used as long as the maximum frequency does not exceed 15,000,000 quadrature states/sec. The controller performs quadrature decoding of the encoder signals resulting in a resolution of quadrature counts (4 x encoder cycles). Note: Encoders that produce outputs in the format of pulses and direction may also be used by inputting the pulses into CHA and direction into Channel B and using the CE command to configure this mode.
Encoder Index, MI+	Once-Per-Revolution encoder pulse. Used in Homing sequence or Find Index command to define home on an encoder index.
Encoder, MA-, MB-, MI-	Differential inputs from encoder. May be input along with CHA, CHB for noise immunity of encoder signals. The CHA- and CHB- inputs are optional.
Auxiliary Encoder, AA+, AB+, Aux A-, Aux B-	Inputs for additional encoder. Used when an encoder on both the motor and the load is required. Not available on axes configured for step motors.
Abort	A low input stops commanded motion instantly without a controlled deceleration. Also aborts motion program.
Reset	A low input resets the state of the processor to its power-on condition. The previously saved state of the controller, along with parameter values, and saved sequences are restored.
Electronic Lock Out	Input that when triggered will shut down the amplifiers at a hardware level. Useful for safety applications where amplifiers must be shut down at a hardware level.
Forward Limit Switch	When active, inhibits motion in forward direction. Also causes execution of limit switch subroutine, #LIMSWI. The polarity of the limit switch may be set with the CN command.
Reverse Limit Switch	When active, inhibits motion in reverse direction. Also causes execution of limit switch subroutine, #LIMSWI. The polarity of the limit switch may be set with the CN command.
Home Switch	Input for Homing (HM) and Find Edge (FE) instructions. Upon BG following HM or FE, the motor accelerates to slew speed. A transition on this input will cause the motor to decelerate to a stop. The polarity of the Home Switch may be set with the CN command.
Input 1 - Input 8 isolated Input 9 - Input 16 isolated	Uncommitted inputs. May be defined by the user to trigger events. Inputs are checked with the Conditional Jump instruction and After Input instruction or Input Interrupt.
Latch	High speed position latch to capture axis position on occurrence of latch signal. AL command arms latch. Input 1 is latch A, Input 2 is latch B, Input 3 is latch C and Input 4 is latch D. Input 9 is latch E, input 10 is latch F, input 11 is latch G, input 12 is latch H.

Outputs

Motor Command	±10 Volt range signal for driving amplifier. In servo mode, motor command output is updated at the controller sample rate. In the motor off mode, this output is held at the OF command level.
Amplifier Enable	Signal to disable and enable an amplifier. Amp Enable goes low on Abort and OE1.
Step Output	For stepper motors: The STEP OUT pin produces a series of pulses for input to a step motor driver. The pulses may either be low or high. The pulse width is 50%. For sign/magnitude mode, please contact a Galil Applications Engineer.
Direction	Provides the direction signal for step motors. For sign/magnitude mode, please contact a Galil Applications Engineer.
Error	The signal goes low when the position error on any axis exceeds the value specified by the error limit command, ER.
Output 1-Output 8 Output 9-Output 16 (DMC-4153 thru 4183)	The optically isolated outputs are uncommitted and may be designated by the user to trigger external events. The output lines are toggled by Set Bit, SB, and Clear Bit, CB, instructions. The OP instruction is used to define the state of all the bits of the Output port.

List of Other Publications

"Step by Step Design of Motion Control Systems"

by Dr. Jacob Tal

"Motion Control Applications"

by Dr. Jacob Tal

"Motion Control by Microprocessors"

by Dr. Jacob Tal

Training Seminars

Galil, a leader in motion control with over 500,000 controllers working worldwide, has a proud reputation for anticipating and setting the trends in motion control. Galil understands your need to keep abreast with these trends in order to remain resourceful and competitive. Through a series of seminars and workshops held over the past 20 years, Galil has actively shared their market insights in a no-nonsense way for a world of engineers on the move. In fact, over 10,000 engineers have attended Galil seminars. The tradition continues with three different seminars, each designed for your particular skill set-from beginner to the most advanced.

MOTION CONTROL MADE EASY

WHO SHOULD ATTEND

Those who need a basic introduction or refresher on how to successfully implement servo motion control systems.

TIME: 4 hours (8:30 am-12:30 pm)

ADVANCED MOTION CONTROL

WHO SHOULD ATTEND

Those who consider themselves a "servo specialist" and require an in-depth knowledge of motion control systems to ensure outstanding controller performance. Also, prior completion of "Motion Control Made Easy" or equivalent is required. Analysis and design tools as well as several design examples will be provided.

TIME: 8 hours (8:00 am-5:00 pm)

PRODUCT WORKSHOP

WHO SHOULD ATTEND

Current users of Galil motion controllers. Conducted at Galil's headquarters in Rocklin, CA, students will gain detailed understanding about connecting systems elements, system tuning and motion programming. This is a "hands-on" seminar and students can test their application on actual hardware and review it with Galil specialists.

Attendees must have a current application and recently purchased a Galil controller to attend this course.

TIME: Two days (8:30-4:30pm)

<http://galil.com/learn/classes>

Contacting Us

Galil Motion Control

270 Technology Way

Rocklin, CA 95765

Phone: 916-626-0101

Fax: 916-626-0102

E-Mail Address: support@galil.com

Web: <http://galil.com/>

WARRANTY

All controllers manufactured by Galil Motion Control are warranted against defects in materials and workmanship for a period of 18 months after shipment. Motors, and Power supplies are warranted for 1 year. Extended warranties are available.

In the event of any defects in materials or workmanship, Galil Motion Control will, at its sole option, repair or replace the defective product covered by this warranty without charge. To obtain warranty service, the defective product must be returned within 30 days of the expiration of the applicable warranty period to Galil Motion Control, properly packaged and with transportation and insurance prepaid. We will reship at our expense only to destinations in the United States and for products within warranty.

Call Galil to receive a Return Materials Authorization (RMA) number prior to returning product to Galil.

Any defect in materials or workmanship determined by Galil Motion Control to be attributable to customer alteration, modification, negligence or misuse is not covered by this warranty.

EXCEPT AS SET FORTH ABOVE, GALIL MOTION CONTROL WILL MAKE NO WARRANTIES EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO SUCH PRODUCTS, AND SHALL NOT BE LIABLE OR RESPONSIBLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

COPYRIGHT (3-97)

The software code contained in this Galil product is protected by copyright and must not be reproduced or disassembled in any form without prior written consent of Galil Motion Control, Inc.

Integrated Components

Overview

When ordered, the following components will reside inside the box of the DMC-41x3 motion controller. The amplifiers and stepper drivers provide power to the motors in the system, and the interconnect modules and communication boards provide the connections for the signals and communications.

A1 – AMP-430x0 (-D3040,-D3020) 2- and 4-axis 500W Servo Drives

The AMP-43040 (four-axis) and AMP-43020 (two-axis) are multi-axis brush/brushless amplifiers that are capable of handling 500 watts of continuous power per axis. The AMP-43040/43020 Brushless drive modules are connected to a DMC-41x3. The standard amplifier accepts DC supply voltages from 20-80 VDC.

A2 – AMP-43140 (-D3140) 4-axis 20W Linear Servo Drives

The AMP-43140 contains four linear drives for operating small brush-type servo motors. The AMP-43140 requires a $\pm 12-30$ DC Volt input. Output power is 20 W per amplifier or 60 W total. The gain of each transconductance linear amplifier is 0.1 A/V at 1 A maximum current. The typical current loop bandwidth is 4 kHz.

Error: Reference source not found

The AMP-43240 is a multi-axis brush/brushless amplifiers that is capable of handling 750 watts of continuous power per axis. The AMP-43240 Brushless drive module is connected to a DMC. The standard amplifier accepts DC supply voltages from 20-80 VDC.

A4 – AMP-43540 (-D3540, -D3520)

The AMP-43540 contains four PWM drives for sinusoidally commutating brushless motors. It is capable of up to 8 Amps of continuous current and 15Amps of peak current and requires a single DC supply voltage in the range of 20-80 VDC.

A5 – AMP-43547 (-D3547, -D3527)

The AMP-43547 is a sinusoidally commutated, 16 bit PWM amplifier that can also be configured as a microstepping drive. This amplifier is unique in that it can run either servo or stepper motors on any axis.

A6 – AMP-43640 (-D3640)

The AMP-43640 contains four linear drives for sinusoidally commutating brushless motors. The AMP-43640 requires a single 15–40VDC input. Output power delivered is typically 20 W per amplifier or 80 W total.

A7 – SDM-44040 (-D4040,-D4020) 4-axis Stepper Drives

The SDM-44040 is a stepper driver module capable of driving up to four bipolar two-phase stepper motors. The current is selectable with options of 0.5, 0.75, 1.0, and 1.4 Amps/Phase. The step resolution is selectable with options of full, half, 1/4 and 1/16.

A8 – SDM-44140 (-D4140) 4-axis Microstep Drives

The SDM-44140 microstepper module drives four bipolar two-phase stepper motors with 1/64 microstep resolution (the SDM-44140 drives two). The current is selectable with options of 0.5, 1.0, 2.0, & 3.0 Amps per axis.

A1 – AMP-430x0 (-D3040,-D3020)

Description

The AMP-43040 resides inside the DMC-41x3 enclosure and contains four transconductance, PWM amplifiers for driving brushless or brush-type servo motors. Each amplifier drives motors operating at up to 7 Amps continuous, 10 Amps peak, 20–80 VDC. The gain settings of the amplifier are user-programmable at 0.4 Amp/Volt, 0.7 Amp/Volt and 1 Amp/Volt. The switching frequency is 66 kHz.

The drive for each axis is software configurable to operate in either a chopper or inverter mode. The chopper mode is intended for operating low inductance motors. The amplifier offers protection for over-voltage, under-voltage, over-current, short-circuit and over-temperature. Two AMP-43040s can be used in 5- thru 8-axis controllers. A shunt regulator option is available. A two-axis version, the AMP-43020 is also available. If higher voltages are required, please contact Galil.

[GDK](#)'s Step-By-Step tool provides an interactive guide for configuring brushless and brushed motors.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Servo (Brushless/Brush)
Supply Voltage	20-80 VDC
Continuous Current	7 Amps
Peak Current	10 Amps
Switching Frequency	66 kHz (up to 140 kHz available)
Amplifier Gains	0.4, 0.7, 1.0 Amps/Volt
Brushless Commutation Angle	120° (60° option available)
PWM Output Operation	Inverter or Chopper (user configurable)
Minimum Load Inductance	$L(mH) = \frac{V_S(V)}{480 * I_{Ripple}(A)}$

V_S = Supply Voltage, I_{ripple} = 10% of the maximum current at chosen gain

Table A1.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A1.2: Molex part numbers for connectors and terminal pin




Figure A1.1: Power and Motor Connector Diagram

Power Connector		
Pin Number	Connection	
1,2,3	DC Power Supply Ground	
4,5,6	+VS (DC Power)	
Motor Connector		
Pin Number	3-phase brushless	Brushed
1	Phase C	No Connect
2	Phase B	Phase A-
3	No Connect	No Connect
4	Phase A	Phase A+

Table A1.3: Power and Motor Connector Pin-outs

Servo Motor Operation

Brushless Motor Setup

NOTE: If you purchased a Galil motor with the amplifier, it is ready for use. No additional setup is necessary.

To begin the setup of the brushless motor and amplifier, it is first necessary to have communications with the motion controller. It is also necessary to have the motor hardware connected and the amplifier powered to begin the setup phase. After the encoders and motor leads are connected, the controller and amplifier need to be configured correctly in software. Take all appropriate safety precautions. For example, set a small error limit ($ER^*=1000$), a low torque limit ($TL^*=3$), and set off on Error to 1 for all axes ($OE^*=1$).

Brushed Motor Operation

The AMP-43040 and AMP-43020 also allow for brush operation. To configure an axis for brush-type operation, connect the 2 motor leads as prescribed in Table A1.3. Connect the encoders, homes, and limits as required. Set the controller into brush-axis operation by issuing BR n,n,n,n. By setting $n=1$, the controller will operate in brushed mode on that axis. For example, BR 0,1,0,0 sets the Y-axis as brush-type, all others as brushless. If an axis is set to brush-type, the amplifier has no need for the Hall inputs. These inputs can subsequently be used as general-use inputs, queried with the QH command.

Setting Amplifier Gain and Current Loop Bandwidth

AG Command:

The AMP-43040 has 3 amplifier gain settings. The gain is set with the AG command as shown in Table A1.4 for $AG_m=n$, where m is a specific axis. The axis must be in a motor off (MO) state prior to execution of the AG command.

AG setting	Gain Value
$n = 0$	0.4 A/V
$n = 1$	0.7 A/V
$n = 2$	1.0 A/V

Table A1.4: Amplifier Gain Settings

AU Command:

Proper configuration of the AU command is essential to optimize the operation of the AMP-430x0. This command sets the gain for the current loop on the amplifier. Table A1.5 indicates the recommended $AU_m=n$ settings for 24 and 48 VDC power supplies based on motor inductance. The axis must be in a motor off (MO) state prior to execution of the AU command.

Vsupply VDC	Inductance L (mH)	n
24	$0.5 \leq L < 5.0$	0
24	$0.2 \leq L < 0.5$	0.5
24	$5.0 \leq L$	1
24	$5.0 \leq L$	1.5
48	$0.5 \leq L < 10.0$	0
48	$0.2 \leq L < 0.5$	0.5
48	$10.0 \leq L$	1
48	$10.0 \leq L$	1.5

Table A1.5: Amplifier Current Loop Gain Settings

Chopper Mode

The AMP-430x0 can be put into what is called a “Chopper” mode. The chopper mode is in contrast to the normal inverter mode in which the amplifier sends PWM power to the motor of $\pm V_S$. In chopper mode, the amplifier sends a 0 to $+V_S$ PWM to the motor when moving in the forward direction, and a 0 to $-V_S$ PWM to the motor when moving in the negative direction. This mode is useful when using low inductance motors because it reduces the losses due to switching voltages across the motor windings. It is recommended to use chopper mode when using motors with 200-500 μ H inductance.

This mode is set with the AU command. A setting of 0.5 is Chopper mode with normal current bandwidth. A setting of 1.5 is Chopper mode with high current bandwidth.

Setting Peak and Continuous Torque Limits

TK and TL Commands:

The peak and continuous torque limits can be set through the TK and TL commands respectively. The controller will command the torque signal (TT) up to the value specified by TK for a maximum of one second, as shown in Figure A1.2. It will then limit the torque to the value specified by TL. The more time the controller commands the torque below TL, the longer it will command it to TK when necessary. The DMC code example below exhibits the behavior of TT being limited by TL and TK, as shown in Figure A1.2.

```
#TK;           'Begin Program
MO;           'Disable all axes
AGA = 2;      'Set maximum amplifier gain of 1.0 A/V
TLA = 5;      'Set continuous torque limit of 5 V
TKA = 9.9982; 'Set maximum peak torque limit of 9.9982 V
SHA;         'Enable A axis
OFA = 9.9982; 'Command torque signal to 9.9982 V
EN;          'End Program
```




Figure A1.2: Peak Current Operation

Using External Amplifiers

Use connectors on top of controller to access necessary signals to run external amplifiers. In order to use the full torque limit, make sure the AG setting for the axes using external amplifiers are set to 0 or 1. Set the BR command to 1 for any axis that will be setup to run external amplifiers (this will disable the hall error protection). For more information on connecting external amplifiers, see Step 2b. Connecting External Amplifiers and Motors in Chapter 2.

ELO Input

If the ELO input on the controller is triggered, the amplifier will be shut down at a hardware level, the motors will be essentially in a Motor Off (MO) state. TA3 will return a 3 and the #AMPERR routine will run when the ELO input is triggered. To recover from an ELO, an MO followed by a WT 2, and an SH must be issued, or the controller must be reset.

It is recommended that OE1 be used for all axes when the ELO is used in an application.

See the Optoisolated Input Electrical Information section in Chapter 3 Connecting Hardware for information on connecting the ELO input.

Error Monitoring and Protection

The amplifier is protected against over-voltage, under-voltage, over-temperature, and over-current for brush and brushless operation. The controller will also monitor for illegal Hall states (000 or 111 with 120° phasing). The controller will monitor the error conditions and respond as programmed in the application. The errors are monitored via the TA command. TA n may be used to monitor the errors with n = 0, 1, 2, or 3. The command will return an eight bit number representing specific conditions. TA0 will return errors with regard to under voltage, over voltage, over current, and over temperature. TA1 will return hall errors on the appropriate axes, TA2 will monitor if the amplifier current exceeds the continuous setting, and TA3 will return if the ELO input has been triggered.

The user also has the option to include the special label #AMPERR in their program to handle soft or hard errors. As long as a program is executing in thread zero and the #AMPERR label is included, when an error is detected the program will jump to the label and execute the user defined routine. Note that the TA command is a monitoring function only, and does not generate an error condition. The over voltage condition will not permanently shut down the amplifier or trigger the #AMPERR routine. The amplifier will be momentarily disabled; when the condition goes away, the amplifier will continue normal operation assuming it did not cause the position error to exceed the error limit.

Hall Error Protection

During normal operation, the controller should not have any Hall errors. Hall errors can be caused by a faulty Hall-effect sensor or a noisy environment. The state of the Hall inputs can also be monitored through the QH command. Hall errors will cause the amplifier to be disabled if OE 1 is set, and will cause the controller to enter the #AMPERR subroutine if it is included in a running program.

Under-Voltage Protection

If the supply to the amplifier drops below 18 VDC, the amplifier will be disabled. The amplifier will return to normal operation once the supply is raised above the 18V threshold; TA 0 will tell the user whether the supply is in the acceptable range.

NOTE: If there is an #AMPERR routine and the controller is powered before the amplifier, then the #AMPERR routine will automatically be triggered.

Over-Voltage Protection

If the voltage supply to the amplifier rises above 94 VDC, then the amplifier will automatically disable. The amplifier will re-enable when the supply drops below 90 V.

WARNING	If this error occurs, it is indicative of a problem at the system level. An Over-Voltage error is usually due to regeneration from the motor and load. Consider using a shunt regulator if this occurs during normal operation.
----------------	---

Over-current Protection

The amplifier also has circuitry to protect against over-current. If the total current from a set of 2 axes (ie A and B or C and D) exceeds 20 A, the amplifier will be disabled. The amplifier will not be re-enabled until there is no longer an over-current draw and then either SH command has been sent or the controller is reset. Since the AMP-43040 is a trans-conductance amplifier, the amplifier will never go into this mode during normal operation. The amplifier will be shut down regardless of the setting of OE, or the presence of the #AMPERR routine.

WARNING

If this error occurs, it is indicative of a problem at the system level. An Over-Current error is usually due to a short across the motor leads or a short from a motor lead to ground.

Over-Temperature Protection

The amplifier is also equipped with over-temperature protection.

Rev A and Rev B amplifiers:

If the average heat sink temperature rises above 100°C, then the amplifier will be disabled. The over-temperature condition will trigger the #AMPERR routine if included in the program on the controller.

The amplifier will re-enable when the temperature drops below 100 °C.

Rev C and newer amplifiers:

If the average heat sink temperature rises above 80°C, then the amplifier will be disabled. The over-temperature condition will trigger the #AMPERR routine if included in the program on the controller.

The amplifier will not be re-enabled until the temperature drops below 80°C and then either an SH command is sent to the controller, or the controller is reset (RS command or power cycle).

Rev C Amplifiers began shipping in December 2008.

WARNING

An Over-Temperature error is usually due to insufficient heat dissipation from the amplifier. Heat must be drawn away from the base of the controller with forced air flow or a heat sink.

A2 – AMP-43140 (-D3140)

Description

The AMP-43140 resides inside the DMC-41x3 enclosure and contains four linear drives for operating small, brush-type servo motors. The AMP-43140 requires a ± 12 -30 VDC input. Output power is 20 W per amplifier or 60 W total. The gain of each transconductance linear amplifier is 0.1 A/V at 1 A maximum current. The typical current loop bandwidth is 4 kHz. The AMP-43140 can be ordered to have a 100mA maximum current output where the gain of the amplifier is 10mA/V. Order as '-D3140(100mA)'.

[GDK's](#) Step-By-Step tool provides an interactive guide for configuring brushed motors.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Servo (Brush)
Supply Voltage	±12-30 VDC (±12-20 available with ISCNTL)
Continuous Current	1.0 Amps (100mA option available)
Amplifier Gains	0.1 A/V (10mA A/V option available)
Power Output (per channel)	20 W
Total Max Power Output	60 W

Table A2.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040
Motor Power Connectors	2-pin Mini-Fit, Jr.™ (Male) Molex #0039012025	Molex #0444761112	2-pin Mini-Fit, Jr.™ (Female) Molex #0039310020

Table A2.2: Molex part numbers for connectors and terminal pin




Figure A2.1: Power and Motor Connector Diagram

Power Connector	
Pin Number	Connection
1, 2	DC Power Supply Ground
3	-VS (-DC Power)
4	+VS (DC Power)
Motor Connector	
Pin Number	Brushed
1	Phase A-
2	Phase A+

Table A2.3: Power and Motor Connector Pin-outs

Servo Motor Operation

Using External Amplifiers

Use connectors on top of controller to access necessary signals to run external amplifiers. In order to use the full torque limit, make sure the AG setting for the axes using external amplifiers are set to 0 or 1. Set the BR command to 1 for any axis that will be setup to run external amplifiers (this will disable the hall error protection). For more information on connecting external amplifiers, see Step 2b. Connecting External Amplifiers and Motors in Chapter 2.

ELO Input

If the ELO input on the controller is triggered, the amplifier will be shut down at a hardware level, the motors will be essentially in a Motor Off (MO) state. TA3 will return a 3 and the #AMPERR routine will run when the ELO input is triggered. To recover from an ELO, an MO followed by a WT 2, and an SH must be issued, or the controller must be reset.

It is recommended that OE1 be used for all axes when the ELO is used in an application.

See the Optoisolated Input Electrical Information section in Chapter 3 Connecting Hardware for information on connecting the ELO input.

-SSR Option

The AMP-43140 linear amplifier require a bipolar power supply. It is possible that the plus and minus (V+ and V-) rise to nominal voltage at different rates during power up and any difference between voltage levels will be seen as an offset in the amplifier. This offset may cause a slight jump during power up prior to the controller establishing closed-loop control. When ordered with the –SSR option a solid state relay is added to the amplifier. This relay disconnects the amplifier power from the motor power leads when the controller is placed in the motor-off state. If the MO jumper is installed, or the MO command is burned into memory, the addition of the –SSR option will eliminate any jump due to the power supply.

A3 – AMP-43240 (-D3240)

Description

The AMP-43240 resides inside the DMC-41x3 enclosure and contains four transconductance, PWM amplifiers for driving brushless or brush-type servo motors. Each amplifier drives motors operating at up to 10 Amps continuous, 20 Amps peak, 20–80 VDC. The gain settings of the amplifier are user-programmable at 0.5 Amp/Volt, 1.0 Amp/Volt and 2.0 Amp/Volt. The switching frequency is 24 kHz.

The drive operates in a Chopper Mode. The amplifier offers protection for over-voltage, under-voltage, over-current, short-circuit and over-temperature. Two AMP-43240s can be used in 5- thru 8-axis controllers. A shunt regulator option is available. If higher voltages are required, please contact Galil.

[GDK](#)'s Step-By-Step tool provides an interactive guide for configuring brushless and brushed motors.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Servo (Brushless/Brush)
Supply Voltage	20-80 VDC
Continuous Current	10 Amps
Peak Current	20 Amps
Switching Frequency	24 kHz
Amplifier Gains	0.5, 1.0, 2.0 Amps/Volt
Brushless Commutation Angle	120° (60° option available)
PWM Output Operation	Chopper
Minimum Load Inductance	$L(mH) = \frac{V_S(V)}{192 * I_{Ripple}(A)}$

V_S = Supply Voltage, I_{ripple} = 10% of the maximum current at chosen gain

Table A3.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A3.2: Molex part numbers for connectors and terminal pin




Figure A3.1: Power and Motor Connector Diagram

Power Connector		
Pin Number	Connection	
1,2,3	DC Power Supply Ground	
4,5,6	+VS (DC Power)	
Motor Connector		
Pin Number	3-phase brushless	Brushed
1	Phase C	No Connect
2	Phase B	Phase A-
3	No Connect	No Connect
4	Phase A	Phase A+

Table A3.3: Power and Motor Connector Pin-outs

Servo Motor Operation

Brushless Motor Setup

NOTE: If you purchased a Galil motor with the amplifier, it is ready for use. No additional setup is necessary.

To begin the setup of the brushless motor and amplifier, it is first necessary to have communications with the motion controller. It is also necessary to have the motor hardware connected and the amplifier powered to begin the setup phase. After the encoders and motor leads are connected, the controller and amplifier need to be configured correctly in software. Take all appropriate safety precautions. For example, set a small error limit ($ER^*=1000$), a low torque limit ($TL^*=3$), and set off on Error to 1 for all axes ($OE^*=1$).

Brushed Motor Operation

The AMP-43240 also allow for brush operation. To configure an axis for brush-type operation, connect the 2 motor leads as prescribed in Table A3.3. Connect the encoders, homes, and limits as required. Set the controller into brush-axis operation by issuing BR n,n,n,n. By setting $n=1$, the controller will operate in brushed mode on that axis. For example, BR 0,1,0,0 sets the Y-axis as brush-type, all others as brushless. If an axis is set to brush-type, the amplifier has no need for the Hall inputs. These inputs can subsequently be used as general-use inputs, queried with the QH command.

Setting Amplifier Gain and Current Loop Bandwidth

AG Command:

The AMP-43240 has 3 amplifier gain settings. The gain is set with the AG command as shown in Table A3.4 for $AGm=n$, where m is a specific axis. The axis must be in a motor off (MO) state prior to execution of the AG command.

AG setting	Gain Value
$n = 0$	0.5 A/V
$n = 1$	1.0 A/V
$n = 2$	2.0 A/V

Table A3.4: Amplifier Gain Settings

AU Command:

Proper configuration of the AU command is essential to optimize the operation of the AMP-43240. This command sets the gain for the current loop on the amplifier. Table A3.5 indicates the recommended $AUm=n$ settings for 24 and 48 VDC power supplies based on motor inductance. The axis must be in a motor off (MO) state prior to execution of the AU command.

Vsupply VDC	Inductance L (mH)	n
24	$0.5 \leq L < 5.0$	0
24	$5.0 \leq L$	1
48	$0.5 \leq L < 10.0$	0
48	$10.0 \leq L$	1

Table A3.5: Amplifier Current Loop Gain Settings

Chopper Mode

The AMP-43240 runs in what is called a “Chopper” mode. The chopper mode is in contrast to the normal inverter mode (AMP-43040) in which the amplifier sends PWM power to the motor of $\pm V_S$. In chopper mode, the amplifier sends a 0 to +VS PWM to the motor when moving in the forward direction, and a 0 to -VS PWM to the motor when moving in the negative direction.

Setting Peak and Continuous Torque Limits

TK and TL Commands:

The peak and continuous torque limits can be set through the TK and TL commands respectively. The controller will command the torque signal (TT) up to the value specified by TK for a maximum of one second, as shown in Figure A3.2. It will then limit the torque to the value specified by TL. The more time the controller commands the torque below TL, the longer it will command it to TK when necessary. The DMC code example below exhibits the behavior of TT being limited by TL and TK, as shown in Figure A3.2.

```
#TK;           'Begin Program
MO;           'Disable all axes
AGA = 2;      'Set maximum amplifier gain of 2.0 A/V
TLA = 5;      'Set maximum continuous torque limit of 5 V
TKA = 9.9982; 'Set maximum peak torque limit of 9.9982 V
SHA;         'Enable A axis
OFA = 9.9982; 'Command torque signal to 9.9982 V
EN;          'End Program
```




Figure A3.2: Peak Current Operation

Using External Amplifiers

Use connectors on top of controller to access necessary signals to run external amplifiers. In order to use the full torque limit, make sure the AG setting for the axes using external amplifiers are set to 0 or 1. Set the BR command to 1 for any axis that will be setup to run external amplifiers (this will disable the hall error protection). For more information on connecting external amplifiers, see Step 2b. Connecting External Amplifiers and Motors in Chapter 2.

ELO Input

If the ELO input on the controller is triggered, the amplifier will be shut down at a hardware level, the motors will be essentially in a Motor Off (MO) state. TA3 will return a 3 and the #AMPERR routine will run when the ELO input is triggered. To recover from an ELO, an MO followed by a WT 2, and an SH must be issued, or the controller must be reset.

It is recommended that OE1 be used for all axes when the ELO is used in an application.

See the Optoisolated Input Electrical Information section in Chapter 3 Connecting Hardware for information on connecting the ELO input.

Error Monitoring and Protection

The amplifier is protected against over-voltage, under-voltage, over-temperature, and over-current for brush and brushless operation. The controller will also monitor for illegal Hall states (000 or 111 with 120° phasing). The controller will monitor the error conditions and respond as programmed in the application. The errors are monitored via the TA command. TA n may be used to monitor the errors with n = 0, 1, 2, or 3. The command will return an eight bit number representing specific conditions. TA0 will return errors with regard to under voltage, over voltage, over current, and over temperature. TA1 will return hall errors on the appropriate axes, TA2 will monitor if the amplifier current exceeds the continuous setting, and TA3 will return if the ELO input has been triggered.

The user also has the option to include the special label #AMPERR in their program to amplifier errors. As long as a program is executing in thread zero and the #AMPERR label is included, when an error is detected the program will jump to the label and execute the user defined routine. Note that the TA command is a monitoring function only, and does not generate an error condition.

See the TA command for detailed information on bit status during error conditions.

Hall Error Protection

During normal operation, the controller should not have any Hall errors. Hall errors can be caused by a faulty Hall-effect sensor or a noisy environment. The state of the Hall inputs can also be monitored through the QH command. Hall errors will cause the amplifier to be disabled if OE 1 is set, and will cause the controller to enter the #AMPERR subroutine if it is included in a running program.

Under-Voltage Protection

If the supply to the amplifier drops below 18 VDC, the amplifier will be disabled. The amplifier will return to normal operation once the supply is raised above the 18V threshold; TA 0 will tell the user whether the supply is in the acceptable range.

NOTE: If there is an #AMPERR routine and the controller is powered before the amplifier, then the #AMPERR routine will automatically be triggered.

Over-Voltage Protection

If the voltage supply to the amplifier rises above 94 VDC, then the amplifier will automatically disable. The amplifier will re-enable when the supply drops below 90 V.

The over voltage condition will not permanently shut down the amplifier or trigger the #AMPERR routine. The amplifier will be momentarily disabled; when the condition goes away, the amplifier will continue normal operation assuming it did not cause the position error to exceed the error limit.

WARNING

If this error occurs, it is indicative of a problem at the system level. An Over-Voltage error is usually due to regeneration from the motor and load. Consider using a shunt regulator if this occurs during normal operation.

Over-Current Protection

The amplifier also has circuitry to protect against over-current. If the total current from a set of 2 axes (ie A and B or C and D) exceeds 40 A, the amplifier will be disabled. The amplifier will not be re-enabled until there is no longer an over-current draw and then either SH command has been sent or the controller is reset. Since the AMP-43240 is a transconductance amplifier, the amplifier will never go into this mode during normal operation. The amplifier will be shut down regardless of the setting of OE, or the presence of the #AMPERR routine.

WARNING

If this error occurs, it is indicative of a problem at the system level. An Over-Current error is usually due to a short across the motor leads or a short from a motor lead to ground.

Over-Temperature Protection

The amplifier is also equipped with over-temperature protection.

If the average heat sink temperature rises above 80°C, then the amplifier will be disabled. The over-temperature condition will trigger the #AMPERR routine if included in the program on the controller.

The amplifier will not be re-enabled until the temperature drops below 80°C and then either an SH command is sent to the controller, or the controller is reset (RS command or power cycle).

WARNING

An Over-Temperature error is usually due to insufficient heat dissipation from the amplifier. Heat must be drawn away from the base of the controller with forced air flow or a heat sink.

A4 – AMP-43540 (-D3540, -D3520)

Description

The AMP-43540 is a sinusoidally commutated, 16 bit PWM amplifier. It can also be ordered in a two axis configuration specified as -D3520. The AMP-43540 can be configured for the motors below with just a few commands.

- 3-phase Brushless Motors
- Brushed Motors

[GDK](#)'s Step-By-Step tool provides an interactive guide for configuring brushless and brushed motors.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Servo (Brushless/Brushed)
Supply Voltage	20-80 V
Continuous Current	8 Amps
Peak Current	15 Amps
Switching Frequency	33 kHz
Amplifier Gains	0.4, 0.8, 1.6 Amps/Volt
Minimum Load Inductance	$L(mH) = \frac{V_s(V)}{264 * I_{Ripple}(A)}$

V_s = Supply Voltage, I_{ripple} = 10% of the maximum current at chosen gain

Table A4.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A4.2: Molex part numbers for connectors and terminal pin




Figure A4.1: Power and Motor Connector Diagram

Power Connector		
Pin Number	Connection	
1,2,3	DC Power Supply Ground	
4,5,6	+VS (DC Power)	
Motor Connector		
Pin Number	3-phase brushless	Brushed
1	Phase C	Phase A-
2	Phase B	No Connect
3	No Connect	No Connect
4	Phase A	Phase A+

Table A4.3: Power and Motor Connector Pin-outs

Servo Motor Operation

3-Phase Brushless Motor Operation

For 3-phase brushless motor operation, MT must be set to 1 for the axis. The 6 commands used for setup are the BA, BM, BX, BZ, BC and BI. Please see the Command Reference for details. Below is the setup procedure for configuring an axis to operate a 3-phase brushless motor.

1. Issue the BA command to specify on which axis to configure sinusoidal commutation.
2. The brushless modulus is the number of encoder counts per magnetic cycle and is set with the BM command. For example, in a rotary motor that has 2 pole pairs and 10,000 counts per revolution, the number of encoder counts per magnetic cycle would be 10,000/2. BM should be assigned to a value of 5,000.
3. Issue either the BI and BC, BZ, or BX command to initialize the motor for sinusoidal commutation. The command must be executed on every reset or power-up of the controller.
 - **BI/BC Commands:**

If the motor includes hall sensors, Galil recommends using the BI and BC commands. The BI command uses the hall sensors to set the approximate location of the motor in the magnetic cycle. The BC command will precisely set the commutation angle upon detecting a hall state transition.
 - **BZ Command:**

If the motor does not include hall sensors, Galil recommends using the BZ command. The BZ command forces the motor to a known location in the magnetic cycle. Note that this can cause up to ½ a magnetic cycle of motion.
 - **BX Command:**

If the motor does not have hall sensors and the BZ command generates too much motion for the application, Galil recommends using the BX command. This command utilizes a minimal movement algorithm in order to determine the correct commutation of the motor.

Brushed Motor Operation

For brushed motor operation, set MT and BR to 1 for the axis.

Setting Amplifier Gain and Current Loop Gain

AG Command:

The AG command will set the amplifier gain (Amps/Volt). The AU command will set the current loop gain. The AMP-43540 has 3 amplifier gain settings. The gain is set with the AG command as shown in Table A4.4 for AGm=n, where m is a specific axis. The axis must be in a motor off (MO) state prior to execution of the AG command.

AG setting	Gain Value
n = 0	0.4 A/V
n = 1	0.8 A/V
n = 2	1.6 A/V

Table A4.4: Amplifier Gain Settings

AU Command:

Proper configuration of the AU command is essential to optimize the operation of the AMP-43540. This command sets the gain for the current loop on the amplifier. Table A4.5 indicates the recommended AUm=n settings for 24 and 48 VDC power supplies based on motor inductance. The axis must be in a motor off (MO) state prior to execution of the AU command.

Vsupply VDC	Inductance L (mH)	n
24	$L < 1$	9
24	$1 \leq L < 2.3$	10
24	$2.3 \leq L < 4.2$	11
24	$4.2 \leq L$	12
48	$L < 2.4$	9
48	$2.4 \leq L < 4.2$	10
48	$4.2 \leq L < 7$	11
48	$7 \leq L$	12

Table A4.5: Amplifier Current Loop Gain Settings

Setting Peak and Continuous Torque Limits

TK and TL Commands:

The peak and continuous torque limits can be set through the TK and TL commands respectively. The controller will command the torque signal (TT) up to the value specified by TK for a maximum of one second, as shown in Figure A4.2. It will then limit the torque to the value specified by TL. The more time the controller commands the torque below TL, the longer it will command it to TK when necessary. The DMC code example below exhibits the behavior of TT being limited by TL and TK, as shown in Figure A4.2.

```
#TK;           'Begin Program
MO;           'Disable all axes
AGA = 2;      'Set maximum amplifier gain of 2.0 A/V
TLA = 5;      'Set maximum continuous torque limit of 5 V
TKA = 9.9982; 'Set maximum peak torque limit of 9.9982 V
SHA;         'Enable A axis
OFA = 9.9982; 'Command torque signal to 9.9982 V
EN;          'End Program
```




Figure A4.2: Peak Current Operation

Error Monitoring and Protection

The amplifier is protected against Over-Current, Over-Voltage, Over-Temperature, and Under-Voltage conditions. These conditions are reported as amplifier errors via the TA command and can be cleared with the AZ command. See the Clearing Latched Amplifier Errors section for details.

The user has the option to include the automatic subroutine #AMPERR in their program to handle amplifier errors. As long as the #AMPERR label is included in the program that is on the controller, the program will jump to the label when an amplifier error is detected and begin executing the user defined routine.

TA n is used to monitor amplifier errors with n = 0-3. The command will return an eight bit bitmask representing specific error conditions. It will also report whether an amplifier error is latched for the bank of axes A - D or the bank of axes E - H. See the TA command in the Command Reference for detailed information on bit status during error conditions.

Over-Current Protection

If there is a short circuit in the amplifier or motor, an Over-Current error will be reported and the amplifier will be disabled. Since the AMP-43540 is a trans-conductance amplifier, the amplifier should not encounter this error during normal operation. The Over-Current amplifier error is a latching error, see the Clearing Latched Amplifier Errors section for details.

WARNING	If this error occurs, it is indicative of a problem at the system level. An Over-Current error is usually due to a short across the motor leads or a short from a motor lead to ground.
----------------	---

Over-Voltage Protection

If the voltage supplied to the amplifier rises above its rated supply voltage, an Over-Voltage error will be reported. While the amplifier is experiencing this condition, current is no longer commanded and the motor phases are shorted together. This results in a drag on the motors causing them to coast to a stop. The amplifier will resume commanding current when the voltage drops below the maximum rated supply voltage. The Over-Voltage amplifier error is *not* a latching error.

WARNING	If this error occurs, it is indicative of a problem at the system level. An Over-Voltage error is usually due to regeneration from the motor and load. Consider using a shunt regulator if this occurs during normal operation.
----------------	---

Over-Temperature Protection

If the average amplifier temperature rises above 80°C, an Over-Temperature error will be reported and the amplifier will be disabled. The error cannot be cleared until the temperature drops below 80°C. The Over-Temperature amplifier error is a latching error, see the Clearing Latched Amplifier Errors section for details.

WARNING	An Over-Temperature error is usually due to insufficient heat dissipation from the amplifier. Heat must be drawn away from the base of the controller with forced air flow or a heat sink.
----------------	--

Under-Voltage Protection

If the voltage supplied to the amplifier drops below its rated supply voltage, an Under-Voltage error will be reported and the amplifier will be disabled. The error cannot be cleared until the supply voltage raises above its minimum rated supply voltage. Under-Voltage does not latch by default. It will become a latching error after AZ2 is issued to the controller. See the Clearing Latched Amplifier Errors section for details.

ELO Input

If the ELO input on the controller is asserted, the power stage of the amplifier will be disabled. The ELO input is a latching input, see the Clearing Latched Amplifier Errors section for details. Reference the Optoisolated Input Electrical Information section in Chapter 3 Connecting Hardware for information on connecting the ELO input.

Clearing Latched Amplifier Errors

Default Error Clearing

Amplifier errors that do not latch will be reported in real-time by the TA command.

For latching errors to report and latch for a bank of axes, at least one axis in that bank must be in a servo here state (SH).

To clear latched amplifier errors, issue the MO command followed by SH. If an axis is moving, motion must be halted before attempting to clear amplifier errors.

Enhanced Error Clearing

Enhanced error clearing and reporting can be enabled by issuing AZ2 to the controller.

While all axes are in a motor off state (MO) and there are no latched amplifier errors, all amplifier errors will be reported in real-time by the TA command. For an amplifier error to latch for a bank of axes, at least one axis in that bank must be in a servo here state (SH).

To clear latched amplifier errors, issue the MO command followed by AZ1. Use the TA command to report if an amplifier error condition is still present. If an axis is moving, motion must be halted before attempting to clear amplifier errors. See the #AMPERR label and AZ command in the Command Reference for more information and examples.

NOTE: Enhanced Error Clearing is supported on the DMC-4103 as of firmware revision 1.3e and amplifier hardware revision 4.

A5 – AMP-43547 (-D3547, -D3527)

Description

The AMP-43547 is a sinusoidally commutated, 16 bit PWM amplifier that can also be configured as a microstepping drive. It can also be ordered in a two axis configuration specified as -D3527. This amplifier is unique in that it can run either servo or stepper motors on any axis. The AMP-43547 can be configured for all of the motors below with just a few commands.

- 3-phase Brushless Motors
- Brushed Motors
- Stepper Motors
- 2-phase Brushless Motors

[GDK](#)'s Step-By-Step tool provides an interactive guide for configuring brushless, brushed, and stepper motors.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Servo (Brushless/Brushed)	Stepper
Supply Voltage	20-80 V	
Continuous Current	8 Amps	-
Peak Current	15 Amps	-
Maximum Current per Phase	-	6 Amps
Step Resolution	-	256 microsteps/full step
Switching Frequency	33 kHz	
Amplifier Gains	0.4, 0.8, 1.6 Amps/Volt	0.75, 1.5, 3, 6 Amps/Phase
Minimum Load Inductance	$L(mH) = \frac{V_s(V)}{264 * I_{Ripple}(A)}$	

V_s = Supply Voltage, I_{ripple} = 10% of the maximum current at chosen gain

Table A5.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A5.2: Molex part numbers for connectors and terminal pin




Figure A5.1: Power and Motor Connector Diagram

Power Connector			
Pin Number	Connection		
1,2,3	DC Power Supply Ground		
4,5,6	+VS (DC Power)		
Motor Connector			
Pin Number	3-phase brushless	Brushed	2-phase brushless or Stepper
1	Phase C	Phase A-	Phase B-
2	Phase B	No Connect	Phase B+
3	No Connect	No Connect	Phase A-
4	Phase A	Phase A+	Phase A+

Table A5.3: Power and Motor Connector Pin-outs

Servo Motor Operation

3-Phase Brushless Motor Operation

For 3-phase brushless motor operation, MT must be set to 1 for the axis. The 6 commands used for setup are the BA, BM, BX, BZ, BC and BI. Please see the Command Reference for details. Below is the setup procedure for configuring an axis to operate a 3-phase brushless motor.

1. Issue the BA command to specify on which axis to configure sinusoidal commutation.
2. The brushless modulus is the number of encoder counts per magnetic cycle and is set with the BM command. For example, in a rotary motor that has 2 pole pairs and 10,000 counts per revolution, the number of encoder counts per magnetic cycle would be 10,000/2. BM should be assigned to a value of 5,000.
3. Issue either the BI and BC, BZ, or BX command to initialize the motor for sinusoidal commutation. The command must be executed on every reset or power-up of the controller.
 - **BI/BC Commands:**

If the motor includes hall sensors, Galil recommends using the BI and BC commands. The BI command uses the hall sensors to set the approximate location of the motor in the magnetic cycle. The BC command will precisely set the commutation angle upon detecting a hall state transition.
 - **BZ Command:**

If the motor does not include hall sensors, Galil recommends using the BZ command. The BZ command forces the motor to a known location in the magnetic cycle. Note that this can cause up to ½ a magnetic cycle of motion.
 - **BX Command:**

If the motor does not have hall sensors and the BZ command generates too much motion for the application, Galil recommends using the BX command. This command utilizes a minimal movement algorithm in order to determine the correct commutation of the motor.

2-Phase Brushless Motor Operation

For 2-phase brushless motor operation, MT must be set to 4 for the axis. Initialization and setup of a 2-phase brushless motor is similar to the 3-phase brushless setup described above. The BZ command must be used to initialize commutation.

Minimum Encoder Resolution

Due to the density of the magnetic cycle in 2-phased brushless motors, operation requires the use of an encoder with a high enough resolution resulting in a minimum BM value of 80 encoder counts per magnetic cycle. Contact a Galil Applications Engineer to review minimum encoder resolution requirements.

Brushed Motor Operation

For brushed motor operation, set MT and BR to 1 for the axis.

Setting Amplifier Gain and Current Loop Gain

AG Command:

The AG command will set the amplifier gain (Amps/Volt). The AU command will set the current loop gain. The AMP-43547 has 3 amplifier gain settings. The gain is set with the AG command as shown in Table A5.4 for AGm=n, where m is a specific axis. The axis must be in a motor off (MO) state prior to execution of the AG command.

AG setting	Gain Value
n = 0	0.4 A/V
n = 1	0.8 A/V
n = 2	1.6 A/V

Table A5.4: Amplifier Gain Settings

AU Command:

Proper configuration of the AU command is essential to optimize the operation of the AMP-43547. This command sets the gain for the current loop on the amplifier. Table A5.5 indicates the recommended AUm=n settings for 24 and 48 VDC power supplies based on motor inductance. The axis must be in a motor off (MO) state prior to execution of the AU command.

Vsupply VDC	Inductance L (mH)	n
24	$L < 1$	9
24	$1 \leq L < 2.3$	10
24	$2.3 \leq L < 4.2$	11
24	$4.2 \leq L$	12
48	$L < 2.4$	9
48	$2.4 \leq L < 4.2$	10
48	$4.2 \leq L < 7$	11
48	$7 \leq L$	12

Table A5.5: Amplifier Current Loop Gain Settings

Setting Peak and Continuous Torque Limits

TK and TL Commands:

The peak and continuous torque limits can be set through the TK and TL commands respectively. The controller will command the torque signal (TT) up to the value specified by TK for a maximum of one second, as shown in Figure A5.2. It will then limit the torque to the value specified by TL. The more time the controller commands the torque below TL, the longer it will command it to TK when necessary. The DMC code example below exhibits the behavior of TT being limited by TL and TK, as shown in Figure A5.2.

```
#TK;           'Begin Program
MO;           'Disable all axes
AGA = 2;      'Set maximum amplifier gain of 2.0 A/V
TLA = 5;      'Set maximum continuous torque limit of 5 V
TKA = 9.9982; 'Set maximum peak torque limit of 9.9982 V
SHA;         'Enable A axis
OFA = 9.9982; 'Command torque signal to 9.9982 V
EN;          'End Program
```




Figure A5.2: Peak Current Operation

Stepper Motor Operation

To configure an axis for a bipolar stepper motor, set MT to -2 for that axis.

Setting Amplifier Gain and Current Loop Gain

The AG command will set the amplifier gain (Amps/Volt). The AU command will set the current loop gain.

AG Command:

The AMP-43547 has 4 amplifier gain (current) settings. The axis must be in a motor off (MO) state prior to execution of the AG command. The gain is set with the AG command as shown in Table A5.6 for AGm=n:

AG setting	Gain Value
n = 0	0.75 A/Phase
n = 1	1.5 A/Phase
n = 2	3 A/Phase
n = 3	6 A/Phase

Table A5.6: Amplifier Gain Settings

AU Command:

Proper configuration of the AU command is essential to optimize the operation of the AMP-43547. This command sets the gain for the current loop on the amplifier. Table A5.5 indicates the recommended AUm=n settings.

Low Current Mode

By default, 100% of the current set by the AG command will be delivered to the motor while the axis is holding position. An axis can be configured for Low Current mode so 25% of the current will be sent to the motor while holding position. Low Current mode can also be configured to wait a specified number of samples after a move is completed before lowering the current to 0%.

LC Setting	Description
n = 0	100% holding current
n > 1	100% current n samples after move finishes before going to 0% holding current
n = 1	25% holding current immediately after move finishes current
n < 0	100% current n samples after move finishes before going to 25% holding current

Table A5.7: Low Current Mode Configurations

Error Monitoring and Protection

The amplifier is protected against Over-Current, Over-Voltage, Over-Temperature, and Under-Voltage conditions. These conditions are reported as amplifier errors via the TA command and are cleared with the AZ command.

The user has the option to include the automatic subroutine #AMPERR in their program to handle amplifier errors. As long as the #AMPERR label is included in the program that is on the controller, the program will jump to the label when an amplifier error is detected and begin executing the user defined routine.

TA n is used to monitor amplifier errors with n = 0-3. The command will return an eight bit bitmask representing specific error conditions. It will also report whether an amplifier error is latched for the bank of axes A - D or the bank of axes E - H. See the TA command in the Command Reference for detailed information on bit status during error conditions.

Over-Current Protection

If there is a short circuit in the amplifier or motor, an Over-Current error will be reported and the amplifier will be disabled. Since the AMP-43547 is a trans-conductance amplifier, the amplifier should not encounter this error during normal operation. The Over-Current amplifier error is a latching error, see the Clearing Latched Amplifier Errors section for details.

WARNING	If this error occurs, it is indicative of a problem at the system level. An Over-Current error is usually due to a short across the motor leads or a short from a motor lead to ground.
----------------	---

Over-Voltage Protection

If the voltage supplied to the amplifier rises above its rated supply voltage, an Over-Voltage error will be reported. While the amplifier is experiencing this condition, current is no longer commanded and the motor phases are shorted together. This results in a drag on the motors causing them to coast to a stop. The amplifier will resume commanding current when the voltage drops below the maximum rated supply voltage. The Over-Voltage amplifier error is *not* a latching error.

WARNING	If this error occurs, it is indicative of a problem at the system level. An Over-Voltage error is usually due to regeneration from the motor and load. Consider using a shunt regulator if this occurs during normal operation.
----------------	---

Over-Temperature Protection

If the average amplifier temperature rises above 80°C, an Over-Temperature error will be reported and the amplifier will be disabled. The error cannot be cleared until the temperature drops below 80°C. The Over-Temperature amplifier error is a latching error, see the Clearing Latched Amplifier Errors section for details.

NOTE: An Over-Temperature error is usually due to insufficient heat dissipation from the amplifier. Heat must be drawn away from the base of the controller with forced air flow or a heat sink.

Under-Voltage Protection

If the voltage supplied to the amplifier drops below its rated supply voltage, an Under-Voltage error will be reported and the amplifier will be disabled. The error cannot be cleared until the supply voltage raises above its minimum rated supply voltage. The Under-Voltage amplifier error is a latching error, see the Clearing Latched Amplifier Errors section for details.

ELO Input

If the ELO input on the controller is asserted, the power stage of the amplifier will be disabled. The ELO input is a latching input, see the Clearing Latched Amplifier Errors section for details. Reference the Optoisolated Input Electrical Information section in Chapter 3 Connecting Hardware for information on connecting the ELO input.

Clearing Latched Amplifier Errors

While all axes are in a motor off state (MO) and there are no latched amplifier errors, all amplifier errors will be reported in real-time by the TA command. For an amplifier error to latch for a bank of axes, at least one axis in that bank must be in a servo here state (SH).

To clear latched amplifier errors, issue the MO command followed by AZ1. Use the TA command to report if an amplifier error condition is still present. If an axis is moving, motion must be halted before attempting to clear amplifier errors. See the #AMPERR label and AZ command in the Command Reference for more information and examples.

A6 – AMP-43640 (-D3640)

Description

The AMP-43640 contains four linear drives for sinusoidally commutating brushless motors. The AMP-43640 requires a single 15–40VDC input. Output power delivered is typically 20 W per amplifier or 80 W total. The gain of each transconductance linear amplifier is 0.2 A/V. When used with a 24VDC power supply, the amplifier will deliver 1A continuous and 2A peak. The current loop bandwidth is approximately 4 kHz. The amplifier will use 12 bit DACs. There is an option for 16 bit DACs to increase the current resolution for systems with high feedback gain.

[GDK](#)'s Step-By-Step tool provides an interactive guide for configuring brushless motors.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Servo (Brushless/Brushed)
Supply Voltage	15-40 VDC (15-20 VDC requires ISCNTL option)
Continuous Current	1.0 Amps
Peak Current	2.0 Amps
Amplifier Gains	0.2 Amps/Volt
Power Output (per channel)	20 W
Total Max Power Output	80 W

Table A6.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A6.2: Molex part numbers for connectors and terminal pin




Figure A6.1: Power and Motor Connector Diagram

Power Connector	
Pin Number	Connection
1,2,3	DC Power Supply Ground
4,5,6	+VS (DC Power)
Motor Connector	
Pin Number	Brushless
1	Phase C
2	Phase B
3	No Connect
4	Phase A

Table A6.3: Power and Motor Connector Pin-outs

Power

Unlike a switching amplifier a linear amplifier does not have a straightforward relationship between the power delivered to the motor and the power lost in the amplifier. Therefore, determining the available power to the motor is dependent on the supply voltage, the characteristics of the load motor, and the required velocity and current.

All of the power delivered by the power supply is either used in the motor or lost in the amplifier.

$$\text{Power of Power Supply } P_{ps} = P_m + P_a$$

The power to the motor is both the power used to provide motion and the power lost to heat.

$$\text{Power of the motor } P_m = \text{Work} + \text{Power Lost in Motor} \quad P_m = K_e * \text{Velocity} * i + i^2 R_m$$

$$\text{Power of amplifier } P_A = (V_s - i * R_m - K_e * \text{Velocity}) * i$$

In addition there is a minimum power dissipated by the amplifier when powered regardless of load. The minimum power that the amplifier will consume is roughly

$$P_{A, \min} \approx \text{drop across op amp power stages} + \text{drop across sense resistor} + \text{op amp supply}$$

$$P_{A, \min} \approx 4i + i^2 * .5 + N \quad \text{Where } N = 1.5W \text{ for } 24V \text{ and } N = 3W \text{ for } 48V$$

For example: assume a 24VDC supply and a motor with $R_m = 4\Omega$ and $K_e = 5V/RPM$ and desired output currents of 1 and .5 amps.

First calculate the minimum power used in the amplifier.

$$P_{A, \min}(1amp) \approx 4 * i + i^2 * .5 + 1.5 = 6W$$

$$P_{A, \min}(.5amp) \approx 4 * .5 + .5^2 * .5 + 3 = 5.125W$$

The power used by the motor will vary by its velocity even though the power lost in the motor is a constant for each value of current. The more power sent to the motor, the less power will be dissipated by the amplifier as heat.




Figure A6.2: Power Dissipation for Velocity and Current

Servo Motor Operation

Brushless Motor Operation

For Brushless motor operation, MT must be set to 1 for the axis. The 6 commands used for setup are the BA, BM, BX, BZ, BC and BI. Please see the Command Reference for details. Below is the setup procedure for configuring an axis to operate a Brushless motor.

1. Issue the BA command to specify on which axis to configure sinusoidal commutation.
2. The brushless modulus is the number of encoder counts per magnetic cycle and is set with the BM command. For example, in a rotary motor that has 2 pole pairs and 10000 counts per revolution, the number of encoder counts per magnetic cycle would be 10000/2. BM should be assigned to a value of 5000.
3. Issue either the BI and BC, BZ, or BX command to initialize the motor for sinusoidal commutation. The command must be executed on every reset or power-up of the controller.
 - **BI/BC Commands:**

If the motor includes hall sensors, Galil recommends using the BI and BC commands. The BI command uses the hall sensors to set the approximate location of the motor in the magnetic cycle. The BC command will precisely set the commutation angle upon detecting a hall state transition.
 - **BZ Command:**

If the motor does not include hall sensors, Galil recommends using the BZ command. The BZ command forces the motor to a known location in the magnetic cycle. Note that this can cause up to ½ a magnetic cycle of motion.
 - **BX Command:**

If the motor does not have hall sensors and the BZ command generates too much motion for the application, Galil recommends using the BX command. This command utilizes a minimal movement algorithm in order to determine the correct commutation of the motor.

Brushed Motor Operation

The AMP-43640 must be configured for brushed motor operation at the factory. Contact Galil prior to placing the order. Once the amplifier is configured for a brushed motor, the controller needs to be set for brushed mode by setting the BR command to a value of 1. The A and C motor phases are used for connecting to the brushed motor (B phase is a no connect).

Setting Peak and Continuous Torque Limits

TK and TL Commands:

The peak and continuous torque limits can be set through the TK and TL commands respectively. The controller will command the torque signal (TT) up to the value specified by TK for a maximum of one second, as shown in Figure A4.2. It will then limit the torque to the value specified by TL. The more time the controller commands the torque below TL, the longer it will command it to TK when necessary. The DMC code example below exhibits the behavior of TT being limited by TL and TK, as shown in Figure A4.2.

```
#TK;           'Begin Program
MO;           'Disable all axes
TLA = 5;      'Set maximum continuous torque limit of 5 V
TKA = 9.9982; 'Set maximum peak torque limit of 9.9982 V
SHA;         'Enable A axis
OFA = 9.9982; 'Command torque signal to 9.9982 V
EN;          'End Program
```




Figure A6.3: Peak Current Operation

ELO Input

If the ELO input on the controller is triggered, the amplifier will be shut down at a hardware level, the motors will be essentially in a Motor Off (MO) state. TA3 will change state and the #AMPERR routine will run when the ELO input is triggered. To recover from an ELO, an MO followed by a WT 2, and an SH must be issued, or the hardware reset of the controller must be performed.

It is recommended that OE1 be used for all axes when the ELO is used in an application.

See the Optoisolated Input Electrical Information section in Chapter 3 Connecting Hardware for information on connecting the ELO input.

Using External Amplifiers

The BR command must be set to a -1 for any axis where an AMP-43640 is installed but the use of an external axis is required. This setting will disable the requirement to have the BA, BM and BX or BZ commands executed prior to being able to issue the SH command for that axis. BR-1 is required for both external servo and stepper drivers.

Use the connectors on top of the controller to access necessary signals to run external amplifiers. For more information on connecting external amplifiers, see Step 2b. Connecting External Amplifiers and Motors in Chapter 2.

A7 – SDM-44040 (-D4040,-D4020)

Description

The SDM-44040 resides inside the DMC-41x3 enclosure and contains four drives for operating two-phase bipolar step motors. The SDM-44040 requires a single 12-30 VDC input. The unit is user-configurable for 1.4 A, 1.0 A, 0.75 A, or 0.5 A per phase and for full-step, half-step, 1/4 step or 1/16 step. A two-axis version, the SDM-44020 is also available.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Stepper
Supply Voltage	12-30 VDC ($\pm 12-20$ available with ISCNTL)
Max Current (Per Axis)	1.4 Amps/Phase (user-configurable)
Amplifier Gains (Amps/Phase)	0.5, 0.75, 1.0, 1.4
Max Step Frequency	6 MHz
Motor Type	Bipolar 2-Phase

Table A7.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A7.2: Molex part numbers for connectors and terminal pin




Figure A7.1: Power and Motor Connector Diagram

Power Connector	
Pin Number	Connection
1,2,3	DC Power Supply Ground
4,5,6	+VS (DC Power)
Motor Connector	
Pin Number	Stepper
1	B-
2	A-
3	B+
4	A+

Table A7.3: Power and Motor Connector Pin-outs

Stepper Motor Operation

Current Level Setup (AG Command)

The AMP-440x0 has 4 amplifier gain settings. The amplifier gain (in Amps/Volt) is set with the AG command as shown in Table A8.4 for AGm=n, where m is a specific axis. The axis must be in a motor off (MO) state prior to execution of the AG command.

AG setting	Gain Value
n = 0	0.5 A/V
n = 1	0.75 A/V
n = 2	1.0 A/V
n = 3	1.4 A/V

Table A8.4: Amplifier Gain Settings

Low Current Setting (LC Command)

By default, Low Current mode is disabled (LCm = 0) which means that 100% of the current set by the AG command will be delivered to the motor while the axis is holding position. An axis can be configured for Low Current mode so either 25% of the current or no current will be sent to the motor while holding position. Low Current mode can also be configured to wait a specified number of samples after a move is completed before lowering the holding current.

Low Current Operation per Axis: YA n,n,n,n,n,n,n

LC setting	Effect on Stepper Phase Current
n > 1	n samples after move finishes before going to 0% holding current
n = 1	25% holding current immediately after move finishes
n = 0	100% holding current
n < 0	n samples after move finishes before going to 25% holding current

Table A8.5: Low Current Mode configurations

Step Drive Resolution Setting (YA command)

When using the SDM-44040, the step drive resolution can be set with the YA command. Note, when running in full step mode – the current to the motor is 70% of maximum. All micro-step settings are able to deliver full current.

Step Drive Resolution per Axis: YA n,n,n,n,n,n,n

AG setting	Gain Value
n = 1	Full
n = 2	Half
n = 4	1/4
n = 16	1/16

Table A8.6: Amplifier Gain Settings

ELO Input

If the ELO input on the controller is triggered, the amplifier will be shut down at a hardware level, the motors will be essentially in a Motor Off (MO) state. TA3 will change state and the #AMPERR routine will run when the ELO input is triggered. To recover from an ELO from the terminal, an MO followed by LC*=0, and an SH must be issued. To recover from an ELO in DMC code, include WT2 after LC*=0 and before the SH command. TA3 will report ELO has been cleared after the SH command is received by the controller.

It is recommended that OE1 be used for all axes when the ELO is used in an application.

See the Error: Reference source not found section in Error: Reference source not found for information on connecting the ELO input.

Using External Amplifiers

Use the connectors on top of the controller to access necessary signals to run external amplifiers. For more information on connecting external amplifiers, see Step A in Chapter 2.

Protection Circuitry

The SDM-44040 has short circuit protection. The short circuit protection will protect against phase to phase shorts, a shorted load and a short to ground or chassis.

In the event of any of a fault, TAO will change state and the SDM-44040 will be disabled.

In the event that power is removed to the SDM-44040 but not to the controller, an amplifier error will occur.

To recover from an error state, all 4 axes need to be set into MO state, LC must set to 0 and then the SH command must be issued.

Clearing Latched Amplifier Errors

Default Error Clearing

Amplifier errors that do not latch will be reported in real-time by the TA command.

For latching errors to report and latch for a bank of axes, at least one axis in that bank must be in a servo here state (SH).

To clear latched amplifier errors, issue the MO command followed by SH. If an axis is moving, motion must be halted before attempting to clear amplifier errors.

Enhanced Error Clearing

Enhanced error clearing and reporting can be enabled by issuing AZ2 to the controller.

While all axes are in a motor off state (MO) and there are no latched amplifier errors, all amplifier errors will be reported in real-time by the TA command. For an amplifier error to latch for a bank of axes, at least one axis in that bank must be in a servo here state (SH).

To clear latched amplifier errors, issue the MO command followed by AZ1. Use the TA command to report if an amplifier error condition is still present. If an axis is moving, motion must be halted before attempting to clear amplifier errors. See the #AMPERR label and AZ command in the Command Reference for more information and examples.

NOTE: Enhanced Error Clearing is supported on the DMC-4000 as of firmware revision 1.3d and amplifier hardware revision 4.

A8 – SDM-44140 (-D4140)

Description

The SDM-44140 resides inside the DMC-40x0 enclosure and contains four microstepping drives for operating two-phase bipolar stepper motors. The drives produce 64 microsteps per full step which results in 12,800 steps/rev for a standard 200-step motor. The maximum step rate generated by the controller is 6,000,000 microsteps/second. The SDM-44140 drives motors operating at up to 3 Amps at 20 to 60 VDC (available voltage at motor is 10% less). There are four software selectable current settings: 0.5 A, 1 A, 2 A and 3 A. Plus, a selectable low current mode reduces the current by 75% when the motor is not in motion. No external heatsink is required.

WARNING	Do not “hot swap” the motor power or supply voltage power input connections. If the amplifier is enabled when the motor connector is connected or disconnected, damage to the amplifier can occur. Galil recommends powering the controller and amplifier down before changing the connector, and breaking the AC side of the power supply connection in order to power down the amplifier.
----------------	---

Electrical Specifications

	Stepper
Supply Voltage	20-60 VDC
Max Current (Per Axis)	3.0 Amps/Phase (user-configurable)
Amplifier Gains (Amps/Phase)	0.5, 1.0, 2.0, 3.0
Max Step Frequency	6 MHz
Minimum Load Inductance	0.5 mH
Motor Type	Bipolar 2-Phase

Table A8.1: Amplifier Electrical Specifications

Mating Connectors

	Cable Connectors	Terminal Pins	On board Connector
POWER	6-pin Mini-Fit, Jr.™ (Male) Molex #0039012065	Molex #0444761112	6-pin Mini-Fit, Jr.™ (Female) Molex #0039310060
A,B,C,D: 4-pin Motor Power Connectors	4-pin Mini-Fit, Jr.™ (Male) Molex #0039012045	Molex #0444761112	4-pin Mini-Fit, Jr.™ (Female) Molex #0039310040

Table A8.2: Molex part numbers for connectors and terminal pin




Figure A8.1: Power and Motor Connector Diagram

Power Connector	
Pin Number	Connection
1,2,3	DC Power Supply Ground
4,5,6	+VS (DC Power)
Motor Connector	
Pin Number	Stepper
1	B-
2	A-
3	B+
4	A+

Table A8.3: Power and Motor Connector Pin-outs

Stepper Motor Operation

Current Level Setup (AG Command)

The AMP-44140 has 4 amplifier gain settings. The amplifier gain (in Amps/Volt) is set with the AG command as shown in Table A8.4 for AGm=n, where m is a specific axis. The axis must be in a motor off (MO) state prior to execution of the AG command.

AG setting	Gain Value
n = 0	0.5 A/V
n = 1	1.0 A/V
n = 2	2.0 A/V
n = 3	3.0 A/V

Table A8.4: Amplifier Gain Settings

Low Current Setting (LC Command)

By default, Low Current mode is disabled (LCm = 0) which means that 100% of the current set by the AG command will be delivered to the motor while the axis is holding position. An axis can be configured for Low Current mode so either 25% of the current or no current will be sent to the motor while holding position. Low Current mode can also be configured to wait a specified number of samples after a move is completed before lowering the holding current.

Low Current Operation per Axis: YA n,n,n,n,n,n,n

LC setting	Effect on Stepper Phase Current
n > 1	n samples after move finishes before going to 0% holding current
n = 1	25% holding current immediately after move finishes
n = 0	100% holding current
n < 0	n samples after move finishes before going to 25% holding current

Table A8.5: Low Current Mode configurations

ELO Input

If the ELO input on the controller is triggered, the amplifier will be shut down at a hardware level, the motors will be essentially in a Motor Off (MO) state. TA3 will change state and the #AMPERR routine will run when the ELO input is triggered. To recover from an ELO from the terminal, an MO followed by LC*=0, and an SH must be issued. To recover from an ELO in DMC code, include WT2 after LC*=0 and before the SH command. TA3 will report ELO has been cleared after the SH command is received by the controller.

It is recommended that OE1 be used for all axes when the ELO is used in an application.

See the Error: Reference source not found section in Error: Reference source not found for information on connecting the ELO input.

Using External Amplifiers

Use the connectors on top of the controller to access necessary signals to run external amplifiers. For more information on connecting external amplifiers, see Step A in Chapter 2.

Error Monitoring and Protection

The amplifier is protected against under-voltage and over-current conditions. The controller will monitor the error conditions and respond as programmed in the application. The errors are monitored via the TA command. TA n may be used to monitor the errors with n = 0 or 3. The command will return an eight bit number representing specific conditions. TA0 will return errors with regard to under voltage, and over current. TA3 will return if the ELO input has been triggered.

The user also has the option to include the special label #AMPERR in their program to handle soft or hard errors. As long as a program is executing in thread zero and the #AMPERR label is included, when an error is detected the program will jump to the label and execute the user defined routine. Note that the TA command is a monitoring function only, and does not generate an error condition.

See the TA command for detailed information on bit status during error conditions.

Over-Current Protection

The stepper driver has circuitry to protect against over-current. If the total current from a set of 2 axes (ie A and B or C and D) exceeds 10 A, the SDM-44140 will be disabled. The amplifier will not be re-enabled until there is no longer an over-current draw and then either SH command has been sent or the controller is reset. The amplifier will never go into this mode during normal operation. The amplifier will be shut down regardless of the setting of OE, or the presence of the #AMPERR routine.

WARNING	If this error occurs, it is indicative of a problem at the system level. An Over-Current error is usually due to a short across the motor leads or a short from a motor lead to ground.
----------------	---

Under-Voltage Protection

If the voltage supplied to the amplifier drops below its rated supply voltage, the amplifier will be disabled. The amplifier will return to normal operation once the supply is raised above its minimum rated supply voltage.

Note: If there is an #AMPERR routine and the controller is powered before the amplifier, then the #AMPERR routine will automatically be triggered.

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at [artisan^{tg}.com](https://www.artisantg.com) for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisan^{tg}.com | [artisan^{tg}.com](https://www.artisantg.com)

