

NI PCI-8432/4

High Performance, Isolated 4-Port Serial Interface (RS-232)



© Artisan Technology Group

In Stock

Used and in Excellent Condition

Open Web Page

<https://www.artisanng.com/71666-12>

All trademarks, brandnames, and brands appearing herein are the property of their respective owners.



Your **definitive** source
for quality pre-owned
equipment.

Artisan Technology Group

(217) 352-9330 | sales@artisanng.com | artisanng.com

- Critical and expedited services
- In stock / Ready-to-ship

- We buy your excess, underutilized, and idle equipment
- Full-service, independent repair center

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

Serial Installation Guide

Contents

Supported Operating Systems	1
PCI/PCI Express/PXI/PXI Express Serial Installation	2
USB Serial Installation.....	2
ENET Serial Installation	3
ExpressCard Serial Installation	3
PCMCIA Serial Installation	4

Supported Operating Systems

The following table lists the operating systems each hardware interface supports.

Interface Type	Windows 7 32	Windows 7 64	Windows Vista 32	Windows Vista 64	Windows XP/2000	Windows 2003 Server R2 32	Windows 2008 Server R2 64	LabVIEW Real-Time
PCI-843x	✓	✓	✓	✓	✓ ³	✓	✓	✓
PCI-232/485	✓	✓	✓	✓	✓ ³	✓	✓	✓
NI PCIe-843x	✓	✓	✓	✓	✓ ³	✓	✓	✓
PXI-843x	✓	✓	✓	✓	✓ ³	✓	✓	✓
NI PXIe-843x	✓	✓	✓	✓	✓ ³	✓	✓	✓
PXI-842x	✓	✓	✓	✓	✓ ³	✓	✓	✓
USB	✓	✓	✓	✓	✓ ³	✓	✓	
ENET	✓	✓ ¹	✓	✓ ¹	✓ ³	✓ ¹	✓	✓ ¹
ExpressCard	✓	✓	✓	✓	✓ ³	✓	✓	
PCMCIA			✓ ²		✓ ²			
¹ NI-VISA support only. ² Supported by NI-Serial versions 3.5.0 and earlier. ³ Windows 2000 supported by NI-Serial versions 3.5.1 and earlier.								



PCI/PCI Express/PXI/PXI Express Serial Installation

Refer to the *Serial Hardware and Software Help* (available on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

1. Log on as Administrator or as a user with administrator privileges.
2. Insert the *NI-Serial Software for Windows* CD.
3. Click **Install Software** and follow the onscreen instructions.
4. Power down the computer, install your serial PCI, PCI Express, PXI, or PXI Express hardware, and power on the computer.
5. After Windows detects your hardware, select **Start»Programs»National Instruments»NI-Serial»Troubleshooting Wizard**.
6. The Troubleshooting Wizard window appears. This application verifies the software and hardware installation and sequentially tests each NI serial port.
7. Connect the cables.

USB Serial Installation



Caution The USB Serial device and the computer must share the same ground potential.

Refer to the *Serial Hardware and Software Help* (available on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

1. Log on as Administrator or as a user with administrator privileges.
2. Insert the *NI-Serial Software for Windows* CD.
3. Click **Install Software** and follow the onscreen instructions.
4. Restart the computer.
5. If you are installing a USB-485/4, connect the external power supply.
6. Connect the USB cable from the USB hardware to an available USB port on your computer or USB hub.
7. Select **Start»Programs»National Instruments»NI-Serial»Troubleshooting Wizard**.
8. The Troubleshooting Wizard window appears. This application verifies the software and hardware installation and sequentially tests each NI serial port.
9. Connect the cables.

ENET Serial Installation

Refer to the *Serial Hardware and Software Help* (available on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

1. Log on as Administrator or as a user with administrator privileges.
2. Insert the *NI-Serial Software for Windows* CD.
3. Click **Install Software** and follow the onscreen instructions.
4. Restart the computer.
5. Install your Serial ENET hardware.
 - a. Select **Start»Programs»National Instruments»NI-Serial»Add Serial ENET** to launch the Add Serial ENET wizard.
 - b. Follow the prompts to add your serial ENET interface(s). If you see the Hardware Installation dialog box, click **Continue Anyway**. You may see two Hardware Installation dialog boxes per port being installed.
 - c. When finished adding your serial ENET interface(s), restart your computer.
6. Select **Start»Programs»National Instruments»NI-Serial»Troubleshooting Wizard**.
7. The Troubleshooting Wizard window appears. This application verifies the software and hardware installation and sequentially tests each NI serial port.
8. Connect the cables.

ExpressCard Serial Installation

Refer to the *Serial Hardware and Software Help* (available on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

1. Log on as Administrator or as a user with administrator privileges.
2. Insert the *NI-Serial Software for Windows* CD.
3. Click **Install Software** and follow the onscreen instructions.
4. Restart the computer.
5. Insert your serial ExpressCard hardware.
6. Select **Start»Programs»National Instruments»NI-Serial»Troubleshooting Wizard**.

7. The Troubleshooting Wizard window appears. This application verifies the software and hardware installation and sequentially tests each NI serial port.
8. Connect the cables.

PCMCIA Serial Installation

Refer to the *Serial Hardware and Software Help* (available on the CD) for more information about troubleshooting problems, configuring the hardware and software, programming requirements, and more.

1. Log on as Administrator or as a user with administrator privileges.
2. Insert the *NI-Serial Software for Windows* CD.
3. Click **Install Software** and follow the onscreen instructions.
4. Restart the computer.
5. Insert your serial PCMCIA hardware.
6. Select **Start»Programs»National Instruments»NI-Serial»Troubleshooting Wizard**.
7. The Troubleshooting Wizard window appears. This application verifies the software and hardware installation and sequentially tests each NI serial port.
8. Connect the cables.

LabVIEW, National Instruments, NI, ni.com, the National Instruments corporate logo, and the Eagle logo are trademarks of National Instruments Corporation. Refer to the *Trademark Information* at ni.com/trademarks for other National Instruments trademarks. The ExpressCard™ word mark and logos are owned by PCMCIA and any use of such marks by National Instruments is under license. Other product and company names mentioned herein are trademarks or trade names of their respective companies. For patents covering National Instruments products/technology, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your media, or the *National Instruments Patent Notice* at ni.com/patents.

© 2005–2010 National Instruments Corporation. All rights reserved.

371583J-01

May10

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at [artisanTG.com](https://www.artisanTG.com) for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisanTG.com | [artisanTG.com](https://www.artisanTG.com)

