



Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

*InstraView*SM REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at www.instraview.com ↗

WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. www.artisanng.com/WeBuyEquipment ↗

LOOKING FOR MORE INFORMATION?

Visit us on the web at www.artisanng.com ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

Contact us: (888) 88-SOURCE | sales@artisanng.com | www.artisanng.com

Document Number: 812628
Version: 1
Date: October 2003

SCP/DCP-122
3U COMPACTPCI
SINGLE BOARD COMPUTER
GETTING STARTED MANUAL

DY 4 Systems Inc.
333 Palladium Drive
Kanata, Ontario, Canada
K2V 1A6
(613) 599-9199

VERSION HISTORY

Version	By	Date	Description
1	JP	October 2003	New document release.

COPYRIGHT NOTICE

The information in this document is subject to change without notice and should not be construed as a commitment by Dy 4 Systems Inc. While reasonable precautions have been taken, Dy 4 Systems Inc. assumes no responsibility for any errors that may appear in this document.

No part of this document may be copied or reproduced without the prior written consent of Dy 4 Systems Inc.

The proprietary information contained in this document must not be disclosed to others for any purpose, nor used for manufacturing purposes, without written permission of Dy 4 Systems Inc. The acceptance of this document will be construed as an acceptance of the foregoing condition.

Copyright © 2003, Dy 4 Systems Inc. All rights reserved.

TRADEMARKS

Flash is a trademark of Seeq Technology.

All other brand and product names are trademarks or registered trademarks of their respective owners.

TABLE OF CONTENTS

1. Product Overview	1-1
Introducing the SCP/DCP-122	1-1
Features List	1-2
PMC Expansion	1-2
Physical Characteristics	1-4
Weight Limits	1-5
Dimensions	1-5
Mating Connectors	1-5
Electrical Characteristics	1-6
Power Requirements.....	1-6
Voltage Requirements.....	1-6
Overview of Supplied Firmware	1-7
Foundation Firmware.....	1-7
Board Support Packages, Drivers	1-7
2. Pre-Installation Tasks.....	2-1
Introduction.....	2-1
Unpacking the Card	2-1
Configuring Jumpers	2-2
Boot Flash Write Protect Jumper	2-4
Application Flash Write Protect Jumper.....	2-5
PABS Flash Write Protect Jumper	2-6
Boot From PABS Memory	2-7
Watchdog Timer Behaviour.....	2-8
Execution Sequence Control Jumper	2-9
Backup FPGA Boot PROM Jumper (Reserved)	2-10
3. Installing PMC Modules on the SCP/DCP-122.....	3-1
Before You Begin.....	3-1
Installation Procedure	3-2
Unpack and Configure the Card.....	3-2
Install the PMC Module on the SCP/DCP-122.....	3-2
4. Hardware Installation.....	4-1
Introduction.....	4-1
Inserting the Card in a Chassis.....	4-2
Before You Begin... ..	4-2
About Card Insertion Force.....	4-2
Choosing a Slot Location	4-2
Connecting a Terminal	4-3
BPK-122-000 Transition Module	4-3
Controlling the Boot Sequence	4-15
Foundation Firmware Used During Power-Up.....	4-15
Initiating the Power-Up Sequence	4-16
Power-Up.....	4-16
Initial LED Activity.....	4-16
Displaying the Initial Screen Message.....	4-16
Troubleshooting	4-17
Verify Insertion in Chassis	4-17
Status LED Stays Red	4-17
Sign-on Message Garbled.....	4-21
The Next Step	4-21

LIST OF FIGURES

Figure 1.1:	DCP-122	1-1
Figure 1.2:	SCP/DCP-122 Functional Block Diagram	1-3
Figure 1.3:	SCP-122 Component Side View	1-4
Figure 1.4:	SCP-122 Solder Side View	1-4
Figure 2.1:	SCP/DCP-122 Jumper Locations	2-3
Figure 2.2:	Boot Flash Write Protect Jumper	2-4
Figure 2.3:	Application Flash Write Protect Jumper.....	2-5
Figure 2.4:	PABS Flash Write Protect Jumper	2-6
Figure 2.5:	Boot From PABS Memory Jumper	2-7
Figure 2.6:	Watchdog Timer Power-up Jumper	2-8
Figure 2.7:	Execution Sequence Control Jumper	2-9
Figure 2.8:	FPGA Boot PROM Select	2-10
Figure 3.1:	Installing a PMC Module on a DCP-122.....	3-3
Figure 4.1:	SCP-122 Terminal Connection via (BPK-122-000) Transition Module	4-3
Figure 4.2:	Digital I/O via the Transition Module.....	4-5
Figure 4.3:	EIA-422 Channel 3 and Channel 4 Header Pins.....	4-7
Figure 4.4:	Using the CBL-SBC-P0-000 with the Transition Module	4-8
Figure 4.5:	CBL-700-001 Used in Conjunction with BPK-122-000	4-9
Figure 4.6:	Sample Diagnostics Results Table (DRT)	4-17

LIST OF TABLES

Table 1.1:	Maximum CCA Mass	1-5
Table 1.2:	Dimensions of the SCP/DCP-122	1-5
Table 1.3:	SCP/DCP-122 Board Current Requirements.....	1-6
Table 2.1:	Jumper Settings Summary	2-2
Table 2.2:	Boot Flash Write Protect Jumper	2-4
Table 2.3:	Application Flash Write Protect Jumper.....	2-5
Table 2.4:	PABS Flash Write Protect Jumper	2-6
Table 2.5:	Enable Booting from PABS Memory.....	2-7
Table 2.6:	Watchdog Timer Power-up Behaviour	2-8
Table 2.7:	User Link Configuration.....	2-9
Table 2.8:	Backup FPGA Boot PROM Select	2-10
Table 4.1:	Serial Channel 1 RS-232 Connector (BPK-122-000 J3) Pinout.....	4-4
Table 4.2:	Serial Channel 2 RS-232 Connector (BPK-122-000 J6) Pinout.....	4-4
Table 4.3:	USB Connector (BPK-122-000 J4) Pinout.....	4-4
Table 4.4:	Ethernet Connector (BPK-122-000 J5) Pinout.....	4-5
Table 4.5:	DIO Header Pinout	4-6
Table 4.6:	EIA-422 Channel 3 Pinout	4-7
Table 4.7:	EIA-422 Channel 4 Pinout	4-7
Table 4.8:	Transition Module P0 Row A Signal Mapping	4-10
Table 4.9:	Transition Module P0 Row B Signal Mapping	4-11
Table 4.10:	Transition Module P0 Row C Signal Mapping	4-12
Table 4.11:	Transition Module P0 Row D Signal Mapping	4-13
Table 4.12:	Transition Module P0 Row E Signal Mapping.....	4-14
Table 4.13:	Foundation Firmware Execution Sequence	4-15

PREFACE

PURPOSE

This manual provides an overview of the features and functions of the SCP/DCP-122 Single Board Computer and explains how to correctly install the card and verify its basic operation.

AUDIENCE

This manual is intended for the reader who has a technical understanding of hardware engineering fundamentals, and a basic understanding of the CompactPCI architecture.




Cross Reference

More in-depth technical information about the SCP/DCP-122 hardware is provided in the SCP/DCP-122 Hardware User's Manual, document number 812629, which is included in the documentation package.

DOCUMENTATION ROADMAP

The figure below will help you understand what documentation is available for the SCP/DCP-122 and related products. These documents are delivered in Adobe Acrobat.pdf format on CD-ROM, or may be obtained via our TechNet web site at <http://www.technet.dy4.com/>.



SCOPE OF THIS MANUAL

This manual contains the following chapters:

Chapter 1 - Product Overview. Provides general information about the features and functions of the SCP/DCP-122.

Chapter 2 - Pre-Installation Tasks. Discusses tasks that must be performed prior to installing the SCP/DCP-122 in a chassis. Provides information on jumper configurations, cabling, and power requirements.

Chapter 3 - Installing PMC Modules on the SCP/DCP-122. Explains how to ensure that thermal and mechanical requirements for PMC module mounting are met when mounting PMC modules on the SCP/DCP-122.

Chapter 4 - Hardware Installation. Explains how to install the SCP/DCP-122 in a chassis and verify that it is operating correctly.

CONVENTIONS USED IN THIS MANUAL

This document and the accompanying documents in the documentation package use various icon conventions and abbreviations to make the documents clearer and easier to read. These conventions cover typography for such elements as sample software code and keystrokes, signal meanings, and graphical elements for important information such as warnings or cautions.

Typographic Conventions

Table 1 lists the typographical conventions used in documents contained in this document and the associated documentation package.

TABLE 1: Typographical Conventions

Item	Convention	Example
Keystrokes	Keys are listed as they appear on most keyboards, surrounded by < > marks. Combinations of key-strokes appear within a single set of < > brackets.	Type < Ctrl-Alt-C > to return to the previous menu. Type < Esc > to exit.
File Names	File names are set in italics.	Open the file named <i>es.h</i> .
Directory Names	Directory names show the full directory path. The last directory in the path does not have a trailing slash following it.	Go to the <i>c:\windows\temp\backup</i> directory.
Monitor Displays	Prompts and other text appearing on monitors is set in bold monospace type.	% mpp MC68040gnu >
Firmware Code	Firmware code, and any information you need to type in response to a prompt, is set in monospace type.	% make -f Makefile.MC68040gnu

Signal Conventions

Table 2 shows symbols which can follow a signal name. For example, the octothorpe (#) is used with a PCI signal name, such as TRDY#.

TABLE 2: Signal Conventions

Symbol	Description
[no symbol]	The signal is active HIGH (with no indication as to which bus the signal is connected).
#	The signal is active LOW and is connected to the PCI bus.

Abbreviations

Table 3 lists the abbreviations used to describe the size of a memory device or a range of addresses.

TABLE 3: Abbreviations

Abbreviation	Convention
1 Kbyte	1,024 bytes
1 Mbyte	1,024 Kbytes
1 Gbyte	1,024 Mbytes

Memory Addresses

Unless otherwise stated, all memory addresses are shown in hexadecimal notation.

Icons

The following icons are used throughout this document:


	<p>Cross references to other documents are used when a subject being discussed is addressed in depth by another, more authoritative document. Cross references are also used for document chapters and sections.</p>
	<p>The warning icon indicates procedures in the manual that, if not carried out, or if carried out incorrectly, could cause physical injury, electrical damage to equipment, or a non-recoverable corruption of data. Warnings include instructions for preventing such damage. Please observe warning icons and read the accompanying text completely before carrying out the procedure.</p>
	<p>The caution icon indicates non-catastrophic incidents, complex practices, or procedures which, if not observed, could result in damage to the hardware. Cautions include specific instructions for avoiding or minimizing these incidents.</p>
	<p>The note icon highlights exceptions and special information.</p>
	<p>Tips provide extra information on the subject matter. This could include hints about how to use your current DY 4 card to its maximum potential.</p>

PRODUCT OVERVIEW

INTRODUCING THE SCP/DCP-122

Designed for space constrained applications, the SCP/DCP-122 offers the greatest processing power of any ruggedized 3U cPCI single board computer on the market today. Based on the IBM 750FX processor, it runs at a clock speed of 800 MHz while executing an impressive 1856 Dhrystone Millions of Instructions per Second (DMIPS). No other rugged COTS 3U cPCI single board computer can match the raw processing power of the SCP/DCP-122.

FIGURE 1.1: DCP-122



FEATURES LIST

- Based on the IBM PowerPC 750FX processor
 - 800+ MHz
 - 1856+ DMIPS
 - 100 MHz CPU bus speed
 - 512 Kbyte of Internal L2 Cache running at core processor speed
- cPCI Bus
 - System controller and Peripheral controller
 - 3.3V or 5V signalling supported
 - 33 or 66MHz operation
- PMC Expansion Site
 - 64-bit, 33/66 MHz
 - Support for 3.3V or +5V PMC's
 - Full 64-bit user I/O
- Memory
 - 128 Mbyte or 256 Mbyte of SDRAM with ECC at 100 MHz
 - 64 Mbyte non-volatile Flash
 - Flash for Permanent Alternate Boot Site (PABS)
 - 32 Kbyte nonvolatile RAM
- I/O
 - 1 x 10/100BaseT Ethernet port
 - 2 x RS-232 Serial port
 - 2 x HDLC/SDLC-capable EIA 422 serial channels (2 asynchronous or 1 synchronous)
 - 1 x USB
 - 8 x general purpose DMA controllers
 - Up to 16-bit Discrete I/O

PMC EXPANSION


To extend system flexibility and enhance system functionality through expansion, the SCP/DCP-122 provides a full speed 64-bit 33/66 MHz PMC site directly on the basecard. A complement of Dy 4 PMC's have been tested and qualified over temperature, shock and vibration to ensure interoperability in harsh environments, including:

- Trinity 2 - PMC-702 graphics controller
- Trinity 1 - PMC-700 graphics controller
- PMC-643 dual channel, conduction cooled Fibre Channel card
- PMC-601 dual MIL-STD 1553 interface

Expansion can further be enhanced by combining the SCP/DCP-122 with Dy 4's conduction cooled cPCI PMC carrier card, the SCP/DCP-201.

Figure 1.2 illustrates the architecture and major components of the SCP/DCP-122.

FIGURE 1.2: SCP/DCP-122 Functional Block Diagram



Cross Reference

Please refer to Chapter 1 of the SCP/DCP-122 Hardware User's Manual, document number 812629, for a detailed description of each of the functional blocks in the above diagram.

PHYSICAL CHARACTERISTICS

The following figures will help familiarize you with the location of the major components and connectors of the SCP/DCP-122. Although the SCP-122 is used for illustration purposes, the board layout for the DCP version product is identical.

FIGURE 1.3: SCP-122 Component Side View





FIGURE 1.4: SCP-122 Solder Side View



The SCP/DCP-122 board has the following physical characteristics:

WEIGHT LIMITS

The mass of the SCP/DCP-122 board does not exceed the values specified in Table 1.1.

TABLE 1.1: Maximum CCA Mass

Card Type	Weight (grams)
DPMC	150
SPMC	200

DIMENSIONS

The SCP/DCP-122 is built on a CompactPCI-compatible single-height (3U) PWB. Table 1.2 lists the dimensions of the SCP/DCP-122.

TABLE 1.2: Dimensions of the SCP/DCP-122

Parameter	Dimensions
Height	100 mm
Depth	160 mm

MATING CONNECTORS

The locations of the connectors on the SCP/DCP-122 are shown in Figure 1.3.

Backplane Connectors

The SCP/DCP-122 incorporates J1 and J2 connectors as specified in the PICMG compact PCI specification 2.0, Revision 3.0.

PMC Connectors

In order to support the mounting of a single PCI Mezzanine Card (PMC) in accordance with the IEEE 1386-2001 standard, the SCP/DCP-122 includes the Pn1, Pn2, Pn3 and Pn4 connectors as specified in the standard.

ELECTRICAL CHARACTERISTICS

POWER REQUIREMENTS

The SCP/DCP-122 maximum and typical power requirements are listed in Table 1.3.

TABLE 1.3: SCP/DCP-122 Board Current Requirements

Voltage	Maximum Current	Typical Current
+3.3V (+5%, -3%)	1.1 A	0.9 A
+5V (+5%, -3%)	2.2 A	1.8 A
+12V \pm 0.6V (\pm 5%)	0 A	Not used by the base card, only routed to the PMC sites.
-12V \pm 0.6V (\pm 5%)	0 A	Not used by the base card, only routed to the PMC sites.

The power dissipation of the SCP/DCP-122 ranges between 12 watts (typical) and 15 watts (maximum), as measured on a small sampling of product over a limited operating temperature range, with no PMC module installed.

VOLTAGE REQUIREMENTS

The SCP/DCP-122 expects the following voltages to be available from the compact PCI backplane, as specified in the PICMG specification: 5V, 3.3V, +VIO, +12V, and -12V.

OVERVIEW OF SUPPLIED FIRMWARE

FOUNDATION FIRMWARE

The SCP/DCP-122 is programmed with the following Foundation Firmware (FFW) modules:

- General Purpose Monitor (GPM): provides comprehensive monitoring and debug functions, which can be accessed from a terminal connected to the SCP/DCP-122 serial channel 1 interface
- Card Level Diagnostics (CLD): provides diagnostic routines which work with your card's Built-In-Test functions
- Card Support Services (CSS): provides a software interface to your card's hardware
- Execution Sequencer (ES): controls the execution sequence of software during a card's boot-up
- Non-Volatile Memory Programmer (NVMP): provides for in-circuit programming of Flash memory.



Cross Reference

Refer to the FF/W Software User Manual (document number 808006) and the FF/W Programmer's Reference (document number 812587) (included in the documentation package) for additional information.

See also the Dy 4 Troubleshooting Wizard, which is available for your convenience at <http://www.technet.dy4.com/wizard/index.htm> (or simply click the FAQ link on the TechNet home page).

BOARD SUPPORT PACKAGES, DRIVERS

Support is provided for the VxWorks operating system. The VxWorks boot loader is pre-loaded on the SCP/DCP-122 hardware. Refer to the BSP Release Notes and the BSP Software User's Manual (delivered on the BSP s/w CD-ROM) for additional information.

PRE-INSTALLATION TASKS

INTRODUCTION

This chapter explains how to configure the SCP/DCP-122 before it is installed in a CompactPCI chassis. Specifically, this chapter provides the following information:

- unpacking the card
- modifying the SCP/DCP-122 jumper settings
- checking cable and power requirements.

UNPACKING THE CARD



Warning

This card uses components that are sensitive to electrostatic discharges. It must be kept in its conductive package until just before the installation begins. Remove the card from its protective package only at a grounded workstation while wearing an approved grounding wrist strap. Avoid touching any metal contacts on the card; static discharge can damage integrated circuits. To avoid damage to the card or to avoid any personal injury, remove the power from the chassis prior to removing or installing cards.

To unpack the card from its protective package, follow these steps:

1. Unpack the card from the shipping carton in a suitable work area. If the shipping carton appears to be damaged, request that an agent of the shipper or carrier be present during unpacking and inspection.
2. Find the packing list. Verify that all the items on the list are present.
3. Save the packing material for storing or reshipping the card.

CONFIGURING JUMPERS



Cross Reference

Depending on your application, it may be necessary to modify the default jumper settings on your SCP/DCP-122. For information about your card's default configuration, refer to the *Product Release Note*.

Table 2.1 summarizes the user-configurable jumper settings. In-depth descriptions of these settings are provided in subsequent pages.

Factory configurations are performed via the installation/removal of configuration resistors. Please contact the factory if you require information about factory configured options. Under normal circumstances, you should not need to alter any of the factory-configured options.

TABLE 2.1: Jumper Settings Summary

Option	Jumper Setting
Flash Boot Write Protect Enable/Disable: Disable Flash Boot Write Protect. Enable Flash Boot Write Protect.	Connect E1-E2 Open E1-E2
Flash Application Bank Write Protect Enable/Disable: Disable Flash Application Bank Write Protect. Enable Flash Application Bank Write Protect.	Connect E3-E4 Open E3-E4
Enable Writes to Permanent Alternate Boot Site (PABS) Memory: Disable Permanent Alternate Boot Bank Write Protect. Enable Permanent Alternate Boot Bank Write Protect.	Connect E5-E6 (caution: for factory use only) Open E5-E6 (normal configuration)
Boot from the Permanent Alternate Boot Site (PABS): Boot from 8-bit PABS site. Boot from the main Flash memory.	Connect E7-E8 Open E7-E8
Configuring Watchdog Timer Behaviour: Watchdog timer generates an interrupt on timeout. Watchdog timer generates a reset on timeout.	Connect E9-E10 Open E9-E10
Changing the Execution Sequence during Card Boot Up: (see "Controlling the Boot Sequence" on page 4-15 for more information)	Connect E11-E12 to connect User Link/Software Switch (SW0) signal to ground. Open E11-E12 to pull up User Link/Software Switch (SW0)

TABLE 2.1: Jumper Settings Summary (Continued)


<p>Configure FPGA from Back-up PROM (Reserved):</p>	<p>Open E13-E14</p>
<p>A provision for a Back-up PROM for the FPGA exists in the design of the SCP/DCP-122, however it has not been implemented at the present time, meaning the jumper at E13-E14 must not be connected.</p>	



Note

All other E jumper locations not specifically mentioned in the above table are reserved for factory use.

FIGURE 2.1: SCP/DCP-122 Jumper Locations




BOOT FLASH WRITE PROTECT JUMPER

The SCP/DCP-122 provides a jumper to allow programming of the main boot Flash. Normally, the E1-2 jumper is not installed and the boot Flash is write-protected. To program the boot Flash, install the E1-E2 jumper.

TABLE 2.2: Boot Flash Write Protect Jumper

Option	Jumper Setting
Main Boot Flash is write-protected.	Open E1-E2 (normal mode). In this mode, the WP_BOOT_BIT (described further in "E2PROM General Control Register" in Chapter 3 of the SCP/DCP-122 Hardware User's Manual) is Read Only.
Disable Main Boot Flash write-protect.	Connect E1-E2. In this mode, application software can change the WP_BOOT_BIT to write protect or not (described further in "E2PROM General Control Register" in Chapter 3 of the SCP/DCP-122 Hardware User's Manual).

FIGURE 2.2: Boot Flash Write Protect Jumper



Cross Reference

The state of the E1-E2 jumper is shown in the WR_PROT_BOOT_JMP bit in the FPGA Miscellaneous Signal Status Register. See Chapter 3 of the SCP/DCP-122 Hardware User's Manual for more information about the Miscellaneous Signal Status Register.

APPLICATION FLASH WRITE PROTECT JUMPER

The SCP/DCP-122 provides a jumper to allow programming of the application Flash. "Application Flash" means all Flash areas except the PABS Flash. The application Flash is in the range 0xFC00 0000 to 0xFDFF FFFF.

For normal operation, remove jumper E3-E4 to write-protect the application Flash. To program the application Flash, install the E3-E4 jumper.




Cross Reference

The state of the E3-E4 jumper is shown in the WR_PROT_APP_JMP bit in the FPGA Miscellaneous Signal Status Register. See Chapter 3 of the SCP/DCP-122 Hardware User's Manual for more information about the Miscellaneous Signal Status Register.

TABLE 2.3: Application Flash Write Protect Jumper

Option	Jumper Setting
Application Flash Write Protect:	
Program application Flash bank	Connect E3-E4
Do not program application Flash bank	Open E3-E4

FIGURE 2.3: Application Flash Write Protect Jumper



PABS FLASH WRITE PROTECT JUMPER

The SCP/DCP-122 provides a jumper to allow programming of the PABS (Permanent Alternate Boot Site) Flash area.



This jumper is intended for factory use only.

For normal operation, remove the jumper E5-E6 so that the PABS is write-protected. To enable programming of the PABS Flash, install the E5-E6 jumper.




Cross Reference

The state of the E5-E6 jumper is shown in the WR_PROT_PABS_JMP bit in the FPGA Miscellaneous Signal Status Register. See Chapter 3 of the SCP/DCP-122 Hardware User's Manual for more information about the Miscellaneous Signal Status Register.

TABLE 2.4: PABS Flash Write Protect Jumper

Option	Jumper Setting
PABS Flash Write Protect:	
Enable programming of PABS Flash bank	Connect E5-E6 (caution: for factory use only)
Write protect the PABS Flash bank	Open E5-E6

FIGURE 2.4: PABS Flash Write Protect Jumper




BOOT FROM PABS MEMORY

The SCP/DCP-122 includes a 32-bit Flash bank and a PABS site. You may boot the SCP/DCP-122 from either of these sources. Normally, the SCP/DCP-122 boots from 32-bit Flash. However, if the Foundation Firmware in the 64-bit Flash is corrupted, you may boot from the PABS site. Once you have booted the card you may use FFWUPD, FlashProg, or NVMP to reprogram the 32-bit Flash. You can then power off the card and remove the jumper to allow local booting. Use the jumper settings described in Table 2.5 to select the bank used for booting. The location of the jumper is shown in Figure 2.5 below.

TABLE 2.5: Enable Booting from PABS Memory

Option	Jumper Setting
Boot from 8-bit PABS site.	Connect E7-E8
Boot from 32-bit main Flash	Open E7-E8

FIGURE 2.5: Boot From PABS Memory Jumper



The functionality described above is optionally available on the SCP/DCP-122 J2 connector, using the ALT_BOOT- signal in place of DIO7 (J2-C11).

WATCHDOG TIMER BEHAVIOUR


The SCP/DCP-122 offers the capability of enabling the watchdog timer immediately following reset without the need for software programming or initialization. This mode of operation is selected by leaving E9-E10 open. The watchdog timer will generate a card reset if left to expire.

With the E9-E10 jumper installed, the watchdog timer is disabled following power-up reset; however, it can be enabled by application software.

TABLE 2.6: Watchdog Timer Power-up Behaviour

Option	Jumper Setting
Watchdog timer is disabled following power-up: (generates interrupt on timeout).	Connect E9-E10
Watchdog timer is enabled following power-up: (generates a card reset on timeout).	Open E9-E10

FIGURE 2.6: Watchdog Timer Power-up Jumper



EXECUTION SEQUENCE CONTROL JUMPER

The SCP/DCP-122 has a software-readable jumper located at E11-E12. This jumper, referred to as the User Link or Software Switch, is used to control the power-up sequence for the Foundation Firmware and applications.

The on-board Foundation Firmware checks the state (connected or open) of the User Link on power-up and uses this along with the serial channel 1 DSR input to select one of four possible execution sequences. See "Initiating the Power-Up Sequence" on page 4-16 for more information.


For information on the code executed, refer to the SCP/DCP-122 Programmer's Reference Manual.

Factory configurations are performed via the installation/removal of configuration resistors. Please contact the factory if you require information about factory configured options. Under normal circumstances, you should not need to alter any of the factory-configured options.

TABLE 2.7: User Link Configuration

Option	Jumper Setting
Execution Sequencer Control: (sets the PCI Control and Status Register bit SW0 = 0).	Connect E11-E12
(sets the PCI Control and Status Register bit SW0 = 1).	Open E11-E12

FIGURE 2.7: Execution Sequence Control Jumper




BACKUP FPGA BOOT PROM JUMPER (RESERVED)

The SCP/DCP-122 has a provision for a jumper to select a backup FPGA boot PROM, however no backup FPGA boot PROM is implemented in the current design of the SCP/DCP-122. Therefore the jumper E13-E14 must be removed in order to use the normal FPGA boot PROM.

TABLE 2.8: Backup FPGA Boot PROM Select

Option	Jumper Setting
<p>Backup FPGA Boot PROM (Reserved):</p> <p>A provision for a Back-up PROM for the FPGA exists in the design of the SCP/DCP-122, however it has not been implemented at the present time, meaning the jumper at E13-E14 must not be connected.</p>	<p>Open E13-E14</p>

FIGURE 2.8: FPGA Boot PROM Select



3

INSTALLING PMC MODULES ON THE SCP/DCP-122

BEFORE YOU BEGIN



Warning

PMC modules include components that are sensitive to electrostatic discharges. Keep your PMC module in its conductive package until just before the installation begins. Remove the card from its protective package only at a grounded workstation while wearing an approved grounding wrist strap. Avoid touching any metal contacts on the card; static discharge can damage integrated circuits. To avoid damage to the card or to avoid any personal injury, remove the power from the chassis prior to removing or installing cards.

INSTALLATION PROCEDURE

Follow the instructions in this chapter to install it on the carrier card.

UNPACK AND CONFIGURE THE CARD

1. Unpack the PMC module from the shipping carton in a suitable work area. If the shipping carton appears to be damaged, request that an agent of the shipper or carrier be present during packing and inspection.
2. Find the packing list. Verify that all items on the list are present.
3. Save the packing material for storing or reshipping the card.

Before installing the PMC module on the SCP/DCP-122, ensure that you complete all pre-installation tasks described in the associated PMC user documentation.

INSTALL THE PMC MODULE ON THE SCP/DCP-122

Install your PMC module on the SCP/DCP-122 using the appropriate mounting kit available from Dy 4 Systems. This kit contains all the screws and additional hardware you need to ensure that the PMC module is firmly installed on your SCP/DCP-122.

Installing a PMC Module on a DCP-122

Figure 3.1 on page 3-3 shows a PMC module in position over a DCP-122.



Note

If the PMC module you are installing on the DCP-122 is not a Dy 4 product, make sure the module has a compatible thermal frame.

Thermal gaskets in the PMC mounting kit ensure a good thermal connection between the frame of the PMC module and the carrier card. These gaskets are white strips of thermal material with holes to match the holes in the primary and secondary thermal interfaces (five holes on the primary interface, and three holes on the secondary). Remove the backing from the thermal gaskets and affix them to the thermal frame of your PMC module.

Your mounting kit may include thermal pads of a thicker material to conduct heat away from some components through the thermal frame on the carrier card. Remove the backing from the pads and affix them to the appropriate components.

The kits also contain at least eighteen 2 mm screws with washers and two 2.5 mm screws to fasten the PMC module to the frame. The two 2.5 mm screws fasten the SCP/DCP-122 to the two integral standoffs on the carrier card frame (as indicated in Figure 3.1).

Alternatively, if the carrier card frame does not include integral standoffs, use the individual standoffs included in the mounting kit. The 2 mm screws and washers affix the card by the primary and secondary thermal interfaces.




Note

Torque the PMC mounting screws at exactly 4 lb-in, as indicated on the basecard generic drawing supplied on your Dy 4 basecard Technical Documentation CD-ROM.

Dy 4 Systems recommends using a thread locking compound, such as Loctite 222MS Threadlocker (Dy 4 part number 163220) to prevent the screws from becoming loose.

FIGURE 3.1: Installing a PMC Module on a DCP-122



4

HARDWARE INSTALLATION

INTRODUCTION

This chapter explains how to install the SCP/DCP-122 in a CompactPCI chassis. Specifically this chapter describes the following procedures:

- inserting the card into a chassis
- connecting a terminal to the card via a serial communications cable
- connecting other devices to the card via the BPK-122-000 Transition Module
- turning on the power and confirming that the Power-up Built-In Test (PBIT) has completed successfully
- displaying the initial screen message and establishing the card's PCI base address
- troubleshooting installation problems.

INSERTING THE CARD IN A CHASSIS

BEFORE YOU BEGIN...



Warning

This card uses components that are sensitive to electrostatic discharges. It must be kept in its conductive package until just before the installation begins. Remove the card from its protective package only at a grounded workstation while wearing an approved grounding wrist strap. Avoid touching any metal contacts on the card; static discharge can damage integrated circuits.

Turn the power off before inserting or removing cards from the chassis. Failure to do so could damage the card circuitry or cause personal injury.

ABOUT CARD INSERTION FORCE

The SCP/DCP-122 employs 110-pin connectors for the J1 and J2 interfaces. Proper mating of these connectors with the CompactPCI backplane requires a significant amount of insertion force. Use extra care when aligning and inserting your SCP/DCP-122 into your chassis to ensure that a secure mechanical and electrical connection is made between the card and the backplane mating connectors.

CHOOSING A SLOT LOCATION

If you want your SCP/DCP-122 to function as the system controller, insert your SCP/DCP-122 in the system slot. The system slot is typically the leftmost or rightmost slot on the backplane and is denoted by a "Δ" symbol.



Note

Either end slot on the backplane may be configured as the System Slot. Refer to the chassis vendor's documentation to determine which slot is the System Slot.

The system controller provides the following to the CompactPCI bus:

- arbitration
- clocks
- terminations
- system reset
- PCI configuration

If the SCP/DCP-122 is inserted into any of the peripheral slots, marked with a circle, it functions as a peripheral card. A peripheral card requires a system controller to provide the above functions.


CONNECTING A TERMINAL

In order to access the features available within the embedded firmware on the SCP/DCP-122, you will need to attach a terminal or PC-emulated equivalent to the Serial Channel 1 interface on the card.

As seen in Figure 4.1 below, connect a terminal to the SCP/DCP-122 J2 connector via the J3 RS-232 connector provided on the SCP/DCP-122 transition module (Dy 4 order number BPK-122-000) available from Dy 4 Systems (for use with either the SCP or DCP product versions).

Default serial communication parameters are 9600 N, 8, 1 (9600 baud, no parity, 8 bits, 1 stop bit).

FIGURE 4.1: SCP-122 Terminal Connection via (BPK-122-000) Transition Module



BPK-122-000 TRANSITION MODULE

The BPK-122-000 Transition Module is used to access the user's I/O from the CPCI chassis backplane. The 122 I/O consists of:

- two RS-232 serial ports (channel 1 and channel 2)
- two EIA-422 serial ports (channel 3 and channel 4). The 422 channels can be configured as two independent asynchronous channels or one synchronous channel (Ch4 data becomes CH3 clock)
- one 10 Base-T/100 Base-TX Ethernet port
- one USB interface
- 16 bits of discrete I/O
- External card Reset
- 64-bit PMC I/O

The transition module may be used in a variety of applications, to optimize connectivity to either the SCP/DCP-122 basecard, or any PMC module that may be installed on the SCP/DCP-122.

BPK-122-000
Serial Channel 1
EIA-232 Interface

Table 4.1 summarizes the pinout information for the BPK-122-000 J3 (RJ-12) connector.

TABLE 4.1: Serial Channel 1 RS-232 Connector (BPK-122-000 J3) Pinout

J3 Pin Number	SCP/DCP-122 Signal Name
1	No Connect
2	No Connect
3	RX
4	TX
5	DSR
6	GND

BPK-122-000
Serial Channel 2
EIA-232 Interface

Table 4.2 summarizes the pinout information for the BPK-122-000 J6 (RJ-12) connector.

TABLE 4.2: Serial Channel 2 RS-232 Connector (BPK-122-000 J6) Pinout

J6 Pin Number	SCP/DCP-122 Signal Name
1	No Connect
2	No Connect
3	RX
4	TX
5	No Connect
6	GND

BPK-122-000 USB
Interface

Table 4.4 summarizes the pinout information for the BPK-122-000 J4 connector.

TABLE 4.3: USB Connector (BPK-122-000 J4) Pinout

J4 Pin Number	SCP/DCP-122 Signal Name
1	USB_VCC
2	USBD-
3	USBD+
4	GND

BPK-122-000 Ethernet Interface

Table 4.4 summarizes the pinout information for the BPK-122-000 J5 (RJ45) connector.

TABLE 4.4: Ethernet Connector (BPK-122-000 J5) Pinout

J5 Pin Number	SCP/DCP-122 Signal Name
1	ENET_TX+
2	ENET_TX-
3	ENET_RX+
4	NC
5	NC
6	ENET_RX-
7	NC
8	NC

BPK-122-000 Transition Module DIO Header

The SCP/DCP-122 Digital I/O (DIO) signals are also available via header pins on the transition module, as shown below in Figure 4.2. The center column of pins are GND signals.

FIGURE 4.2: Digital I/O via the Transition Module




TABLE 4.5: DIO Header Pinout

DIO Pin Number	Signal Name	DIO Pin Number	Signal Name	DIO Pin Number	Signal Name
E1	DIO0/RTC Standby	E9	GND	E17	DIO8
E2	DIO1	E10	GND	E18	DIO9
E3	DIO2	E11	GND	E19	DIO10
E4	DIO3	E12	GND	E20	DIO11
E5	DIO4	E13	GND	E21	DIO12
E6	DIO5	E14	GND	E22	DIO13
E7	DIO6	E15	GND	E23	DIO14
E8	DIO7/ALTBOOT	E16	GND	E24	DIO15

**BPK-122-000
Transition Module
Channel 3 and 4
Header Pins**

Figure 4.3 shows the location and orientation of the header pins on the transition module associated with the Channel 3 and Channel 4 EIA-422 interfaces available from the SCP/DCP-122.

FIGURE 4.3: EIA-422 Channel 3 and Channel 4 Header Pins




TABLE 4.6: EIA-422 Channel 3 Pinout

Pin Number	SCP/DCP-122 Signal Name	Differential I/O Pair
E25	422_CH3_TX+	Diff I/O Out 0
E26	422_CH3_TX-	
E27	422_CH3_RX-	Diff I/O In 0
E28	422_CH3_RX+	
E29	GND	

TABLE 4.7: EIA-422 Channel 4 Pinout

Pin Number	SCP/DCP-122 Signal Name	Differential I/O Pair
E30	422_CH4_TX+ / CH3_TXClock+	Diff I/O Out 1
E31	422_CH4_TX- / CH3_TXClock-	
E32	422_CH4_RX- / CH3_RXClock-	Diff I/O In 1
E33	422_CH4_RX+ / CH3_RXClock+	
E34	GND	

Basecard I/O Mode

The default configuration assumes no PMC module is present on the SCP/DCP-122, allowing the full range of basecard I/O to be distributed via the transition module. This includes the following interfaces:

- Optional basecard I/O allows for DIO7 to be replaced with ALT_BOOT-, and/or DIO0 to be replaced by RTC standby power.
- RS-232 is available on J3 and J6
- Ethernet is available on J5
- USB is available on J4
- DIO (0) to DIO (15) available on header block
- EIA-422 Channel 3 and 4 available on pin headers
- Card Reset is routed to E36 and E37

Individual standard cables are required for RS-232, Ethernet and USB ports.


PMC-601 Support

If a PMC-601 is present on the SCP/DCP-122, the transition board provides access to the PMC-601 signals in conjunction with the Dy 4's standard SBC P0 cable (CBL-SBC-P0-000). See Figure 4.4 below for more information.

This option supports the following combination of interfaces:

- two RS-232 ports available on Transition Module J3 and J6 connectors.
- 64-bit PMC I/O available on the 78-Way connector via the P0 cable (into which the PMC-601 cable assembly (#901321-000) may be connected to further break out the MIL-STD-1553 signals)
- Ethernet is available on J5 and it is also accessible via the P0 cable.
- USB is not available (multiplexed with PMC I/O). The USB power signal (USBVBUS) is isolated from the USB connectors (0 ohm resistor not populated)
- Discrete I/O's are not available (multiplexed with PMC I/O)
- one asynchronous EIA-422 serial port (CH3) accessible via on board pin headers. EIA-422 channel 4 is not available (multiplexed with PMC I/O).
- Card Reset is available on E36 and E37 and P0 cable

FIGURE 4.4: Using the CBL-SBC-P0-000 with the Transition Module




PMC-700 Support

If a PMC-700 is present on the SCP/DCP-122, the transition board provides access to the PMC-700 signals in conjunction with the Dy 4's standard PMC-700 P0 cable (CBL-700-001).

- one RS-232 port available on BPK-122-000 J3 and P0 cable. 0 Ohm resistor is used to route RS-232 to the 700 P0 cable. The 700 RS-232 signals share the same P0 pins with DIO 13, DIO 14 and DIO 15. When RS-232 is routed to these pins, the user still have access to all 16 DIO via the on board pin headers.
- one 10 Base-T/100 Base-TX Ethernet Port available on J3 native connector and P0 cable.
- one USB port available only on J4 native USB connector
- 12 bits of parallel I/O available via the P0 cable (but all 16 DIO are accessible via the on board pin headers).
- four pairs of TMDS signals accessible via the DVI connector on the P0 cable.
- one VGA interface

Figure 4.5 below illustrates this in further detail:

FIGURE 4.5: CBL-700-001 Used in Conjunction with BPK-122-000



P0 Cable Interface Pinout

The following tables show how signals are mapped from the SCP/DCP-122 J2 interface through the transition module to each row of the P0 Cable Interface connector on the transition module.

TABLE 4.8: Transition Module P0 Row A Signal Mapping

P0 Cable Interface Row A Pin Number	CBL-SBC-P0-000	CBL-700-001	SCP/DCP-122 Signal Name (J2 Interface Pin #)
1	ENET2_UTP2	ENET_GND1	NC
2	ENET2_TXD-	ENET_TXD-	ENET_TX- (J2-E21)
3	ENET2_RXD-	ENET_RXD-	ENET_RX- (J2-C21)
4	PMC_05	TXC GND	PMC_05 (J2-C18)
5	PMC_10		PMC_10_DIO3 (J2-C19)
6	PMC_15		PMC_15_422TX+ (J2-B15)
7	PMC_20		PMC_20 (J2-B13)
8	PMC_25		PMC_25 (J2-D13)
9	DIO (0) / RTC	PIO (0)	PMC_06_DIO0_RTC (J2-E16)
10	DIO (7) / ALT_BOOT-		PMC_33_ALTBOOT- (J2-C11)
11	DIO (12)		PMC_27_DIO12 (J2-E12)
12	PMC_30		PMC_30_DIO15 (J2-A12)
13	PMC_35	TX1-	PMC_35 (J2-E11)
14	PMC_40	DDC CLK	PMC_40 (J2-A10)
15	PMC_45		PMC_45 (J2-D9)
16	PMC_50	VSYNC RTN	PMC_50 (J2-C10)
17	PMC_55		PMC_55 (J2-E6)
18	PMC_60	RED	PMC_60 (J2-C5)
19	DIO (11)	PIO (11)	PMC_43_DIO11 (J2-E9)

TABLE 4.9: Transition Module P0 Row B Signal Mapping

P0 Cable Interface Row B Pin Number	CBL-SBC-P0-000	CBL-700-001	SCP/DCP-122 Signal Name (J2 Interface Pin #)
1	ENET2_UTP1	ENET_GND1	
2	ENET2_TXD+	ENET_TXD+	ENET_TX+ (J2-D21)
3	ENET2_RXD+	ENET_RXD+	ENET_RX+ (J2-C20)
4	PMC_04	TX0+	PMC_04 (J2-A18)
5	PMC_09		PMC_09_DIO2 (J2-A17)
6	PMC_14		PMC_14_USBD- (J2-D20)
7	PMC_19		PMC_19_422RX+ (J2-E14)
8	PMC_24		PMC_24 (J2-E19)
9	DIO (1)	PIO (1)	PMC_07_DIO1 (J2-B17)
10	DIO (2)	PIO (2)	PMC_09_DIO2 (J2-A17)
11	VCC_USB2		PMC_08_USBVB (J2-D19)
12	PMC_29		PMC_29_DIO14 (J2-D12)
13	PMC_34	TX1+	PMC_34 (J2-B11)
14	PMC_39		PMC_39_DIO9 (J2-E10)
15	PMC_44	HSYNC RTN	PMC_44 (J2-A9)
16	PMC_49		PMC_49 (J2-D8)
17	PMC_54	BLUE RTN	PMC_54 (J2-A7)
18	PMC_59	TX2 GND	PMC_59 (J2-C6)
19	PMC_64	GREEN	PMC_64 (J2-E5)

TABLE 4.10: Transition Module P0 Row C Signal Mapping

P0 Cable Interface Row C Pin Number	CBL-SBC-P0-000	CBL-700-001	SCP/DCP-122 Signal Name (J2 Interface Pin #)
1	DIO (15)	CH1TXD	A12/C8
2	GND	GND	A19, B19-B21
3	CRESET-	CRESET	PB_RST- (J2-C17)
4	PMC_03	TXC+	PMC_03 (J2-D18)
5	PMC_08		PMC_08_USBVB (J2-D19)
6	PMC_13		PMC_13_DIO5 (J2-A16)
7	PMC_18		PMC_18 (J2-A14)
8	PMC_23		PMC_23_DIO6 (J2-E13)
9	DIO (3)	PIO (3)	PMC_10_DIO3 (J2-C19)
10	DIO (4)	PIO (4)	PMC_11_DIO4 (J2-B16)
11	USB2+		PMC_12_USBD+ (J2-E20)
12	PMC_28		PMC_28_DIO 13 (J2-B12)
13	PMC_33	TX1 GND	PMC_33_DIO7_ALT B- (J2-C11)
14	PMC_38		PMC_38 (J2-B10)
15	PMC_43		PMC_43_DIO11 (J2-E9)
16	PMC_48	VSYNC	PMC_48 (J2-A8)
17	PMC_53		PMC_53 (J2-D7)
18	PMC_58	RED RTN	PMC_58 (J2-A6)
19	PMC_63	TX2+	PMC_63 (J2-B5)

TABLE 4.11: Transition Module P0 Row D Signal Mapping

P0 Cable Interface Row D Pin Number	CBL-SBC-P0-000	CBL-700-001	SCP/DCP-122 Signal Name (J2 Interface Pin #)
1	DIO (14)	CH1RXD	C9 / D12
2	Reserved		
3	CARDFAIL-		
4	PMC_02	TX0-	PMC_02 (J2-B18)
5	PMC_07		PMC_07_DIO1 (J2-B17)
6	PMC_12		PMC_12_USBD+ (J2-E20)
7	PMC_17		PMC_17_422_TX- (J2-A15)
8	PMC_22		PMC_22 (J2-A13)
9	DIO (5)	PIO (5)	PMC_13_DIO5 (J2-A16)
10	DIO (6)	PIO (6)	PMC_23_DIO6 (J2-E13)
11	USB2-		PMC_14_USBD- (J2-D20)
12	PMC_27		PMC_27_DIO12 (J2-E12)
13	PMC_32		PMC_32 (J2-C13)
14	PMC_37		PMC_37_DIO8 (J2-D11)
15	PMC_42	DDC DATA	PMC_42 (J2-B9)
16	PMC_47		PMC_47 (J2-E8)
17	PMC_52		PMC_52 (J2-B7)
18	PMC_57		PMC_57 (J2-D6)
19	PMC_62	GREEN RTN	PMC_62 (J2-D5)

TABLE 4.12: Transition Module P0 Row E Signal Mapping

P0 Cable Interface Row E Pin Number	CBL-SBC-P0-000	CBL-700-001	SCP/DCP-122 Signal Name (J2 Interface Pin #)
1	DIO (13)	CH1DSR	DSR (J2-B12 / C7)
2	DIO (9)	PIO (9)	PMC_39_DIO9 (J2-E10)
3	DIO (10)	PIO (10)	PMC_41_DIO10 (J2-D10)
4	PMC_01	TXC-	PMC_01 (J2-E18)
5	PMC_06	TX0 GND	PMC_06_DIO0_RTCV (J2-E16)
6	PMC_11		PMC_11_DIO4 (J2-B16)
7	PMC_16		PMC_16 (J2-B14)
8	PMC_21		PMC_21_422_RX- (J2-D14)
9	DIO (7)	PIO (7)	PMC_33_DIO7_ALTB- (J2-C11)
10	DIO (8)	PIO (8)	PMC_37_DIO8 (J2-D11)
11			A19, B19-B21
12	PMC_26		PMC_26 (J2-C14)
13	PMC_31		PMC_31 (J2-C12)
14	PMC_36		PMC_36 (J2-A11)
15	PMC_41		PMC_41_DIO10 (J2-D10)
16	PMC_46	HSYNC	PMC_46 (J2-B8)
17	PMC_51		PMC_51 (J2-E7)
18	PMC_56	BLUE	PMC_56 (J2-B6)
19	PMC_61	TX2-	PMC_61 (J2-A5)

CONTROLLING THE BOOT SEQUENCE

The boot sequence for the Foundation Firmware depends on the settings of the User Link and the state of the Serial Channel 1 DSR line. The possible power-up sequences are shown in Table 4.13.

TABLE 4.13: Foundation Firmware Execution Sequence

Condition	Execution Sequence
User Link (E11–E12) off DSR negated (cable out)	PBIT → Default Application → GPM When the SCP/DCP-122 boots, it executes PBIT and then calls the default application. If the default application returns, it returns to GPM.
User Link (E11–E12) off DSR asserted (terminal connected to SCP/DCP-122 serial channel 1)	PBIT → GPM → Default Application → GPM When the SCP/DCP-122 boots, it executes PBIT and then GPM. Type “rts” at the GPM prompt to call the default application. If the default application returns, it returns to GPM.
User Link (E11–E12) on DSR negated (cable out)	Default Application → GPM When the SCP/DCP-122 boots, it calls the default application immediately. If the default application returns, it returns to GPM.
User Link (E11–E12) on DSR asserted (terminal connected to SCP/DCP-122 serial channel 1)	Recovery Mode (CBOOT parameters are not used) The card uses Foundation Firmware default parameters instead of the CBOOT parameters set in the Configuration Boot Manager (CBM). GPM When the SCP/DCP-122 boots, it executes GPM.

FOUNDATION FIRMWARE USED DURING POWER-UP

The card can run the following programs during power-up:

Power-up Built-In Test (PBIT): PBIT tests all major subsystems on the card. Test results are placed in the Diagnostic Results Table (DRT).



Cross Reference

Power-up Built-In-Test (PBIT) is an application that is run at power-up, after a reset, or invoked at GPM to execute a preconfigured list of Card Level Diagnostics (CLD). For more information about PBIT, see the V8 Foundation Firmware User’s Manual, document number 808006.

General Purpose Monitor (GPM): The GPM is the standard Dy 4 monitor shipped with most SBCs. This allows users to examine memory, download and execute programs and communicate with other boards in the CompactPCI system.

Default Application: This is any user application programmed into the on-board Flash. The VxWorks boot loader is initially programmed as the default application.

INITIATING THE POWER-UP SEQUENCE

POWER-UP

Switch the CompactPCI chassis on.

INITIAL LED ACTIVITY

Immediately on power-up, the Status LED will indicate red.

Once the card passes its initial diagnostics, PBIT turns the Status LED green. If a diagnostic fails, the LED remains red.



Cross Reference

If the Status LED stays red after the power-up, then PBIT has found one or more problems or the selected execution sequence did not include PBIT. See "Troubleshooting" on page 4-17 for information on locating the problem.

DISPLAYING THE INITIAL SCREEN MESSAGE

After control is transferred to the GPM, pressing any key on the keyboard will inform the GPM that I/O data is being received from the serial data port. The GPM will then display a sign-on message similar to the following:

```
SCP/DCP-122, PowerPC 750FX General Purpose Monitor, Version 8.0  
(c) DY 4 Systems Inc.  
Type ? for help  
40000000*
```

The last line is the initial prompt which shows the PCI base address of the card. In this example the base address is 4000 0000H.



Cross Reference

Type '?' at the prompt to display the help screen for the GPM. For more detailed information on using the GPM, refer to the V8 Foundation Firmware User's Manual (808006).

TROUBLESHOOTING

VERIFY INSERTION IN CHASSIS

Power down the chassis. Make sure that the card is properly seated in the CompactPCI chassis. Because of the five-row backplane, a considerable amount of insertion force is required.

STATUS LED STAYS RED

If the Status LED stays red after power-up, then PBIT found one or more problems or PBIT was not run. The DRT command displays addresses for the binary, ASCII, and start-up PBIT binary and ASCII DRTs. It also displays the ASCII DRTs for both PBIT and start-up PBIT. Use the GPM drt command to display the DRT as shown in the example below:

FIGURE 4.6: Sample Diagnostics Results Table (DRT)

SCP/DCP-122, PowerPC 750FX General Purpose Monitor, Version 8.0
Copyright 1998 to 2003 DY 4 Systems

Type ? for help

40000000* drt

DRT header address: 0x5400

Binary DRT address: 0x5440

Diag	Sub	Result	Progress	Fail a	Fail b	Fail c	Fail d
Pass	0	Pass	0	0	0	0	0
CpuSpaceDecode	0	Pass	0	0	0	0	0
EEPROM	0	Pass	0	0	0	0	0
RAM	0	Pass	0	0	0	0	0
Serial Port	0	Pass	0	0	0	0	0
Serial Port	0	Pass	0	0	0	0	0
Base Card Diag	0	Pass	0	0	0	0	0
RAM	0	Pass	0	0	0	0	0
Partition	0	Pass	0	0	0	0	0
ISP1160	0	Pass	0	0	0	0	0
FPGA TIMER	0	Pass	0	0	0	0	0
L2 Cache	0	Pass	0	0	0	0	0
PCI Ven/Dev ID	0	Pass	0	0	0	0	0
GT64260Ethernet	0	Pass	0	0	0	0	0
BCM5221	0	Pass	0	0	0	0	0
ECC	0	Pass	0	0	0	0	0
MAX6634	0	Pass	0	0	0	0	0

ASCII DRT address: 0x5A00

CLD complete: 17 diagnostics were executed

```

Summary;: Pass
Pass: Pass
Cpu Space Decode; : Pass
EPROM transfer: Pass
RAM data convergence: Pass
RAM address convergence: (0x0003ABD4-0x0003BB70) Pass
RAM misaligned transfer: Pass
RAM read/write: (0x0003ABD4-0x0003BB70) Pass
UART Reset Condition: Pass
UART Controllable bits: Pass
UART Loopback: Pass
UART Reset Condition: Pass
UART Controllable bits: Pass
UART Loopback: Pass
Base Card Common CSR RESET: Pass
Base Card Common CSR Controllable bits: Pass
Base Card-Specific CSR RESET: Pass
Base Card-Specific CSR Controllable bits: Pass
RAM data convergence: Pass
RAM misaligned transfer: Pass
RAM read/write: (0xF4008000-0xF400FFEC) Pass
Partition checksum: Pass
ISP1160 Reset Condition: Pass
ISP1160 Controllable bits: Pass
ISP1160 Reg Data Convergence Test: Pass
FPGA Timer Run Test: Pass
FPGA Timer INT Test: Pass
L2 RAM Data Test: Pass
L2 RAM Address Test: Pass
L2 Cache Miss Test: Pass
PCI Ven/Dev ID (0x80000000) expect 0x643011AB: Pass
GT64260 Ethernet Reset Condition: Pass
GT64260 Ethernet Controllable bits: Pass
GT64260 Ethernet Loopback: Pass
GT64260 Ethernet Loopback Ext: Pass
BCM5221 Reset Condition: Pass
BCM5221 Controllable bits: Pass
GT64260 ECC Polled: Pass
GT64260 ECC Interrupt: Pass
Temperature Sensor Reset: Pass
Temperature Sensor Controllable bits: Pass

```

Start-up PBIT Binary DRT address: 0x59C0

Diag	Sub	Result	Progress	Fail a	Fail b	Fail c	Fail d
Cbm	0	Pass	0	0	0	0	0
RAM	0	Pass	0	0	0	0	0

Start-up PBIT ASCII DRT address: 0x6F00

CLD complete: 2 diagnostics were executed

```

Summary;: Pass
CBOOT Checksum Check: Pass
CBOOT Format Check: Pass
RAM size Check: Pass

```

40000000*

Drt results after reset:

SCP/DCP-122, PowerPC 750FX General Purpose Monitor, Version 8.0
Copyright 1998 to 2003 DY 4 Systems

Type ? for help

40000000* drt

DRT header address: 0x5400

Binary DRT address: 0x5440

Diag	Sub	Result	Progress	Fail a	Fail b	Fail c	Fail d
Pass	0	Pass	0	0	0	0	0
CpuSpaceDecode	0	Pass	0	0	0	0	0
EEPROM	0	Pass	0	0	0	0	0
RAM	0	Pass	0	0	0	0	0
Serial Port	0	Pass	0	0	0	0	0
Serial Port	0	Pass	0	0	0	0	0
Base Card Diag	0	Pass	0	0	0	0	0
RAM	0	Pass	0	0	0	0	0
Partition	0	Pass	0	0	0	0	0
ISP1160	0	Pass	0	0	0	0	0
FPGA TIMER	0	Pass	0	0	0	0	0
L2 Cache	0	Pass	0	0	0	0	0
PCI Ven/Dev ID	0	Pass	0	0	0	0	0
GT64260Ethernet	0	Pass	0	0	0	0	0
BCM5221	0	Pass	0	0	0	0	0
ECC	0	Pass	0	0	0	0	0
MAX6634	0	Pass	0	0	0	0	0

ASCII DRT address: 0x5A00

CLD complete: 17 diagnostics were executed

Summary;: Pass

Pass: Pass

Cpu Space Decode; : Pass

EPR0M transfer: Pass

RAM data convergence: Pass

RAM address convergence: (0x0003ABD4-0x0003BB70) Pass

RAM misaligned transfer: Pass

RAM read/write: (0x0003ABD4-0x0003BB70) Pass

UART Reset Condition: Pass

UART Controllable bits: Pass

UART Loopback: Pass

UART Reset Condition: Pass

UART Controllable bits: Pass

UART Loopback: Pass

Base Card Common CSR RESET: Pass

Base Card Common CSR Controllable bits: Pass

Base Card-Specific CSR RESET: Pass

Base Card-Specific CSR Controllable bits: Pass

```

RAM data convergence: Pass
RAM misaligned transfer: Pass
RAM read/write: (0xF4008000-0xF400FFEC) Pass
Partition checksum: Pass
ISP1160 Reset Condition: Pass
ISP1160 Controllable bits: Pass
ISP1160 Reg Data Convergence Test: Pass
FPGA Timer Run Test: Pass
FPGA Timer INT Test: Pass
L2 RAM Data Test: Pass
L2 RAM Address Test: Pass
L2 Cache Miss Test: Pass
PCI Ven/Dev ID (0x80000000) expect 0x643011AB: Pass
GT64260 Ethernet Reset Condition: Pass
GT64260 Ethernet Controllable bits: Pass
GT64260 Ethernet Loopback: Pass
GT64260 Ethernet Loopback Ext: Pass
BCM5221 Reset Condition: Pass
BCM5221 Controllable bits: Pass
GT64260 ECC Polled: Pass
GT64260 ECC Interrupt: Pass
Temperature Sensor Reset: Pass
Temperature Sensor Controllable bits: Pass

```

Start-up PBIT Binary DRT address: 0x59C0

Diag	Sub	Result	Progress	Fail a	Fail b	Fail c	Fail d
Cbm	0	Pass	0	0	0	0	0
RAM	0	Pass	0	0	0	0	0

Start-up PBIT ASCII DRT address: 0x6F00

CLD complete: 2 diagnostics were executed

```

Summary;: Pass
CBOOT Checksum Check: Pass
CBOOT Format Check: Pass
RAM size Check: Pass

```

40000000*



Cross Reference

If the Status LED is green, the DRT will confirm that all its tests passed. Refer to the V8 Foundation Firmware User's Manual and the Product Release Note for more information on the CLD routines.

If the CLD does not report any results, check the power-up sequence being run. See "Foundation Firmware Used During Power-Up" on page 4-15.

SIGN-ON MESSAGE GARBLED

If the sign-on message is garbled, check that your terminal settings match 9600 8, N, 1 (9600 baud, 8 data bits, no parity, 1 stop bit). Also, ensure that you are using a cable compatible with the ones identified in Chapter 2.

THE NEXT STEP

Once the hardware is correctly configured and installed in the chassis, the next step is to install the board support package software. See the section "Overview and Installation Instructions," in Chapter 1 of your BSP Software User's Manual. Give careful consideration to the specific references to the SCP/DCP-122 that this document makes.



Cross Reference

Additional troubleshooting assistance is available via the Dy 4 Systems TechNet web site, which includes a "Troubleshooting Wizard" to assist you with a number of typical problems, and answer many frequently asked questions.

Go to <http://www.technet.dy4.com/wizard/index.htm> to give the wizard a try.

A

About Card Insertion Force 4-2
Application Flash Write Protect Jumper 2-5

B

Backplane Connectors 1-5
Backup FPGA Boot PROM Jumper (Reserved) 2-10
Backup FPGA Boot PROM Select 2-10
Basecard I/O Mode 4-8
Before You Begin... 4-2
block diagram, SCP/DCP-122 1-3
Board Support Packages, Drivers 1-7
Boot Flash Write Enable Jumper 2-4
Boot Flash Write Protect Jumper 2-4
Boot From PABS Memory 2-7
Boot From PABS Memory Jumper 2-7
BPK-122-000 Ethernet Interface 4-5
BPK-122-000 Serial Channel 1 EIA-232 Interface 4-4
BPK-122-000 Transition Module 4-3
BPK-122-000 Transition Module Channel 3 and 4 Header Pins 4-7
BPK-122-000 Transition Module DIO Header 4-5
BPK-122-000 USB Interface 4-4

C

Choosing a Slot Location 4-2
Configuring Jumpers 2-2
Connecting a Terminal 4-3
Controlling the Boot Sequence 4-15

D

DCP-122 1-1
 photo 1-1
Digital I/O via the Transition Module 4-5
Dimensions 1-5
Dimensions of the SCP/DCP-122 1-5
DIO Header Pinout 4-6
Displaying the Initial Screen Message 4-16

E

EIA-422 Channel 3 and Channel 4 Header Pins 4-7
EIA-422 Channel 3 Pinout 4-7
EIA-422 Channel 4 Pinout 4-7
Electrical Characteristics 1-6
Enable Booting from PABS Memory 2-7
Ethernet Connector (BPK-122-000 J5) Pinout 4-5
Execution Sequence Control Jumper 2-9

F

Features List 1-2
Foundation Firmware 1-7
Foundation Firmware Execution Sequence 4-15
Foundation Firmware Used During Power-Up 4-15
FPGA Boot PROM Select 2-10

I

Initial LED Activity 4-16
Initiating the Power-Up Sequence 4-16
Inserting the Card in a Chassis 4-2
Install the PMC Module on the SCP/DCP-122 3-2
Installation Procedure 3-2
Installing a PMC Module on a DCP-122 3-2, 3-3
Installing a PMC Module on a DCP-201 3-2
Installing PMC modules 3-2
integral standoffs 3-2
Introducing the SCP/DCP-122 1-1
Introduction 2-1, 4-1

J

jumper locations 2-3
Jumper Settings Summary 2-2

M

Mating Connectors 1-5
Maximum CCA Mass 1-5
memory map 4-3

O

Overview of Supplied Firmware 1-7

P

P0 Cable Interface Pinout 4-7, 4-10
PABS Flash Write Protect Jumper 2-6
Physical Characteristics 1-4
PMC Connectors 1-5
PMC Expansion 1-2
PMC-601 Support 4-8
PMC-700 Support 4-9
Power Requirements 1-6
Power-Up 4-16

S

Sample Diagnostics Results Table (DRT) 4-17
SCP/DCP-122
 block diagram 1-3
SCP/DCP-122 Board Current Requirements 1-6
SCP/DCP-122 Functional Block Diagram 1-3
SCP/DCP-122 Jumper Locations 2-3
SCP-122 Component Side View 1-4
SCP-122 Solder Side View 1-4
SCP-122 Terminal Connection via (BPK-122-000)
 Transition Module 4-3
SCP-122 Terminal Connection via Transition Module
 4-3
Serial Channel 1 RS-232 Connector (BPK-122-000
 J3) Pinout 4-4
Sign-on Message Garbled 4-21
Status LED Stays Red 4-17

T

The Next Step 4-21
thermal gaskets 3-2
thermal pads 3-2
thread locking compound 3-2
Transition Module 4-3
Transition Module P0 Row A Signal Mapping 4-10
Transition Module P0 Row B Signal Mapping 4-11
Transition Module P0 Row C Signal Mapping 4-12
Transition Module P0 Row D Signal Mapping 4-13
Transition Module P0 Row E Signal Mapping 4-14
Troubleshooting 4-17

U

Unpack and Configure the Card 3-2
Unpacking the Card 2-1
USB Connector (BPK-122-000 J4) Pinout 4-4
User Link Configuration 2-5, 2-7, 2-8, 2-9, 2-10
Using the CBL-SBC-P0-00 with the Transition Mod-
 ule 4-8
Using the CBL-SBC-P0-000 with the Transition Mod-
 ule 4-8

V

Verify Insertion in Chassis 4-17
Voltage Requirements 1-6

W

Watchdog Timer Behaviour 2-8
Watchdog Timer Power-up Behaviour 2-8
Watchdog Timer Power-up Jumper 2-8
Weight Limits 1-5



Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

*InstraView*SM REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at www.instraview.com ↗

WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. www.artisanng.com/WeBuyEquipment ↗

LOOKING FOR MORE INFORMATION?

Visit us on the web at www.artisanng.com ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

Contact us: (888) 88-SOURCE | sales@artisanng.com | www.artisanng.com