



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)



# 6200 VME to PCI Interface Adapter Installation Guide





# **6200**

## **VME to PCI Interface Adapter Installation Guide**



Document No. UG06200-000, REVA

Release Date: October 30, 1996



6200.bk : 6200.ttl 3 Wed Oct 30 17:24:17 1996





## Copyright Notice

© 1996 by Interphase Corporation. All rights reserved.

Printed in the United States of America, 1996.

This manual is licensed by Interphase to the user for internal use only and is protected by copyright. The user is authorized to download and print a copy of this manual if the user has purchased one or more of the Interphase adapters described herein. All copies of this manual shall include the copyright notice contained herein. No part of this manual, whether modified or not, may be incorporated into user's documentation without prior written approval of

Interphase Corporation  
13800 Senlac  
Dallas, Texas 75234  
Phone: (214) 654-5000  
Fax: (214) 654-5500

## Disclaimer

Information in this manual supersedes any preliminary specifications, preliminary data sheets, and prior versions of this manual. While every effort has been made to ensure the accuracy of this manual, Interphase Corporation assumes no liability resulting from omissions, or from the use of information obtained from this manual. Interphase Corporation reserves the right to revise this manual without obligation to notify any person of such revision. Information available after the printing of this manual will be in one or more Read Me First documents included with this product.

## Trademark Acknowledgments

Interphase® is a registered trademark and CellView™ and (i)chip™ are trademarks of Interphase Corporation.

Windows® and Windows NT® are registered trademarks of Microsoft, Inc.

Novell® and NetWare® are registered trademarks of Novell, Inc.

Solaris® and NFS® are registered trademarks and SunOS™ and ONC™ are trademarks of Sun Microsystems, Inc.

SPARC® is a registered trademark of SPARC International, Inc. SPARCstation™ is a trademark of SPARC International, Inc., licensed exclusively to Sun Microsystems, Inc. LattisCell™, EtherCell™, and SAHI™ are trademarks of Bay Networks, Inc.

UNIX® is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Ltd.

IBM® and OS/2® are registered trademarks and AIX™ and PowerPC™ are trademarks of International Business Machines Corporation.

HP-UX® is a registered trademark and Tachyon™ and Precision Bus™ are trademarks of Hewlett-Packard Company.

Intel® and Pentium® are registered trademarks of Intel Corporation.

TI® is a registered trademark of Texas Instruments.

Compu-shield® is a registered trademark of Stewart Connectors Systems, Inc.

Tundra® is a registered trademark and Universe™ is a trademark of Tundra Semiconductor Corporation.

Ethernet® is a registered trademark of Xerox Corporation.



DG/UX® and AViiON® are registered trademarks of Data General Corporation.  
Apple® and Power Macintosh® are registered trademarks and Macintosh™, MacOS™,  
Mac™, and AppleTalk™ are trademarks of Apple Computer, Inc.  
UnixWare® is a registered trademark of Novell, Inc.

## **Assistance**

### **Product Purchased from Reseller**

Contact the reseller or distributor if

- You need ordering, service or any technical assistance.
- You received a damaged, incomplete or incorrect product.

### **Product Purchased Directly from Interphase Corporation**

Contact Interphase Corporation directly for assistance with this, or any other Interphase Corporation product. Please have your purchase order and serial numbers ready.

#### **Customer Support**

United States: Telephone: (214) 654-5555  
Fax: (214) 654-5500  
E-Mail: intouch@iphase.com

United Kingdom: Telephone: 44 (0) 1869-321222  
Fax: 44 (0) 1869-247720

Asia / Pacific Rim: Sales: (81) 3-5423-6513  
Fax: (81) 3-5423-6511  
Support: (81) 3-5423-6514

#### **World Wide Web**

<http://www.ipphase.com>

#### **Anonymous FTP Server**

<ftp.ipphase.com>

## **Safety Precautions**

The following general safety precautions must be observed during all phases of operation of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates



safety standards of design, manufacture, and intended use of the equipment. Interphase Corporation assumes no liability for the user's failure to comply with these requirements. You, as the user of the product, must observe all stated warnings and safety precautions in order to safely operate the equipment in your environment.

### **Do Not Substitute Parts or Modify Equipment**

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification of the equipment. Contact your local Interphase representative for service and repair to ensure that safety features are maintained.

### **Ground the Instrument**

To minimize shock hazard, the equipment chassis and enclosure must be connected to an electrical ground. The power cable must either be plugged into an approved three-contact electrical outlet or used with a three-contact to two-contact adapter, with the grounding wire (green) firmly connected to an electrical ground (safety ground) at the power outlet.

### **Do Not Operate in an Explosive Atmosphere**

Do not operate the equipment in the presence of flammable gases or fumes. Operation of any electrical equipment in such an environment constitutes a definite safety hazard.

### **Keep away from Live Circuits**

Do not install or replace the component with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

### **Observe Dangerous Procedure Warnings**

Warnings precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed. You should also employ all other safety precautions which you deem necessary for the operation of the equipment in your operating environment.





**Warning**

**This equipment generates, uses, and can radiate electromagnetic energy. It may cause or be susceptible to electromagnetic interference (EMI) if not installed and used in a cabinet with adequate EMI protection.**





## Warranty

Interphase warrants that the Products provided to customer hereunder will be free of defects in material and workmanship for twelve (12) months after shipment to the customer (the "Warranty Period"). Products must be returned in accordance with Interphase's standard warranty return policy. This warranty shall not apply to Products that have been damaged due to accident, misuse, electrical stress, or from any other cause due to use of the Products not in accordance with the Product's documentation. Customer shall be charged a fee for Products returned to Interphase which are diagnosed as "no problem found (NPF)".

REMEDIES AND EXCLUSIONS. THE SOLE LIABILITY OF INTERPHASE AND CUSTOMER'S SOLE REMEDY FOR FAILURE TO CONFORM TO THESE WARRANTIES SHALL BE LIMITED TO, AT INTERPHASE'S SOLE OPTION, REPAIR OR REPLACEMENT OF THE PRODUCTS OR CORRECTION OF THAT PART OF THE SOFTWARE, WHICH FAILS TO CONFORM TO THESE WARRANTIES. EXCEPT AS EXPRESSLY STATED HEREIN, AND EXCEPT AS TO TITLE, THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE, IN CONNECTION WITH OR ARISING OUT OF ANY PRODUCT OR SOFTWARE PROVIDED FOR IN THIS AGREEMENT OR UNDER ANY PURCHASE ORDER. IN NO EVENT SHALL INTERPHASE BE LIABLE FOR ANY INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES SUCH AS LOSS OF DATA, LOSS OF ANTICIPATED PROFITS OR ANY OTHER ECONOMIC LOSS IN CONNECTION WITH OR OTHERWISE ARISING OUT OF A BREACH OF THE WARRANTIES STATED HEREIN.



# Contents

<b>Conventions</b> .....	iii
Icon Conventions .....	iii
Text Conventions .....	iv
<b>CHAPTER 1 Introduction</b>	
Overview .....	1
Product Features .....	1
Package Contents .....	2
System Requirements .....	2
<b>CHAPTER 2 Installing the 6200 Adapter</b>	
Overview .....	3
Inspect the Board .....	3
Set Onboard Jumpers .....	4
Jumper Blocks for Interphase Use Only .....	6
Reserved Jumper Blocks and Pins .....	6
Jumper Blocks J7 and J8 .....	6
Required .....	6
VME Address Space .....	7
Base Address Space .....	7
A16 Example .....	8
A24 Example .....	9
A32 Example .....	10
Power Off System .....	10
Install the Board .....	11
<b>APPENDIX A 6200 Specifications</b>	
Architecture .....	13



*Contents*

---

VMEBus Specifications .....	13
PCI Local Bus Specifications .....	13
Mechanical (Nominal).....	14
Power Requirements .....	14
Operating Environment .....	14
Storage Environment .....	14

**APPENDIX B VME Technology Overview**

VME Technology .....	15
Obtaining VME Specifications .....	15

**APPENDIX C PCI/PMC Technology Overview**

PCI/PMC Technology .....	17
--------------------------	----

<b>Index</b> .....	19
--------------------	----



# Conventions

---

## Icon Conventions

Icons draw your attention to especially important information:



The Note icon indicates important points of interest related to the current subject.

---



The Caution icon brings to your attention those items or steps that, if not properly followed, could cause problems in your machine's configuration or operating system.

---



The Warning icon alerts you to steps or procedures that could be hazardous to your health, cause permanent damage to the equipment, or impose unpredictable results on the surrounding environment.

---

## Text Conventions

The following conventions are used in this manual. Computer-generated text is shown in typewriter font. Examples of computer-generated text are: program output (such as the screen display during the software installation procedure), commands, directory names, file names, variables, prompts, and sections of program code.

Computer-generated text example

Commands to be entered by the user are printed in **bold Courier** type. For example:

```
cd /usr/tmp
```

Pressing the return key (↵ **Return**) at the end of the command line entry is assumed, when not explicitly shown. For example:

```
/bin/su
```

is the same as:

```
/bin/su ↵ Return
```

Required user input, when mixed with program output, is printed in **bold Courier** type. References to UNIX programs and manual page entries follow the standard UNIX conventions.

When a user command, system prompt, or system response is too long to fit on a single line, it will be shown as

```
Do you want the new kernel moved into  
\ vmunix?[y]
```

with a backslash at either the beginning of the continued line or at the end of the previous line.

# Introduction

# 1

## Overview

The 6200 VME to PCI Interface adapter provides a bridge between a VME bus and a PCI bus. The 6200 adapter's VMEbus features are fully programmable from the VMEbus side. The 6200 supports read-modify-write cycles on the VMEbus. With its other VMEbus functions, the 6200 provides full VME interrupt and multilevel requester capabilities.

## Product Features

- 6U or 9U compatibility. Because of its 6U form factor, this product can be integrated into 6U and, with an adapter, 9U VMEbus card cages.
- 2 PMC population sites, for either one or two daughtercards, thus allowing for 2 independent PMC adapters
- Fully compliant, 32-bit, 33 MHz PCI local bus interface
- Fully compliant 64-bit high performance VMEbus interface
- Integral FIFOs for write posting to maximize bandwidth utilization
- Programmable DMA controller with linked list support
- VMEbus transfer rates of 60-70 MBps
- Complete suite of VMEbus address and data transfer modes
  - A32/A24/A16 master and slave
  - D64 (MBLT)/D32/D16/D08 master and slave

### Package Contents

---

- BLT, ADOH, RMW, LOCK
- Flexible register set, programmable from the VMEbus port
- Implements all of the addressing and data transfer modes documented in the VME64 specifications (except A64 and those intended to support 3U applications, that is, A40 and MD32)

## Package Contents

The 6200 Software Developer's Kit (SDK) includes the following items:

- 6200 VME to PCI Interface adapter
- *6200 VME to PCI Interface Adapter Installation Guide*
- Newbridge Microsystems' *Universe™ User Manual*
- Sample 6200 driver source code (available from an Interphase password-protected ftp site)

## System Requirements

System requirements for the 6200 adapter are as follows:

- Approximately 200K free disk space for driver installation
- VME-based system



# Installing the 6200 Adapter

## 2

### Overview

Installing the 6200 adapter involves 4 basic steps:

1. Inspect the board.
2. Set onboard jumpers.
3. Power off system.
4. Install the board.

### Inspect the Board



#### Caution

**Handle the 6200 adapter carefully; the card is sensitive to static electricity. Interphase ships the board in an anti-static bag. Do not touch the adapter's components or metal parts (hold the adapter by its edges). To prevent card damage from electrostatic discharge, wear a grounding strap.**

Remove the 6200 from its anti-static bag, and visually inspect it to ensure that no damage has occurred during shipment. A visual inspection is usually sufficient, as Interphase thoroughly checks each board just prior to shipment.



---

*Set Onboard Jumpers*

---

If the board is undamaged, proceed with the installation. If the board is damaged, refer to the Assistance information at the front of this manual. In addition to contacting your reseller or Interphase, contact the carrier (for example, UPS or Federal Express) that delivered the package.



**Do not install, or apply power to, a damaged board. Failure to observe this warning could result in extensive damage to the board and/or the system.**


---

## Set Onboard Jumpers

Set the onboard jumpers so that the 6200 is properly configured for operation in your system. Figure 2-1 on page 5 shows the location of the jumpers. In this manual, IN refers to the jumper being installed across the pins indicated; OUT indicates the jumper is removed.



**Note:** The boxed pins are pin position #1



**Figure 2-1. 6200 Motherboard Jumper Pins**



---

*Set Onboard Jumpers*

---

## Jumper Blocks for Interphase Use Only

The following jumper blocks are for Interphase use only:

- J1, Board Reset Switch (for debugging only)
- J2, PCI Bus Reset Switch (for debugging only)
- J4, In-System Programming Header

## Reserved Jumper Blocks and Pins

The following jumper blocks are reserved:

- J5
- J6

J7 pins 3 and 4 through 19 and 20 are reserved.



**Note**

**In jumper blocks J5 through J8, pin 2 is directly underneath pin 1 (see Figure 2-1 on page 5).**



---

## Jumper Blocks J7 and J8

Use these jumper blocks to

- Choose VME address space
- Set base address space for VME bus register slave image

### Required

J8 pins 1 and 2 must be IN to enable the slave register image. This is the default.



## VME Address Space

To choose VME address space:

To choose this VME address space . . .	J8 pins 3 and 4	J8 pins 5 and 6
A16	OUT	OUT
A24	OUT	IN
A32	IN	OUT

## Base Address Space

Set the following jumpers to select the short I/O space the board will respond to according to the VME address space you chose:

These pins . . .	Represent this bit if you chose A16 . . .	Represent this bit if you chose A24 . . .	Represent this bit if you chose A32 . . .
J8 pins 7 and 8	A15	A23	A31
J8 pins 9 and 10	A14	A22	A30
J8 pins 11 and 12	A13	A21	A29
J8 pins 13 and 14	A12	A20	A28
J8 pins 15 and 16	n/a	A19	A27
J8 pins 17 and 18	n/a	A18	A26
J8 pins 19 and 20	n/a	A17	A25
J7 pins 1 and 2	n/a	A16	A24

*Set Onboard Jumpers***Note**

If you choose A16, the system provides bits A11 through A8.

**A16 Example**

If you choose VME address space A16 and want the board to respond to the short I/O space 8000, you would set your block J7 and J8 jumpers as follows:

Pins	Setting
J8 pins 1 and 2	IN
J8 pins 3 and 4	OUT
J8 pins 5 and 6	OUT
J8 pins 7 and 8	IN
J8 pins 9 and 10	OUT
J8 pins 11 and 12	OUT
J8 pins 13 and 14	OUT
J8 pins 15 and 16	OUT
J8 pins 17 and 18	OUT
J8 pins 19 and 20	OUT
J7 pins 1 and 2	OUT
J7 pins 3 and 4 through 19 and 20	n/a (Reserved)

### A24 Example

If you choose VME address space A24 and want the board to respond to the short I/O space 800000, you would set your block J7 and J8 jumpers as follows:

Pins	Setting
J8 pins 1 and 2	IN
J8 pins 3 and 4	OUT
J8 pins 5 and 6	IN
J8 pins 7 and 8	IN
J8 pins 9 and 10	OUT
J8 pins 11 and 12	OUT
J8 pins 13 and 14	OUT
J8 pins 15 and 16	OUT
J8 pins 17 and 18	OUT
J8 pins 19 and 20	OUT
J7 pins 1 and 2	OUT
J7 pins 3 and 4 through 19 and 20	n/a (Reserved)

---

*Power Off System*

---

**A32 Example**

If you choose VME address space A32 and want the board to respond to the short I/O space 80000000, you would set your block J7 and J8 jumpers as follows:

<b>Pins</b>	<b>Setting</b>
J8 pins 1 and 2	IN
J8 pins 3 and 4	IN
J8 pins 5 and 6	OUT
J8 pins 7 and 8	IN
J8 pins 9 and 10	OUT
J8 pins 11 and 12	OUT
J8 pins 13 and 14	OUT
J8 pins 15 and 16	OUT
J8 pins 17 and 18	OUT
J8 pins 19 and 20	OUT
J7 pins 1 and 2	OUT
J7 pins 3 and 4 through 19 and 20	n/a (Reserved)

**Power Off System**

Once the board is configured, ensure that the host system and peripherals are turned off.





**Caution**

**System power and peripheral power must be turned off before attempting to install the 6200. Failure to do so can result in severe damage to the board and/or the system.**

## Install the Board

Install the 6200 adapter as follows:

1. Carefully slide the 6200 into the VMEbus card slot. It should slide all the way in without any difficulty.
2. Once the board is properly seated in the slot, tighten the captive mounting screws on each end of the front panel.



*Install the Board*

---



# 6200 Specifications

A

## Architecture

PCI-VME Bridge	Tundra® Semiconductor's Universe™
Local Buffer	512 KBytes

## VMEBus Specifications

Capable data transfers	D32 BLT 30 MBps D64 MBLT 60 MBps
Address and data transfer modes	A32/A24/A16 D64/D32/D16/D08 BLT (Block Transfer) ADOH (Address-Only-With- Handshake) RMW (Read-Modify-Write) LOCK
Short I/O address	Jumper selectable

## PCI Local Bus Specifications

- 33 MHz, 32-bit PCI local bus interface
- 2 sets of PMC connectors
- 5V only

*Mechanical (Nominal)***Mechanical (Nominal)**

The 6200 occupies one 6U single-height VMEbus slot.

Width	9.20" (233 mm)
Height	6.30" (160 mm)
Thickness	20 mm
Weight	214 g (no daughtercards)

**Power Requirements**

6200 motherboard	1.1A at +5VDC
------------------	---------------

**Operating Environment**

Temperature	0–55° C / 32–131° F
Relative humidity	10–95% noncondensing
Altitude	-1000–15,000 feet
Air flow	250 LFM minimum

**Storage Environment**

This section assumes the adapter is stored in its original anti-static bag and box.

Temperature	-40–85° C / -42–185° F
Relative humidity	10–95% noncondensing
Altitude	-1000 to 50,000 feet



# VME Technology Overview

**B**

## VME Technology

VMEbus features a 32-bit address bus (up to 4 gigabytes of memory) and a 32-bit data bus, both of which can be dynamically configured. VMEbus also performs multiprocessing and can smoothly handle seven interrupt levels. VMEbus handles data transfers at speeds in excess of 40 MBps.

VMEbus uses a master-slave architecture. Masters transfer data to and from modules called slaves. Before a master can transfer data it must first acquire the bus using a central arbiter. This arbiter is part of the system controller. Its function is to determine which master accesses the bus next.

All bus activity is performed by the following four sub-busses:

- Data Transfer Bus
- Data Transfer Arbitration Bus
- Priority Interrupt Bus (interrupt processing)
- Utility Bus (16 Mhz clock and power-up reset)

For more information about VME terminology, see the glossary.

## Obtaining VME Specifications

- VME64 Specification, available from:  
VME International Trade Association  
10229 North Scottsdale Road, Suite B  
Scottsdale, AZ 85253





*Obtaining VME Specifications*

---

- VMEbus Specification Revision D, IEEE, available from:

IEEE Service Center  
Publications Sales Department  
445 Hoes Lane  
Piscataway, NJ 08854-4150



# PCI/PMC Technology Overview



## PCI/PMC Technology

A PCI bridge provides a high bandwidth path allowing PCI masters direct access to main memory. Intel® Corporation and the PCI SIG designed the PCI bus as the next generation I/O expansion bus. Its predecessors were ISA, EISA, and MCA. The PCI bus is a high-performance bus found in systems ranging from low-end PCs to high-end servers.

Three sizes of PCI add-in boards are defined: long, short, and variable short length. Systems are not required to support all board types. To accommodate the 5V and 3.3V signaling environments and to facilitate a smooth migration path between the voltages, three add-in board electrical types are specified: a “5 volt” board which plugs into only 5V connectors, a “universal” board which plugs into both 5V and 3.3V connectors, and a “3.3 volt” board which plugs into only 3.3V connectors.

The PMC bus was designed for embedded environments. It implements PCI bus logic in a daughtercard (mezzanine) form factor.



*PCI/PMC Technology*

---





## Index

---

When using this index, keep in mind that a page number indicates only where referenced material begins. It may extend to the page or pages following the page referenced.

### **B**

board installation 3

### **E**

environment  
    operating 14  
    storage 14

### **I**

installing the board 3

### **J**

jumpers 4

### **S**

system requirements 2

### **V**

VME address space 6



*Index*

---





## Product Registration Card

Please take a minute to register your Interphase product. This will enable us to notify you about software updates and product enhancements.

Name \_\_\_\_\_  
Title \_\_\_\_\_  
Company Name \_\_\_\_\_  
Company Address \_\_\_\_\_  
City \_\_\_\_\_  
State \_\_\_\_\_ Zip \_\_\_\_\_ Country \_\_\_\_\_  
Province \_\_\_\_\_  
Telephone ( ) \_\_\_\_\_  
Fax ( ) \_\_\_\_\_  
E-mail Address \_\_\_\_\_

Which product did you purchase? \_\_\_\_\_  
Serial Number \_\_\_\_\_  
Where did you purchase this product (company name)? \_\_\_\_\_  
Date Purchased \_\_\_\_\_

Number of client nodes at this site: \_\_\_\_\_

Operating System(s) being used with this product:

- |                                  |                                     |                                      |                                     |
|----------------------------------|-------------------------------------|--------------------------------------|-------------------------------------|
| <input type="checkbox"/> Solaris | <input type="checkbox"/> SunOS      | <input type="checkbox"/> AIX         | <input type="checkbox"/> NetWare    |
| <input type="checkbox"/> HP-UX   | <input type="checkbox"/> IRIX       | <input type="checkbox"/> Mac OS      | <input type="checkbox"/> Windows NT |
| <input type="checkbox"/> PC NFS  | <input type="checkbox"/> DEC Ultrix | <input type="checkbox"/> Other _____ |                                     |

Operating System Version: \_\_\_\_\_

Network Protocol(s) in use:

- |                                 |                              |                                    |                                      |
|---------------------------------|------------------------------|------------------------------------|--------------------------------------|
| <input type="checkbox"/> TCP/IP | <input type="checkbox"/> IPX | <input type="checkbox"/> AppleTalk | <input type="checkbox"/> Other _____ |
|---------------------------------|------------------------------|------------------------------------|--------------------------------------|

We welcome your comments, ideas, and suggestions. Attach additional sheets if necessary.

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

If you are interested in receiving information on other products from Interphase, please check the appropriate boxes:

- |                              |                               |                               |  |                                    |
|------------------------------|-------------------------------|-------------------------------|--|------------------------------------|
| <input type="checkbox"/> ATM | <input type="checkbox"/> FDDI | <input type="checkbox"/> SCSI | <input type="checkbox"/> Fibre Channel | <input type="checkbox"/> 100 BaseT |
|------------------------------|-------------------------------|-------------------------------|--|------------------------------------|


If you are mailing this card from outside the United States, please add postage.

9/96





NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES



6200.blk : smlmrmrg.doc 22 Wed Oct 30 17:24:17 1996



**BUSINESS REPLY MAIL**  
FIRST-CLASS MAIL PERMIT NO. 5784 DALLAS TEXAS

POSTAGE WILL BE PAID BY ADDRESSEE

ATTN: WARRANTY DEPARTMENT  
INTERPHASE CORPORATION  
13800 SENLAC DR  
DALLAS TX 75234-9600





## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)