ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Pickering 10-930A-001* at our website: *Click HERE*

USER MANUAL

IEEE-488 / GPIB

SYSTEM 10 / 20 ANCILLARIES (CASES, POWER SUPPLIES, EXPANSION CASES & EXPANSION MODULES)



Issue 3.1 July 2008

pickering

www.pickeringtest.com

ISO 9002
Reg No. FM38792

© COPYRIGHT (2008) PICKERING INTERFACES. ALL RIGHTS RESERVED.

No part of this publication may be reproduced, transmitted, transcribed, translated or stored in any form, or by any means without the written permission of Pickering Interfaces.

Technical details contained within this publication are subject to change without notice.

TECHNICAL SUPPORT

For Technical Support please contact Pickering Interfaces either by phone, fax, the website or via e-mail.

WARRANTY

All products manufactured by Pickering Interfaces are warranted against defective materials and workmanship for a period of two years, excluding PXI chassis, from the date of delivery to the original purchaser. Any product found to be defective within this period will, at the discretion of Pickering Interfaces be repaired or replaced.

Products serviced and repaired outside of the warranty period are warranted for ninety days.

Extended warranty and service are available. Please contact Pickering Interfaces by phone, fax, the website or via e-mail.

ENVIRONMENTAL POLICY

Pickering Interfaces operates under an environmental management system similar to ISO 14001.

Pickering Interfaces strives to fulfil all relevant environmental laws and regulations and reduce wastes and releases to the environment. Pickering Interfaces aims to design and operate products in a way that protects the environment and the health and safety of its employees, customers and the public. Pickering Interfaces endeavours to develop and manufacture products that can be produced, distributed, used and recycled, or disposed of, in a safe and environmentally friendly manner.



Observe the Electrical Hazard Warning detailed in Section 9.



Observe the Electrostatic Sensitive Device Caution detailed in Section 9.

Worldwide Technical Support and Product Information

http://www.pickeringtest.com

Pickering Interfaces Headquarters

Stephenson Road Clacton-on-Sea CO15 4NL United Kingdom
Tel: +44 (0)1255-687900
Fax: +44 (0)1255-425349
E-Mail: sales@pickeringtest.com

Pickering Interfaces Inc.
2900 Northwest Vine Street
Grants Pass
Oregon 97526
USA

Tel: +1 541 471 0700
Fax: +1 541 471 8828
E-Mail: ussales@pickeringtest.com

Pickering Interfaces Inc.
(East Coast Regional Office)
12 Alfred Street Suite 300-3
Woburn Massachusetts 01801
USA

Tel: +1 781 897 1710
Fax: +1 781 897 1701
E-mail: useastsales@pickeringtest.com

Pickering Interfaces GmbH
Johann-Karg-Straße 30
D-85540
Haar-Salmdorf
Germany

Tel: +49 89 125 953 160
Fax: +49 89 125 953 189
E-Mail: desales@pickeringtest.com

Pickering Interfaces s.r.o.
Smetanova 525
Třinec
739 61
Czech Republic

Tel: +42 0558 339 168
Fax: +42 0558 340 888
E-mail: cesales@pickeringtest.com

Pickering Interfaces AB
Karl Nordströmsväg 31
432 53
Varberg
Sweden

Tel: +46 340-69 06 69
Fax: +46 340-69 06 68
E-Mail: ndsales@pickeringtest.com

Pickering Interfaces SARL
6 Rue De La Mare Blanche
77186 Noisiel
Marne Le Vallee
France

Tel +33 1 60 53 55 50
Fax +33 1 60 53 55 99
email frsales@pickeringtest.com

THIS PAGE INTENTIONALLY BLANK

CONTENTS

Copyright Statement ii

Technical Support and Warranty.....iii

Contents (this page).....v

Section 1
Enclosures 1.1
Case Dimensional Data 1.1
System 10 Case Schematic Diagrams 1.1
Mixed System 10/20 Case Schematic Diagrams ...1.1

Section 2
System Backplanes.....2.1
Overview 2.1
Backplane Layout 2.1

Section 3
Power Supplies.....3.1
Features 3.1
Power Supply Up/Down Sequencing Option.....3.1
Typical Driving Capability 3.1
Using External Power Supplies 3.1

Section 4
Expansion Cases and Modules.....4.1
Features 4.1
Expansion Cases and Sub-Racks 4.1
Expansion Modules 4.1

Section 5
Prototyping Modules.....5.1
Features 5.1

Section 6
Warnings and Cautions 6.1

THIS PAGE INTENTIONALLY BLANK

SECTION 1 - ENCLOSURES

1.1 Features

- DIN 41494 (IEC297) compatible.
- Compact Free standing case - case is also rack mountable -
- Full rack width (84HP), available in heights of 3U or 6U.
- Choice Of Module Access At Front Or Rear of Case
- Includes complete system motherboard.
- Expansion Cases Available
- Accepts all System 10/20 switching modules.

Switching System Cases come in a variety of sizes and may be benchtop or rack mounted, with either front or rear access versions to suit all cabling needs. Any combination of switching modules may be loaded into a case. Expansion cases are available for larger systems.

All System 10/20 Cases come complete with pre-wired internal backplane and module guides to match the configuration required, unused slots have blanking panels inserted. Interface and power supplies must be ordered separately.

1.1.1 Front or Rear Access

All case types are available with a choice of front or rear switching module loading:

“Front Access Cases” are generally popular for smaller systems where the unit will be used on a benchtop, the switching modules plug into the front of the case.

“Rear Access Cases” are usually more convenient for larger systems where a complete test or data acquisition system is being assembled into a cabinet. The switching modules plug into the rear of the case, keeping all wiring inside the cabinet, leaving the front panel uncluttered. This case version has a simple front panel with power indicator as shown in Figure 1.6.

Front Access cases require power supply, type 10-910-001, while rear access type require type 10-910-002.

On both versions power enters at the rear of the case on an IEC connector.

1.1.2 Serviceability

All Pickering Interfaces case types are passive, they contain no active components. Therefore maintenance and servicing can be done by simple module swapping, without having to remove the case.

1.1.3 Earth & Shielding Details

The whole case (all external surfaces) is earthed to the a.c. power ground. All plug-in modules earth by means of 2 or 4 earth bonding screws on their front panel.

For shielding purposes all switching modules have a shield connection point to be used with user constructed cable assemblies. An earthing stud (M8) mounted on a 6HP panel suitable for a central earthing is available, type 10-942-906.

In addition most modules have supplementary RFI screening, especially RF/Microwave types.

1.1.4 System 20 Modules

System 20 modules may be used within a mixed System 10/20 case, type 20-935A or 20-936A, please refer to Section 1.4.

1.1 Case Dimensional Data

All cases conform to DIN 41494 Part 5, IEC 297 Sec 2, see figs 1.2 and 1.3, for further dimensional data please contact Pickering Interfaces.

Case Colour: Light Grey

Case Weight: Depends upon case size and number and type of modules being used, there are too many combinations to list here, please contact factory to discuss.

Case Width: 449mm (not including rack mount brackets)

Case Height: 3U (133mm), 6U (266mm)

Case Depth: 250mm

Rack Mounting: Cases have built-in ears that can be pulled out when rack mounting is required.

Case Type: Vero Electronics KM7 II

For rear access case types allow extra space for switching module protruding connectors (possible up to 100mm).

10-930A-001	3U Full Width Case, Front Access
10-930A-002	3U Full Width Case, Rear Access
10-934A-001	6U Full Width Case, Front Access
10-934A-002	6U Full Width Case, Rear Access

Table 1.1 System 10 Case Order Codes

10-941-001	PCB Card Guide
10-941-002	Plug-In Module Card Guide
10-942-003	3HP Blanking Panel (3U)
10-942-006	6HP Blanking Panel (3U)
10-942-012	12HP Blanking Panel (3U)
10-942-021	21HP Blanking Panel (3U)
10-942-906	Earthing Stud (M8) on 6HP Panel (3U)

Table 1.2 System 10 Accessories Order Codes




Figure 1-1. System 10 Case 10-930A-001 Unloaded

1.1 System 10 Case Schematic Diagrams

The following diagrams illustrate all case variants, showing how much switching module space is available for each type. These will allow the most suitable case type to be selected. If your application exactly fills a case it may be worth looking at the next size up, so that unforeseen requirements needing additional modules can easily be added at a later date.

Other case sizes & options are available, please contact factory if you require further information.




Figure 1-2. Full Width Single Height Case 10-930A-001 or 10-390A-002




Figure 1-3. Full Width Double Height Case 10-934A-001 or 10-934-002




Figure 1-4. System 10 Front Access Case



Figure 1-5. System 10 Rear Access Case



Figure 1-6. 6U Rear Access System 10 Case, Viewed from front

1.4 Mixed System 10/20 Case Schematic Diagrams

The 20-935A/936A Switching System Cases should be chosen when both System 10 and 20 switching modules are required. The cases are suitable for both benchtop and rack mount use (hinged brackets are fitted to the case and can be flipped out when required). They are supplied complete with pre-wired internal backplane and module guides to match the configuration required, unused slots have blanking panels inserted.

The standard option for 6U cases is a split of 24/60 between System 10 and 20, however the case may be ordered to match any combination of switching modules required by the customer.

3U cases do not have any split options and mix System 10 modules mounted vertically and System 20 modules mounted horizontally. See Figure 1.10.

1.4.1 Case Schematic Diagrams

The following diagrams illustrate all case variants (types 20-935A and 20-936A) showing how much switching module space is available for each type. These will allow the most suitable case type to be selected. If your application exactly fills a case it may be worth looking at the next size up, so that unforeseen requirements needing additional modules can easily be added at a later date.

The standard 6U cases are split 24/60 (see illustrations), many other configurations are available, for instance the 12/72 split shown. Please contact factory if you require further information.

20-935A-001 **20-935A-002**	6U System 10/20 Case, Front Access 6U System 10/20 Case, Rear Access
20-936A-001 **20-936A-002**	3U System 10/20 Case, Front Access 3U System 10/20 Case, Rear Access

Table 1.3 System 10/20 Case Order Codes

10-941-001 **10-941-002**	PCB Card Guide Plug-In Module Card Guide
10-942-003 **10-942-006** **10-942-012** **10-942-021**	3HP Blanking Panel (3U) 6HP Blanking Panel (3U) 12HP Blanking Panel (3U) 21HP Blanking Panel (3U)
10-942-906	Earthing Stud (M8) on 6HP Panel (3U)
20-942-003 **20-942-006** **20-942-012** **20-942-021**	3HP Blanking Panel (6U) 6HP Blanking Panel (6U) 12HP Blanking Panel (6U) 21HP Blanking Panel (6U)
20-942-906	Earthing Stud (M8) on 6HP Panel (6U)

Table 1.4 System 20 Accessories Order Codes




Figure 1-7. System 10/20 Case Split 42/42 (20-935A-001-42/42 or 20-935A-002-42/42)




Figure 1-8. System 10/20 Case Split 12/72 (20-935A-001-12/72 or 20-935A-002-12/72)




Figure 1-9. System 10/20 Case Split 24/60 (20-935A-001-24/60 or 20-935A-002-24/60)




Figure 1-10. Full Width Single Height System 10/20 Case (20-936A-001 or 20-936A-002)




Figure 1-11. System 10/20 Front Access Case Split 24/60




Figure 1-12. System 10/20 Front Access Case Split 12/72




Figure 1-13. Mixed System 10/20 Front Access Case (Split 42/42)



Figure 1-14. 3U Mixed System 10/20 Front Access Case

SECTION 2 - SYSTEM BACKPLANES

2.1 Overview

All System 10/20 cases have a standard backplane which provides power, digital communications and a 10 pole analogue bus to all switching modules.

Switching modules may be placed anywhere on the backplane (i.e. they are not position dependant). Each module slot has a DIN 41612 64 way connector. All slots are arranged on a 0.6 Inch pitch.

There are 10 slots in the half width case and 24 slots in the full width case. Maximum number of modules per backplaneis 20.

2.2 Backplane Layout

2.2.1 Power Supply

Provides the three voltage supplies to all System 10 modules.

2.2.2 System Digital Bus

This is the internal bus used to communicate with all System 10 modules. It has a “Master/Slave” configuration with the GPIB/RS-232 interface module being the master.

Note: The communication bus is actually a direct implementation of the IEEE-488 bus put onto the backplane 64 way connectors. Recent modules use a high speed proprietary serial bus with a built in error checking/correction protocol.

2.2.3 Analogue Bus

Used by multiplexer and matrix modules to carry analogue signals. System 10 has a 10 line shielded bus, System 20 has the 10 pole bus plus a further 24 pole shielded bus. An optional high density 128 pole analogue bus is available (20-943) for use with the 20-630 multiplexer series.

2.2.4 Workspace Area

This area is available to the user for use in custom interconnection between modules. It is only suitable for voltages <100V & current <1.5A. Modules which currently have access to this are model series : 10-600 and 10-200.

2.2.5 Backplane Connector

Type:	DIN 41612 type socket.
No. of contacts:	64 (160 for high density backplane type 10-943).
Rated number of insertions:	400.




Figure 2-1. System 10/20 Backplane Pin Connections (Power, Communications and 10 Pole Analogue Bus)




Figure 2-2. System 20 Standard 24 Pole Analog Bus Backplane Pin Connections




Figure 2-3. System 20 High Density 128 Pole Analog Bus Backplane Pin Connections Model 20-943-001 (160 Way Reversed DIN 41612)

SECTION 3 - POWER SUPPLIES

3.1 Features

- Triple output 100W DC power supply.
- Low noise highly efficient secondary switcher.
- Power trading provides flexible outputs.
- Univeral voltage operation, between 100V and 250V AC
- Front panel LED indicators.

Input Voltages: 100V AC to 250V AC (45 - 65 Hz).

Outputs: Triple outputs with maximum total power 100W. Refer to Table 3.1 for current capacity.

Output Voltage	Nominal Current	Continuous Current	Peak Current
+5V logic supply	4.0A	7.0A	10.0A
+5V relay supply	3.0A	7.0A	10.0A
+12V relay supply	2.0A	3.0A	5.0A

Table 3.1 Power Supply Output Current Capacity

Isolation: 4kV input to output

Environment: 0-70°C, Derate by 2.5% per °C above 45°C.

Connector: DIN 41612 type H.

Weight: 10-910-001: 1.45Kg approx.

10-910-002: 1.70Kg approx.

Safety Specifications: IEC 380, IEC 435, BS 5850, BS 6301, VDE 0804, VDE 0806, UL 478 & CSA 22.2.

Model 10-910A-001

Suitable for front panel mounting, 12HP wide:

Use this model with cases: 10-930-001, 10-934-001, 20-935-001, 20-936-001

Model 10-910A-002

Suitable for rear panel mounting, 12HP wide:

Includes mains socket/filter & on/off switch.

Use this model with cases: 10-930-002, 10-934-002, 20-935-002, 20-936-002

3.2 Power Supply Up/Down Sequencing Option

This provides controlled sequencing of the three power supplies during mains on and off, particularly useful for unexpected mains fail and restore. This feature will prevent any possibility of unstable 5V logic momentarily operating relay coils.

Power Up Sequence

Delays connection of the two relay supplies (+5V & +12V) for approximately 3 seconds, thus allowing the logic on all switching modules to power up to a known state before applying relay power supplies - softstart is applied to the 12 Volt line.

Power Down Sequence

Upon sensing a mains fail (due either to turning off power switch or a direct mains fail) the two relay supply voltages are disconnected and immediately crowbarred (i.e. connected to ground through a low impedance path).

This feature is tolerant of mains failures below approximately 10ms (i.e. half of 50Hz cycle). Typical tolerance will be somewhat longer, however this will be very dependent upon power supply loading.

The Power Up/Down Sequencing function is fitted to all on all System 10/20 power supplies.

3.3 Typical Driving Capability

This power supplies will typically drive in excess of 20 switching modules, i.e. this will run all but the largest switching systems. However this will vary depending upon module type and the maximum number of relays to be simultaneously operated. The table below gives an indication of module power consumption. If in the unlikely event of approaching or exceeding the 100W power limit the preferred approach is to split the system into two cases joined with a pair of expansion modules (this will be software transparent).

Module	Description	Module State	Typical Power	Max No. Per Case
10-921	IEEE-488.2	—	1W	—
10-115	Reed Relay Module	All Relays Off 8 Relays On	0.6W 2.3W	>30 >30
10-410	Digital I/O Module	—	1.3W	>30
10-530	8x8 Matrix	0 Crosspoints On 8 Crosspoints On	0.8W 2W	>30 >30
10-740-	RF Multiplexer	2 Channels On	1.5W	>30
20-510	20x8 Matrix	0 Crosspoints On 8 Crosspoints On 20 Crosspoints On	0.8W 2W 3W	>30 >30 25
20-310	High Volts Module	8 Relays On	3W	25

Table 3.2 Power Supply Typical Driving Capability




Figure 3-1. 10-910A-001 Power Supply



Figure 3-2. 10-910A-002 Power Supply

3.4 Using External Power Supplies

In OEM applications it may be required to operate the switching system from an external DC power supply. However it is very important that the logic supply be kept completely separate from the voltage supply used to drive the relay coils, especially when using power or high voltage relays, in addition sequencing of these two supplies is important at power on and off. For further information please contact factory.




Figure 3-3. 10-910A-001 Power Supply Internal Connector (DIN 41612 Type H15))




Figure 3-4. 10-910A-002 Power Supply Internal Connector (DIN 41612 Type H15))

THIS PAGE INTENTIONALLY BLANK

SECTION 4 - EXPANSION CASES AND MODULES

4.1 Features

If the number of modules you require does not fit within a standard case or if you wish to split the switching system into two or more cases (e.g. to keep high voltage modules away from low voltage types) then you will need to use type the 10-925 expansion module.

The case with the IEEE-488 interface module acts as the master with all other cases acting as slaves. Each case must contain a it's own power supply unit plus expansion module/s. Expansion modules must be used in pairs, the expansion cable linking them can be ordered to the length required. The limit of 20 modules per System 10/20 master rack should still not be exceeded.

Reasons for using Expansion Racks

- Main rack overflow.
- To keep noisy switching modules away from the main case (e.g. high voltage switching).
- To keep individual switching modules as close to the load being switched as possible (e.g. RF Switching)

4.2 Expansion Cases & Sub-Racks

Expansion cases and sub-racks have the same order codes as the standard versions, refer to Section 1, each case requires it's own power supply and expansion module. For particular requirements the power supply from the master case may be used (please contact factory to discuss your application).

4.3 Expansion Modules

To connect an expansion case to the main case you will have to have use a pair of expansion modules, one in each rack. The expansion module carries all module digital communications (and power supplies for specialised requirements), **but NOT the internal Analogue Buses.**


If your slave case does not have it's own power supply then please consider the power supply requirements of the expansion case (it should not exceed 45W), if in doubt please contact factory to discuss your application. All power supplies are decoupled and have limited transient protection, but if noisy signals are being switched then a separate power supply may be needed.

Expansion module (10-925-001) has a front panel mounted 37 way D-type female connector, the two modules must be linked by the 10-953-020 expansion cable assembly (available in various lengths, 2m is standard). A pin out diagram is shown in Fig 4.1.

10-925-001	System 10/20 Expansion Module
10-953-020	Expansion Cable Assembly (2m length) Other cable lengths may be specified, e.g.. -010 = 1m, -005 = 0.5m.

Expansion Modules must be used in pairs.

Table 4.1 Expansion Module Order Codes



† Each expansion case usually has it's own power supply, but power can be carried from the master to the slave case for applications with low power requirements (consult factory for further information).

Figure 4-1. Expansion Connector Pin-Out

SECTION 5 - PROTOTYPING MODULES

5.1 Features

Prototyping modules are available for users to construct their own circuitry in. They consist of a fully screened module with a blank front panel and internal stripboard with built on DIN 41612 connector.

These modules are based on Vero Electronics type KM6 II, further dimensional information is available in their catalogue.

Users working with these modules may have to re-work the blank front panel to suit their own connector requirements. Pickering Interfaces have a range of Breadboard modules with built in drive circuitry and front panel connectors (model types 10-210 and 10-220).

System 10 Prototyping Modules are available in three sizes

10-944-012	2.4 Inch Front Panel Width 12HP (3U)
10-944-024	4.8 Inch Front Panel Width 24HP (3U)
10-944-042	9.6 Inch Front Panel Width 42HP (3U)

System 20 Prototyping Modules are available in three sizes

20-944-012	2.4 Inch Front Panel Width (12HP, 6U)
20-944-024	4.8 Inch Front Panel Width (24HP, 6U)
20-944-042	9.6 Inch Front Panel Width (42HP, 6U)




Figure 5-1. System 10 Prototype Module Exploded View




Figure 5-2. System 10 Prototype Module Top and Bottom Screen Positioning





Figure 5-3. System 10 Prototype Module Side Screen Positioning

SECTION 8 - WARNINGS & CAUTIONS



WARNING - DANGER OF ELECTRIC SHOCK

THESE MODULES CONTAIN HAZARDOUS VOLTAGES. BEFORE REMOVING THE OUTER COVERS REMOVE ALL SUPPLIES.



CAUTION
Handling of Electrostatic-Sensitive Semiconductor Devices

Certain semiconductor devices used in the equipment are liable to damage due to static voltage. Observe the following precautions when handling these devices in their unterminated state, or sub-units containing these devices:

(1) Persons removing sub-units from an equipment using these devices must be earthed by a wrist strap and a resistor at the point provided on the equipment.

(2) Soldering irons used during the repair operations must be low voltage types with earthed tips and isolated from the mains voltage by a double insulated transformer.

(3) Outer clothing worn must be unable to generate static charges.

(4) Printed Circuit Boards (PCBs) fitted with these devices must be stored and transported in anti-static bags.

THIS PAGE INTENTIONALLY BLANK

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP