ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Acces USB-DIO-48-T-RA* at our website: ***Click HERE***

ACCES I/O PRODUCTS, INC.
10623 Roselle Street, San Diego, CA 92121 • (858) 550-9559 • FAX (858) 550-7322
contactus@accesio.com • www.accesio.com

MODEL USB-DIO-48
USB 48 CHANNEL DIGITAL INPUT/OUTPUT MODULE

USER MANUAL

FILE: MUSB-DIO-48.A1j

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Notice

The information in this document is provided for reference only. ACCES does not assume any liability arising out of the application or use of the information or products described herein. This document may contain or reference information and products protected by copyrights or patents and does not convey any license under the patent rights of ACCES, nor the rights of others.

IBM PC, PC/XT, and PC/AT are registered trademarks of the International Business Machines Corporation.

Printed in USA. Copyright 2009 by ACCES I/O Products Inc, 10623 Roselle Street, San Diego, CA 92121. All rights reserved.

WARNING!!

ALWAYS CONNECT AND DISCONNECT YOUR FIELD CABLING WITH THE COMPUTER POWER OFF. ALWAYS TURN COMPUTER POWER OFF BEFORE INSTALLING A CARD. CONNECTING AND DISCONNECTING CABLES, OR INSTALLING CARDS INTO A SYSTEM WITH THE COMPUTER OR FIELD POWER ON MAY CAUSE DAMAGE TO THE I/O CARD AND WILL VOID ALL WARRANTIES, IMPLIED OR EXPRESSED.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Warranty

Prior to shipment, ACCES equipment is thoroughly inspected and tested to applicable specifications. However, should equipment failure occur, ACCES assures its customers that prompt service and support will be available. All equipment originally manufactured by ACCES which is found to be defective will be repaired or replaced subject to the following considerations.

Terms and Conditions

If a unit is suspected of failure, contact ACCES' Customer Service department. Be prepared to give the unit model number, serial number, and a description of the failure symptom(s). We may suggest some simple tests to confirm the failure. We will assign a Return Material Authorization (RMA) number which must appear on the outer label of the return package. All units/components should be properly packed for handling and returned with freight prepaid to the ACCES designated Service Center, and will be returned to the customer's/user's site freight prepaid and invoiced.

Coverage

First Three Years: Returned unit/part will be repaired and/or replaced at ACCES option with no charge for labor or parts not excluded by warranty. Warranty commences with equipment shipment.

Following Years: Throughout your equipment's lifetime, ACCES stands ready to provide on-site or in-plant service at reasonable rates similar to those of other manufacturers in the industry.

Equipment Not Manufactured by ACCES

Equipment provided but not manufactured by ACCES is warranted and will be repaired according to the terms and conditions of the respective equipment manufacturer's warranty.

General

Under this Warranty, liability of ACCES is limited to replacing, repairing or issuing credit (at ACCES discretion) for any products which are proved to be defective during the warranty period. In no case is ACCES liable for consequential or special damage arriving from use or misuse of our product. The customer is responsible for all charges caused by modifications or additions to ACCES equipment not approved in writing by ACCES or, if in ACCES opinion the equipment has been subjected to abnormal use. "Abnormal use" for purposes of this warranty is defined as any use to which the equipment is exposed other than that use specified or intended as evidenced by purchase or sales representation. Other than the above, no other warranty, expressed or implied, shall apply to any and all such equipment furnished or sold by ACCES.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Table of Contents

Chapter 1: Introduction 5
Features 5
Applications 5
Functional Description 6
Figure 1-1: Block Diagram 7
Ordering Guide 7
Model Options 7
Special Order 7
Included with your board 8
Optional Accessories 8
Figure 1-2: Enclosure Label 9
Chapter 2: Installation 10
Software CD Installation 10
Hardware Installation 10
Chapter 3: Hardware Details 11
Option Selections 11
Figure 3-1: 48 Channel Board Option Selection Map 11
Figure 3-2: 48 Channel OEM Board with Right Angle Headers Map 11
USB Connector 12
Embedded USB Connector 12
LED 12
DC Power Jack (Optional) 12
-ST Screw Terminals for High Retention Ext. Power 12
50 Pin Box Headers 12
5V Resettable Fused Outputs 12
Pull-Up / Pull-Down Configuration Jumpers 12
Chapter 4: USB Address Information 13
Chapter 5: Programming 14
unsigned long DIO_Configure(DeviceIndex, bTristate, pOutMask, pData) 14
unsigned long DIO_WriteAll(DeviceIndex,pData) 14
unsigned long DIO_ReadAll(DeviceIndex,Buffer) 14
Chapter 6: Connector Pin Assignments 15
Table 6-1: 50-Pin Connector Pin Assignments 15
Chapter 7: Specifications 16
Customer Comments 17

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 1: Introduction

Features

- 48 lines of digital I/O
- High-speed USB 2.0 device, USB 1.1 backwards compatible
- Six (6) 8-bit ports independently selectable for inputs or outputs
- All I/O lines buffered with 32 mA source, 64mA sink current capabilities
- I/O buffers can be enabled or tri-stated under program control
- Drivers and sample application provided
- Jumper selectable I/O pulled up to 5V (via 10KΩ), pulled down to ground or floating
- Jumper selectable power provided via USB cable or external power supply for higher current sourcing capabilities
- Resettable fused +5VDC output per I/O connector
- Standard 50-pin IDC-type shrouded connectors with key
- PC/104 size board (3.550 by 3.775 in.)
- Rugged industrial enclosure
- Compatible with Industry-Standard I/O Racks such as Gordos, OPTO22, Potter & Brumfield, etc.

Applications

- Automatic Test Systems
- Laboratory Automation
- Robotics
- Machine Control
- Security Systems, Energy Management
- Relay Monitoring and Control
- Parallel Data Transfer to PC
- Sensing Switch Closures or TTL, DTL, CMOS Logic
- Driving Indicator Lights or Recorders

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Functional Description

This USB board is an ideal solution for adding portable, easy-to-install digital I/O capabilities to any computer with a USB port. The board is a USB 2.0 high speed device, offering the fastest speed available with the USB bus. It is fully compatible with both USB 1.1 and USB 2.0 ports. The card is plug-and-play allowing quick connect/disconnect whenever you need additional I/O on your USB port.

The board features 48 bits of TTL-compatible digital I/O with high-current capabilities. Each digital port can be programmed to accept inputs or to drive outputs in 6 groups of 8-bit ports. Power is supplied to the card via the USB cable or for higher current capabilities, external power may be used. The I/O wiring connections are via two industry standard 50-pin connectors. For external circuits, fused +5VDC power is available at each I/O connector on pin 49. There is one resettable fuse per connector. The resettable fuses are rated at 0.5A.

All I/O lines are buffered by a type 74ABT543A tristate buffer transceiver capable of sourcing 32 mA or sinking 64 mA. The buffers are configured under program control for input or output.

I/O Lines are jumper selectable with pull-ups (to +5 VDC via 10KΩ) or with pull-downs (to ground).

Unlike most USB digital I/O products which primarily use a human interface device (HID) driver, we provide an easy to use, Windows-based, custom function driver optimized for maximum data throughput. This approach exposes the full functionality of the hardware along with maximizing the advantage of using the high-speed USB 2.0 bus.

Power is supplied to the card via the USB cable or for higher current capabilities, external power may be used. Complimenting the high-retention USB type B connector (quickly recognized by the orange insulator) is a factory option for a high-retention external power screw terminal pair.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 1-1: Block Diagram

Ordering Guide

USB-DIO-48	USB 48-channel digital input/output module

Model Options

- -OEM Board only version with no enclosure
- -RA Right angle headers (USB-DIO-48-OEM only)
- -DIN DIN rail mounting bracket for integrating into existing DIN rail systems
- -PR On-board DC power circuitry and external regulated AC/DC (5V) adapter
- -ST Ext. pwr components & screw term's for reg. 5V pwr input (high retention)
- -RoHS This product is available in a RoHS compliant version. Please call for specific pricing then be sure to add this suffix to the model number on any hard-copy or verbal purchase orders.

Special Order

Contact factory with your special requirement. Examples of special orders would be conformal coating, latching I/O headers.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Included with your board

The following components are included with your shipment, depending on options ordered. Please take the time now to ensure that no items are damaged or missing.

- USB Module in labeled enclosure with an anti-skid bottom
- 6' USB 2.0 cable
- Software Master CD
- USB I/O Quick-Start Guide

Optional Accessories

• CUSB-EMB-X	USB Type A to micro-fit OEM header, X=1 for 1’ cable, 6 for 6’ cable	
• CAB50F-6	Six-foot ribbon cable assembly with 50-pin female connectors	
• CAB50-6	Six-foot ribbon cable assembly with a 50-pin female header connector and a 50-pin female edge connector	
• STB-50	Screw terminal board, typically ships with standoffs but can also mount on SNAP-TRACK or DIN-SNAP	
• STB-48CH	50-Pin Multi-Header Universal Screw Terminal Board with steel powder coated enclosure for up to 48 Digital I/O Channels	
• IIB-24	24-Channel Optically Isolated Input Board	
• ROB-24	24-Channel Electromechanical Relay Board	
• DIN-SNAP-6	Six inch length of SNAP-TRACK with two clips, for mounting one STB-50 screw terminal board on a DIN rail	
• DIN-SNAP	One foot length of SNAP-TRACK with four clips, for mounting up to two STB-50 screw terminal boards on a DIN rail	
• MP104-DIN	DIN-rail mounting adapter plate for affixing any USB/104 module to a DIN-rail	

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 1-2: Enclosure Label

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 2: Installation

Software CD Installation

The software provided with this board is contained on one CD and must be installed onto your hard disk prior to use. To do this, perform the following steps as appropriate for your software format and operating system. Substitute the appropriate drive letter for your CD-ROM or disk drive where you see D: in the examples below.

WIN NT/2000/XP/2003

a. Place the CD into your CD-ROM drive.
b. The install program should automatically run. If it does not click START | RUN and type D:INSTALL, click OK or press Enter.
c. Follow the on-screen prompts to install the software for this board.

Hardware Installation

The board can be installed in any USB 2.0 or USB 1.1 port. Please refer to the USB I/O Quick Start Guide which can be found on the CD, for specific, quick steps to complete the hardware and software installation.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 3: Hardware Details

Option Selections

Refer to the setup programs on the CD provided with the board. Also, refer to the Block Diagram and the Option Selection Map when reading this section of the manual.

There are two primary versions of this board, each has an option selection map.




Figure 3-1: 48 Channel Board Option Selection Map




Figure 3-2: 48 Channel OEM Board with Right Angle Headers Map

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

USB Connector

The USB connector is a Type B high-retention type connector and mates with the cable provided. The USB port provides communication signals along with +5 VDC power. The board can be powered from the USB port or, if needed for higher source current applications, an external power supply can be used.

Embedded USB Connector

Micro 5-pin header provides embedded devices with a compact USB interface.

LED

The LED on the front of the enclosure is used to indicate power and data transmissions. When the LED is in an illuminated steady green state, this signifies that the board is successfully connected to the computer and has been detected and configured by the operating system. A continuously flashing LED signifies transmitted data over the USB.

DC Power Jack (Optional)

For high current applications when current sourced on outputs is anticipated to output more than a USB port can provide (typically 500 mA). The DC jack has a 2.00mm post and is designed to be used with the AC/DC regulated 5V external power supply shipped with this option. To configure for use, switch the jumper located near the USB connector to VEXT (please consult the option selection map for a visual reference).

-ST Screw Terminals for High Retention Ext. Power

Specify “-ST” when ordering the OEM version of this board to connect external power via secure screw terminals instead of a non-retained DC jack. Strip your wires approximately 4mm and tin, then tighten the regulated +5 VDC source leads into the labeled terminals.

50 Pin Box Headers

The 50 pin box headers have standard 0.100" spacing between pins and are keyed to prevent improper connections. It can be used with standard IDC type ribbon cables.

5V Resettable Fused Outputs

Two 0.5A resettable fuses each feed two I/O connectors at pin 49 used to power external module racks or relay boards and such. If an over-current persists on a circuit protected by a resettable fuse, it will open interrupting power to the circuit. Response time depends on over-current level and ambient temperature, humidity, etc. The fuse will remain open until the bi-metal elements cool sufficiently, at which time the circuit will be restored.

Pull-Up / Pull-Down Configuration Jumpers

One configuration jumper controls connector group 0 and another configuration jumper controls connector group 1. The I/O lines are either pulled up to +5V via 10KΩ (for dry-contact monitoring) or pulled down (for positive control logic applications). When no jumpers are installed, the lines are left floating, however due to the 10K resistor packs any un-used input will not have suppressed cross-talk. For pull-ups (most common), install these jumpers in the +5V position. For pull-downs, install these jumpers in the GND position. For neither, remove these jumpers.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 4: USB Address Information

Use the provided driver to access the USB board. This driver will allow you to determine how many supported USB devices are currently installed, and each device type. This information is returned as a Vendor ID (VID), Product ID (PID) and Device Index.

The VID is “0x1605" and the 48 bit board PID is “0x8002”.

The Device Index is determined by how many of the devices you have in your system, and provides a unique identifier allowing you to access a specific board.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 5: Programming

The driver software provided with the board uses a 32-bit .dll front end compatible with any Windows programming language. Samples provided in Borland C++Builder, Borland Delphi, Microsoft Visual Basic, and Microsoft Visual C++ demonstrate the use of the driver.

The following is a list of the most common function calls provided by the driver in Windows.

For a complete list of available functions and details on how to use them refer to the USB Software Reference Manual located in the installation path for this board.

unsigned long DIO_Configure(DeviceIndex, bTristate, pOutMask, pData)

unsigned long **DIO_Configure**(
unsigned long DeviceIndex - number from 0-31 of the device you want to configure
unsigned char bTristate - boolean value. TRUE causes all bits on the device to enter tristate (high-impedance) mode. FALSE removes the tristate. The tristate is changed **after** the remainder of the configuration has occurred. All devices with this feature power-on in the "tristate" mode at this time.
void *pOutMask - a pointer to the first element of an array of bytes; one byte per 8 ports or fraction. Each "1" bit in the array indicates that the corresponding byte of the device is Output.
void *pData - a pointer to the first element of an array of bytes. Each byte is copied to the digital output ports on the device before the ports are taken out of tristate. Any bytes in the array associated with ports configured as input are ignored.
)

The size of the out mask and data is as follows:

Out Mask	2 bytes
Data	12 bytes

unsigned long DIO_WriteAll(DeviceIndex,pData)

unsigned long DeviceIndex - number from 0-31 of the device to which you wish to write all output bits
void *pData - pointer to the first element of an array of bytes. Each byte is copied to the corresponding output byte. Bytes written to ports configured as inputs are ignored
)
Note that the size of "all" is the same as the size of the data given under DIO_Configure.


unsigned long DIO_ReadAll(DeviceIndex,Buffer)

unsigned long DeviceIndex - number from 0-31 of the device from which you wish to read all digital bits
void *Buffer - pointer to the first element of an array of bytes. Each port will be read, and the reading stored in the corresponding byte in the array.
)
Note that the size of "all" is the same as the size of the data given under DIO_Configure.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 6: Connector Pin Assignments

Two 50-pin male headers are provided for I/O connections designated as P2 and P3, which are also referred to as Groups 0 and 1 respectively.



PIN	P2	P3	PIN	FUNCTION
1	I/O 23	I/O 47	2	GROUND
3	I/O 22	I/O 46	4	GROUND
5	I/O 21	I/O 45	6	GROUND
7	I/O 20	I/O 44	8	GROUND
9	I/O 19	I/O 43	10	GROUND
11	I/O 18	I/O 42	12	GROUND
13	I/O 17	I/O 41	14	GROUND
15	I/O 16	I/O 40	16	GROUND
17	I/O 15	I/O 39	18	GROUND
19	I/O 14	I/O 38	20	GROUND
21	I/O 13	I/O 37	22	GROUND
23	I/O 12	I/O 36	24	GROUND
25	I/O 11	I/O 35	26	GROUND
27	I/O 10	I/O 34	28	GROUND
29	I/O 09	I/O 33	30	GROUND
31	I/O 08	I/O 32	32	GROUND
33	I/O 07	I/O 31	34	GROUND
35	I/O 06	I/O 30	36	GROUND
37	I/O 05	I/O 29	38	GROUND
39	I/O 04	I/O 28	40	GROUND
41	I/O 03	I/O 27	42	GROUND
43	I/O 02	I/O 26	44	GROUND
45	I/O 01	I/O 25	46	GROUND
47	I/O 00	I/O 24	48	GROUND
49	+5VDC	+5VDC	50	GROUND

Table 6-1: 50-Pin Connector Pin Assignments

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Chapter 7: Specifications

Digital Inputs (TTL Compatible)

- Logic High: 2.0 VDC min, 5.5 VDC max
- Logic Low: 0.8 VDC max, -0.5 VDC min
- Bias Resistors: 10K Ω

Digital Outputs

- Logic High: 2.0 VDC min., source 32 mA
- Logic Low: 0.55 VDC max., sink 64 mA

Bus Type

- USB2.0 high-speed (480 Mb/s)

Power

- Basic 48 bit unit: <300 mA typical (no load)
- +5 VDC from the USB bus or external power supply depending on user configuration. The USB bus is specified to provide 500 mA to most desktop environments. This gives you 182 mA available (500 mA - 300mA = 200 mA). If using more than a total of 500mA, use optional Regulated 5 VDC external power supply and **remove** VUSB jumper and place jumper on VEXT. Then plug in external power before plugging into USB port.
- +5V with 0.5A resettable fuse for each connector

Environmental

- Operating Temperature: 0 °C. to 70 °C.
- Storage Temperature: -40 °C. to +85 °C.
- Humidity: 0 to 90% RH, non-condensing.
- Board Dimension: 3.550 x 3.775 inches.
- Box Dimension: 4.00 x 4.00" x 1.25 inches.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Customer Comments

If you experience any problems with this manual or just want to give us some feedback, please email us at: ***manuals@accesio.com***. Please detail any errors you find, we will reply with manual updates

ACCES I/O PRODUCTS, INC.
10623 Roselle Street, San Diego CA 92121
Tel. (858)550-9559 FAX (858)550-7322
www.accesio.com

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP