

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Visit our website - *Click HERE*

37XR

Meterman®


Professional Digital Multimeter

True-RMS with Component and Logic Test

Users Manual

- Mode d'emploi
- Bedienungshandbuch
- Manuale d'Uso
- Manual de uso





1. **Display**
   Afficheur
   Anzeige
   Display
   Pantalla

2. **Feature Buttons**
   Boutons de fonctions
   Funktionstasten
   Pulsanti delle funzioni
   Botones de función

3. **Function/Range Switch**
   Commutateur de gamme/fonction
   Funktion/Bereich-Schalter
   Selettore funzione/portata
   Selector de la función y del rango

4. **Test Lead Connections**
   Branchements des cordons de test
   Messleitungsanschlüsse
   Boccole per i cavetti
   Conexiones de los conductores de prueba

5. **Strap Clip**
   Clip de bretelle
   Klemme
   Clip in velcro
   Clip para correa

6. **Battery/Fuse Cover**
   Capot des fusibles/pile
   Batterie-/Sicherungsabdeckung
   Sportello del vano portapile/fusibili
   Puerta de la batería y el fusible

37XR

Contents

Safety Information 2
  Symbols Used in this Manual 2
Introduction 3
Making Measurements 3
  Verify Instrument Operation 3
  Range Selection 3
  Correcting an Overload (OL or -OL) Indication 3
  Measuring DC Voltage ..... See Figure -1- 4
  Measuring AC Voltage (True rms) ..... See Figure -2 - & -3- 4
  Preparing for Current Measurements 4
  Measuring DC Current ..... See Figure -4- 4
  Measuring AC Current (True rms) ..... See Figure -3- & -5- 4
  Measuring Resistance ..... See Figure -6- 5
  Testing for Continuity ..... See Figure -7- 5
  Testing Diodes ..... See Figure -8- 5
  Measuring Capacitance ..... See Figure -9- 5
  Measuring Inductance ..... See Figure -10- 6
  Measuring Frequency ..... See Figure -11- 6
  Measuring Dutycycle ..... See Figure -12- 6
  Measuring dBm ..... See Figure -13- 6
  Testing Logic Levels ..... See Figure -14- 6
Additional Features 7
  Input Test Lead Warning 7
  True-rms Measurements 7
  MIN MAX AVG Measurements 7
  Peak Hold Measurements 7
  Beeper Off 8
  Auto Power Off 8
  REL (Relative) Measurements 8
  HOLD Measurements 8
  Backlight 8
Product Maintenance 9
  Battery and Fuse Replacement ..... See Figure -15- 9
Repair 9
  WARRANTY 10
Specifications 11

Safety Information

- The 37XR Digital Multimeter is UL, CSA, and EN61010-1 certified for Installation Category III – 600V and Category II – 1000V. It is recommended for use with local level power distribution, appliances, portable equipment, etc, where only smaller transient overvoltages may occur, and not for primary supply lines, overhead lines and cable systems.
- Do not exceed the maximum overload limits per function (see specifications) nor the limits marked on the instrument itself. Never apply more than 1000V dc/750 V ac rms between the test lead and earth ground.
- Inspect the DMM, test leads and accessories before every use. Do not use any damaged part.
- Never ground yourself when taking measurements. Do not touch exposed circuit elements or test probe tips.
- Do not operate the instrument in an explosive atmosphere.
- Exercise extreme caution when: measuring voltage >20V // current >10mA // AC power line with inductive loads // AC power line during electrical storms // current, when the fuse blows in a circuit with open circuit voltage >1000 V // servicing CRT equipment.
- Always measure current in series with the load – NEVER ACROSS a voltage source. Check fuse first. Never replace a fuse with one of a different rating.
- Do not change the position of the Function/Range Switch while the **MIN MAX,** feature is enabled. Erroneous readings will result.
- Remove test leads before opening the Battery Cover or case.

Symbols Used in this Manual

	Battery		Refer to the manual
	Double insulated		Dangerous Voltage
⎓	Direct Current	⏚	Earth Ground
~	Alternating Current	)))	Audible tone
	Fuse		Underwriters Laboratories, Inc
CE	Complies with EU directives		Canadian Standards Association

Introduction

The 37XR is a true rms autoranging handheld digital multimeter for measuring or testing the following:

- DC and AC voltage
- DC and AC current
- Resistance
- Inductance
- Frequency
- Dutycycle
- Capacitance
- Diodes
- Continuity
- dBm
- Logic Levels, TTL or CMOS

Additional features include: MIN MAX AVG, HOLD, REL, PEAK±, Backlight, and Range Lock

Making Measurements

Verify Instrument Operation

Before attempting to make a measurement, verify that the instrument is operational and the battery is good. If the instrument is not operational, have it repaired before attempting to make a measurement.

Range Selection

In addition to autoranging the 37XR allows you to manually select and lock a range by pressing the **RANGE** button. **RANGE** appears on the display to indicate that manual ranging is active. Each subsequent press of the range button steps the meter to the next higher range. When the highest range is reached the next press returns the meter to the lowest range. To return to autoranging press and hold the **RANGE** button for 2 seconds. **RANGE** no longer shows on the display.

Use autorange for all initial measurements. Then, when appropriate, use the **RANGE** button to select and lock a range.

Warning

To avoid electrical shock while manual ranging use the display annunciators to identify the actual range selected.

Correcting an Overload (OL or -OL) Indication ⚠

An OL or -OL indication may appear on the display to indicate that an overload condition exists. For voltage and current measurements, an overload should be immediately corrected by selecting a higher range. If the highest range setting does not eliminate the overload, interrupt the measurement until the problem is identified and eliminated. The OL indication is normal for some functions; for example, resistance, continuity, and diode test.

Measuring DC Voltage ⎓ See Figure -1-

1. Set the Function Switch to V⎓.
2. If **RANGE** is displayed, press the **RANGE** button to enable autoranging.
3. Connect the Test Leads: Red to **V** Ω ⇥⊢, Black to **COM**
4. Connect the Test Probes to the circuit test points.
5. Read the display, and, if necessary, correct any overload (OL) conditions.

Measuring AC Voltage (True rms) See Figure -2 - & -3-

See *Additional Features* to find out the advantages of true rms.

1. Set the Function Switch to V~.
2. If **RANGE** is displayed, press the **RANGE** button to enable autoranging.
3. If **dBm** is displayed, press the yellow button to turn off **dBm** (enable V~)
4. Connect the Test Leads: Red to **V** Ω ⇥⊢, Black to **COM**
5. Connect the Test Probes to the circuit test points.
6. Read the display, and, if necessary, correct any overload (OL) conditions.

Preparing for Current Measurements

- Turn off circuit power before connecting the test probes.
- Allow the meter to cool between measurements if current measurements approach or exceeds 10 amps.
- A warning tone sounds if you connect a test lead to a current input before you select a current function.
- Open circuit voltage at the measurement point must not exceed 1000 V.
- Always measure current in series with the load. Never measure current across a voltage source.

Measuring DC Current See Figure -4-

1. Set the Function Switch to a current function, **µA**, **mA**, or **10A**.
2. If the **10A** function is not selected and **RANGE** is displayed, press the **RANGE** button to enable autoranging.
3. Connect the Test Leads: Red to **µA mA** or **10A**, Black to **COM**
4. Turn off power to the circuit being measured.
5. Open the test circuit (—✕—) to establish measurement points.
6. Connect the Test Probes in series with the load.
7. Turn on power to the circuit being measured.
8. Read the display, and, if necessary, correct any overload (OL or -OL) conditions.

Measuring AC Current (True rms) See Figure -3- & -5-

See *Additional Features* to find out the advantages of true rms.

1. Set the Function Switch to a current function and range, **µA**, **mA**, or **10A**.
2. If **DC** is displayed, press the yellow button to turn on **AC**.
3. If the **µA** or **mA** function is not selected and **RANGE** is displayed, press the **RANGE** button to enable autoranging.
4. Connect the Test Leads: Red to **µA mA** or **10A**, Black to **COM**
5. Turn off power to the circuit being measured.

5. Open the test circuit (—✕—) to establish measurement points.
6. Connect the Test Probes in series with the load.
7. Turn on power to the circuit being measured.
8. Read the display, and, if necessary, correct any overload (OL) conditions.

Measuring Resistance See Figure -6-

1. Set the Function Switch to Ω.
2. If))) is displayed, press the yellow button to display Ω.
3. If **RANGE** is displayed, press the **RANGE** button to enable autoranging.
4. Connect the Test Leads: Red to **V** Ω →|←, Black to **COM**
5. Turn off power to the circuit being measured. Never measure resistance across a voltage source or on a powered circuit.
6. Discharge any capacitors that may influence the reading.
7. Connect the Test Probes across the resistance.
8. Read the display. If OL appears on the highest range, the resistance is too large to be measured.

Testing for Continuity See Figure -7-

1. Set the Function Switch to))).
2. If Ω is displayed, press the yellow button to display).
3. Connect the Test Leads: Red to **V** Ω →|←, Black to **COM**
4. Turn off power to the circuit being measured.
5. Discharge any capacitors that may influence the reading.
6. Connect the Test Probes across the resistance.
7. Listen for the tone that indicates continuity (< 40 Ω).

Testing Diodes See Figure -8-

1. Set the Function Switch to →|←.
2. Connect the Test Leads: Red to **V** Ω →|←, Black to **COM**
3. Turn off power to the circuit being measured.
4. Free at least one end of the diode from the circuit.
5. Connect the Test Probes across the diode.
6. Read the display. A good diode has a forward voltage drop of about 0.6 V. An open or reverse biased diode will read OL.

Measuring Capacitance See Figure -9-

1. Set the Function Switch to the ⊣⊢ function.
2. If **RANGE** is displayed, press the **RANGE** button to enable autoranging.
3. Connect the Test Leads: Red to **COM**, Black to **mA**
4. Turn off power to the circuit being measured.
5. Discharge the capacitor using a 100 kΩ resistor.
6. Free at least one end of the capacitor from the circuit.
7. Connect the Test Probes across the capacitor. When measuring an electrolytic capacitor match the test lead polarity to the polarity of the capacitor.
8. Read the display.

Measuring Inductance See Figure -10-

1. Set the Function Switch to **mH** or **H**.
2. If **RANGE** is displayed, press the **RANGE** button to enable autoranging.
3. Connect the Test Leads: Red to **⊣⊢H mA**, Black to **COM**
4. Turn off power to the circuit being measured.
5. Free at least one end of the inductor from the circuit.
6. Connect the Test Probes across the inductor.
7. Read the display.

Measuring Frequency See Figure -11-

1. Set the Function Switch to **Hz**.
2. If **%** is displayed, press the yellow button to display **Hz**.
3. If **RANGE** is displayed, press the **RANGE** button to enable autoranging.
4. Connect the Test Leads: Red to **Hz**, Black to **COM**
5. Connect the Test Probes to the signal source.
6. Read the display.

Measuring Dutycycle See Figure -12-

1. Set the Function Switch to **%**.
2. If **Hz** is displayed, press the yellow button to display **%**.
3. Connect the Test Leads: Red to **%**, Black to **COM**
4. Connect the Test Probes to the signal source.
5. Read the display.

Measuring dBm See Figure -13-

The 37XR measures dBm relative to 1 mW referenced to 50 Ω. That is, 10 dBm = 10 mW, 0 dBm = 1 mW, -10 dBm = 0.1 mW, etc.

1. Set the Function Switch to **dBm**.
2. Press the yellow button. The display shows **dBm** to verify the selection.
3. Connect the Test Leads: Red to **V Ω →⊢**, Black to **COM**
4. Connect the Test Probes to the signal source.
5. Read the display.

Testing Logic Levels See Figure -14-

The 37XR tests logic levels for both TTL and CMOS logic. The meter displays OL plus a ∧ for a high-level (true) condition. The meter beeps and displays an OL and a ∨ for a low-level (false) condition. See *Specifications* for the logic 1 and logic 0 voltage limits. Out-of-limits indications are dispalyed as OL only, no ∧, ∨ or beep occur.

1. Set the Function Switch to **LOGIC**
2. Press the **TTL CMOS** button to display the selected type.
3. Connect the Test Leads: Red to **V Ω →⊢**, Black to **COM**
4. Connect the black lead to logic common.
5. Connect the red lead to the logic test point.
6. Read the display.

Additional Features

Input Test Lead Warning

The meter emits a continuous tone when a test lead is placed in the **mA** or **10A** input jack and the Function/Range Switch is not set to a correct current position. (If the meter is connected to a voltage source with leads connected for current, very high current could result). All current ranges are protected by fast acting fuses.

True-rms Measurements

For ac measurements most DMMs average the ac input signal and display the result as an estimated rms value. This average-responding method is accurate for sinusoidal waveforms, but can be very inaccurate for distorted waveforms. To ensure the most accurate measurements, always use a true-rms DMM when measuring ac voltage or ac current on circuits for the following kinds of applications:

- Power Supplies - diodes
- Controllers
- Power Limiting - SCR or Triac
- Starting - motors
- Florescent Lighting - ballasts
- Speed Control - motors
- Pulsed Signals
- Any non-sinusoidal ac waveform

MIN MAX AVG Measurements

The MIN MAX AVG function reads and updates the display to show the maximum or minimum value measured after you press the **MIN MAX AVG** button.

Pressing the **MIN MAX AVG** button for less than 1 second will put the meter into a mode of displaying the maximum, minimum, average, or actual readings. Each time the button is pressed, the meter will cycle to the next display mode as shown in the table below. Press the **MIN MAX AVG** button for more than 2 seconds to disable this feature.

Button	Display	Value Displayed
< 1 second	**REC MAX**	Maximum value after feature activated
	REC MIN	Minimum value after feature activated
< 1 second	**REC AVG**	Average value after feature is activated
< 1 second	**REC**	Actual reading, min max being recorded.
> 2 seconds	Exit **MIN MAX AVG**	Normal measurement, actual reading

Peak Hold Measurements

Note: The PEAK function calibrates itself to meet the specifications.

Peak Hold records and stores the positive and negative peak values that occur while measuring ac current or ac voltage. To enable the Peak Hold feature press the **PEAK** button for more than 2 seconds. The display will show **CAL** to indicate the calibration cycle is in process. After the **CAL** indication clears, press the **PEAK** button again to display the maximum (P+) value for the ac voltage or ac current being measured. The display will toggle between the P+ and P- readings each time the **PEAK** button is pressed. Press the **PEAK** button for more than 1 second to exit the PEAK function.

Beeper Off

The beeper is an aural indicator to identify when the DMM is performing a function, making a range change, detecting a limit, and so on. To disable the beeper use the following procedure:

1. Set the Function Switch to **OFF**.
2. Press and hold the **HOLD** button while turning the Function Switch to the desired function. The no-beep symbol shows on the display.
3. Release the **HOLD** button. The Auto Power Off feature will remain disabled until the meter is turned off and then on.

Note: To disable both the beeper and Auto Power Off press and hold the **REL** *button while turning on the DMM.*

Auto Power Off

Auto Power Off is a battery saving feature that puts the meter into a sleep mode if the Function/Range Switch has not changed position in the last 30 minutes. To wake the meter turn it off and then on.

The Auto Power Off feature can be disabled to keep the meter from going to sleep. This feature is useful when using the MIN MAX mode for extended periods. To disable the Auto Power Off feature use the following procedure:

1. Set the Function Switch to **OFF**.
2. Press and hold the **MIN MAX AVG** button while turning the Function Switch from **OFF** to the desired function. The **SLEEP OFF** message shows on the display.
3. Release the **MIN MAX AVG** button. The Auto Power Off feature will remain disabled until the meter is turned off and then on.

Note: To disable both Auto Power Off and the beeper press and hold the **REL** *button while turning on the DMM.*

REL (Relative) Measurements

The Relative mode displays the difference between the actual reading and a reference value. It may be used with any function or range. To make a relative measurement first establish a reference value by measuring a value and then pressing the **REL** button after the reading has stabilized. This stores the measured value as the reference and sets the display to zero. The meter subtracts the reference value from subsequent measurements and displays this difference as the relative value. Measurement values greater than the reference value will be positive and values less than the reference value will be negative.

To exit the Relative Mode, Press and hold the **REL** button for 2 seconds.

HOLD Measurements

The **HOLD** button causes the meter to capture and continuously display a measurement reading. To use the **HOLD** feature make a measurement, and then, after the reading has stabilized, momentarily press the **HOLD** button. You can remove the test leads and the reading will remain on the display. Pressing the **HOLD** button again releases the display.

Backlight

Pressing the ☼ button illuminates the display with a blue backlight. The backlight will automatically turn off in about 60 seconds. Frequent use of the backlight will decrease battery life.

Product Maintenance

Cleaning

To clean the meter, use a soft cloth moistened with water. To avoid damage to the plastic components do not use benzene, alcohol, acetone, ether, paint thinner, lacquer thinner, ketone or other solvents to clean the meter.

Troubleshooting

If the meter appears to operate improperly, check the following items first.

1. Review the operating instructions to ensure the meter is being used properly.
2. Inspect and test the continuity of the test leads.
3. Make sure the battery is in good condition. The low battery symbol appears when the battery falls below the level where accuracy is guaranteed. Replace a low-battery immediately.
4. Check the condition of the fuses if the current ranges operate incorrectly.

Battery and Fuse Replacement See Figure -15-

⚠⚠WARNING

To avoid electrical shock remove the test leads from both the meter and the test circuit before accessing the battery or the fuses.

To access the battery and the mA fuse remove the two screws holding the Battery/Fuse Cover in place, and lift the cover from the meter.

To replace the mA fuse, pry it from its clips using a small screwdriver. A spare mA fuse is located between the battery and the mA fuse.

mA Fuse: Fast Blow .5A/1000V, minimum interrupt rating 30 kA (6.3 x 32 mm) (Meterman FP500)

To replace the 10 A fuse: 1) Remove the battery. 2) Remove the four rear-case screws. 3) Separate the case. 4) Remove the 10 A fuse cover. 5) Remove and replace the 10A fuse. 6) Re-install the fuse cover. 7) Reassemble the meter.

10A Fuse: Fast Blow 10A/1000V, minimum interrupt rating 30 kA (10 x 38 mm) (Meterman FP100).

Repair

All test tools returned for warranty or non-warranty repair or for calibration should be accompanied by the following: your name, company's name, address, telephone number, and proof of purchase. Additionally, please include a brief description of the problem or the service requested and include the test leads with the meter. Non-warranty repair or replacement charges should be remitted in the form of a check, a money order, credit card with expiration date, or a purchase order made payable to Meterman Test Tools.

In-Warranty Repairs and Replacement – All Countries

Please read the warranty statement located at the front of this manual and check your batteries and fuses before requesting repair. During the warranty period any defective test tool can be returned to your Meterman Test Tools distributor for an exchange for the same or like product. Please check the "Where to Buy" section on www.metermantesttools.com for a list of distributors near you. Additionally, in the United States and Canada In-Warranty repair and replacement units can also be sent to a Meterman Test Tools Service Center (see below for address).

Non-Warranty Repairs and Replacement – US and Canada

Non-warranty repairs in the United States and Canada should be sent to a Meterman Test Tools Service Center. Call Meterman Test Tools or inquire at your point of purchase for current repair and replacement rates.

In USA
Meterman Test Tools
1420 75th Street SW
Everett, WA 98203
Tel: 800-993-5853
Fax: 425-446-6390

In Canada
Meterman Test Tools
400 Britannia Rd. E. Unit #1
Mississauga, ON L4Z 1X9
Tel: 905-890-7600
Fax: 905-890-6866

Non-Warranty Repairs and Replacement – Europe

European non-warranty units can be replaced by your Meterman Test Tools distributor for a nominal charge. Please check the "Where to Buy" section on www.metermantesttools.com for a list of distributors near you.

European Correspondence Address*
Meterman Test Tools Europe
P.O. Box 1186
5602 BD Eindhoven
The Netherlands

** (Correspondence only – no repair or replacement available from this address. European customers please contact your distributor.)*

WARRANTY

This 37XR Digital Multimeter is warranted against any defects of material or workmanship within a period of three (3) years following the date of purchase of the multimeter by the original purchaser or original user. Any multimeter claimed to be defective during the warranty period should be returned with proof of purchase to an authorized Meterman Test Tools Service Center or to the local Meterman Test Tools dealer or distributor where your multimeter was purchased. See Repair section for details. Any implied warranties arising out of the sale of a Meterman Test Tools multimeter, including but not limited to implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the above stated one (1) year period. Meterman Test Tools shall not be liable for loss of use of the multimeter or other incidental or consequential damages, expenses, or economical loss or for any claim or claims for such damage, expenses or economical loss. Some states do not allow limitations on how long implied warranties last or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Specifications

General Specifications

(Stated accuracy at 23 °C ±5 °C, <75 % relative humidity.)

Display: 4 ¾ digit liquid crystal display (LCD) with a 41 segment analog bar-graphic.

Auto ranging: 9999 counts

Manual ranging: 9999 counts

Polarity: Automatic, positive implied, negative polarity indication.

Overrange: (OL) or (-OL) is displayed.

Zero: Automatic.

Low battery indication: The is displayed when the battery voltage drops below the operating level.

Auto power off: Approx. 30 minutes.

Measurement rate: 2 times per second, nominal.

Operating environment: 0 °C to 45 °C at <70 % R.H.

Storage temperature: -20 °C to 60 °C, 0 to 80 % R.H. with battery removed from meter.

Temperature Coefficient: 0.1 × (specified accuracy) per °C. (0 °C to 18 °C, 28 °C to 45 °C).

Altitude: (2000 m) 6562 feet

Power: Single standard 9-volt battery, NEDA 1604, JIS 006P, IEC 6F22.

Battery life: 75 hours typical with carbon-zinc. 150 hours typical with alkaline. Using the backlight will decrease battery life.

Dimensions:

196 mm (H) ×92 mm (W) ×60 mm (D).

Weight:

with battery and holster, 482 grams

Box contents:

Test leads /w alligator clips	1 set
Users Manual	1
Magne-Grip® Holster	1
Clip, magnet, and strap.	1
9V battery (installed)	1
spare mA fuse 0.5A/1000V	1

Approvals:

Safety: Conforms to EN61010- 1: Cat II – 1000V / Cat III - 600V; Class 2, Pollution degree II; UL3111-1; CSA C22.2 No. 1010.1, criteria B.

EMC: Conforms to EN61326-1.

This product complies with requirements of the following European Community Directives: 89/ 336/ EEC (Electromagnetic Compatibility) and 73/ 23/ EEC (Low Voltage) as amended by 93/ 68/ EEC (CE Marking). However, electrical noise or intense electromagnetic fields in the vicinity of the equipment may disturb the measurement circuit. Measuring instruments will also respond to unwanted signals that may be present within the measurement circuit. Users should exercise care and take appropriate precautions to avoid misleading results when making measurements in the presence of electronic interference.

Electrical Specifications

DC VOLTS

Ranges: 1000mV, 10V, 100V, 1000V (Auto/Manual ranging)

Resolution: 100 µV

Accuracy: ±(0.1 % rdg + 5 dgts)

Input impedance: 10 MΩ

Overload protection: 1000 V dc or 750 V ac rms

AC VOLTS TRUE RMS (45 Hz - 2 kHz)

Ranges: 1000mV, 10V, 100V, 750V (Auto/Manual ranging)

Resolution: 100 µV

Minimum reading on 1000mV range: 14 mV

Accuracy:

±(1.2 % rdg + 10 dgts) 45 Hz to 500 Hz

±(2.0% rdg + 10 dgts) 500 Hz to 2 kHz

±(2.0% rdg + 10 dgts) 45 Hz to 1 kHz on 750 V range

Peak Hold accuracy: ±(3.0 % + 200 dgts) on 100V, 750V range

1000mV, 10V ranges unspecified

Crest Factor: ≤ 3

Input impedance: 10 MΩ

AC coupled true rms specified from 5% to 100% of range

Overload protection: 1000 V dc or 750 V ac rms

DC CURRENT

Ranges: 100µA, 1000µA, 10mA, 100mA, 400mA, 10A (Auto/Manual ranging)

Resolution: 0.01 µA

Accuracy:

±(0.5 % rdg +10 dgts) on 100µA range

±(0.5 % rdg + 5 dgt) on 1000µA to 400mA ranges

±(1.5 % rdg + 10 dgts) on 10A range

Input protection: 0.5A/1000V fast blow ceramic fuse 6.3×32 mm on µA/mA input

10A/1000V fast blow ceramic fuse 10×38 mm on 10A input

10A input: 10 A for 4 minutes maximum followed by a 12 minute cooling period

Burden voltage:

µA Range:	1 mV/ 1 µA
mA Range:	10 mV/ 1 mA
A Range:	35 mV/ 1 A

AC CURRENT TRUE RMS (45 Hz to 1 kHz)

Ranges:100µA, 1000µA, 10mA, 100mA, 400mA, 10A (Auto/Manual ranging)

Resolution: 0.01 µA

Accuracy:

±(1.5% rdg +10 dgts) on 100µA to 100mA ranges

±(2.0% rdg +10 dgts) on 400mA range

±(2.5% rdg + 20 dgts) on 10A range

Peak Hold accuracy: ±(3.0 % + 200 dgts) 100µA range unspecified

Crest Factor: 3 ≤

AC coupled true rms specified from 5 % to 100 % of range

Input protection: 0.5A/1000V fast blow ceramic fuse 6.3×32 mm on µA/mA input

10A/1000V fast blow ceramic fuse 10×38 mm on 10A input

10A input: 10 A for 4 minutes maximum followed by a 12 minute cooling period

Burden voltage: See DC Current

RESISTANCE

Ranges: 1000Ω, 10kΩ, 100kΩ, 1000kΩ, 10MΩ, 40MΩ (Auto/Manual ranging)

Resolution: 100 mΩ

Accuracy: ±(0.5% rdg + 8 dgts) on 1000Ω to 1000kΩ ranges

±(1.0% rdg + 10 dgts) on 10MΩ range

±(2.0% rdg + 10 dgts) on 40MΩ range

Open circuit volts: -0.45 V dc typical

Overload protection: 1000 V dc or 750 V ac rms

CAPACITANCE

Ranges: 40nF, 400nF, 4µF, 40µF 400uF (3999 counts) (Auto/Manual ranging)

Resolution: 0.01 nF

Accuracy: ±(3.0 % rdg + 10 dgts) on 40nF, 400uF ranges

±(3.0 % rdg + 5 dgts) on 400nF to 40uF ranges

Test voltange: < 1 V

Test Frequency: 1.3 Hz on 40nF to 40µF ranges; 0.7 Hz on 400µF range

Input protection: 0.5A/1000V fast blow ceramic fuse 6.3×32 mm on µA/mA input

INDUCTANCE

Ranges: 4mH, 40mH, 400mH, 4H, 40H (3999 counts) (Auto/Manual ranging)

Resolution: 1 µH

Accuracy: ±(5.0 % rdg + 30 dgts)*

*For values of Q ≤ 7

Test frequecy: 1 kHz on 4mH, 40mH ranges, 200 Hz on 400mH to 40H ranges.

Input protection: 0.5A/1000V fast blow ceramic fuse 6.3×32 mm on µA/mA input

FREQUENCY

Ranges: 100Hz, 1000Hz, 10kHz, 100kHz, 1000KHz, 10MHz, (Auto/Manual ranging)

Resolution: 0.01 Hz

Accuracy: ±(0.1 % rdg + 5 dgts)

Sensitivity: 3Hz to 1MHz: >1.5 V rms; 1MHz to 10MHz: >2 V rms, <5 V rms

Minimum input range: 100Hz range > 3 Hz, 1000Hz range > 30 Hz

Minimum pulse width: > 25 ns

Duty cycle limits: > 30 % and < 70 %

Overload protection: 1000 V dc or 750 V ac rms

DUTY CYCLE

Ranges: 0 to 90 %

Resolution: 0.01 %

Pulse width:>10 us

Frequency range:

0% to 10% (40 Hz to 990 Hz)

10% to 90% (40 Hz to 20 kHz)

Accuracy: (5 V logic) ±(2.0 % rdg + 20 dgts)

Overload protection: 1000 V dc or 750 V ac rms

LOGIC TEST

Logic Type: TTL, CMOS

Thresholds Logic 1 (Hi):

TTL : 2.8 V ± 0.8 V, CMOS: 4 V ± 1 V

Thresholds Logic 0 (Lo):

TTL : 0.8 V ± 0.5 V, CMOS: 2 V ± 0.5 V

Test Voltage: TTL: 5 V dc, CMOS: > 5 V dc and < 10 V dc

Frequency Response: 20 MHz

Pulse Width: 25 ns min

Duty Cycle: >30 % and <70 %

Indication: 40 ms beep at logic 0 (LO)

Overload protection: 1000 V dc or 750 V ac rms

dBm

Ranges: -13dBm to + 50dBm

Resolution: 0.01 dBm

Accuracy:

±0.7 dB + 8 dgts (45 Hz to 5 kHz)

±2.5 dB + 8 dgts (5 kHz to 10 kHz)

Reference impedance: 50 Ω

Input protection: 10 MΩ

Overload protection: 1000 V dc or 750 V ac rms

CONTINUITY

Audible indication: Less than 40Ω

Response time: 100 ms

Overload protection:1000 V dc or 750 V ac rms

DIODE TEST

Test current: 1.0 mA (approximate)

Accuracy: ±(1.5 % rdg + 5 dgts)

Resolution: 1 mV

Open circuit volts: 3.0 dc typical

Overload protection:

1000 V dc or 750 V ac rms

mA, 10A jack: Input warning detects wrong function selection

AUXILIARY FEATURES

MIN/AVG/MAX: Displays the maximum, minimum, or average reading following a MIN, MAX, or AVG selection.

DATA HOLD: Freeze the latest reading on the display.

REL: Initiates relative measurements.

PEAK+/-: Record the peak+ or peak– value in a measurement. It is usable with ac voltage, ac current measurements. If the pressed time >2 seconds, the PEAK function will enter the calibration mode; the LCD will show CAL and the internal buffer will remember the internal offset voltage then go back to the measure mode.

RANGE: Initiates manual-range selection.


Backlight: Backlight auto-off approx. 60 seconds

TTL/CMOS: Shift LOGIC TTL or CMOS







Shift: Shift dBm, ACA, continuity, DUTY CYCLE

REPLACEMENT PARTS


TL36	Test Lead Set with Alligator clips
FP500	mA fuse - Fuse Pack 0.5A/1000V (4 each)
FP100	10A fuse - Fuse Pack 10A/1000V (2 each)
XR-H2	Magne-Grip® Holster, clip, magnet, and strap



1
V
Meterman
37XR
DC
387.5
V
MIN MAX AVG
REL
RANGE
PEAK ±
TTL CMOS
cal>2sec
LOGIC
%
Hz
mH
H
Ω
dBm
OFF
µA
mA
10A
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
dBm %
Hz
400m MAX FUSED
10A MAX FUSED
5
2
1
3
4
+
–
2
V
Meterman
37XR
AC
RANGE
115.1
V
MIN MAX AVG
REL
RANGE
PEAK ±
cal>2sec
LOGIC
%
Hz
mH
H
Ω
dBm
OFF
µA
mA
10A
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
dBm %
Hz
400m MAX FUSED
10A MAX FUSED
6
2
3
1
4
5


3 True rms


Input Waveform Signal d'entrØe Eingangsschwingungsform Forma d'onda d'ingresso Forma de onda de entrada		37XR AC True rms *
Sine Wave Sinuso dale Sinusschwingung Onda sinusoidale Onda sinusoidal		.707 x Vpeak CF = 1.414
Full Wave, Sine Wave Onde complŁte, Sinuso dale Volle Schwingung, Sinusschwingung Onda sinusoidale, onda intera Onda completa, Onda sinusoidal		0.308 x Vpeak CF = 3.247
Half-Wave, Sine Wave Demi-onde, sinuso dale Halbschwingung, Sinusschwingung Onda sinusoidale, semionda Media onda, onda sinusoidal		0.386 x Vpeak CF = 2.591
Square Wave Onde carrØe Rechteckschwingung Onda quadra Onda cuadrada		1.000 x Vpeak CF = 1.000
Square Wave Onde carrØe Rechteckschwingung Onda quadra Onda cuadrada		0.500 x Vpeak CF = 2.000
Pulse Wave Onde impulsionnelle Impulsschwingung Onda delI'impulso Onda de impulsos		Vpeak x K CF = 1 / K
Sawtooth Wave Onde en dent de scie S gezahnschwingung Onda a denti di sega Onda diente de sierra		0.577 x Vpeak CF = 1.733


* CF = Crest Factor, Crest Factor = Vpeak / Vrms



4
Meterman
37XR
DC
RANGE
MIN MAX AVG
REL
RANGE
PEAK ±
TTL CMOS
cal >2sec
LOGIC
TRUE RMS
CAT II 1000V
CAT III 600V
10A
OFF
8
2
1
3
4
7
5
6
5
Meterman
37XR
AC
RANGE
MIN MAX AVG
REL
RANGE
PEAK ±
TTL CMOS
cal >2sec
LOGIC
TRUE RMS
CAT II 1000V
CAT III 600V
10A
OFF
9
3
2
1
4
5
8
6
7



6 Ω
Meterman 37XR
10.83 kΩ
RANGE
MIN MAX AVG REL RANGE
PEAK ±
cal>2sec
LOGIC
%
Hz
mH
H
Ω
µA
mA
10A
dBm
V
OFF
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
COM
VΩ
400mA MAX FUSED
10A MAX FUSED
8
3
2
1
4
5
6
7



7
Meterman 37XR
.025
MIN MAX AVG REL RANGE HOLD
PEAK ±
TTL CMOS
cal>2sec
LOGIC
%
Hz
mH
H
Ω
µA
mA
10A
dBm
V
OFF
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
dBm %
Hz
400m MAX FUSED
10A MAX FUSED
2
1
3
6
4
5
7



8
Meterman
37XR
0.600
V
MIN MAX AVG
REL
RANGE
HOLD
PEAK ±
TTL CMOS
cal>2sec
LOGIC
%
Hz
mH
H
µA
mA
10A
dBm
OFF
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
dBm %
Hz
COM
10A
400m MAX FUSED
10A MAX FUSED
1
2
3
4
5
6


9
Meterman
37XR
RANGE
22.47
µF
MIN MAX AVG
REL
RANGE
PEAK ±
TTL CMOS
cal>2sec
LOGIC
%
Hz
mH
H
µA
mA
10A
dBm
OFF
TRUE RMS
CAT II 1000V
CAT III 600V
dBm %
Hz
COM
10A
+
1
2
3
4
5
6
7
8



10
Meterman
37XR
12.62
mH
RANGE
MIN MAX AVG
REL
RANGE
PEAK ±
TTL CMOS
cal>2sec
LOGIC
%
Hz
mH
H
Ω
dBm
OFF
µA
mA
10A
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
10A
400mA MAX FUSED
10A MAX FUSED
dBm %
Hz
COM
7
2
1
3
6
4
5


11
Hz
Meterman
37XR
3.007
k Hz
RANGE
MIN MAX AVG
REL
RANGE
PEAK ±
cal>2sec
LOGIC
%
Hz
mH
H
Ω
dBm
OFF
mA
10A
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
10A
400mA MAX FUSED
10A MAX FUSED
dBm %
Hz
COM
6
3
2
1
4
5



12
Meterman
37XR
20%
MIN MAX AVG
REL
RANGE
HOLD
PEAK ±
TTL CMOS
cal>2sec
LOGIC
Hz
mH
H
Ω
V
dBm
OFF
mA
10A
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
10A
COM
dBm %
Hz
400mA MAX FUSED
10A MAX FUSED
20%
100%
1
2
3
4
5


13 dBm
Meterman
37XR
2.06
dBm
MIN MAX AVG
REL
RANGE
HOLD
PEAK ±
TTL CMOS
cal>2sec
LOGIC
Hz
mH
H
Ω
V
dBm
OFF
µA
mA
10A
TRUE RMS
CAT II 1000V
CAT III 600V
mA µA
10A
COM
dBm %
Hz
400mA MAX FUSED
10A MAX FUSED
1
2
3
4
5

14 IOIOI



15 ⊟/+



⊗ (2)

9 V Battery
Pile 9 V
9 V Batterie
Pila de 9 V
Batería de 9 V

Spare 500 mA fuse
Fusible 500 mA de rechange
500 mA Ersatzsicherung
Fusibile di ricambio da 500 mA
Fusible de recambio de 500 mA

500 mA Fuse
Fusible 500 mA
500 mA Sicherung
Fusibile da 500 mA
Fusible de 500 mA

⊗ (2) ⊗ (4)

10 A Fuse
Fusible de 10 A
10 A Sicherung
Fusibile da 10 A
Fusible de 10 A

37XR

Meterman®

U.S. Service Center
Meterman Test Tools
1420 75th Street SW
Everett, WA 98203
Tel: 800-993-5853
Fax: 425-446-6390

Canadian Service Center
Meterman Test Tools
400 Britannia Rd. E. Unit #1
Mississauga, ON L4Z 1X9
Tel: 905-890-7600
Fax: 905-89-6866

European Correspondence Address*
Meterman Test Tools Europe
P.O. Box 1186
5602 BD Eindhoven
The Netherlands
**Correspondence only - no repair or replacement available from this address. European customers please contact your distributor.*

Visit www.metermantesttools.com for
- Catalog
- Application notes
- Product specifications
- Product manuals

PN 1990741
October 2002

© Meterman Test Tools.
All rights reserved. Printed in Taiwan.

Please Recycle

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP