

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Instek SPS-606* at our website: ***Click HERE***

SAFETY TERMS AND SYMBOLS

These terms may appear in this manual or on the product:



WARNING. Warning statements identify condition or practices that could result in injury or loss of life.



CAUTION. Caution statements identify conditions or practice that could result in damage to this product or other property.

The following symbols may appear in this manual or on the product:



DANGER High Voltage



DANGER Hot Surface



ATTENTION refer to Manual



Protective Conductor Terminal



Equipotentiality

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com


FOR UNITED KINGDOM ONLY

NOTE
This lead/appliance must only be wired by competent persons

WARNING
THIS APPLIANCE MUST BE EARTHED

IMPORTANT
The wires in this lead are coloured in accordance with the following code:

Green/ Yellow: Earth
Blue : Neutral
Brown: Live (Phase)



As the colours of the wires in main leads may not correspond with the colours marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with the letter E or by the earth symbol ⏚ or coloured Green or Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the Letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse; refer to the rating information on the equipment and/or user instructions for details. As a guide, cable of 0.75mm ² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any moulded mains connector that requires removal/replacement must be destroyed by removal of any fuse & fuse carrier and disposed of immediately, as a plug with bared wires is hazardous if a engaged in live socket. Any re-wiring must be carried out in accordance with the information detailed on this label.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

EC Declaration of Conformity

We

GOOD WILL INSTRUMENT CO.,LTD.

(1) NO. 95 - 11, Pao Chung Rd., Hsin-Tien City, Taipei Hsien, Taiwan

(2) Plot 522, Lorong Perusahaan Baru 3, Prai Industrial Estate, 13600 Prai, Penang, Malaysia

declare, that the below mentioned product

SPS-1820, SPS-3610, SPS-606

are herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Law of Member States relating to Electromagnetic Compatibility (89/336/EEC,92/31/EEC,93/68/EEC) and Low Voltage Equipment Directive(73/23/EEC).

For the evaluation regarding the Electromagnetic Compatibility and Low Voltage Equipment Directive, the following standards were applied:

EN 61326-1: Electrical equipment for measurement, control and laboratory use — EMC requirements (1997+A1: 1998)

Conducted Emission Radiated Emission	EN 55022 (1994)+A1(1995)+A2(1997)	Class A	Electrostatic Discharge	EN 61000-4-2	(1995)
			Radiated Immunity	EN 61000-4-3	(1996)
Current Harmonic (1995)/A12(1996)/A13(1997)/A1(1998)/A2(1998)/prA14(2000)	EN61000-3-2	Class A	Electrical Fast Transients	EN 61000-4-4	(1995)
			Surge Immunity	EN 61000-4-5	(1995)
Voltage Fluctuation	EN61000-3-3	(1995)+A1(1998)	Conducted Susceptibility	EN 61000-4-6	(1996)
———————	—————	———————	Voltage Dip/Interruption	EN 61000-4-11	(1994)

Low Voltage Equipment Directive 73/23/EEC & amended by 9368/EEC

Low Voltage Directive	EN 61010-1: 1990+A1: 1993+A2: 1995 EN 60950: 1992+A1+A2+A3+A4+A11

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

CONTENTS

SECTION		PAGE
1.	INTRODUCTION	1
2.	SPECIFICATIONS	2
	2-1 General	2
	2-2 Constant Voltage Operation	3
	2-3 Constant Current Operation	3
	2-4 Indicator Meter	3
	2-5 Insulation	3
3.	PRECAUTIONS BEFORE OPERATION	4
	3-1 Unpacking the Switching Power Supply	4
	3-2 Checking the line voltage	4
	3-3 Environment	5
	3-4 Equipment installation and operation	5
4.	THEORY OF OPERATION	6
5.	PANEL CONTROLS AND INDICATORS	9
	5-1 Front Panel	9
	5-2 Real Panel	9
6.	OPERATION INSTRUCTIONS	12
	6-1 Precaution	12
	6-2 Setting Current Limit	15
	6-3 Constant Voltage/Constant Current Characteristic	15
	6-4 Operation Mode	16
7.	MAINTANCE	17
	7-1 Fuse Replacement	17
	7-2 Line voltage Conversion	17
	7-3 Adjustment	18
	7-4 Cleaning	20

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

. INTRODUCTION

The series of switching power supplies for measuring instrument have ruled out the inconvenience of big volume and heavyweight of a traditional power supply possess.

The output voltage and current is controlled by two variable resistors with coarse and fine regulation for more handy and precise adjustment.

Features:

- With more extensive range of input voltage at 97V~133V (for 115V) and 195V~265V (for 230V).
- With high frequency operation can reduce the size of power transformer.
- With small size, light weight and high density power.
- Entire efficiency rate higher up to 70%.
- Auto control the voltage and current mode.
- Zero adjustment for the output of voltage and current.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2.SPECIFICATION

2-1. General

Main supply : 115V/230V±15% 50/60Hz (Switch selectable).

Rating, dimension and weight : See Table 2-1.

Table 2-1

Model	MAX. RATING		INPUT RATING		FUSE STYLE & RATING		WEIGHT
	Voltage	Current	Watts	VA	115V	230V	kg
SPS-1820	18V	20A	500	900	T 10A 250V	T 6.3A 250V	3.3
SPS-3610	36V	10A	500	900	T 10A 250V	T 6.3A 250V	3.3
SPS-606	60V	6A	500	900	T 10A 250V	T 6.3A 250V	3.3
Dimensions：128(W) ×145(H) ×285(D) mm.							

WARNING: Voltage over 60V DC is a lethal shock hazard to the user. Be careful when connecting power supplies in series to achieve voltage higher than 60V DC totally or 60V DC between any connection and earth ground.

Operation Environment : Indoor use,
Altitude up to 2000m,
Installation Category II,
Pollution degree 2.

Operation Temperature &Humidity : 0℃ to 40℃, <80%.

Storage Temperature & Humidity : -10℃ to 70℃, <70%.

Accessories : Test Lead (current < 4A)..... × 1
Operation Manual ..... × 1

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2-2.Constant Voltage Operation

(1) Output Voltage ranges from 0 to rating voltage with continuous adjustment.

(2) Voltage regulation

line regulation≦5mV.

load regulation≦5mV.

(3) Recovery time≦500μs(50% Load change, minimum load 0.5A).

(4) Ripple & Noise≦5mVrms, 100mVp-p (tested by 20MHz oscilloscope.)

(5) Temperature coefficient≦100ppm/℃.

2-3.Constant Current Operation

(1) Output current ranges from 0 to rating current with continuous adjustment.

(2) Current regulation

line regulation≦3mA.

load regulation≦3mA.

(3) Ripple & Noise≦3mArms (SPS-606).

≦5mArms (SPS-3610).

≦10mArms (SPS-1820).

2-4.Indicator Meter

1)Voltage:

Display : 3 1/2 Digits 0.39” Green LED display.

Accuracy : ±(0.5% of rdg + 2 digits).

2)Current:

Display : 3 1/2 Digits 0.39” Red LED display.

Accuracy : ±(0.5% of rdg + 2 digits).

2-5.Over Voltage Protection

(1) Over Voltage Protection ranges from 5% rating to rating +5.5%.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

(2) OVP Accuracy ±(Vset 1%+0.6V)

2-6.Insulation

Between Chassis and Output Terminal : ≧20MΩ (DC500V).

Between Chassis and AC Cord : ≧30MΩ (DC500V).

3. PRECAUTIONS BEFORE OPERATION

3.1 Unpacking the Switching Power Supply

The instrument has been fully inspected and tested before shipping from the factory. Upon receiving the instrument, please unpack and inspect it to check if there is any damages caused during transportation. If any sign of damage is found, notify the bearer and/or the dealer immediately.

3.2 Checking the Line Voltage

The instrument can be applied any kind of line voltage shown in the table below. Before connecting the power plug to an AC line outlet, make sure the voltage selector of the rear panel is set to the correct position corresponding to the line voltage. It might be damaged the instrument if connected to the wrong AC line voltage.



WARNING: To avoid electrical shock the power cord protective grounding conductor must be connected to ground.

When line voltages are changed, replace the required fuses shown below.

Line voltage	Range	Fuse	Line voltage	Range	Fuse
115V	97-133V	T 10A 250V	230V	195-265V	T 6.3A 250V

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



WARNING: To avoid personal injury, disconnect the power cord before removing the fuse holder.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

3.3 Environment

The normal ambient temperature range of this instrument is from 0° to 40°C (32° to 104°F). Operation of the instrument above this temperature range may cause damage to the circuits.

Do not use the instrument in a place where strong magnetic or electric field exists as it may disturb the measurement.

3.4 Equipment Installation, and Operation

Ensure there is proper ventilation for the vents in the SPS power supplies case. If this equipment is used in a manner not according to the specification, the protection provided by the equipment may be impaired.



WARNING: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

I.THEORY OF OPERATION

- **Block Configuration of SPS- System**

  The SPS-Series comprise a Bridge rectifier, a Pulse Width Modulation, a Driver Circuit, a Driver Transformer, a Rectifier Circuit, a Voltage Control Circuit, a Current Shunt, an Output Filter, a Voltage/Current Adjusting Circuit, a Buffer Circuit, an Error Amplifier, an Opto-Isolator, and an Auxiliary Switching Supply and etc.

- **Component List for each circuit configuration**

Bridge Rectifier:	BD101.
Pulse Width Modulation:	U102.
Driver Circuit:	T104, Q105~Q108.
Driver Transformer:	T301.
Rectifier Circuit:	D301~D302.
Voltage Control Circuit:	Q303.
Current Shunt:	R341.
Output Filter:	Common Choke L302, C325.
Voltage/Current Adjusting Circuit:	U302.
Buffer Circuit:	U302, Q301.
Error Amplifier:	U301, U303.
Opto-isolator:	U304.
Auxiliary Switching Supply:	U201, U202, T201.
OVP:	U401, U402
Remote Control:	RL401, D402

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Description of Circuit Theory

1) +10V Voltage reference circuit?

Start up the circuits of R306 and D302 to ensure the output voltage of OPA U301, PIN 1 is in positive status when power is on. A this moment, the output voltage of PIN 1 will pass through R307 to maintain the voltage of both ends of ZENER DIODE ZD301(6.2V to 6.2V. As OPA has the character of false short circuit, so U301 PIN3=6.2V, refer to the following formula:

$$Vref = 6.2\frac{VR301 + R304 + R305}{R305} = 6.2\frac{VR301 + 4.99k + 10k}{10k} \cong 10V$$

Therefore, the OPA' s output voltage can be changed by adjusting the VR301 as shown in the following formula:

$Vref=10V \rightarrow VR301=1.14k\Omega$

2) Voltage Adjusting Circuit

The R311, and R313 are voltage feedback attenuating resistors while R312 is to control the output of Reference voltage. Please refer to the following formula:

$$Vout = Vref\frac{R311 + R313}{R313}$$

$$Vout = Vref\frac{52.3k + 20k}{20k} = 10\frac{72.3k}{20k} = 36.15V$$

If Vref=10V R311=52.3kΩ R313=20kΩ

And the R316, R317, C313, C314, and C315 are compensated circuits for voltage frequency.

3) Current Adjusting Circuit:

The U302 is an Error Amplifier with the gain at: $A = \frac{R326}{R342} = \frac{100k}{3.57k} = 28.01$

$$Io \times R341 \times A = 10V \times \frac{R321}{R321 + R322 + VR303} = Vpin12 = Vpin13$$


Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

For example: SPS-1820, Io=20A？ R341=10mΩ

Vpin12=Io×R341×A=20×0.01×28.01=5.602V

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

- **Figure 1: Block Diagram**



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

5.PANEL CONTROLS AND INDICATORS

5-1.Front panel

(1)	CV Indicator	Lights when the power is on and in constant voltage operation.
(2)	CC Indicator	Lights when in constant current operation.
(3)	Voltage coarse	For the coarse adjustment of the output voltage.
(4)	Voltage fine	For the fine adjustment of the output voltage.
(5)	Current coarse	For the coarse adjustment of the output current.
(6)	Current fine	For the fine adjustment of the output current.
(7)	"+" output terminal	Positive polarity (Red).
(8)	"GND" terminal	Earth and chassis ground (Green).
(9)	" – "output terminal	Negative polarity (Black).
(10)	Meter	Indicates the output voltage.
(11)	Meter	Indicates the output current.
(12)	Power control	On/Off switch.
(13)	Current HI/LO control	Current indicates HI/LO range selection.

5-2.Rear panel

(14)	Fuse holder	
(15)	Power socket.	
(16)	AC selects switch	With 115V or 230V voltage and current ranges selection (Refer to the diagrammatic instruction to prevent mis-operating).
(17)	Fan	Cooling fan.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

(18)	+ sense terminal	Screw type + sense input terminal.
(19)	– sense terminal	Screw type – sense input terminal.
(20)	+ output terminal	Screw type + output terminal.
(21)	– output terminal	Screw type – output terminal.
(22)	Ground terminal	Screw type ground terminal (connected to case chassis).
(23)	Remote Control	Short or open the remote control terminal for output on or off.
(24)	OVP ADJ	Adjust trimmer VR401 to set the OVP value.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Fig. 4-1 Front Panel

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Fig. 4-2 Rear Panel

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

5.OPERATION INSTRUCTIONS

5-1.Precaution

(1)AC input

AC input should be within the range of line voltage±15% 50/60Hz.



WARNING: To avoid electrical shock, the power cord protective grounding conductor must be connected to ground.

(2)Installation


Avoid using the power supply in a place where ambient temperature exceeds 40℃. The heat sink located at rear of the power supply must have sufficient space for radiation.



CAUTION: To prevent the instrument from damage, ensure the working environment is under 40℃ of temperature. If exceeding 40℃, please refer to the drawing shown as (3) of next page.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

(3) Output Current/Temperature Cure Line Chart:



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

4) Output Test lead Selection:

The Selection of Output Test Lead and Feedback Test Lead:

For safety assurance, please select the adequate output test lead according to the following list:

UL (CSA) Model	Conductor				Maximum Conductive Resistor Ω/km	Permissible Current A(amp)
	Wire No. AWG	Component pc/mm	Cross Section Area $(mm)^2$	Outer Diameter mm		
1015 TEW Twisted Wire)	24	11/0.16	0.22	0.64	88.6	7.64
	22	17/0.16	0.34	0.78	62.5	10.0
	20	21/0.18	0.53	0.95	39.5	13.1
	18	34/0.18	0.87	1.21	24.4	17.2
	16	26/0.254	1.32	1.53	15.6	22.6
	14	41/0.254	2.08	2.03	9.90	30.4
	12	65/0.254	3.29	2.35	6.24	40.6
	10	65/0.32	5.23	3.00	3.90	55.3

Remark:

1. The ambient temperature of "Permissible Current" is at 40℃, the withstanding temperature of conductor is at 105℃ according to the condition of the distributed single wire.
2. The permissible current listed as above is suggested to be used under 70%.
3. If the feedback test leads are in need, the level above UL(CSA) AWG24, 22, 20… can be accepted. Besides, when the load is a capacitive load, please use the twine wire by twisting (+)output test lead with (S+) feedback test lead. Same way used on (-) output test lead and (S-) feedback test lead.
4. When the current value exceeds above suggestive list, can select more wires used in parallel according to above list.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

6-2.Setting Current Limit

(1) Determine the maximum safe current for the device to be powered.
(2) Temporarily short the (+) and (-) terminals of the power supply together with a test lead.
(3) Rotate the COARSE VOLTAGE control away from zero sufficiently to have the CC indicator lightened.
(4) Adjust the CURRENT control for the desired current limit. Read the current value on the Ammeter.
(5) The current limit (overload protection) has now been preset. Do not change the CURRENT control setting after this step.
(6) Remove the short between the (+) and (-) terminals and hook up for constant voltage operation.

5-3.Constant Voltage / Constant Current Crossover Characteristic

The working characteristic of this series is called a constant voltage/constant current automatic crossover type. This permits continuous transition from constant current to constant voltage modes in response to the load change. The intersection of constant voltage and constant current modes is called the crossover point. Fig.5-1 shows the relationship between this crossover point and the load.

For example, if the load is such that the power supply is operating in the constant voltage mode, a regulated output voltage is provided. The output voltage remains constant as the load increases, up until the point where the preset current limit is reached. At that point, the output current becomes constant and the output voltage drop is proportioned to further increases in load. The crossover point is indicated by the front panel LED indicators. The crossover point is reached when the CV indicator goes out and the CC indicator is on.




Fig. 5-1 Constant Voltage/Constant Current Characteristic.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Similarly, crossover from the constant current to the constant voltage mode automatically occurs from a decrease in load, a good example of this would be seen when charging a 12 volt battery. Initially, the open circuit voltage of the power supply may be preset for 13.8 volts. A low battery will place a heavy load on the supply and it will operate in the constant current mode, which may be adjusted for a 1 amp charging rate. As the battery becomes charged, and its voltage approaches 13.8 volts, its load decreases to the point where it no longer demands the full 1 amp charging rate. This is the crossover point where the power supply goes into the constant voltage mode.

3-4.Operation mode: Voltage Operation Mode:

A. Set Power switch to "OFF" position.
B. Make sure that line voltage is correct for the input power voltage.
C. Plug power cord into the power outlet.
D. Set Power switch to "ON" position.
E. Adjust "Voltage" and "Current" control to the desired output voltage and current.
F. Connect the external load to the output binding posts. Make sure both "+" and "-" terminals are connected correctly.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

7. MAINTENANCE

WARNING

The following instructions are used by qualified personnel only. To avoid electrical shock, do not perform any servicing other than the operating instructions of the manual unless you are qualified to do so.

7-1.Fuse Replacement

If the fuse blown, the CV or CC indicators will not light and the power supply will not operate. The fuse should not normally blow unless a problem has developed in the unit. Try to determine and correct cause of the blown fuse, then replace only with a fuse of the correct rating and type.

The fuse is located on the rear panel (see Fig. 4-2).



WARNING: For continued fire protection. Replace with 250V fuse of the specified type and rating, and disconnect the power cord before replacing fuse.

7-2.Line Voltage conversion

The primary winding of the power transformer is tapped to permit operation from 115/230 VAC, 50/60 Hz line voltage. Conversion from one line voltage to another is done by change AC selects switch as shown in Fig. 4-2.

To convert to different line voltage, perform the following procedure:

(1) Make sure the power cord is unplugged.

(2) Set the AC switch to the desired line voltage position.

(3) The change of line voltage may also require a corresponding change of fuse value. Install correct fuse value according to the instruction shown on rear panel.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

7-3.Internal adjustments

The unit was accurately adjusted at the factory before shipment. So, readjustment is suggested only when the accuracy of circuit is affected by the repair, or when you have the reason to believe that the unit is out of accuracy. The recommended calibration device is a multimeter with an accuracy of ±0.1% dcv or better. (GOOD WILL model GDM-8145 or equivalent).

If readjustment is required, proceed the following procedure. Locations of the adjustments are shown in Fig. 6-1 and Fig.6-2.

(1) Adjustment of the Rating Voltage

A. Connect an accurate (±0.1%) external multimeter to measure the dc voltage at output terminals of the power supply.
B. Set the COARSE and FINE VOLTAGE controls to maximum (fully clockwise).
C. Adjust trimmer VR301 for a reading on the multimeter to be 18.50V for SPS-1820, 36.50V for SPS-3610, and 60.50V for SPS-606.
D. Adjust trimmer pot VR2 to set the reading value of voltmeter as same as the one shown on the multimeter..

(2) Adjustment of the rating Current

A. Set the CURRENT control to HI.
B. Set the COARSE and FINE CURRENT controls to minimum (fully counterclockwise).
C. Set the COARSE and FINE VOLTAGE controls to the center position.
D. Connect an external multimeter to measure dc current of output terminal.
E. Adjust trimmer VR304 to have a reading of –0.00A indicated on the current meter.
F. Set the COARSE and FINE CURRENT controls to maximum (fully clockwise)
G. Adjust trimmer VR303 for a reading on the multimeter to be 20.10A for SPS-1820, 10.10A for SPS-3610, and 6.10A for SPS-606.
H. Adjust trimmer VR2 to set the reading value of Amp-meter as the same as the one shown on the multimeter.
I. Set CURRENT control to LOW.
J. Adjust trimmer VR310 to set the reading value of Amp-meter as 0.5 times to the rating current.
K. Adjust trimmer VR401 to set the OVP value.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Fig. 6-1 Adjustment Location




Fig. 6-2 Adjustment Location



Fig. 6-3 Adjustment Location

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

7-4 Cleaning

To clean the power supply, use a soft cloth dampened in a solution of mild detergent and water. Do not spray cleaner directly onto the instrument, since it may leak into the cabinet and cause damage. Do not use chemicals containing benzine, benzene, toluene, xylene, acetone, or similar solvents. Do not use abrasive cleaners on any portion of the instrument.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP