ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *BEC DMM-402* at our website: *Click HERE*

LUMANTEK
Let's Ubiquitous

PCI Adaptors
T-DMB/DAB Modulator

DMM-402/UPC-231

Reference and Installation Guide

Manual Ver 1.0



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

LUMANTEK
Let's Ubiquitous

PCI Adaptors
T-DMB/DAB Modulator

DMM-402/UPC-231

Reference and Installation Guide

Manual Ver 1.0

"This manual is Installation Guide for LUMANTEK PCI Adaptor Users"

All specifications and features are subject to change without notice.
For the Device Driver, you may download on the web.
Others:

Written on: Jul, 2005
Revised on: Jun 2007 (1'st)
LUMANTEK Co., Ltd Lab
Tel: 82-2-2027-2400, Fax: 82-2-2027-2409

These Installation Guide includes as bellows PCI Adaptors.

1. DMM-402 (DMB Modulation PCI ADAPTER)

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Trademarks and copyright

COPYRIGHT © 2006, LUMANTEK Unit 1208, Woolim Lion's Valley II, 680 Gasan-Dong, Gumcheon-Gu, Seoul Korea (153-830), Tel: +82 2 2027 2400, Fax: +82 2 2027 2409 All rights reserved.

This document contains information that is proprietary to LUMANTEK. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, electronically, mechanically, by photocopying, or otherwise, without the prior written permission of LUMANTEK. Nationally and internationally recognized trademarks and trade names are the property of their respective holders and are hereby acknowledged.

Portions of this software are © 1996-2006 LUMANTEK Ltd. All intellectual property rights in such portions of the Software and documentation are owned by LUMANTEK and are protected by United States copyright laws, other applicable copyright laws and international treaty provisions. LUMANTEK and its suppliers retain all rights not expressly granted.

Disclaimer

The information in this document is furnished for informational purposes only, is subject to change without prior notice, and should not be construed as a commitment by LUMANTEK.

The information in this document is believed to be accurate and reliable; however LUMANTEK assumes no responsibility or liability for any errors or inaccuracies that may appear in this document, nor for any infringements of patents or other rights of third parties resulting from its use. No license is granted under any patents or patent rights of LUMANTEK.

This document was written by the Technical Support Department of LUMANTEK, Korea. We are committed to maintaining a high level of quality in all our documentation. Towards this effort, we welcome your comments and suggestions regarding the content and structure of this document. Please fax or mail your comments and suggestions to the attention of:

LUMANTEK Attn: Product Support Department Unit 1208, Woolim Lion's Valley II, 680 Gasan-Dong, Gumcheon Gu, Seoul Korea (153-830), +82 2 2027 2400, Fax: +82 2 2027 2409

Environmental Issues

Thank you for buying a product which contributes to a reduction in pollution and thereby helps save the environment. Our products reduce the need for travel and transport and thereby reduce pollution. Our products have either no or few consumable parts (chemicals, toner, gas, paper). Our products are low energy consuming products.

Waste handling:

There is need to send material back to LUMANTEK. Please contact your local dealer for information on recycling the product by sending the main parts of the product for disassembly at local electronic waste stations.

Production of products:

Our factories employ the most efficient environmental methods for reducing waste and pollution by ensuring that the products are recyclable.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Operator Safety Summary

For your protection, please read these safety instructions completely before operating the equipment and keep this manual for future reference. The information in this summary is intended for operators. Carefully observe all warnings, precautions and instructions both on the apparatus and in the operating instructions.



Equipment Markings
The lighting flash symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltages” within the product’s enclosure that may be of sufficient magnitude to constitue a risk of electrical shock.

The exclamation mark within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions within literature accompanying the equipment.

Warnings
Water and Moisture - Do not operate the equipment under or near water - for example near a bathtub, kitchen sink, or laundry tub, in a wet basement, near a swimming poor or in areas with high humidity.

Cleaning - Unplug the apparatus from the wall outlet before cleaning or polishing. Do not use liquid cleaners or aerosol cleaners. Use a lint-free cloth lightly moistened with water for cleaning the exterior of the apparatus.

Ventilation - Do not block any of the ventilation openings of the apparatus. Install in accordance with the installation instructions. Never cover the slots and openings with a cloth or other material. Never install the apparatus near heat sources such as radiator, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Grounding or Polarization - Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plus has two blades and a third grounding prong. The wide blade or third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician.

Power-Cord Protection - Route the power cord so as to avoid it being walked on or pinched by items placed upon or against it, paying particular attention to the plugs, receptacles, at the point where the cord exits form the apparatus.

Attachments - Only use attachments as recommended by the manufacture.

Accessories - Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

Lighting - Unplug this apparatus during lightning storms or when unused for long periods of time.



ISDN cables - CAUTION - to reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord.

Servicing - Do not attempt to service the apparatus yourself as opening or removing covers may expose you to dangerous voltages or other hazards, and will void the warranty. Refer all servicing to qualified service personnel.

Damaged Equipment - Unplug the apparatus from the outlet and refer servicing to qualified personnel under the follwing conditions:
When the power cord or plug is damaged or frayed
If liquid has been spilled or objects have fallen into the apparatus
If the apparatus has been exposed to rain or moisture
If the apparatus has been subjected to excessive shock by being dropped, or the cabinet has been damaged
If the apparatus fails to operate in accordance with the operating instruction

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

CONTENTS

1 T-DMB/DAB Modulator / Upconvertor PCI BUS

1-1. Overview ----------6
1-2. DMM-402----------6
1-3. UPC-231 ----------7

2 PCI Adaptor Installation

2-1. Hardware Installation----------8
2-2. Driver Installation----------9
2-3. Verification of Device Driver ----------12

3 Cable Connecting for DMM-402 and UPC-231

3-1. 1 Channel ETI Streaming Case (1*DMM-402 and 1*UPC-231) ------13
3-2. 2 Channel ETI Streaming case (1*DMM-402 and 2*UPC-231) ------13

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

1. T-DMB/DAB Modulator / Upconvertor PCI BUS

1-1. Overview

DMB Modulator PCI Adaptor is designed for OEM developer of T-DMB transmitter and provided with Driver and API reference for customer's own design application software.
DMM-402 is PCI DMB modulator and UPC-231 is PCI DMB RF Upconvertor and DMM-402 is designed to be interfaced with max 2 UPC-231. At final, DMM-402 have ability to ETI streaming (Upto 2 channel) by 2 UPC-231 at the same time with different setting of value.

1-2. DMM-402


* Key Features

- DAB/T-DMB Modulator PCI BUS
- Compliant with EN 300 401 andETS 300 799
- Support to all DAB Mode I, II, III, IV modes
- Easy ETI stream play out
- High Performance modulation (MER, IF Stability, and other)
- Support device driver and API for Window 2000/XP
- Offer double I/Q SMA port
- Output Frequency : Band II, III and L-Band


* Specification

- 2 x IQ Output Support
- Output Voltage : 1 Vp-p
- Output Impedance : 50Ω
- Connector : SMA-Connector


* Physical Side View




Top View



3D View



Side View



Front View

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

1-3. UPC-231

* RF OUT

- **Frequency**

  Range : Band II : 87.5 MHz ~ 108 MHz
  Band III : 174 MHz ~ 250 MHz
  L Band : 1.452 GHz ~ 1.492 GHz
  Resolution : Band II / III : 1 KHz
  L Band : 100 KHz
  Accuracy : ±1 ppm

- **Level**

  Range : 0 dBm ~ -120 dBm
  Resolution : 0.5 dB
  Accuracy : ±1 dB
  Connector : SMA - Connector


* I/Q Input

- Input Voltage : 1 Vp-p
- Input Impedance : 50Ω
- Connector : SMA-Connector
- Simultaneous Band II / III, L-Band transmission and configuration I^2C Interface - Support daisy chain configuration


* Power Requirements

- DC 12V (640mA), DC 5V (910 mA)


* Physical Side View




Top View



3D View



Right Side View



Left Side View


Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2. PCI Adaptor Installation

Mount PCI Adaptor (DMM-402 & UPC-231) on computer and install Device Driver provided with PCI Adaptor to operate. Just insert CD (provided with PCI Adaptor) into CD-ROM driver and then you may install device driver easily to follow the request of computer dialogue box.

2-1. Hardware Installation

1. Computer power off and open the computer cover.
2. Plug in the Adaptor on PCI slot.



3. Fasten the adaptor into the bracket tightly.
4. Cover the computer cover.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2-2. Driver Installation

1. Computer recognizes new device driver as Window starts after PCI Adaptor plug in.



2. Hardware Wizard will operate after the Adaptor is recognized on computer. To install, click “Next” menu box.




3. To install the driver provided with the Adaptor, select ‘Search for a suitable driver for my device (recommended)’ menu, then click ‘Next’ button.



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

4. Device Driver is in CD-ROM provided with Adaptor, so, select 'CD-ROM drivers' and click 'Next' button



5. Select the driver location in CD-ROM using 'Browse…' button. (Egg: if the CD-ROM driver is assigned on 'G' Driver, then you may make "G:\DMB directory" and click 'OK' button.



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

6. You already found out the driver on above paragraph #5 action, click 'Next' button on 'Driver Files Search Results' window.



7. Device Driver will be installed as you click 'Yes' button on 'Digital Signature Not Found' window.




Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

8. This means 'IMK-DVB Input/Output Adapter Device' was installed.
   Click 'Finish' button to complete installation.



2-3. Verification of Device Driver


If Device Driver is installed successfully doing above action, you can see on 'Device Manager window' that 'IMK-DVB Input/Output Adaptor Device' is installed. (You may select 'Device manager' through 'Start' → 'Settings' → 'Control Panel' → 'System' → 'Hardware' → 'Device Manager.')
If "Device Manager is not assigned or collision and protection, etc." are appeared on monitor, then it means ASI Card Device Driver was not installed correctly.



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com


3. Cable Connecting for DMM-402 and UPC-231

3-1. 1 Channel ETI Streaming Case (1*DMM-402 and 1*UPC-231)




1. Connect I²C cable from card ①(DMM-402) to card ②(UPC-231).
   You could connect to whether right or left I²C socket of UPC-231
2. The left side ADDRESS jumper must leave as factory default.
   Also, do not touch jumper #1 and #2 which are blocked by tube. You could use jumper #3 or #4.
   When one UPC-231 is mounted, you have to plug in jumper at ADDRESS #3.
   (Jumper #4 is open)
3. Then, connect to 4-pin power cable which we supplied.

3-2. 2 Channel ETI Streaming case (1*DMM-402 and 2*UPC-231)



1. When you install 2 UPC-231 PCI cards with 1 DMM-402 PCI, do not set same ADDRESS on both UPC-231 PCI cards. For example, plug in one jumper at ADDRESS#3 of upper UPC-231 and plug in another jumper at ADDRESS #4 of down UPC-231.
   For the ADDRESS #1 and #2 , do not use them.
2. I²C cable from card ②(DMM-402) may be interfaced with I²C socket of any UPC-231 (card ① or card ③). Then connect any right or left connector. For example, if I²C cable is interfaced between card ②(DMM-402) and card ③(UPC-231) then another I²C cable should be interfaced between card ③(UPC-231) and card ①(UPC-231) as above picture.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



3. Then, connect to 4-pin power cable which we supplied.
4. You can connect I/Q like above, in other way you can connect I-1 / Q-1 in left side, or connect I-2 / Q-2 in right side.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

IMPORTANT NOTICE

LUMANTEK Incorporated and its subsidiaries (LMT) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to LMT's terms and conditions of sale supplied at the time of order acknowledgment.

LMT warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with LMT's standard warranty. Testing and other quality control techniques are used to the extent LMT deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

LMT assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using LMT components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

LMT does not warrant or represent that any license, either express or implied, is granted under any LMT patent right, copyright, mask work right, or other LMT intellectual property right relating to any combination, machine, or process in which LMT products or services are used. Information published by LMT regarding third–party products or services does not constitute a license from LMT to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from LMT under the patents or other intellectual property of LMT.

Reproduction of information in LMT data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. LMT is not responsible or liable for such altered documentation.

Resale of LMT products or services with statements different from or beyond the parameters stated by LMT for that product or service voids all express and any implied warranties for the associated LMT product or service and is an unfair and deceptive business practice. LMT is not responsible or liable for any such statements.

Mailing Address:

LUMANTEK Unit 1208, Woolim Lion's Valley II, 680 Gasan-Dong, Gumcheon Gu, Seoul Korea

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



Unit 1208, Woolim Lion's Valley II,
680 Gasan-Dong, Gumcheon Gu, Seoul Korea
T. +82-2-2027-2400 / F. +82-2-2027-2409
www.lumantek.com

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP