

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Visit our website - *Click HERE*

Coilcraft SMD-G Test Fixture

Accurate and repeatable measurements of SMD chip inductors and other SMD components can be made using the Coilcraft SMD-G fixture and many 4-terminal (Kelvin) impedance measurement instruments.

Fixture Characteristics

SMD Size Range:	0603 to 0805
Frequency Range:	DC to 30 MHz
Connectors:	BNC (4)

Package Contents

SMD-G test fixture with standard placement mask

Low capacitance placement mask

Shorting bars

Sample chip inductors

General Measurement Procedure

Note: For instrument-specific procedures, follow the instructions supplied with the test instrument.

1. Determine the required test frequency or frequency range from the component data sheet or specification. Verify that the required test frequency is within the fixture frequency range specified above.
2. Set the instrument for the required frequency range, measurement parameters (e.g. L, Q, Z, θ, R, X), number of measurement (frequency) points, and averaging parameters.

Note: If your instrument uses fixture compensation to provide the calibration zero reference, skip step 3.

3. Calibrate the instrument using accurate reference standards.
4. Attach the appropriate size mask to the SMD-G test fixture. Different placement masks are provided to locate each SMD component in a repeatable position. See **Changing Placement Masks**.
5. Connect the SMD-G to the test instrument by sliding the fixture onto the test instrument terminals. When the terminals are fully inserted, rotate the fixture connectors until snug.
6. Make sure there is no component or shorting bar in the fixture, and perform OPEN fixture compensation.
7. Select a shorting bar that is closest in size to the test component.

(Continued on other side)

8. Place the shorting bar into the fixture mask and center over the white ring. Lower the plunger and perform SHORT fixture compensation. Remove the shorting bar.
9. Place the test component into the fixture mask and center over the white ring. Lower the plunger.
10. Read the displayed value on the instrument.

Changing Placement Masks

Each placement mask has templates to accommodate different size components. The standard placement mask is initially installed in the fixture. A low capacitance mask is also included for low impedance measurements.

1. Carefully remove the four cap screws and the retaining ring from the top of the fixture.
2. Exchange the existing mask with the required mask.
3. Replace the retaining ring. Install, but do not tighten the four cap screws.
4. Rotate the placement mask so that the template is located directly under the plunger.
5. Tighten the four cap screws until they are just snug.

References

The following application notes are available on the Coilcraft website at www.coilcraft.com/appnotes.cfm

Test Fixture Compatibility Chart

Calibration, Compensation and Correlation

Testing Inductors at Application Frequencies

1102 Silver Lake Road Cary, Illinois 60013
Phone 847/639-6400 **Fax** 847/639-1469
E-mail info@coilcraft.com
Web http://www.coilcraft.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP