ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Datalogic HLD-8000* at our website: ***Click HERE***

HLD-P080

Desk/Wall Holder Mounting Instructions





The HLD-P080 is a plastic holder for the PowerScan™ 8000 and PowerScan™ 9000 families of barcode readers, designed to be mounted on a wall or fixed to a desk.

Installation

The mounting kit supplied with the holder contains the following components:

- 1 HLD-P080
- 1 spacer
- 2 self-tapping screws
- 2 threaded dowels
- 2 adhesive strips

When used with PowerScan™ 8000 readers without display, the spacer must be installed to the holder as shown in Figure 1.

Figure 1



www.datalogic.com

820057014 (Rev. C) February 2014

©2007-2014 Datalogic, Inc. • All rights reserved. Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A.in many countries, including the U.S.A. and the E.U.

Desktop Use

To fix the HLD-P080 to a desktop, use the double-sided adhesive strips following the steps below:

1. Carefully clean the surfaces of the desk and of the bottom of the HLD-P080 with alcohol to remove any impurities that could reduce the adhesion.
2. Remove the protective plastic from one side of the adhesive strips and stick them on the HLD-P080 bottom as shown in Figure 2.

Figure 2



3. Remove the plastic from the other side of the strips and affix the HLD-P080 to the desk.

Wall-Mount Use

Wall mounting is accomplished using the two threaded dowels and the self-tapping screws, which will be inserted into the two holder mounting holes.

Figure 3



1. Using the holder mounting holes as a pattern, mark the wall where you desire to mount the HLD-P080.
2. Drill two appropriate-size holes.
3. Insert the threaded dowels into the holes.
4. Position the holder on the wall with the opening inclined upwards and affix it by means of the two screws.

Figure 4



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP