

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *National Instruments TPC-2206* at our website: *Click HERE*

TPC-2206/TPC-2212

User Manual

December 2010
373297A-01

NATIONAL INSTRUMENTS™

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Worldwide Technical Support and Product Information

ni.com

National Instruments Corporate Headquarters

11500 North Mopac Expressway Austin, Texas 78759-3504 USA Tel: 512 683 0100

Worldwide Offices

Australia 1800 300 800, Austria 43 662 457990-0, Belgium 32 (0) 2 757 0020, Brazil 55 11 3262 3599, Canada 800 433 3488, China 86 21 5050 9800, Czech Republic 420 224 235 774, Denmark 45 45 76 26 00, Finland 358 (0) 9 725 72511, France 01 57 66 24 24, Germany 49 89 7413130, India 91 80 41190000, Israel 972 3 6393737, Italy 39 02 41309277, Japan 0120-527196, Korea 82 02 3451 3400, Lebanon 961 (0) 1 33 28 28, Malaysia 1800 887710, Mexico 01 800 010 0793, Netherlands 31 (0) 348 433 466, New Zealand 0800 553 322, Norway 47 (0) 66 90 76 60, Poland 48 22 328 90 10, Portugal 351 210 311 210, Russia 7 495 783 6851, Singapore 1800 226 5886, Slovenia 386 3 425 42 00, South Africa 27 0 11 805 8197, Spain 34 91 640 0085, Sweden 46 (0) 8 587 895 00, Switzerland 41 56 2005151, Taiwan 886 02 2377 2222, Thailand 662 278 6777, Turkey 90 212 279 3031, United Kingdom 44 (0) 1635 523545

For further support information, refer to the *Technical Support and Professional Services* appendix. To comment on National Instruments documentation, refer to the National Instruments Web site at ni.com/info and enter the Info Code feedback.

© 2010 National Instruments Corporation. All rights reserved.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Important Information

Warranty

The TPC-2206 and TPC-2212 are warranted against defects in materials and workmanship for a period of one year from the date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace equipment that proves to be defective during the warranty period. This warranty includes parts and labor.

The media on which you receive National Instruments software are warranted not to fail to execute programming instructions, due to defects in materials and workmanship, for a period of 90 days from date of shipment, as evidenced by receipts or other documentation. National Instruments will, at its option, repair or replace software media that do not execute programming instructions if National Instruments receives notice of such defects during the warranty period. National Instruments does not warrant that the operation of the software shall be uninterrupted or error free.

A Return Material Authorization (RMA) number must be obtained from the factory and clearly marked on the outside of the package before any equipment will be accepted for warranty work. National Instruments will pay the shipping costs of returning to the owner parts which are covered by warranty.

National Instruments believes that the information in this document is accurate. The document has been carefully reviewed for technical accuracy. In the event that technical or typographical errors exist, National Instruments reserves the right to make changes to subsequent editions of this document without prior notice to holders of this edition. The reader should consult National Instruments if errors are suspected. In no event shall National Instruments be liable for any damages arising out of or related to this document or the information contained in it.

EXCEPT AS SPECIFIED HEREIN, NATIONAL INSTRUMENTS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND SPECIFICALLY DISCLAIMS ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. CUSTOMER'S RIGHT TO RECOVER DAMAGES CAUSED BY FAULT OR NEGLIGENCE ON THE PART OF NATIONAL INSTRUMENTS SHALL BE LIMITED TO THE AMOUNT THERETOFORE PAID BY THE CUSTOMER. NATIONAL INSTRUMENTS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF. This limitation of the liability of National Instruments will apply regardless of the form of action, whether in contract or tort, including negligence. Any action against National Instruments must be brought within one year after the cause of action accrues. National Instruments shall not be liable for any delay in performance due to causes beyond its reasonable control. The warranty provided herein does not cover damages, defects, malfunctions, or service failures caused by owner's failure to follow the National Instruments installation, operation, or maintenance instructions; owner's modification of the product; owner's abuse, misuse, or negligent acts; and power failure or surges, fire, flood, accident, actions of third parties, or other events outside reasonable control.

Copyright

Under the copyright laws, this publication may not be reproduced or transmitted in any form, electronic or mechanical, including photocopying, recording, storing in an information retrieval system, or translating, in whole or in part, without the prior written consent of National Instruments Corporation.

National Instruments respects the intellectual property of others, and we ask our users to do the same. NI software is protected by copyright and other intellectual property laws. Where NI software may be used to reproduce software or other materials belonging to others, you may use NI software only to reproduce materials that you may reproduce in accordance with the terms of any applicable license or other legal restriction.

Trademarks

LabVIEW, National Instruments, NI, ni.com, the National Instruments corporate logo, and the Eagle logo are trademarks of National Instruments Corporation. Refer to the *Trademark Information* at `ni.com/trademarks` for other National Instruments trademarks.

Other product and company names mentioned herein are trademarks or trade names of their respective companies.

Members of the National Instruments Alliance Partner Program are business entities independent from National Instruments and have no agency, partnership, or joint-venture relationship with National Instruments.

Patents

For patents covering National Instruments products/technology, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your media, or the *National Instruments Patent Notice* at `ni.com/patents`.

WARNING REGARDING USE OF NATIONAL INSTRUMENTS PRODUCTS

(1) NATIONAL INSTRUMENTS PRODUCTS ARE NOT DESIGNED WITH COMPONENTS AND TESTING FOR A LEVEL OF RELIABILITY SUITABLE FOR USE IN OR IN CONNECTION WITH SURGICAL IMPLANTS OR AS CRITICAL COMPONENTS IN ANY LIFE SUPPORT SYSTEMS WHOSE FAILURE TO PERFORM CAN REASONABLY BE EXPECTED TO CAUSE SIGNIFICANT INJURY TO A HUMAN.

(2) IN ANY APPLICATION, INCLUDING THE ABOVE, RELIABILITY OF OPERATION OF THE SOFTWARE PRODUCTS CAN BE IMPAIRED BY ADVERSE FACTORS, INCLUDING BUT NOT LIMITED TO FLUCTUATIONS IN ELECTRICAL POWER SUPPLY, COMPUTER HARDWARE MALFUNCTIONS, COMPUTER OPERATING SYSTEM SOFTWARE FITNESS, FITNESS OF COMPILERS AND DEVELOPMENT SOFTWARE USED TO DEVELOP AN APPLICATION, INSTALLATION ERRORS, SOFTWARE AND HARDWARE COMPATIBILITY PROBLEMS, MALFUNCTIONS OR FAILURES OF ELECTRONIC MONITORING OR CONTROL DEVICES, TRANSIENT FAILURES OF ELECTRONIC SYSTEMS (HARDWARE AND/OR SOFTWARE), UNANTICIPATED USES OR MISUSES, OR ERRORS ON THE PART OF THE USER OR APPLICATIONS DESIGNER (ADVERSE FACTORS SUCH AS THESE ARE HEREAFTER COLLECTIVELY TERMED "SYSTEM FAILURES"). ANY APPLICATION WHERE A SYSTEM FAILURE WOULD CREATE A RISK OF HARM TO PROPERTY OR PERSONS (INCLUDING THE RISK OF BODILY INJURY AND DEATH) SHOULD NOT BE RELIANT SOLELY UPON ONE FORM OF ELECTRONIC SYSTEM DUE TO THE RISK OF SYSTEM FAILURE. TO AVOID DAMAGE, INJURY, OR DEATH, THE USER OR APPLICATION DESIGNER MUST TAKE REASONABLY PRUDENT STEPS TO PROTECT AGAINST SYSTEM FAILURES, INCLUDING BUT NOT LIMITED TO BACK-UP OR SHUT DOWN MECHANISMS. BECAUSE EACH END-USER SYSTEM IS CUSTOMIZED AND DIFFERS FROM NATIONAL INSTRUMENTS' TESTING PLATFORMS AND BECAUSE A USER OR APPLICATION DESIGNER MAY USE NATIONAL INSTRUMENTS PRODUCTS IN COMBINATION WITH OTHER PRODUCTS IN A MANNER NOT EVALUATED OR CONTEMPLATED BY NATIONAL INSTRUMENTS, THE USER OR APPLICATION DESIGNER IS ULTIMATELY RESPONSIBLE FOR VERIFYING AND VALIDATING THE SUITABILITY OF NATIONAL INSTRUMENTS PRODUCTS WHENEVER NATIONAL INSTRUMENTS PRODUCTS ARE INCORPORATED IN A SYSTEM OR APPLICATION, INCLUDING, WITHOUT LIMITATION, THE APPROPRIATE DESIGN, PROCESS AND SAFETY LEVEL OF SUCH SYSTEM OR APPLICATION.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Electromagnetic Compatibility Guidelines

This product was tested and complies with the regulatory requirements and limits for electromagnetic compatibility (EMC) as stated in the product specifications. These requirements and limits are designed to provide reasonable protection against harmful interference when the product is operated in its intended operational electromagnetic environment.

This product is intended for use in industrial locations. There is no guarantee that harmful interference will not occur in a particular installation, when the product is connected to a test object, or if the product is used in residential areas. To minimize the potential for the product to cause interference to radio and television reception or to experience unacceptable performance degradation, install and use this product in strict accordance with the instructions in the product documentation.

Furthermore, any changes or modifications to the product not expressly approved by National Instruments could void your authority to operate it under your local regulatory rules.



Caution To ensure the specified EMC performance, operate this product only with shielded cables and accessories.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Conventions

The following conventions are used in this manual:

»	The » symbol leads you through nested menu items and dialog box options to a final action. The sequence **Options»Settings»General** directs you to pull down the **Options** menu, select the **Settings** item, and select **General** from the last dialog box.
	This icon denotes a note, which alerts you to important information.
	This icon denotes a caution, which advises you of precautions to take to avoid injury, data loss, or a system crash. When this symbol is marked on a product, refer to the *Safety* section of Appendix A, *Specifications*, for information about precautions to take.
	When symbol is marked on a product, it denotes a warning advising you to take precautions to avoid electrical shock.
bold	Bold text denotes items that you must select or click in the software, such as menu items and dialog box options. Bold text also denotes parameter names.
italic	Italic text denotes variables, emphasis, a cross-reference, or an introduction to a key concept. Italic text also denotes text that is a placeholder for a word or value that you must supply.
`monospace`	Text in this font denotes text or characters that you should enter from the keyboard, sections of code, programming examples, and syntax examples. This font is also used for the proper names of disk drives, paths, directories, programs, subprograms, subroutines, device names, functions, operations, variables, filenames, and extensions.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Contents

Chapter 1
General Information

Introduction 1-1
I/O Ports 1-1
Cleaning 1-2

Chapter 2
System Setup

Important Safety Information 2-1
Setup 2-2
Touchscreen Calibration 2-4
Panel Mounting 2-4

Chapter 3
Jumpers and Connectors

Jumper and Connector Functions 3-1
Jumper and Connector Locations 3-3

Appendix A
Specifications

Appendix B
Serial Port Settings

Appendix C
Features in Windows XP Embedded

Appendix D
Touchscreen Configuration

Appendix E
Technical Support and Professional Services

Index

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

1 General Information

This chapter includes general information about the TPC-2206/TPC-2212 Human Machine Interface (HMI).

Introduction

The TPC-2206/TPC-2212 touch panel computer, an HMI based on an *x*86 platform, includes these key features:

- **Powerful processing**—The TPC-2206/TPC-2212 uses the Intel Atom processor, specifically designed for embedded, industrial applications.
- **Fanless**—By using an advanced but low-power Intel Atom processor, the TPC-2206/2212 does not require a fan for cooling.
- **Robust communication**—The TPC-2206/TPC-2212 is a powerful I/O interface for easy communication with other devices. The I/O interface includes serial ports, gigabit Ethernet, and USB 2.0 support.
- **Wide operating temperature and isolation protection**—The TPC-2206/TPC-2212 provides a –20 to 60 °C operating temperature range and complete isolation protection for the serial ports.
- **Windows Embedded support**—The TPC-2206/TPC-2212 supports the latest embedded Windows operating systems from Microsoft, including Windows XP Embedded (XPe).


I/O Ports

The TPC-2206/TPC-2212 includes the following ports:

- Two serial ports: RS232 (COM1) and RS422/485 (COM2)
- Two USB 2.0 ports compliant with USB 1.0 and 1.1
- Two RJ-45 Gigabit Ethernet ports

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Figure 1-1 shows the I/O port arrangement.



1	LAN 1	3	USB	5	COM1 (RS232)
2	LAN 2	4	COM2 (RS422/485)		

Figure 1-1. I/O Port Arrangement

For more TPC-2206/TPC-2212 specifications, refer to Appendix A, *Specifications*.

Cleaning

If you need to clean the unit, use a soft, nonmetallic brush. Make sure that the unit is completely dry and free from contaminants before returning it to service.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2

System Setup

This chapter includes setup information for the TPC-2206/TPC-2212.

Important Safety Information

Before setting up the TPC-2206/TPC-2212, read these safety instructions carefully.

Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.

For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.

Keep this equipment away from excessive humidity.

Place this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.

The openings on the enclosure are for air convection and protect the equipment from overheating. *Do not cover the openings.*

Make sure the power source voltage is correct before connecting the equipment to the power outlet.

Position the power cord so that it cannot be stepped on. Do not place anything over the power cord.

All cautions and warnings on the equipment should be noted.

If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.

Never pour any liquid into an opening. This may cause fire or electrical shock.

Never open the equipment. For safety reasons, only qualified service personnel should open the equipment.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

If one of the following situations arises, have service personnel check the equipment:

- The power cord or plug is damaged.
- Liquid has penetrated into the equipment.
- The equipment has been exposed to moisture.
- The equipment does not work well, or you cannot get it to work according to the user manual.
- The equipment has been dropped and damaged.
- The equipment has obvious signs of breakage.

Do not leave this equipment in an environment where the storage temperature may go below –20 °C (–4 °F) or above 60 °C (140 °F). Doing so could damage the equipment. The equipment should be in a controlled environment.

Caution There is a danger of explosion if the battery is incorrectly replaced. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

The sound pressure level at the operator's position according to IEC 704-1:1982 is no more than 70 dB (A).

Caution The protection this equipment provides may be impaired if it is used in a manner not described in this manual.

Setup

Follow these steps to set up the TPC-2206/TPC-2212:

1. Unpack the TPC-2206/TPC-2212. Be sure your kit includes the following items:
   - The TPC-2206/TPC-2212 HMI
   - Six panel mounting clamps (TPC-2206)
   - Six panel mounting screws (TPC-2206)
   - Eight panel mounting clamps (TPC-2212)
   - Eight panel mounting screws (TPC-2212)
   - One 3-pin power connector
   - One HMI Resource CD
   - One earth ground cable

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

If any items are missing or damaged, contact National Instruments.

Caution Be sure system power is off before plugging in or pulling out the CompactFlash card.

2. Verify that the CompactFlash card containing Windows Embedded or another operating system is installed in the unit.
3. Connect the power connector to an 18–32 VDC power line. Be sure to connect the positive, negative, and ground lines as shown in Figure 2-1. The power lines can be from either a power adapter or in-house power source.




Figure 2-1. Power Connector

4. Connect the power connector to the power receptor on the TPC-2206/TPC-2212. The power receptor pin assignment is shown in Figure 2-2.




Figure 2-2. Power Receptor and Pin Assignment

5. The system turns on immediately after you apply power.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Touchscreen Calibration

The TPC-2206/TPC-2212 touchscreen should be correctly calibrated and ready to use when you power on the system. However, if the calibration is not correct or you want to choose custom calibration options, refer to Appendix D, *Touchscreen Configuration*.

Panel Mounting

Follow these steps to mount the TPC-2206/TPC-2212 in a panel:

1. Be sure the adhesive waterproof gasket on the front bezel is in position.
2. Install the TPC-2206/TPC-2212 in the panel opening. (Refer to Appendix A, *Specifications*, for cutout dimensions.)
3. Hook the clamps included in the accessory pack to the holes around the four sides of the bezel. Be sure to remove the protective inserts in the panel mounting holes.
4. Insert the screws included in the accessory pack into the clamps. To fasten the TPC-2206/TPC-2212 to the panel, tighten the screws so they push against the mounting panel.

Note The mounting panel thickness should be less than 6 mm (0.236 in.).

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

3

Jumpers and Connectors

This chapter describes the TPC-2206/TPC-2212 jumpers and connectors.

Jumper and Connector Functions

Table 3-1 lists the jumper and connector functions.

Table 3-1. Mainboard Connectors and Jumpers

Label	Function	Description
BH1	Battery	RTC battery bracket
CN1	LAN2	Gigabit Ethernet: LAN2
CN2	LAN1	Gigabit Ethernet: LAN1
CN3	LCD Power	LCD power connection
CN4	LCD Power	LCD power voltage
CN5	LVDS	LVDS video connection
CN6/CN7	CompactFlash	CompactFlash bracket
CN8	USB2	Two USB type-A female
CN11	COM1	Serial port: COM1 RS232
CN12	COM2	Serial port: COM2 RS422/485
CN13	DC in	DC power in connector (5.08 mm, 3-pin housing)
CN16	CMOS	CMOS clear select
CN17	IDE	AT mode select
CN18	Touchscreen	Touchscreen interface
FS1	Fuse	Fuse bracket
SODIMM1	RAM	DDR2 SODIMM bracket

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Table 3-1. Mainboard Connectors and Jumpers (Continued)

Label	Function	Description
SW1	LCD Resolution	LCD resolution select
SW2	LCD Function	LCD controlled function
SW3	Touchscreen	Touchscreen type
SW4	Termination	Serial termination resistor
U2	CPU	CPU
U4	SCH	System controller hub
U12	BIOS	BIOS chip

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Jumper and Connector Locations

Figures 3-1 and 3-2 show the jumper and connector locations.




Figure 3-1. Main Board Jumpers and Connectors—Top Side

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 3-2. Main Board Jumpers and Connectors—Bottom Side

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

A

Specifications

This appendix lists the TPC-2012/TPC-2512 system specifications.

Physical

TPC-2206

Weight ..... 1.43 kg

Dimensions (W × H × D) ..... 195 × 148 × 58 mm
(7.68 × 5.83 × 2.28 in.)

Cutout dimensions..... 189.1 × 142.1 mm (suggested)
(7.44 × 5.59 in.)

TPC-2212


Weight ..... 2.5 kg

Dimensions (W × H × D) ..... 311 × 237 × 54 mm
(12.24 × 9.33 × 2.13 in.)

Cutout dimensions..... 302.5 × 228.5 mm (suggested)
(11.91 × 9.00 in.)


Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Dimensions (TPC-2206)



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Dimensions (TPC-2212)



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

System

CPU ..... Intel Atom Processor Z520PT 1.33 GHz w/HyperThreading

SCH ..... Intel System Controller Hub US15WPT

Video ..... Intel GMA 500

BIOS ..... Award 4 Mbit flash

Ethernet ..... Realtek RTL8168C(P) × 2; 10/100/1000, IEEE 802.3ab protocol compatible

RAM ..... 1 GB DDR2

Watchdog timer ..... SCH3114X1watchdog timer; 1 to 255 s timeout period

CompactFlash ..... Ultra ATA/100, UDMA/100 compatible, 4 GB minimum

LCD

Display type ..... TFT LCD

Size (diagonal) ..... 5.7 in. (TPC-2206)
12.1 in. (TPC-2212)

Maximum resolution ..... 640 × 480 VGA (TPC-2206)
800 × 600 SVGA (TPC-2212)

Maximum colors 262,000

Viewing angle ..... 160°/140°

Luminance (cd/m²) 700 (TPC-2206)
450 (TPC-2212)

Contrast ratio 800:1 (TPC-2206)
700:1 (TPC-2212)

Operating temperature ..... –30 to 85 °C (–22 to 185 °F) (ambient, LCD Only)

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Backlight ..... LED

Backlight lifespan ..... 50,000 h

Note There may be several bright or dark pixels on the LCD. This phenomenon is normal in LCD manufacturing.

Touchscreen

Touch type..... Resistive 4-wire (TPC-2206)
Resistive 5-wire (TPC-2212)

Base glass construction ..... Tempered glass

Resolution ..... 1024 × 1024

Light Transmission ..... 80% ± 3%

Controller ..... RS-232 interface (COM3)

Lifespan..... 1 million touches at a single point

Power

Input voltage ..... 18 to 32 VDC

Typical ..... 24 VDC @ 0.93 A

Note Providing power levels either below or above the stated range is not recommended.

Fuse

Rating ..... T3.15 A, 250 V

Size..... 5 × 20 mm

Note When replacing the fuse, use only a fuse of the same type and rating.

Note For your protection, the fuse is set to break if the input voltage exceeds 33 VDC.

Environment

Operating temperature..... –20 to 60 °C (–4 to 140 °F)

Storage temperature ..... –20 to 60 °C (–4 to 140 °F)

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Humidity .....40 °C @ 10 to 95% relative humidity (noncondensing)

Vibration .....2 grms (5 to 500 Hz)

Maximum altitude.....2,000 m

Pollution Degree 2

Indoor use only

Note The front bezel is compliant with NEMA4 and IP65.

Safety

This product is designed to meet the requirements of the following standards of safety for information technology equipment:

- IEC 60950-1, EN 60950-1
- UL 60950-1, CSA 60950-1

Note For UL and other safety certifications, refer to the product label or the *Online Product Certification* section.

Electromagnetic Compatibility

This product meets the requirements of the following EMC standards for information technology equipment:

- EN 55024 (CISPR 24); Immunity
- EN 55022 (CISPR 22); Class A Emissions
- EN 55011 (CISPR 11); Class A Emissions
- AS/NZS CISPR 11; Class A Emissions
- AS/NZS CISPR 22; Class A Emissions
- FCC 47 CFR Part 15B: Class A Emissions
- ICES-003: Class A Emissions

Note In the United States (per FCC 47 CFR), Class A equipment is intended for use in commercial, light-industrial, and heavy-industrial locations. In Europe, Canada, Australia and New Zealand (per CISPR 11) Class A equipment is intended for use only in heavy-industrial locations.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Note Group 1 equipment (per CISPR 11) is any industrial, scientific, or medical equipment that does not intentionally generate radio frequency energy for the treatment of material or inspection/analysis purposes.

Note For the standards applied to assess the EMC of this product, refer to the *Online Product Certification* section.

CE Compliance CE

This product meets the essential requirements of applicable European Directives as follows:

- 2006/95/EC; Low-Voltage Directive (safety)
- 2004/108/EC; Electromagnetic Compatibility Directive (EMC)

Online Product Certification

Refer to the product Declaration of Conformity (DoC) for additional regulatory compliance information. To obtain product certifications and the DoC for this product, visit `ni.com/certification`, search by model number or product line, and click the appropriate link in the Certification column.

Environmental Management

NI is committed to designing and manufacturing products in an environmentally responsible manner. NI recognizes that eliminating certain hazardous substances from our products is beneficial to the environment and to NI customers.

For additional environmental information, refer to the *NI and the Environment* Web page at `ni.com/environment`. This page contains the environmental regulations and directives with which NI complies, as well as other environmental information not included in this document.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Waste Electrical and Electronic Equipment (WEEE)



EU Customers At the end of the product life cycle, all products *must* be sent to a WEEE recycling center. For more information about WEEE recycling centers, National Instruments WEEE initiatives, and compliance with WEEE Directive 2002/96/EC on Waste and Electronic Equipment, visit `ni.com/environment/weee`.

电子信息产品污染控制管理办法 （中国 RoHS）



中国客户 National Instruments 符合中国电子信息产品中限制使用某些有害物质指令 (RoHS)。
关于 National Instruments 中国 RoHS 合规性信息，请登录 `ni.com/environment/rohs_china`。
(For information about China RoHS compliance, go to `ni.com/environment/rohs_china`.)

Mercury Disposal and Recycling

LCD lamp(s) in this monitor contain mercury. Dispose or recycle according to local, state or federal laws. Consult the Electronic Industries Alliance at `www.eiae.org` for more information. For specific information on lamp disposal, consult `www.lamprecycle.org`.

Cleaning

If you need to clean the unit, use a soft, nonmetallic brush. Make sure that the unit is completely dry and free from contaminants before returning it to service.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com


B

Serial Port Settings

This appendix describes the TPC-2206/TPC-2212 serial port settings.

COM1 Connector Pinout

The TPC-2206/TPC-2212 COM1 serial port is RS232 only. The following figure and table show the COM1 connector pinout.



Pin	Signal
1	NDCD
2	NRX
3	NTX
4	NDTR
5	GND
6	NDSR
7	NRTS
8	NCTS
9	NRI


Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

COM2 Connector Pinout

The TPC-2206/TPC-2212 COM2 serial port is adjustable. You can set it to RS422 or RS485, and it has auto data flow control capability. In other words, the TPC-2206/TPC-2212 can automatically detect the data flow direction at this port when two-wired RS485 communication is activated.

You must configure the TPC-2206/TPC-2212 COM ports in the BIOS.

The following figure and table show the COM2 pinout and settings.



PIN	RS-422	RS-485
1	TX–	D–
2	TX+	D+
3	RX+	—
4	RX–	—
5	GND	GND

COM2 Port Mode

You must configure the TPC-2206/TPC-2212 COM2 mode in the BIOS. Before performing the following steps, connect a USB keyboard to the TPC-2206/TPC-2212.

1. Power on the TPC-2206/2212.
2. While the unit is booting, but prior to the Windows splash screen, press <Del> to enter the BIOS setup.
3. In the BIOS, select **Integrated Peripherals**.
4. Under **Serial Port 2 Mode**, select either **RS-422** or **RS-485**.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

C

Features in Windows XP Embedded

The TPC-2206/TPC-2212 supports the Windows XP Embedded platform (commonly abbreviated XPe), which is a componentized version of the Windows XP Professional edition.

EWF and FBWF

Enhanced Write Filter (EWF) provides an upper filter in the storage device driver stack that redirects disk write operations to volatile (RAM) or nonvolatile (disk) storage. EWF protects a volume from write access and offers the following benefits:

- Write-protects one or more partitions on your system.
- Enables read-only media, such as CD-ROM or flash, to boot and run.
- Prolongs the lifespan of write-sensitive storage, such as CompactFlash.

File Based Write Filter (FBWF) also redirects disk write operations to volatile (RAM) or nonvolatile (disk) storage. Where EWF protects entire volumes from writes, FBWF protects only individual files and directories. Although FBWF is not as robust as EWF, because EWF protects entire volumes, it is very useful when you need to write to specific files and have those changes persist between reboots.

You can enable and disable EWF and FBWF only between reboots.

To disable/enable EWF/FBWF, go to **Start»All Programs»Utilities** and select the EWF tab. The default setting is disabled for both.

When EWF is enabled, the `C:` partition is protected from any disk writing. In this mode, any changes on the C: partition (including modifications to files or the registry) are redirected to memory. Thus, these changes are discarded in the next system startup. You can enable this mode manually after finishing all system changes such as installing your applications or adjusting system settings.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

HORM

Hibernate Once, Resume Many (HORM) enables users to create a single hibernation file and boot to that file repeatedly. Using HORM, you can boot to a known state each time the system is powered on. HORM works only when EWF is enabled on all system partitions. HORM does not work with FBWF. Depending on the system state, HORM can reduce boot times.

To enable HORM, you first must enable EWF as described in the *EWF and FBWF* section. Once enabled, return to the EWF utility at **Start»All Programs»Utilities»EWF**. Select the **HORM** tab and select **HORM**. This hibernates the system and creates the hibernation file. After you perform this step, all subsequent reboots resume from that hibernation file.

Note You can programmatically control EWF, FBWF, and HORM using VIs included with the LabVIEW 2010 or later Touch Panel Module.

Drivers

The TPC-2206/TPC-2212 is configured with all necessary drivers installed. If you need to reinstall any drivers, they are on the HMI Resources CD, which is included in the kit. They are also on the TPC-2206/TPC-2212 under `C:\DriverInstall`.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

D

Touchscreen Configuration

This appendix explains how to configure the TPC-2206/TPC-2212 touchscreen using the PenMount Control Panel.

To calibrate the TPC-2206/TPC-2212, go to **Start»All Programs» PenMount Windows Universal Driver»Utility»PenMount Control Panel**. Select **PenMount 6000 RS232** under **Select a device to configure** and click **Configure**. Here you can select either **Standard Calibration** or **Advanced Calibration**. Follow the onscreen instructions for either choice.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

E

Technical Support and Professional Services

Visit the following sections of the award-winning National Instruments Web site at `ni.com` for technical support and professional services:

- **Support**—Technical support at `ni.com/support` includes the following resources:
  - **Self-Help Technical Resources**—For answers and solutions, visit `ni.com/support` for software drivers and updates, a searchable KnowledgeBase, product manuals, step-by-step troubleshooting wizards, thousands of example programs, tutorials, application notes, instrument drivers, and so on. Registered users also receive access to the NI Discussion Forums at `ni.com/forums`. NI Applications Engineers make sure every question submitted online receives an answer.
  - **Standard Service Program Membership**—This program entitles members to direct access to NI Applications Engineers via phone and email for one-to-one technical support as well as exclusive access to on demand training modules via the Services Resource Center. NI offers complementary membership for a full year after purchase, after which you may renew to continue your benefits.

    For information about other technical support options in your area, visit `ni.com/services`, or contact your local office at `ni.com/contact`.
- **Training and Certification**—Visit `ni.com/training` for self-paced training, eLearning virtual classrooms, interactive CDs, and Certification program information. You also can register for instructor-led, hands-on courses at locations around the world.
- **System Integration**—If you have time constraints, limited in-house technical resources, or other project challenges, National Instruments Alliance Partner members can help. To learn more, call your local NI office or visit `ni.com/alliance`.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

If you searched ni.com and could not find the answers you need, contact your local office or NI corporate headquarters. Phone numbers for our worldwide offices are listed at the front of this manual. You also can visit the Worldwide Offices section of ni.com/niglobal to access the branch office Web sites, which provide up-to-date contact information, support phone numbers, email addresses, and current events.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Index

C

CE compliance specifications, A-7
cleaning, 1-2, A-8
COM1 connector pinout, B-1
COM2 connector
    mode, B-2
    pinout, B-2
connectors, 3-1
    function descriptions (table), 3-1
    locations
        bottom side (table), 3-4
        top side (table), 3-3
conventions used in the manual, *v*

D

diagnostic tools (NI resources), E-1
dimensions
    TPC-2206, A-2
    TPC-2212, A-3
documentation
    conventions used in the manual, *v*
    NI resources, E-1
drivers, C-2
    NI resources, E-1
drivers (NI resources), E-1

E

electromagnetic compatibility specifications, A-6
Enabled Write Filter (EWF), C-1
environmental management specifications, A-7
environmental specifications, A-5
examples (NI resources), E-1

F

File Based Write Filter (FBWF), C-1
fuse specifications, A-5

H

help, technical support, E-1
Hibernate Once, Resume Many (HORM), C-2

I

I/O ports, 1-1
    arrangement (figure), 1-2
instrument drivers (NI resources), E-1
introduction, 1-1

J

jumpers, 3-1
    function descriptions (table), 3-1
    locations
        bottom side (table), 3-4
        top side (table), 3-3

K

KnowledgeBase, E-1

L

LCD specifications, A-4

M

mercury disposal and recycling specifications, A-8

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

N

National Instruments support and services, E-1

O

online product certification specifications, A-7

P

panel mounting, 2-4
physical specifications, A-1
pinouts
  COM1 connector, B-1
  COM2 connector, B-2
power connector (figure), 2-3
power receptor (figure), 2-3
power specifications, A-5
programming examples (NI resources), E-1

S

safety
  information, 2-1
  specifications, A-6
serial port settings, B-1
setup, 2-2
software (NI resources), E-1
specifications, A-1
  CE compliance, A-7
  cleaning, 1-2, A-8
  dimensions
    TPC-2206, A-2
    TPC-2212, A-3
  electromagnetic compatibility, A-6
  environmental, A-5
  environmental management, A-7
  fuse, A-5
  LCD, A-4
  mercury disposal and recycling, A-8
  online product certification, A-7
  physical, A-1
  power, A-5
  safety, A-6
  system, A-4
  touchscreen, A-5
  Waste Electrical and Electronic Equipment, A-8
support, technical, E-1
system setup, 2-2
system specifications, A-4

T

technical support, E-1
touchscreen
  calibration, 2-4, D-1
  specifications, A-5
TPC-2206/TPC-2212
  CE compliance specifications, A-7
  cleaning specifications, 1-2, A-8
  COM1 connector pinout, B-1
  COM2 connector
    mode, B-2
    pinout, B-2
  connectors, 3-1
  dimensions
    TPC-2206, A-2
    TPC-2212, A-3
  drivers, C-2
  electromagnetic compatibility specifications, A-6
  Enable Write Filter (EWF), C-1
  environmental management specifications, A-7
  environmental specifications, A-5
  File Based Write Filter (FBWF), C-1
  fuse specifications, A-5
  Hibernate Once, Resume Many (HORM), C-2
  I/O ports, 1-1
  introduction, 1-1

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

jumpers, 3-1
LCD specifications, A-4
mercury disposal and recycling specifications, A-8
online product certification specifications, A-7
panel mounting, 2-4
physical specifications, A-1
power connector (figure), 2-3
power receptor (figure), 2-3
power specifications, A-5
safety
information, 2-1
specifications, A-6
serial port settings, B-1
specifications, A-1
system setup, 2-2
system specifications, A-4
touchscreen
calibration, 2-4, D-1
specifications, A-5
Waste Electrical and Electronic Equipment specifications, A-8
Windows XP Embedded features, C-1
training and certification (NI resources), E-1
troubleshooting (NI resources), E-1

W

Waste Electrical and Electronic Equipment specifications, A-8
Web resources, E-1
Windows XP Embedded features, C-1

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP