

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Visit our website - *Click HERE*

68M-50F STEP/SERVO BULKHEAD CABLE ADAPTER


Thank you for purchasing a 68M-50F step/servo bulkhead cable adapter.

Using the 68M-50F step/servo bulkhead cable adapter, you can connect a 68-pin motion controller to a 50-pin motion accessory, or you can connect a 50-pin ValueMotion controller to a 68-pin motion accessory. You set switches to configure the adapter for stepper or servo operation, as well as to set each axis as either a trigger input or a breakpoint output.

Configuring Your Adapter

Make sure the power is off to the controller and the accessory before setting the switches.

Figure 1 shows the location of the switches on the adapter.



1	Step/Servo Switch Bank	4	Axis 3 Trigger/Breakpoint Switch
2	Axis 1 Trigger/Breakpoint Switch	5	Axis 4 Trigger/Breakpoint Switch
3	Axis 2 Trigger/Breakpoint Switch		

Figure 1. 68M-50F Adapter Switch Locations

ValueMotion™ is a trademark of National Instruments Corporation. Product and company names mentioned herein are trademarks or trade names of their respective companies.

 © Copyright 1999 National Instruments Corp. All rights reserved.

Step/Servo Configuration

You must set all of the step/servo switches to match your motor type. Refer to Figure 1 for the location of the step/servo switches. If you are controlling a stepper motor, set *all* of the switches to STEP. If you are controlling a servo motor, set *all* of the switches to SERVO.





Breakpoint/Trigger Configuration

You must set the breakpoint/trigger switches to match the desired operation of your motion controller. Refer to Figure 1 for the location of the breakpoint/trigger switches. Each breakpoint/trigger switch is associated with a single axis and can be set individually for either breakpoint output or trigger input operation. Set the switch to TRIG if the axis is used as a trigger input. Set the switch to BP if the axis is used as a breakpoint output.

Installing Your Adapter

You have several options for installing your adapter, depending on the devices you are connecting to each other and the cable that you are using to make the connection. To install the adapter, make sure the power is off to the controller and the accessory, and set the switches as required for your application. Then, refer to Table 1 to determine how to connect your controller to your accessory using the adapter and the appropriate cable. The adapter is shown as a box with an "A" inside it.

Table 1. Adapter Connection Options

Controller Connector	Cable	Accessory Connector
50-pin		68-pin SCSI-II
50-pin		68-pin VHDCI
68-pin VHDCI		50-pin
68-pin SCSI-II		50-pin

322543A-01 Aug99

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP