ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction


All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *National Instruments GPIB-USB-HS* at our website: *Click HERE*


日本語版は裏面をご覧ください

Getting Started


1 Insert CD, then choose **Install Software**.




2 Select **Plug and Play Interface** and click **Next**.



3 Select **Restart**.



4 Connect USB cable[1].



5 Run NI-488.2 Getting Started Wizard.



[1] **Caution** Ensure the GPIB devices and the computer containing the GPIB-USB interface share the same ground potential. For help installing your hardware, refer to the *GPIB Hardware Guide* (available on the CD through **Getting Started Documentation**).

© 1999–2004 National Instruments Corporation. All rights reserved.


National Instruments™, ni.com™, and NI-488.2™ are trademarks of National Instruments Corporation. Product and company names listed are trademarks or trade names of their respective companies.

For patents covering National Instruments products, refer to the appropriate location: **Help»Patents** in your software, the `patents.txt` file on your CD, or `ni.com/patents`.


371258A-01 0704

はじめにお読みください


1 CDを挿入して、**ソフトウェアをインストール**を選択します。




2 **プラグアンドプレイインタフェース**を選択して、**次へ**をクリックします。




3 **再起動**を選択します。



4 USBケーブルを接続します(注)。



5 NI-488.2クイックスタートウィザードを実行します。



⚠ (注) 警告　GPIBデバイスおよびGPIB-USBインタフェースを含むコンピュータが、同じグラウンド電位を共有していることを確認してください。ハードウェアのインストール方法については、『GPIBハードウェアガイド』を参照してくださいCDの「ドキュメントを表示」からご利用いただけます)。

© 1999–2004 National Instruments Corporation. All rights reserved.

National Instruments™、ni.com™、NI-488.2™ は National Instruments Corporation の商標です。記載されている製品名および会社名は、該当各社の商標または商号です。

National Instrumentsの製品を保護する特許については、「ヘルプ」→「特許」を選択すると表示される製品情報、このCDにある `patents.txt` ファイル、`ni.com/patents` のうち、該当するものを参照してください。

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP