ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Pickering 40-792-701* at our website: ***Click HERE***

User Manual

PXI

8 Tributary 75Ω Daisy Chain Switch
(Model No. 40-792)



Issue 4.1 May 2017

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

© COPYRIGHT (2017) PICKERING INTERFACES. ALL RIGHTS RESERVED.

No part of this publication may be reproduced, transmitted, transcribed, translated or stored in any form, or by any means without the written permission of Pickering Interfaces.

Technical details contained within this publication are subject to change without notice.

ISO 9001
Reg No. FM38792

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

TECHNICAL SUPPORT

For Technical Support please contact Pickering Interfaces either by phone, the website or via e-mail.

WARRANTY

All products manufactured by Pickering Interfaces are warranted against defective materials and workmanship for a period of three years, excluding programmable power supplies, from the date of delivery to the original purchaser. Any product found to be defective within this period will, at the discretion of Pickering Interfaces be repaired or replaced.

Products serviced and repaired outside of the warranty period are warranted for ninety days.

Extended warranty and service are available. Please contact Pickering Interfaces by phone, the website or via e-mail.

ENVIRONMENTAL POLICY

Pickering Interfaces operates under an environmental management system similar to ISO 14001.

Pickering Interfaces strives to fulfil all relevant environmental laws and regulations and reduce wastes and releases to the environment. Pickering Interfaces aims to design and operate products in a way that protects the environment and the health and safety of its employees, customers and the public. Pickering Interfaces endeavours to develop and manufacture products that can be produced, distributed, used and recycled, or disposed of, in a safe and environmentally friendly manner.

Worldwide Technical Support and Product Information

pickeringtest.com

Pickering Interfaces Headquarters

Stephenson Road Clacton-on-Sea CO15 4NL United Kingdom
Tel: +44 (0)1255-687900
E-Mail: sales@pickeringtest.com

USA
Tel: (West) +1 541 471 0700
Tel: (East) +1 781 897 1710
E-mail: ussales@pickeringtest.com

France
Tel +33 9 72 58 77 00
E-mail frsales@pickeringtest.com

Germany
Tel: +49 89 125 953 160
E-mail: desales@pickeringtest.com

Sweden
Tel: +46 340-69 06 69
E-mail: ndsales@pickeringtest.com

Czech Republic
Tel: +420 558 987 613
E-mail: desales@pickeringtest.com

China
Tel: +86 4008 799 765
E-mail: chinasales@pickeringtest.com

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

PRODUCT SAFETY

SAFETY SYMBOLS

The following safety symbols may be used on the product and throughout the product documentation.

MEANING / DESCRIPTION	SYMBOL
PROTECTIVE EARTH (GROUND) To identify any terminal which is intended for connection to an external conductor for protection against electric shock in case of a fault, or the terminal of a protective earth (ground) electrode.	
DANGEROUS VOLTAGE To indicate hazards arising from dangerous voltages.	
WARNING / CAUTION An appropriate safety instruction should be followed or caution to a potential hazard exists. Refer to the relevant instructions detailed within the product manual.	
HEAVY If this product is heavy reference should be made to the safety instructions for provisions of lifting and moving.	
STATIC SENSITIVE To indicate that static sensitive devices are present and handling precautions should be followed.	

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

CONTENTS

Copyright Statement II

Technical Support and Warranty III

Product Safety IV

Contents (this page) V

Warnings and Cautions VII

Section 1
Technical Specification 1.1

Section 2
Technical Description 2.1
- Functional Description 2.1
- Relay Schematic 2.2

Section 3
Installation 3.1
- Pre Operation Checks 3.1
- Hardware Installation 3.2
- Software Installation 3.2
- Testing Operation 3.3

Section 4
Programming Guide 4.1
- Programming Options For Pickering PXI Cards 4.1
- Module Architecture 40-792 ..... 4.3
- Sub-Units 4.3
- Programming The Module 40-792 ..... 4.4

Section 5
Connector Information 5.1

Section 6
Trouble Shooting 6.1

Section 7
Maintenance Information 7.1
- Relay Lookup Tables 7.1
- Component Layout 7.2

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

THIS PAGE INTENTIONALLY BLANK

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

WARNINGS AND CAUTIONS

WARNING - HAZARDOUS ENVIRONMENTS	SYMBOL
This product is not specifically designed for use in hazardous environments, for example in explosive atmospheres. If the product is to be used in hazardous environments we recommend that the user ensures suitable protective measures are taken.	

WARNING - DANGER OF ELECTRIC SHOCK	SYMBOL
This module may contain hazardous voltages. Before removing the module from the rack remove all supplies and disconnect user I/O signals. Unused slots in the PXI/LXI chassis are populated with blanking plates to prevent access to user I/O signals that may be present. Blanking panels are available to order from Pickering in a variety of slot widths. If the product is not used in this manner for example by using an extender card then additional care must be taken to avoid contact with exposed signals.	

CAUTION - HANDLING OF ELECTROSTATIC-SENSITIVE DEVICES	SYMBOL
Certain semiconductor devices used in this equipment are liable to damage due to static voltage. Observe the following precautions when handling these devices in their unterminated state, or sub-assemblies containing these devices: 1. Persons removing sub-assemblies from equipment using these devices must be earthed by a wrist strap and a resistor at the point provided on the equipment. 2. Soldering irons used during the repair operations must be low voltage types with earthed tips and isolated from the mains voltage by a double insulated transformer. 3. Outer clothing worn must be unable to generate static charges. 4. Printed Circuit Boards (PCBs) fitted with these devices must be stored and transported in anti-static bags.	

CAUTION - PRODUCT DOCUMENTATION	SYMBOL
Suitably qualified & trained users should ensure that the accompanying documentation is fully read and understood before attempting to install or operate the product.	

SAFETY INSTRUCTIONS

SAFETY INSTRUCTIONS
All cleaning and servicing requires the equipment to be isolated and disconnected from the power source and user I/O signals (refer to the Maintenance Section). • Appropriate manual handling procedures should be followed as dictated by the weight of the individual module or the combined weight of the modules & chassis. • Should a fault occur with the module or chassis, immediately isolate and disconnect the incoming power to the chassis and the user I/O signals. • Ensure the equipment is installed, operated and maintained by trained and authorised personnel. • For suitably equipped products in the event of an emergency press the red “emergency stop” button situated on the front of the unit.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com


THIS PAGE INTENTIONALLY BLANK

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 1 - TECHNICAL SPECIFICATION

40-792/793
2MBit/s Daisy-Chain Tributary Switching Module

- Suitable For Testing SONET/SDH Transmission Multiplexers
- 8 or 16 Tributaries Per 1-Slot Module
- Up To 272 Tributaries Per 18-Slot PXI Chassis
- Expandable To Any Size: 8, 16, 24,....
- 75Ω Impedance
- All Tributaries Can Be Daisy-Chained to One Signal
- Pickering Interfaces Can Construct and Test Custom Switching Networks
- VISA, IVI & Kernel Drivers Supplied for Windows
- Supported by PXI or LXI Chassis
- 3 Year Warranty




The 40-792/793 Daisy Chain Switching Module is designed for telecom test applications. It allows production or verification testing of SONET/SDH transmission multiplexers switching 2MBit/s or 1.5MBIt/s data with a characteristic impedance of 75Ω.

Range Description:

- **40-792** 8 Trib Daisy Chain Switch
- **40-793** 16 Trib Daisy Chain Switch

Multiple modules can be cascaded together to form very large systems, for example a 7 slot PXI chassis can contain a 112 tributary switching system and an 18 slot PXI chassis can contain up to 272 Tributaries.

Traffic is sequentially Daisy-Chained through all tributaries (or any selection of tributaries), modules can be cascaded to test any number of tributaries. Two additional multiplexers have been built in to allow Transmit or Receive instrumentation to connect to any individual tributary this allows specific testing of that port, for example to measure pulse shape distortion or return loss. Refer to graphic below.



Block Diagram of 16-Channel Tributary Daisy Chain Switching Module

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com


General Specification (All Versions)


Maximum Voltage:	100VDC/100VAC
Maximum Power:	30W
Maximum Switch Current:	1.0A
On Path Resistance:	<500mΩ
Off Path Resistance:	>1x10^{8}Ω
Expected Life (Low Power):	>1x10^8 operations
Expected Life (Max Power):	>2x10^5 operations
Total Switching Time:	10ms
Relay Mechanical Setting Time:	<3ms


R.F. Specification (Multiplexer)

Characteristic Impedance:	75Ω
Maximum Frequency:	100MHz
Rise Time:	<1ns
Insertion Loss (<10MHz):	<0.3dB
Return Loss (<10MHz):	>21dB
VSWR (<10MHz):	<1:1.15
Isolation (<10MHz):	>50dB









Typical RF Performance Plots for 40-793-701
(1 Tributary Switched To The Test Multiplexer)

SDH/SONET Tributary Testing is a very specialised area, please contact Pickering Interfaces for additional application information and to discuss your exact requirements.

Pickering Interfaces also have SDH/SONET switching solutions in our System 30 (VXI) and System 20 (IEEE-488) switching systems.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Using The Tributary Daisy Chain Switch

The 40-792/793 comprises 2 sections (see graphic on previous page).

1. Daisy-Chain switches. These are used to feed 2M signals into and out of the DUT (device under test), any selection of tributaries may be routed (e.g. all even, all odd, etc).

2. Breakout multiplexer. This is used to test a specific tributary.

The 40-792/793 is programmed as a 4x16 matrix:-

1st row is used to route the Daisy-Chain switches. The default setting is for all tributaries to be selected.

2nd row is used to switch polarity.

3rd row is used to select the receive multiplexer to a specific tributary.

4th row is used to select the transmit multiplexer to a specific tributary.

Power Requirements

+3.3V	+5V	+12V	-12V
0	500mA (typ 340mA)	0	0

Width and Dimensions

Single width slot 3U PXI (CompactPCI card).

3D models for all versions in a variety of popular file formats are available on request.

Connectors

PXI bus via 32-bit P1/J1 backplane connector.

Signals via front panel 96-pin male micro-D connector.

Product Order Codes

8 Trib Daisy Chain Switch, 75Ω	**40-792-701**
16 Trib Daisy Chain Switch, 75Ω	**40-793-701**

Support Products

Spare Relay Kits


Kits of replacement relays are available for the majority of Pickering's PXI switching modules, simplifying servicing and reducing down-time. The relay kits for the 40-792/793 range are as follows:

91-100-040 & 91-100-023 kits for 40-792-701
91-100-040 & 91-100-023 kits for 40-793-701

For further assistance, please contact your local Pickering sales office.

Mating Connectors & Cabling

For connection accessories for the 40-792/793 modules please refer to the **90-016D** 96-pin micro-D connector data sheet where a complete list and documentation can be found for accessories, or refer to the Connection Solutions catalog.



40-793-701 16 Tributary Daisy Chain Switch Module

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Programming

Pickering provide kernel, IVI and VISA (NI & Keysight) drivers which are compatible with all Microsoft supported versions of Windows and popular older versions. For a list of all supporting operating systems, please see: www.pickeringtest.com/os
The VISA driver is also compatible with Real-Time Operating Systems such as LabVIEW RT. For other RTOS support contact Pickering. These drivers may be used with a variety of programming environments and applications including:

- **Pickering Interfaces Switch Path Manager**
- **MTQ Testsolutions** Tecap Test & Measurement Suite
- **National Instruments** products (LabVIEW, LabWindows/CVI, Switch Executive, MAX, TestStand, VeriStand, etc.)
- **Microsoft Visual Studio** products (Visual Basic, Visual C+)
- **Keysight** VEE • **Mathworks** Matlab • **Marvin** ATEasy

Drivers for popular Linux distributions are available, other environments are also supported, please contact Pickering with specific enquiries.

Operating/Storage Conditions

Operating Conditions

Operating Temperature:	0°C to +55°C
Humidity:	Up to 90% non-condensing
Altitude:	5000m

Storage and Transport Conditions

Storage Temperature:	-20°C to +75°C
Humidity:	Up to 90% non-condensing
Altitude:	15000m

PXI & CompactPCI Compliance

The module is compliant with the PXI Specification 2.2. Local Bus, Trigger Bus and Star Trigger are not implemented.
Uses a 33MHz 32-bit backplane interface.

Safety & CE Compliance

All modules are fully CE compliant and meet applicable EU directives: Low-voltage safety EN61010-1:2001, EMC Immunity EN61000-6-1:2001, Emissions EN55011:1998.

PXI & LXI Chassis Compatibility

Compatible with all chassis conforming to the 3U PXI and 3U cPCI specification. Compatible with Legacy and Hybrid peripheral slots in a 3U PXI Express chassis.
Compatible with Pickering Interfaces LXI Modular Chassis. For information on driving your switching solution in an LXI environment refer to the LXI Product Guide.



Latest Details


Please refer to our Web Site for Latest Product Details.
www.pickeringtest.com




Please refer to the 200 page Pickering Interfaces "**Connection Solutions**" catalog for the full list of connector/cabling options, including drawings, photos and specifications. Available in either print or as a download.
Alternatively our web site has dynamically linked connector/cabling options, including pricing, for all Pickering PXI modules.




"**The Big PXI Catalog**" gives full details of Pickering's entire range of PXI switch modules, instrument modules and support products.
At over 500 pages, the Big PXI Catalog is available on request or can be downloaded from the Pickering website.



Ever wondered what PXI is all about?
Pickering Interfaces' "**PXImate**" explains the basics of PXI and provides useful data for engineers working on switch based test systems.
The PXImate is available free on request from the Pickering website.



The "**Cables & Connectors Map**" - outlines the cable and connector options available for all PXI Modules.



The "**PXI Module Map**" - a simple fold-out selection guide to all Pickering's 1000+ PXI Modules.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 2 - TECHNICAL DESCRIPTION

FUNCTIONAL DESCRIPTION

A functional block diagram is provided in Figure 2.1. The Daisy Chain Module is powered by +5V and inputs via Compact PCI connector J2. The interface to the user test equipment is via the front panel mounted 96-pin micro-D connector, J1. The module comprises a PCB populated with relays configured as Daisy Chains and tributaries. The relays are energised via control signals from relay drivers U8 to U12. The relay drivers are addressed by PCI bridge U1, via the control logic, to output the required signal. Module configuration is determined by data stored in EEPROM U7. PCI Bridge U1 is configured by EEPROM U2.

Figure 2.2 provides a schematic representation of the Daisy Chain and Tributary (Rx/Tx) paths. The Daisy Chain paths are suitable for low quality measurements, e.g. Bit Error Rate Test. The Rx/Tx Select paths are suitable for high quality measurement e.g. Return Loss/SWR, Pulse Shape.




Figure 2.1 - 8 Tributary 75Ω Daisy Chain Switch: Functional Block Diagram

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 2.2 - 8 Tributary Daisy Chain Switch 75Ω (40-792): Relay Schematic

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 3 - INSTALLATION

Refer to the Warnings and Cautions at the front of this manual

Modular products require installation in a suitable PXI/LXI chassis. The module is designed for indoor use only.

PREOPERATION CHECKS (UNPACKING)

1. Check the module for transport damage and report any damage immediately to Pickering Interfaces. Do not attempt to install the product if any damage is evident.
2. Position the chassis relative to any other equipment the module(s) will connect with. Ensure the chassis is not connected to the electrical supply.
3. Ensure that the designated area for the chassis containing the module is of flat and solid construction to withstand and support the combined weight of the module(s) and chassis.




Figure 3.1 - Installing the Module into a PXI/cPCI/LXI Chassis

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

HARDWARE INSTALLATION
ELECTRICAL CONNECTION (CHASSIS)

1. The chassis must be electrically installed in accordance with local regional electrical codes by a qualified engineer.
2. The chassis must be grounded.

Electrostatic discharge can damage the components on the module. To avoid such damage in handling the board refer to page VII.

Ensure that there is adequate ventilation.

The module should be installed in accordance with the following procedure:

1. Ensure that the system is turned OFF but still connected to mains so that it remains grounded.
2. Choose an appropriate slot in the rack.
3. Remove the blanking plate for the chosen slot.
4. Ensure that the injector/ejector handle is in its downward position. Align the module with the card guides on the top and bottom of the slot.

   Do not raise the injector/ejector handle whilst inserting the module as the module will not insert properly.
5. Hold the handle whilst slowly sliding the module into the card guides until the handle catches on the injector/ejector rail (refer to Figure 3.1).
6. Raise the injector/ejector handle until the module firmly seats into the backplane. The front panel of the module should be flush with the front panel of the chassis.
7. Secure the front panel of the module using both screws to the chassis front panel mounting rails.
8. In a system employing a remote control interface to connect an external controller to a PXI chassis or to link multiple chassis, power-up the system as follows:
   a. For a system comprising an external controller and one chassis, power up the chassis before powering up the external controller.
   b. For a system comprising more than one chassis, turn ON the last chassis in the system followed by the penultimate, etc, and finally turn ON the external controller or chassis containing the system controller.
9. For Pickering Interfaces modular LXI installation there is no requirement to use any particular power up sequence.

SOFTWARE INSTALLATION

First install the appropriate Pickering PXI switch card drivers by running the installer program Setup.exe (provided in a compressed zip file), either from the CD-ROM supplied, or by downloading the latest version from our website **pickeringtest.com** - the recommended method. Setup is accompanied by a ReadMe file containing additional installation information. A single installation covers all cards in the System 40, System 45 and System 50 ranges.

When installation completes, the installed drivers' ReadMe file is offered for display. It can also be displayed later using a shortcut on the Programs>>Pickering menu.

If you are not a LabVIEW user you should choose the "full" version, and once that has been installed run the LabVIEW Runtime Engine installer via the shortcut on the Programs>>Pickering menu. In the absence of LabVIEW the Runtime Engine is required to support the Pickering Test Panels application.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

TESTING OPERATION

After installation of the hardware and Pickering PXI Driver software package start the General Soft Front Panel (GSFP) using the desktop icon or via the Start menu (***Start Menu-> Pickering Interfaces Ltd -> General Soft Front Panel***).



Figure 3.2 - General Soft Front Panel Icon

A selector panel will appear, listing all installed Pickering PCI, PXI or LXI switch cards and resistor cards. Click on the card you wish to control, and a graphical control panel is presented allowing operation of the card. Panels can be opened simultaneously for all the installed cards.




Figure 3.3 - General Soft Front Panel Selector

More details how to use the GSFP can be found in the manual, via menu ***Help\Manual***

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

THIS PAGE INTENTIONALLY BLANK

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 4 - PROGRAMMING GUIDE

PROGRAMMING OPTIONS FOR PICKERING INTERFACES PXI CARDS

Software drivers are supplied for Microsoft Windows operating systems, with specific support for the following development environments:

- Microsoft Visual Studio (VB, C++, C#)
- Borland C++
- National Instruments LabWindows/CVI
- National Instruments LabVIEW and LabVIEW RT

Windows drivers are supplied in the form of Dynamic Link Libraries, which should also be usable in any other development environment that supports them.

Some recent drivers developed for the LXI platform are capable of addressing both PXI and LXI domains. Such duality may be of help to users considering future migration from PXI based systems to LXI based systems, or indeed systems containing both PXI and LXI components.

Programming for PXI

A number of different Windows drivers are available to meet particular system requirements, and should none of these be suitable there is also the option of register-level programming. Drivers are generally ‘universal’, handling all models in the System 40, 45 and 50 ranges; however some models that are not compliant with the Ivi Swtch class cannot be used with the pi40iv IVI driver. The pipx40 and Pilpxi drivers are also applicable to certain models in the System 41 (PXI Instruments) range - see these drivers’ System 41 support list.

Please note that this documentation is available in its most up-to-date form as HTML help files, fully hyperlinked for easy access - both pipx40 and Pilpxi documents are included in the Pipx40vpp software installation.

IVI Driver for Windows - pi40iv

The pi40iv IVI (Interchangeable Virtual Instrument) driver supports all Pickering Interfaces PXI switch cards that are consistent with the Iviswtch class model - as are the great majority of cards in the System 40/45/50 ranges. It integrates well with LabWindows/CVI and LabVIEW, and is fully compatible with Switch Executive. It is also usable in general-purpose programming environments such as Visual C++ and Visual Basic.

Prior installation of the VISA and IviEngine from National Instruments are required for the correct installation and operation of this driver.

VISA Driver for Windows - pipx40

The pipx40 driver conforms to the VISA (Virtual Instrument Software Architecture) standard for programmable instrumentation. Instrument control environments such as LabVIEW and LabWindows/CVI are based on VISA, and pipx40 support libraries are provided for them.

Prior installation of VISA from National Instruments is required for the operation of this driver.

Where VISA is available, pipx40 can also be used in general-purpose programming environments such as Visual C++ and Visual Basic. When IVI is not a system requirement this driver will often yield faster operation than the pi40iv driver.

Direct I/O Driver for Windows - Pilpxi

The Pilpxi driver accesses cards directly, without using the VISA software layer, while offering similar overall functionality to pipx40. It is most commonly used in general-purpose programming environments such as Visual C++ and Visual Basic. Operating speed of the VISA and Direct I/O drivers is generally comparable.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Register-level Programming

Where the supplied drivers are not suitable, register-level programming can be employed - for example:

- If the functionality of the supplied drivers does not meet the application requirements
- If security considerations demand full source-code for the application
- In development environments that have alternate mechanisms for accessing PCI bus
- For operating systems other than Windows

Programming for LXI

When Pickering PXI cards are inserted into an LXI Modular Chassis a different set of drivers is available.

IVI Driver for Windows - pi40iv

The pi40iv IVI also supports LXI inserted cards simply by changing the resource string to address string to the appropriate address.

Direct I/O Driver for Windows - Piplx

The piplx driver is based on the PXI Direct I/O driver pilpxi, but with added functionality to deal with the added need to address the chassis using an IP address. It integrates well with LabWindows/CVI and LabVIEW, and is fully compatible with Switch Executive. It is also usable in general-purpose programming environments such as Visual C++ and Visual Basic.

Please note that this driver may also be used in the PXI domain. If the addressed card is in the local computer PCI/PXI system, commands will be passed through to the PXI Direct I/O driver. This mechanism allows the piplx driver to be used for both PXI and LXI cards.

The LXI format offers additional interface options not available in PXI :

.NET

A .NET native driver is also available. Once again this may be used for both LXI and PXI card control.

SOAP

Pickering LXI products include a SOAP interface which is usable from a wide variety of platforms and languages.

SSH

Pickering LXI products include an SSH interface which allows remote command line access to control cards, or, using a suitable package, programmatic control.

The user is advised to visit the Pickering web site for further details of all the above drivers, where documentation, example programs, and further help with driver choice are available.

LabVIEW, LabWindows/CVI and Switch Executive are trademarks of National Instruments Corporation.

General Pickering Card Architecture

With most drivers, before programming a Pickering card it is important to understand the basic architecture of Pickering cards.

The switches on a Pickering card are organized into logical sub-units, each sub-unit containing a set of objects of similar type and use. These objects may be switches, digital outputs, digital inputs, resistors, power supplies etc, depending on the nature of the specific card.

For example a simple matrix card will usually contain a single sub-unit containing the switches arranged in a 2-dimensional array. However a similar card with additional isolating relays connected to the matrix will contain additional sub-units containing those isolation relays.


Low level drivers include functions to allow the programmer to query the card to ascertain the number of sub-units, and the size and type of each sub-unit.

For full details of the driver functions available the programmer should refer to the documentation provided.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

MODULE ARCHITECTURE 40-792

The 40-792 utilises an array of thirty four 2 Form C changeover relays. In the default state the daisy chain is routed through all tributaries and the multiplexers are inactive. Energising a particular relay creates a signal path between its C and A terminals the effects of which vary depending on the relays function. The relay module's switching architecture is shown in detail in Figure 2.2. The architecture of an individual 2 Form C relay is as shown below:



2 Form C Relay

Three sub-units of 8 bits are used to control the module's relays as shown in the table below. Enabling a particular bit closes the C to A signal paths of the associated relays.

Sub-Unit	Bit	Tributary Selection	Daisy Chain Relays	Rx Select Relays	Tx Select Relays	Loop-Back Relays
1	1	1	RL1, RL2	-	-	-
	2	2	RL3, RL4	-	-	-
	3	3	RL7, RL8	-	-	-
	4	4	RL9, RL10	-	-	-
	5	5	RL13, RL14	-	-	-
	6	6	RL15, RL16	-	-	-
	7	7	RL19, RL20	-	-	-
	8	8	RL21, RL22	-	-	-
2	1	1	-	RL52, RL53, RL56	RL60, RL61, RL64	-
	2	2	-	RL52, RL53	RL60, RL61	-
	3	3	-	RL52, RL53, RL54, RL56	RL60, RL61, RL62, RL64	-
	4	4	-	RL52, RL53, RL54	RL60, RL61, RL62, RL64	-
	5	5	-	RL53, RL54, RL55	RL61, RL62, RL63	-
	6	6	-	RL53, RL54	RL61, RL62	-
	7	7	-	RL53, RL55	RL61, RL63	-
	8	8	-	RL53	RL61	-
3	1	1	-	-	-	RL5
	2	2	-	-	-	RL6
	3	3	-	-	-	RL11
	4	4	-	-	-	RL12
	5	5	-	-	-	RL17
	6	6	-	-	-	RL18
	7	7	-	-	-	RL23
	8	8	-	-	-	RL24

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

PROGRAMMING THE MODULE 40-792

Here are some simple examples of using the drivers with the 40-792 module.

Using PILPXI

To operate a relay the user could use the simple OpBit command or the WriteSub commands

OpBit

```
DWORD sub_unit = 1;
PIL_OpBit( card_num, sub_unit, 1, 1);   // Selects Tributary 1
PIL_OpBit( card_num, sub_unit, 1, 0);   // Releases Tributary 1
PIL_OpBit( card_num, sub_unit, 6, 1);   // Selects Tributary 6
```

WriteSub

```
// Sub-unit 1 is 8 bits wide, so 1 DWORD is needed to hold the pattern
DWORD data[1];
data[0] = 1;            // Sets lowest bit to 1, Selects Tributary 1
PIL_WriteSub( card_num, sub_unit, data);
data[0] = 0x20;         // Sets 6th bit, Selects Tributary 6
                        // All other relays are set to off
PIL_WriteSub( card_num, sub_unit, data);
```

Using PIPX40

setChannelState

```
ViUInt32 sub_unit = 1;
pipx40_setChannelState(vi, sub_unit, 1, VI_ON);     // Selects Tributary 1
pipx40_setChannelState(vi, sub_unit, 1, VI_OFF);    // Releases Tributary 1
pipx40_setChannelState(vi, sub_unit, 6, VI_ON);     // Selects Tributary 6
```

setChannelPattern

```
// Sub-unit 1 is 8 bits wide, so 1 ViUInt32 value is needed to hold the entire pattern
ViUInt32 data[1];
data[0] = 1;            // Sets lowest bit to 1, Selects Tributary 1
pipx40_setChannelPattern( vi, sub_unit, data);
data[0] = 0x20;         // Sets 6th bit, Selects Tributary 6
                        // All other relays are set to off
pipx40_setChannelPattern( vi, sub_unit, data);
```

Using pi40iv

The IVI driver labels this card in a similar manner to the Sub-units of the table above using the normal comA/chA (etc) labelling tags.

```
pi40iv_Connect(vi, comA, chA1);     // Selects Tributary 1
pi40iv_Disconnect(vi, comA, chA1);  // Releases Tributary 1
pi40iv_Connect(vi, comA, chA6);     // Selects Tributary 6
```

Note: comB is equivalent to Sub-unit 2, and com3 to Sub-unit 3.

The IVI Swtch driver specification contains no bulk setting capabilities.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 5 - CONNECTOR INFORMATION




Figure 5.1 - Daisy Chain Module 40-792: Pinouts
(96-pin micro-D connector viewed from front of module)

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

THIS PAGE INTENTIONALLY BLANK

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 6 - TROUBLE SHOOTING

Refer to the Warnings and Cautions at the front of this manual 

INSTALLATION PROBLEMS

The Plug & Play functionality of Pickering switch cards generally ensures trouble-free installation.

If you do experience any installation problems you should first ensure that all cards are properly seated in their slots. Improperly mated cards may go undetected by the operating system, or may be detected as a card of an unknown type. They can also cause the computer to freeze at various stages in the boot sequence.

If your system employs a remote control interface you should check the integrity of all remote control interface links. When the system is powered up, and during Windows start-up, you should expect to see periodic activity on the remote control interface RX/TX (yellow) indicators, clearing to leave only the PWR/LNK (green) LEDs illuminated. The RX/TX indicators should show activity when you attempt to access a card.

DIAGNOSTIC UTILITY

The Pickering Diagnostic Utility (accessible through the Programs>>Pickering>>PXI Utilities menu) generates a diagnostic report of the system's PCI configuration, highlighting any potential configuration problems. Specific details of all installed Pickering switch cards are included. All the installed Pickering switch cards should be listed in the "Pilpxi information" section - if one or more cards is missing it may be possible to determine the reason by referring to the PCI configuration dump contained in the report, but interpretation of this information is far from straightforward, and the best course is to contact Pickering support: support@pickeringtest.com, if possible including a copy of the diagnostic report.

In the "VISA information" section, if VISA is not installed its absence will be reported. This does not affect operation using the Direct I/O driver, and is not a problem unless you wish to use VISA. VISA is a component of National Instruments LabWindows/CVI and LabVIEW, or is available as a standalone environment.

If VISA is present and is of a sufficiently recent version, the section "Pipx40 information" should present a listing similar to "Pilpxi information".

Please note that the Diagnostic Utility cannot access cards if they are currently opened by some other application, such as the Test Panels or Terminal Monitor.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

THIS PAGE INTENTIONALLY BLANK

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

SECTION 7 - MAINTENANCE INFORMATION

Refer to the Warnings and Cautions at the front of this manual

PERIODIC MAINTENANCE

This product and its corresponding chassis do not require any periodic maintenance.

GENERAL CLEANING

- Isolate the electrical power from the chassis and ensure that no user I/O signals are being applied.
- Wipe the product & chassis surfaces with a clean dry anti-static cloth only.

SOFTWARE UPDATE

For PXI modules operating in a PXI chassis, no module software updates are required. For the latest version of the driver please refer to our web site **pickeringtest.com** where links to our Software Download page will provide the latest version of the driver software for the various programming environments encountered.

For PXI modules which are supported in one of Pickering Interfaces' Modular LXI Chassis (such as the 60-102B and 60-103B) no module software update is required. If the module was introduced after the LXI chassis was manufactured the module may not be recognized, in this case the chassis firmware may need upgrading. This is a simple process which is described in the manual for the Modular LXI Chassis.

RELAY LOOK-UP TABLES

The following pages provide a cross reference between the signal paths of the Relay Module and the physical relays on the PCB. The tables can be used in the fault finding process and should be used in conjunction with the corresponding PCB layout diagrams to identify the position of faulty relays.




Figure 7.1 - Daisy Chain Switch: 40-792

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Table 7.1 - Daisy Chain Switch 40-792: Relay Numbering

Tributary Selection	Daisy Chain Relays	Rx Select Relays	Tx Select Relays	Loop-Back Relays
1	RL1, RL2	RL52, RL53, RL56	RL60, RL61, RL64	RL5
2	RL3, RL4	RL52, RL53	RL60, RL61	RL6
3	RL7, RL8	RL52, RL53, RL54, RL56	RL60, RL61, RL62, RL64	RL11
4	RL9, RL10	RL52, RL53, RL54	RL60, RL61, RL62, RL64	RL12
5	RL13, RL14	RL53, RL54, RL55	RL61, RL62, RL63	RL17
6	RL15, RL16	RL53, RL54	RL61, RL62	RL18
7	RL19, RL20	RL53, RL55	RL61, RL63	RL23
8	RL21, RL22	RL53	RL61	RL24

Table 7.2 - Daisy Chain Switch 40-792: Multiplexer Numbering

Signal Path	Relay Numbers
Rx Sel to Rx1	RL1, RL56, RL52, RL53
Rx Sel to Rx2	RL3, RL52, RL53
Rx Sel to Rx3	RL7, RL56, RL54, RL52, RL53
Rx Sel to Rx4	RL9, RL54, RL52, RL53
Rx Sel to Rx5	RL13, RL55, RL54, RL53
Rx Sel to Rx6	RL15, RL54, RL53
Rx Sel to Rx7	RL19, RL55, RL53
Rx Sel to Rx8	RL21, RL53
Tx Sel to Tx1	RL2, RL64, RL60, RL61
Tx Sel to Tx2	RL4, RL60, RL61
Tx Sel to Tx3	RL8, RL64, RL62, RL60, RL61V
Tx Sel to Tx4	RL10, RL62, RL60, RL61
Tx Sel to Tx5	RL14, RL63, RL62, RL61
Tx Sel to Tx6	RL16, RL62, RL61
Tx Sel to Tx7	RL20, RL63, RL61
Tx Sel to Tx8	RL22, RL61




Figure 7.2 - Daisy Chain Switch 40-792: Component Layout

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP