

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Visit our website - *Click HERE*

SIEMENS

Basic Operator Panel (BOP)


Operating Instructions




Safety Information

- The BOP can be fitted to and removed from the inverter whilst power is applied.
- If the BOP has been set as the I/O control (P0700 = 1), the drive will stop if the BOP is removed.
- The BOP does not have an individual UL listing. When the BOP is fitted to the inverter the complete unit becomes a UL listed system.


Fitting the Operator Panel




REVERSE DIRECTION OF ROTATION GB
UMGEKEHRTER DREHRICHTUNG D
INVERSION DU SENS ROTATION F
INVERSIONE DI DIREZIONE I
INVERSION DE GIRO E
OMGEKEERDE DRAAIRICHTING NL
SKIFT OMLØBSRETNING DK
GB FUNCTION
D FUNKTION
F FONCTION
I FUNZIONI
E FUNCIÓN
NL FUNCTIE
DK FUNKTION
START INVERTER GB
START UMRICHTER D
MISE EN MARCHE DE L'ENTRAINEMENT F
AVVIAMENTO DELL'INVERTITORE I
ARRANQUE DEL CONVERTIDOR E
START OMVORMER NL
START DK
GB INCREASE VALUE / UP
D ERHOHUNG
F AUGMENTER VALEUR / PLUS
I AUMENTO DEL VALORE / SU
E INCREMENTAR VALOR / ARRIBA
NL VERHOOG DE WAARDE / HOGER
DK FOROG VÆRDI / OP
STOP INVERTER GB
STOP UMRICHTER D
ARRET DE L'ENTRAINEMENT F
ARRESTO DELL'INVERTITORE I
PARADA DEL CONVERTIDOR E
STOP OMVORMER NL
STOP DK
GB DECREASE VALUE / DOWN
D REDUZIERUNG
F DIMINUER VALEUR / MOINS
I DIMINUZIONE DEL VALORE / GIU'
E DIMINUZIONE DEL VALOR / ABAJO
NL VERLAAG DE WAARDE / LAGER
DK FORMINDSK VÆRDI / NED
I
FN
JOG
P
RUN AT PRESET FREQUENCY GB
START MIT VORGEGEBENER FREQUENZ D
MARCHE A LA VITESSE PRE SELECTIONNEE F
FUNCZIONAMENTO A LA FREQUENZA PREDEFINITA I
FUNCIONAMIENTOR A FRECUENCIA PREFIJADA E
IN BEDRIJF OP INGESTELDE FREQUENTIE NL
KØR MED FORUDINDSTILLET FRELENEUS DK
GB SELECT CHOICE / VALUE
D AUSWAHL
F SELECTION CHOIX / VALEUR
I SCELTA OPZIONE / VALORE
E SELECCIONAR / VALOR
NL SELECTEER KEUS / WAARDE
DK VÆLG FUNKTION / VÆRDI

For product support and further information, please visit:

http://support.automation.siemens.com



Printed in United Kingdom

May 2010

Siemens plc
Industry Sector
Drive Technologies
Varey Road,
Congleton
CW12 1PH
United Kingdom

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP