

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.


Visit our website - *Click HERE*

125 Serial ATA Mobile Rack


User's Manual

---Features of product ---

- Sata to Sata interface
- High performance – Support upto ATA 150 mb/s
- Point to point connection
- Extension front SATA Data & power ports (SNT-125E)
- Twin power design: 15pin power & 4pin power
- Customizing design – Easy HDD Installation
- Turbo cooling heat dissipation (support 10000/15000rpm HDD)
- Power Control
- Patent balance handle – No skew In/Out
- Support Hot plug & hotswappable
- Cableless connection
- Optional Sensor & Alarm (SNT-125ET)
- Support SATA RAID 0,1,5
- Dim: 185(L) x 146(W) x 42(H)mm
- Color for choice: black or beige
- Weight : 0.4kg




---Safety lock---(see picture A)




Picture A

---Front panel--- (see picture B)




Picture B

---Rear View--- (see picture C)



Picture C

Picture D



No.1--- (POWER SW): Power ON/OFF.

No.2--- Power LED: Power on, LED indicates Green.

No.3--- HDD Access LED (for external connection): Amber LED blinking while HDD access.

No.4--- Overheating LED: When overheating occurs and the buzzer alarms (default setting: 60℃ and the temperature LED turns red mean while buzzer is alarming and LED is blinking). Press the Reset Switch to stop the alarm. LED goes off. (Model: SNT-125ET)

No.5--- FAN LED: LED is indicating Green when it is working. When fan faild, LED turns Red.

No.6--- Reset Switch: For buzzer alarm and Overheating LED. When overheating occurs the buzzer alarms (default setting: 60℃) and the temperature LED turns red meanwhile buzzer is alarming and LED is blinking. Press the Reset Switch to stop the alarm. LED goes off.

No.7 (10)--- Extension front/rear SATA Data ports

No.8 (9)--- Extension front/rear SATA power ports

No.11--- (POWER1): 15pin Serial ATA Power connector

If power is from SATA 15pin connector, connect it to the 15pin connector

No.12--- 4pin Power connector: If your power is not from SATA 15pin connector, then, use the 4pin power connector, the 4pin power will automatically be convert to SATA power.

No.13--- 7pin Serial ATA Signal connector

No.14--- External HDD Access pin connections--

How to connect (See Picture D)

Connect to pins on the motherboard (wire white color is "-"), (see picture D-A)

HD LED (to the computer LED), (see picture D-B)

Connect to HDD pins on the mobile rack (see picture D-C)

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP