



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)

---

# ES1331.1

## Signal Generator Board (4-CH)

User's Guide

## Copyright

---

The data in this document may not be altered or amended without special notification from ETAS GmbH. ETAS GmbH undertakes no further obligation in relation to this document. The software described in it can only be used if the customer is in possession of a general license agreement or single license. Using and copying is only allowed in concurrence with the specifications stipulated in the contract.

Under no circumstances may any part of this document be copied, reproduced, transmitted, stored in a retrieval system or translated into another language without the express written permission of ETAS GmbH.

© **Copyright 2000 - 2003** ETAS GmbH, Stuttgart, Germany

The names and designations used in this document are trademarks or brands belonging to the respective owners.

R1.0.2 EN - 07.2003

TTN F 00K 700 304

---

# Contents

<b>1</b>	Introduction . . . . .	5
<b>1.1</b>	Features . . . . .	5
<b>1.2</b>	Applications . . . . .	6
<b>1.3</b>	Block Diagram . . . . .	7
<b>2</b>	Hardware . . . . .	9
<b>2.1</b>	Functional Description . . . . .	9
<b>2.1.1</b>	Digital Signal Processor . . . . .	9
<b>2.1.2</b>	Virtual Dual-Ported RAM . . . . .	9
<b>2.1.3</b>	Digital/Analog Converters . . . . .	9
<b>2.1.4</b>	Interface to the Piggyback Module . . . . .	10
<b>2.1.5</b>	VMEbus Interface . . . . .	10
<b>2.2</b>	Hardware Configuration . . . . .	10
<b>2.2.1</b>	Base Address . . . . .	12
<b>2.2.2</b>	Interrupt Number . . . . .	13
<b>2.2.3</b>	Port A, B, C . . . . .	13

<b>2.3.2</b>	Connector X2: Optional Digital Inputs and Outputs . . . . .	16
<b>2.4</b>	Technical Data . . . . .	17
<b>3</b>	ETAS Contact Addresses . . . . .	21
	List of Figures . . . . .	23
	List of Tables . . . . .	25
	Index . . . . .	27

## 1 Introduction

---

This section contains information about the basic features and applications of the ES1331.1 Signal Generator Board. A block diagram shows the schematic layout of the plug-in board.

### **note**

*Some components of the ES1331.1 may be damaged or destroyed by electrostatic discharges. Therefore, keep the plug-in board in its storage package until it is installed.*

*The ES1331.1 may only be taken from the storage package, configured and installed at a working place that is protected against static discharges.*

### 1.1 Features

---

The ES1331.1 Signal Generator Board is used to generate analog and digital output signals in VMEbus systems. The plug-in board has its own digital signal processor (DSP) working independently from the main processor of the VME system.

By using a DSP, the signal form of the output signal can be programmed as desired; even stringent requirements regarding the variation speeds of amplitude, frequency, and pulse width can be met with ease.

The 64Kword virtual dual-ported RAM (DPRAM) allows write/read access by both the system processor and the DSP. This memory area is intended for the exchange of programs and data between the DSP and the system processor.

Optionally, the DSP can use an additional 64-Kword EPROM as program memory. This memory area can be write-accessed by the DSP.

For analog signal generation, the plug-in board has four digital/analog converters with 12-bit resolution and a maximum conversion delay of 6  $\mu$ sec. The output voltage range is -10 V to +10 V relative to the ground potential of the VMEbus system.


The digital output signals are generated by a piggyback module providing eight counters. Every two counters form one output channel. The address, data and control lines of the DSP are passed on to the piggyback module.

The board has the following features:

- TMS320C203 digital signal processor
- 64-Kword virtual dual-ported RAM as program or data memory
- four digital/analog converters with 12-bit resolution and a max. output voltage range of -10 V to +10 V
- front panel ports for analog and digital output signals

- interrupt generation on the VME bus
- VMEbus interface
- optional 64-Kword EPROM as program or data memory
- piggyback module for digital signal generation

The following figure shows the front panel and the position of the connectors.



**Fig. 1-1** Front panel

## 1.2 Applications


The ES1331.1 Signal Generator Board is intended for use in VMEbus systems where analog and digital signal shapes of different frequencies, amplitudes, and pulse widths need to be generated. The digital signal processor (DSP) allows flexible signal generation independently from the system processor.

Sample applications are:

- generation of active or passive speed sensor signals for driving-dynamics systems
- generation of speed signals for gearbox control units

### 1.3 Block Diagram

The following figure shows a block diagram of the ES1331.1 Signal Generator Board



**Fig. 1-2** Block diagram

In the center of the block diagram, you can see the digital signal processor. To the right of the signal processor is the dual-ported RAM manager that allows access to the 128-KB RAM by the DSP and VME bus. To the left of the DSP, you can see the four digital/analog converters and the signal conditioner for the four analog outputs.

The data, address, and control signals of the DSP, as well as the digital outputs of the front panel, are passed on to a piggyback module.

The piggyback module contains eight counters in four groups that can be used to generate PWM signals with variable frequencies and pulse duty factors.



**8 Introduction**

## 2 **Hardware**

---

This section contains a detailed functional description, information about the jumpers and solder straps, the pin allocation of the connectors, and the technical data of the ES1331.1 Signal Generator Board.

### 2.1 **Functional Description**

---

This section gives you a detailed overview of the features of the ES1331.1 Signal Generator Board. You will find information on the following subjects:

- digital signal processor
- virtual dual-ported RAM
- analog/digital converter
- interface to the piggyback module
- VMEbus interface

#### 2.1.1 **Digital Signal Processor**

---

The digital signal processor TMS320C203 is used as the CPU of ES1331.1. The digital signal processor (DSP) can operate independently from the main processor of the VME system. Data are exchanged between the two processors via a virtual dual-ported RAM. The processing performance of the signal processor is 40 MIPS with a word size of 16 bits. The signal processor has an internal 544-word program or data memory.

The signal processor can be started either from an external EPROM or from the dual-ported RAM. This can be selected by jumpers.

#### 2.1.2 **Virtual Dual-Ported RAM**

---

The virtual dual-ported RAM is used for the communication between the main processor of the VME system and the digital signal processor. The two processors can access a shared RAM area of 128 KB (64 Kwords) via a dual-ported RAM manager. The dual-ported RAM manager prevents address conflicts and prioritizes the access requests.

The dual-ported RAM can be used both for data and program storage. The program of the signal processor can be loaded from the VME system processor into the dual-ported RAM; it can then be used to start the DSP.

#### 2.1.3 **Digital/Analog Converters**

---

The four digital/analog converters of the ES1331.1 have a 12-bit resolution at a maximum conversion delay of 6  $\mu$ sec. The output voltage range is -10 V to +10 V relative to the ground potential of the VME system. The output voltages of all four D/A converters can be output in sync with each other.

#### 2.1.4 Interface to the Piggyback Module

An optional piggyback module can be used to implement additional memory or peripheral functions. The address, data and control signals of the signal processor, as well as the analog output signals, are passed to the piggyback module. 13 lines run from the front panel connector to the piggyback module.

#### 2.1.5 VMEbus Interface

For the VME bus, the ES1331.1 has a slave interface with 16 or 24 address lines and 16 data lines. The base address of the board is set via hex switches. The board occupies an address range of 128 KB.


The board can generate interrupts on the VME bus. The interrupt level is selected via solder straps. The interrupt vector is set by software either from the DSP or from the system processor.

### 2.2 Hardware Configuration


This section contains the information required for configuring the jumpers of the ES1331.1 Signal Generator Board. The jumpers are used to configure the following settings:

- VMEbus base address
- interrupt number
- boot program source
- supply voltage output
- supply voltage for 12 V stand-alone mode

The figures below show the position of the jumpers and solder straps on the component and solder sides of the board.



**Fig. 2-1** Jumpers and solder straps (component side)



**Fig. 2-2** Solder straps (solder side)

**note**

*The solder straps Pa to Pd, LP8, and LP9 determine manufacturer options and may not be modified.*

### 2.2.1 Base Address

The base address of the ES1331.1 Signal Generator Board is selected by the two hex switches HEXHN and HEXLN.

The board occupies an address range of 128 KB from the base address.

**note**

*Make sure that the address range of the ES1331.1 Signal Generator Board does **not** overlap the address ranges of other boards in your system.*

Switch	Address	Default setting
HEXHN	A23 - A20	\$C
HEXLN	A19 - A18	\$0

**Tab. 2-1** Setting the base address

### 2.2.2 Interrupt number

The solder straps P1 to P10 determine the interrupt number.

Solder strap	Interrupt number	Default setting
P1	1	open
P2	2	open
P3	3	open
P4	4	open
P5	5	open
P6	6	open
P7	7	open
P8	8	open
P9	9	open
P10	10	open

**Tab. 2-2** Setting the interrupt number

**note**

*Only one of the solder straps P1 to P10 may be closed.*

### 2.2.3 Boot Program Source

Use the jumper ROMSEL to select the source of the boot program for the signal processor.

**note**

*"Boot from ROM" (pin 2 and 3 bridged) may only be set, if the ES1331.1 is equipped with an appropriate piggyback module. Without an appropriate piggyback module, there is no boot ROM available to the signal processor.*

Pin	Description
1-2	Boot from RAM
2-3	Boot from ROM (default)

**Tab. 2-3** Setting the source of the boot program

#### 2.2.4 Supply Voltage Output

Use the jumper J5 to connect the +5 V supply voltage of the VME system with pin 5 of the front panel connector X1.

Jumper	open	closed
J5	X1 pin 5 empty	X1 pin 5 set to +5 V supply voltage (default setting)

**Tab. 2-4** Selection of the supply voltage output

#### 2.2.5 Supply Voltage for 12 V Stand-Alone Mode

The ES1331.1 includes DC/DC converters allowing it to be used with the VME bus, connected only to a 12 V supply voltage.

**note**

*The jumper J6 may not be inserted if the board is operated with the VME bus.*

Jumper	open	closed
J6	Operation with VME bus (default setting)	Operation with a single 12 V supply


**Tab. 2-5** Selection of stand-alone mode

## 2.3 Pin Allocation

This section describes the pin allocations of the ES1331.1 Signal Generator Board.

### 2.3.1 Connector X1: Analog Outputs

The connector X1 includes the four analog output signals of the ES1331.1. The connector also provides a +5 V voltage supply for external assemblies.



**Fig. 2-3** Connector X1: Analog Outputs

Pin	Function	Pin	Function
1	Channel 1	2	Channel 2
3	Channel 3	4	Channel 4
5	+5 V output	6	Analog GND
7	Analog GND	8	Analog GND
9	Analog GND		Analog GND

**Tab. 2-6** Input Allocation X1: Analog Outputs


**note**

*The +5 V output voltage at pin 5 is only available when the jumper J5 is set.*



### 2.3.2 Connector X2: Optional Digital Inputs and Outputs

The connector X2 contains the 14 input and output lines of the piggyback module. The pin layout of this connector depends on the functions of the piggyback module.



**Fig. 2-4** Connector X2: Optional Inputs/Outputs

Pin	Function	Pin	Function
1	X3 Pin 1	2	X3 Pin 3
3	X3 Pin 5	4	X3 Pin 7
5	GND	6	X3 Pin 11 and -15 V DC
7	X3 Pin 13 and +15 V DC	8	V <sub>CC</sub> (DC-DC converter)
9	X3 Pin 2	10	X3 Pin 4
11	X3 Pin 6	12	X3 Pin 8
13	X3 Pin 10	14	X3 Pin 12
15	X3 Pin 14		

**Tab. 2-7** Pin Allocation X2: Optional Inputs/Outputs

## 2.4 Technical Data

This section contains the technical data of the ES1331.1 Signal Generator Board in tabular form.

### *Digital Signal Processor*

Type	TMS320C203
Cycle time	25 nsec
Word length	16 bits
Program/data storage	544 words internally

### *Analog Outputs*

Resolution	12 bits
Voltage range	-10 V to +10 V
Max. conversion delay	6 $\mu$ sec
Number of channels	4
Max. data rate	166 k samples/sec
Max. output current	10 mA
Transient time	14 $\mu$ sec (0.1% at 10 V step)

### *Digital Outputs*

Number of counters	4 11-bit counters 4 5-bit counters
Number of output channels	4
Signal level	5 V

### *Dual-Ported RAM*

---

Size	64 Kwords
Access time	50 nsec 150 nsec with interrupts from VME bus

---

### *Flash-EPROM*

---

Size	64 Kwords
Access time	120 nsec
Programmability	by DSP

---

### *VMEbus*

---

Type	Slave interface
Address and data lines	24 bits address and 16 bits data
Base address	\$000000 to \$FE0000 selected by hex switches
Address range	128 KB
Address modifier	Standard or short supervisor/user data
Interrupt	Single Level, IRQ 1 to 10 IRQ level, interrupt vector, and source selected by jumpers
Interrupt source	DSP program

---

### *Power Supply*

---

VME bus mode	5 V DC, $\pm 5\%$ , max. 700 mA 12 V DC, $\pm 5\%$ , max. 200 mA
Stand-alone mode	12 V DC, $\pm 5\%$ , max. 900 mA

---

### *Environmental Conditions*

---

Ambient temperature during operation	0 °C to +70 °C (standard)
Storage temperature	-55 °C to +85 °C
Relative humidity	0 to 90%, no condensation

### *Connectors*

---

Backplane	96-pin DIN 41612 C
Front panel	Analog: 9-pin Submin-D, piggyback module: 15-pin Submin-D

### *Physical Dimensions*

---

Circuit board	100 x 160 mm <sup>2</sup>
Front panel	Height: 3 U Width: 4 HP (20.3 mm)



### 3 **ETAS Contact Addresses**

---

#### *ETAS HQ*

---

##### **ETAS GmbH**

Borsigstr. 14	Phone:	+49 (711) 8 96 61-0
70469 Stuttgart	Fax:	+49 (711) 8 96 61-105
Germany	E-mail:	sales@etas.de
	WWW:	www.etas.de

#### *France*

---

##### **ETAS SAS**

1, place des Etats-Unis	Phone:	+33 (1) 56 70 00 50
SILIC 310	Fax:	+33 (1) 56 70 00 51
94588 Rungis Cedex	E-mail:	sales@etas.fr
France	WWW:	www.etas.fr

#### *Great Britain*

---

##### **ETAS Engineering Tools Application and Services Ltd.**

Studio 3, Waterside Court	Phone:	+44 (0) 1283 - 546512
3rd Avenue, Centrum 100	Fax:	+44 (0) 1283 - 548767
Burton-upon-Trent	E-mail:	sales@etas-uk.net
Staffordshire DE14 2WQ	WWW:	www.etas-uk.net
England		

#### *Japan*

---

##### **ETAS K.K.**

9-1, Ushikubo 3-chome,	Phone:	+81 (45) 912-9550
Tsuzuki-ku	Fax:	+81 (45) 912-9552
Yokohama 224-0012	E-mail:	sales@etas.co.jp
Japan	WWW:	www.etas.co.jp

*Korea*

---

**ETAS Korea Co. Ltd.**

3F, Samseung Bldg.	Phone:	+82 (2) 5747 016
61-1, Yangjae-dong	Fax:	+82 (2) 5747 120
Seocho-gu	E-mail:	sungik.hong@etas.co.kr
Seoul		
Republic of Korea		

*North America*

---

**ETAS Inc.**

3021 Miller Road	Phone:	+1 (888) ETAS INC
Ann Arbor, MI 48103	Fax:	+1 (734) 997-9449
USA	E-mail:	sales@etasinc.com
	WWW:	www.etasinc.com

*South America*

---

**UNIT**

Av. Cel Amancio Bueno, 30	Phone:	+55 (19) 3242 0620
Jd. Chapadao	Fax:	+55 (19) 3241 96 96
Campinas SP 13066 740	E-mail:	unit@mpc.com.br
Brazil		

---

## List of Figures

<b>Fig. 1-1</b>	Front panel .....	6
<b>Fig. 1-2</b>	Block diagram .....	7
<b>Fig. 2-1</b>	Jumpers and solder straps (component side).....	11
<b>Fig. 2-2</b>	Solder straps (solder side) .....	12
<b>Fig. 2-3</b>	Connector X1: Analog Outputs .....	15
<b>Fig. 2-4</b>	Connector X2: Optional Inputs/Outputs .....	16





---

## List of Tables

<b>Tab. 2-1</b>	Setting the base address .....	13
<b>Tab. 2-2</b>	Setting the interrupt number.....	13
<b>Tab. 2-3</b>	Setting the source of the boot program .....	14
<b>Tab. 2-4</b>	Selection of the supply voltage output .....	14
<b>Tab. 2-5</b>	Selection of stand-alone mode.....	14
<b>Tab. 2-6</b>	Input Allocation X1: Analog Outputs.....	15
<b>Tab. 2-7</b>	Pin Allocation X2: Optional Inputs/Outputs.....	16



---

# Index

## A

Analog outputs 17  
Applications 6

## B

Base address 12  
Block diagram 7  
BU5 15

## C

Configuration 10  
Connectors 19  
    BU5 15

## D

Data  
    analog input 17

## E

Environmental conditions 19  
EPROM 18

## F

Features 5  
Flash-EPROM 18  
Front panel 6  
Functional description 9

## I

Interface  
    VMEbus 10  
Interrupt 10

## **R**

RAM 18

## **S**

Signal processor 17

Solder straps 11

## **T**

Technical data 17

## **V**

VMEbus 18

VMEbus interface 10



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)