



Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

*InstraView*SM REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at www.instraview.com ↗

WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. www.artisanng.com/WeBuyEquipment ↗

LOOKING FOR MORE INFORMATION?

Visit us on the web at www.artisanng.com ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

Contact us: (888) 88-SOURCE | sales@artisanng.com | www.artisanng.com

U S E R ' S M A N U A L

ACTIVE MODULE CARRIER

MODEL
VX402C-64

COPYRIGHT

C&H Technologies, Inc. (C&H) provides this manual "as is" without warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. C&H may make improvements and/or changes in the product(s) and/or program(s) described in this manual at any time and without notice.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of this publication.

Copyright © 2002, 2008 by C&H Technologies, Inc.

The information and/or drawings set forth in this document and all rights in and to inventions disclosed herein which might be granted thereon disclosing or employing the materials, methods, techniques or apparatus described herein, are the exclusive property of C&H Technologies, Inc.

A Reader's Comment Form is provided at the back of this publication. If this form has been removed address comments to:

C&H Technologies, Inc.
Technical Publications
445 Round Rock West Drive
Austin, Texas 78681-5012

Or visit our web site for support information at:

<http://www.chtech.com>.

C&H may use or distribute any of the information you supply in any way that it believes appropriate without incurring any obligations.

AMENDMENT NOTICE

C&H Technologies, Inc. makes every attempt to provide up-to-date manuals with the associated equipment. Occasionally, changes are made to the equipment wherein it is necessary to provide amendments to the manual. If any amendments are provided for this manual they are printed on colored paper and will be provided with the module and manual. Manual updates may also be found on our web site at www.chtech.com.

NOTE

The contents of any amendment may affect operation, maintenance, or calibration of the equipment.

REVISION HISTORY

| <u>Rev</u> | <u>Date</u> | <u>Description</u> |
|------------|-------------|---|
| * | 03-20-2002 | Original release |
| A | 09-13-2004 | Corrected Figure A-3 (J1) & A-4 (J2) Pin Configurations |
| B | 07-10-2008 | Added -0003 and -0004 version information Clarified Electrical information (Section 1.2.2) Clarified Pass-Through Cable information (Section 3.3.3) |

INTRODUCTION

This manual describes the operation and use of the C&H Model VX402C-64 VXI Active Carrier Module (Part Number 11028500 Revision B or higher). This VXI module is one of a number of test and data acquisition/control modules in the VME and VXI format provided by C&H.

Contained within this manual are the physical and electrical specifications, installation and startup procedures, functional description, and configuration guidelines to adequately use the product.

The part numbers covered by this manual are:

| <u>Part Number</u> | <u>Description</u> |
|--------------------|---|
| 11028500-0001 | VX402C-64 (with +3.3V supplied from VXI +5V) |
| 11028500-0002 | VX402C-64 (without +3.3V supply) |
| 11028500-0003 | VX402C-64 (with +3.3V supplied from VXI -24V) |
| 11028500-0004 | VX402C-64 (with +3.3V supplied from VXI +24V) |

TABLE OF CONTENTS

| | |
|--------------------------------------|-----|
| 1.0 GENERAL DESCRIPTION | 7 |
| 1.1 PURPOSE OF EQUIPMENT..... | 7 |
| 1.2 SPECIFICATIONS OF EQUIPMENT..... | 8 |
| 1.2.1 Key Features | 8 |
| 1.2.2 Electrical | 8 |
| 1.2.3 Mechanical..... | 10 |
| 1.2.4 Environmental..... | 10 |
| 1.2.5 Bus Compliance | 10 |
| 2.0 INSTALLATION | 11 |
| 2.1 UNPACKING AND INSPECTION | 11 |
| 2.2 HANDLING PRECAUTIONS..... | 11 |
| 2.3 INSTALLATION | 11 |
| 2.4 PREPARATION FOR RESHIPMENT..... | 11 |
| 3.0 FUNCTIONAL DESCRIPTION | 13 |
| 3.1 GENERAL | 13 |
| 3.2 TRIGGERS..... | 14 |
| 3.2.1 TTL TRIGGERS | 14 |
| 3.2.2 ECL TRIGGERS..... | 15 |
| 3.3 CONNECTORS..... | 15 |
| 3.3.1 VXI REAR Connectors..... | 15 |
| 3.3.2 VME-64 FRONT CONNECTORS..... | 15 |
| 3.3.3 PASS-THROUGH CONNECTORS | 16 |
| 3.4 SUMBUS CONFIGURATION | 18 |
| 3.4.1 SUMBUS CUSTOM AREA | 18 |
| 3.4.2 SUMBUS JUMPER SETTINGS..... | 19 |
| 4.0 OPERATING INSTRUCTIONS | 21 |
| APPENDIX A - CONNECTORS..... | A-1 |

LIST OF FIGURES

| | |
|---|----|
| Figure 1. Front Panel and Top View (Top Shield Not Shown) | 7 |
| Figure 2. Power Schematic (-0001 version)..... | 8 |
| Figure 3. Power Schematic (-0002 version)..... | 9 |
| Figure 4. Power Schematic (-0003 & -0004 versions)..... | 9 |
| Figure 5. Functional Block Diagram | 13 |
| Figure 6. TTL Trigger Direction..... | 14 |
| Figure 7. ECL Trigger Direction | 15 |
| Figure 8. Pass-Through Connector Location | 16 |
| Figure 9. SUMBUS Custom Area..... | 18 |
| Figure 10. SUMBUS Jumper Settings..... | 19 |

LIST OF TABLES

| | |
|--|----|
| Table I. Power Supply Capabilities..... | 10 |
| Table II. VXI/VME Pass-Through Connections | 17 |

1.0 GENERAL DESCRIPTION

The VX402C-64 Active Carrier allows an A- or B-size VME, VXI, or VME64 module to be used in a C-size VXI mainframe chassis. Throughout the rest of this manual, the VME/VXI card being carried will be referred to as the VME module.

The carrier provides an actively-buffered electrical interface for the standard VME bus signals. The VX402C-64 does not support the full VME64 extension bus; however, -0001, -0003, and -0004 versions provide +3.3V power to the P1 row D VME64 extension. The adapter also features a VXI C-size mechanical enclosure to support and shield the VME module. The carrier and its enclosure have been designed so that the front panel of the VME module sits flush with the front panels of other C-size modules as shown in Figure 1.

The VX402C-64 supports interrupts and provides a capability for bringing P2 VME signals to the front panel. The carrier also supports VXI VXITTL triggers and a prototype area is provided for buffering the VXI SUMBUS signal. These features allow the VME module to transparently interface to a C-size chassis.




Figure 1. Front Panel and Top View (Top Shield Not Shown)

1.1 PURPOSE OF EQUIPMENT

This VX402C-64 was designed to provide an interface for using B-size VME modules in a VXI C-size chassis. The active nature of the module allows extensions of the VXI bus without violation of VME/VXI electrical bus standards.

1.2 SPECIFICATIONS OF EQUIPMENT

1.2.1 Key Features

- Provides direct access to the VME module's front panel I/O connections
- Supplies buffered data, address, interrupt, and trigger lines (ECL and TTL)
- Includes direct SUMBUS connections, as well as a prototyping area with fused $\pm 12\text{V}$ power supplies for buffered SUMBUS connections (jumper selectable)
- Conforms with VMEbus/VXIbus driving and loading specifications
- Provides VME64 +3.3V supplies (-0001, -0003, and -0004 versions only)
- Mates with VXI, VME, and VME64 rear connectors

1.2.2 Electrical

The -0001, -0003, and -0004 versions provide +3.3V power to the P1 row D VME64 extension. The -0002 version does not provide +3.3V power. A simplified power schematic for each version is shown in Figure 2, Figure 3, and Figure 4. Excluding the +3.3V supply, the VX402C-64 only requires 300mA of +5V power from the VXI backplane. This power requirement is for the VX402C-64 alone. Any attached module will increase this value by the amount specified in its data sheet.

Table I provides a summary of the supply capabilities of each version. The table assumes that the VXI backplane is capable providing 1.2A on each of the seven +5V power pins. For versions -0003 and -0004, 1.2A on the -24V and +24V pins.




Figure 2. Power Schematic (-0001 version)




Figure 3. Power Schematic (-0002 version)




Figure 4. Power Schematic (-0003 & -0004 versions)

Table I. Power Supply Capabilities

| | VX402C-64 Version | | | |
|-------------------------------------|-------------------|----------|----------|----------|
| | -0001 | -0002 | -0003 | -0004 |
| VXI +5V Supply Capability | 42.0W | 42.0W | 42.0W | 42.0W |
| VXI +24V Supply Capability | not used | not used | not used | 29W |
| VXI -24V Supply Capability | not used | not used | 29W | not used |
| Internal +5V Power Consumption | 1.5W | 1.5W | 1.5W | 1.5W |
| Remaining +5V Power Available | 40.5W | 40.5W | 40.5W | 40.5W |
| | | | | |
| +3.3V Converter Efficiency | 92% | n/a | 80% | 80% |
| +5V Power Available to VME Module | 37W Total | 40.5W | 40.5W | 40.5W |
| +3.3V Power Available to VME Module | | 0W | 23W | 23W |

n/a = not applicable

1.2.3 Mechanical

The mechanical dimensions of the VX402C-64 are in conformance with the VXI bus specification for the height and width of Size-C modules. The nominal dimensions are 233.35 mm (9.187 in) high x 156.337 mm (6.155 in) deep. Once the VX402C-64 is adapted to a VME module, the total dimensions are 233.35 mm (9.187 in) high x 340.0 mm (13.386 in) deep. The module is designed for a mainframe with 30.48 mm (1.2 in) spacing between slots.

1.2.4 Environmental

The environmental specifications of the module are:

Operating Temperature: 0°C to +55°C
Storage Temperature: -40°C to +75°C
Humidity: <95% without condensation

1.2.5 Bus Compliance

The module complies with the VXIbus Specification Revision 1.4 and with VMEbus Specification ANSI/IEEE STD 1014-1987, IEC 821 and IEC 822.

Module: VME to VXI Extender
Device Type: Active Carrier

2.0 INSTALLATION

2.1 UNPACKING AND INSPECTION

In most cases the VX402C-64 is individually sealed and packaged for shipment. Verify that there has been no damage to the shipping container. If damage exists then the container should be retained as it will provide evidence of carrier caused problems. Such problems should be reported to the carrier immediately as well as to C&H. If there is no damage to the shipping container, carefully remove the module from its box and anti static bag and inspect for any signs of physical damage. If damage exists, report immediately to C&H.

2.2 HANDLING PRECAUTIONS

The VX402C-64 contains components that are sensitive to electrostatic discharge. When handling the module for any reason, do so at a static-controlled workstation, whenever possible. At a minimum, avoid work areas that are potential static sources, such as carpeted areas. Avoid unnecessary contact with the components on the module.

2.3 INSTALLATION

CAUTION: Read the entire User's Manual before proceeding with the installation and application of power.

If necessary, remove the shield from the VX402C-64 and configure the switches and jumpers. Replace the shield and insert the carrier into the appropriate slot according to the desired priority. Insert the VME module through the front panel of the VX402C-64. Push firmly until the VME module's rear connectors are fully inserted into the front connector of the VX402C-64. Apply power. If no obvious problems exist, proceed to communicate with the VME module.

The VX402C-64 connectors require high insertion force to completely connect with the VME module. If it is difficult to assemble the unit through the front panel, it is recommended that the VX402C-64 shield be removed, and the boards be mated before insertion into the chassis.

2.4 PREPARATION FOR RESHIPMENT

If the module is to be shipped separately it should be enclosed in a suitable water and vapor proof anti static bag. Heat seal or tape the bag to insure a moisture-proof closure. When sealing the bag, keep trapped air volume to a minimum.

The shipping container should be a rigid box of sufficient size and strength to protect the equipment from damage. If the module was received separately from a C&H system, then the original module shipping container and packing material may be re-used if it is still in good condition.

3.0 FUNCTIONAL DESCRIPTION

3.1 GENERAL

VX402C-64 is a general purpose carrier module for VXI C-Size chassis. The module provides actively buffered signals, which meet all VME specifications, to the VME module. A functional block diagram is shown in Figure 5.




Figure 5. Functional Block Diagram

3.2 TRIGGERS

Both ECL and TTL triggers are supplied through the VX402C-64. There are switches on the carrier which are used to set the direction of the triggers (to the backplane and from the backplane).

3.2.1 TTL TRIGGERS

Eight TTL Trigger lines pass through the VX402C-64 to the front panel: TTLTRG0-7. Each trigger line may be set as an input or output trigger. The trigger direction is set using switch S1 which can be seen in Figure 6. The directions are also clearly marked on the board itself.




Figure 6. TTL Trigger Direction

3.2.2 ECL TRIGGERS

The VX402C-64 supports two ECL Trigger lines: ECLTRG0-1. Each trigger line may be set as an input or output trigger. The trigger direction is set using switch S2 which can be seen in Figure 7. The trigger directions are clearly marked on the board itself.




Figure 7. ECL Trigger Direction

3.3 CONNECTORS

3.3.1 VXI REAR Connectors

The P1 and P2 connectors are configured in accordance with the VXI specification and utilize the ECL and TTL trigger lines. Pinout details for the rear connectors can be found in Appendix A.

3.3.2 VME-64 FRONT CONNECTORS

The VX402C-64 interfaces with the VME module through two 160 pin VME-64 connectors: J1 and J2. These connectors conform to VME and VXI specifications and can accept both 160 pin VME-64 (DIN 41 612 type C) and standard 96 pin VME/VXI connectors. Pinout details for the front connectors can be found in Appendix A.

3.3.3 PASS-THROUGH CONNECTORS

One major difference between the VME bus and the VXI bus is that the outer rows of the P2 connector are not defined on the VME bus and they are defined on the VXI bus. For this reason, the VX402C-64 Active Module Carrier provides a Pass-Through Connector system that be used to optionally connect or not connect the VME P2 Rows A & C signals to the VXI P2 Rows A & C signals.

The VX402C-64 can be shipped with an optional pass-through connector cable (11028508-0001). This cable is used to make internal connections between the P2 and J2 connectors on the VX402C-64. When the cable is installed, signals on the J2 connector of the VME module are routed to signals on the P2 connector of the backplane. Only use this cable for modules which utilize the outer rows on the J2 connector and completely adhere to the VXI specification. If the VME module has no outer row connections, it is unnecessary to install the cable.

If the VME module has P2 signals which do not conform to the VXI spec, it may be necessary to make a custom pass-through cable. Also, if the VME module does not support the outer row of the J2 connector, a longer cable may be used to directly access these signals. Pinout details for the pass-through connectors can be found in Appendix A. Figure 8 shows the placement of the pass-through connectors on the VX402C-64.




Figure 8. Pass-Through Connector Location

A one-to-one cable that connects Pin 1 (C32) on the VXI side to Pin 1 (C32) on the VME side, and so on, could only be used if the VME module was designed to meet all of the VXI bus specifications for these pins. If the installed VME module can not handle -24V, +24V, -5.2V or any other signal on the corresponding pin, then a one-to-one cable can not be used.

The signal list for both the VXI side and the VME side is shown in Table II. The pass-through connectors on the PCB are standard 64-pin (32x2) shrouded headers, specifically Samtec TST-132-01-S-D. Mating connectors are very common in both IDC and discreet wire varieties.

Table II. VXI/VME Pass-Through Connections

| VXI SIDE PASS-THROUGH CONNECTOR | | | | | | VME SIDE PASS-THROUGH CONNECTOR | | | | | |
|---------------------------------|-----|----------|-----|-----|----------|---------------------------------|-----|----------|-----|-----|----------|
| PN | P2 | SIGNAL | PIN | P2 | SIGNAL | PN | P2 | SIGNAL | PIN | P2 | SIGNAL |
| 1 | C32 | -24V | 2 | A32 | SUMBUS | 1 | C32 | USER DEF | 2 | A32 | USER DEF |
| 3 | C31 | +24V | 4 | A31 | GND | 3 | C31 | USER DEF | 4 | A31 | USER DEF |
| 5 | C30 | GND | 6 | A30 | MODID | 5 | C30 | USER DEF | 6 | A30 | USER DEF |
| 7 | C29 | RSV3 | 8 | A29 | RSV2 | 7 | C29 | USER DEF | 8 | A29 | USER DEF |
| 9 | C28 | GND | 10 | A28 | GND | 9 | C28 | USER DEF | 10 | A28 | USER DEF |
| 11 | C27 | TTLTRG7* | 12 | A27 | TTLTRG6* | 11 | C27 | USER DEF | 12 | A27 | USER DEF |
| 13 | C26 | TTLTRG5* | 14 | A26 | TTLTRG4* | 13 | C26 | USER DEF | 14 | A26 | USER DEF |
| 15 | C25 | GND | 16 | A25 | +5V | 15 | C25 | USER DEF | 16 | A25 | USER DEF |
| 17 | C24 | TTLTRG3* | 18 | A24 | TTLTRG2* | 17 | C24 | USER DEF | 18 | A24 | USER DEF |
| 19 | C23 | TTLTRG1* | 20 | A23 | TTLTRG0* | 19 | C23 | USER DEF | 20 | A23 | USER DEF |
| 21 | C22 | GND | 22 | A22 | GND | 21 | C22 | USER DEF | 22 | A22 | USER DEF |
| 23 | C21 | LBUSC11 | 24 | A21 | LBUSA11 | 23 | C21 | USER DEF | 24 | A21 | USER DEF |
| 25 | C20 | LBUSC10 | 26 | A20 | LBUSA10 | 25 | C20 | USER DEF | 26 | A20 | USER DEF |
| 27 | C19 | -5.2V | 28 | A19 | -5.2V | 27 | C19 | USER DEF | 28 | A19 | USER DEF |
| 29 | C18 | LBUSC09 | 30 | A18 | LBUSA09 | 29 | C18 | USER DEF | 30 | A18 | USER DEF |
| 31 | C17 | LBUSC08 | 32 | A17 | LBUSA08 | 31 | C17 | USER DEF | 32 | A17 | USER DEF |
| 33 | C16 | GND | 34 | A16 | GND | 33 | C16 | USER DEF | 34 | A16 | USER DEF |
| 35 | C15 | LBUSC07 | 36 | A15 | LBUSA07 | 35 | C15 | USER DEF | 36 | A15 | USER DEF |
| 37 | C14 | LBUSC06 | 38 | A14 | LBUSA06 | 37 | C14 | USER DEF | 38 | A14 | USER DEF |
| 39 | C13 | -2V | 40 | A13 | -5.2V | 39 | C13 | USER DEF | 40 | A13 | USER DEF |
| 41 | C12 | LBUSC05 | 42 | A12 | LBUSA05 | 41 | C12 | USER DEF | 42 | A12 | USER DEF |
| 43 | C11 | LBUSC04 | 44 | A11 | LBUSA04 | 43 | C11 | USER DEF | 44 | A11 | USER DEF |
| 45 | C10 | GND | 46 | A10 | GND | 45 | C10 | USER DEF | 46 | A10 | USER DEF |
| 47 | C9 | LBUSC03 | 48 | A9 | LBUSA03 | 47 | C9 | USER DEF | 48 | A9 | USER DEF |
| 49 | C8 | LBUSC02 | 50 | A8 | LBUSA02 | 49 | C8 | USER DEF | 50 | A8 | USER DEF |
| 51 | C7 | GND | 52 | A7 | -5.2V | 51 | C7 | USER DEF | 52 | A7 | USER DEF |
| 53 | C6 | LBUSC01 | 54 | A6 | LBUSA01 | 53 | C6 | USER DEF | 54 | A6 | USER DEF |
| 55 | C5 | LBUSC00 | 56 | A5 | LBUSA00 | 55 | C5 | USER DEF | 56 | A5 | USER DEF |
| 57 | C4 | -5.2V | 58 | A4 | GND | 57 | C4 | USER DEF | 58 | A4 | USER DEF |
| 59 | C3 | GND | 60 | A3 | ECLTRG1 | 59 | C3 | USER DEF | 60 | A3 | USER DEF |
| 61 | C2 | CLK10- | 62 | A2 | -2V | 61 | C2 | USER DEF | 62 | A2 | USER DEF |
| 63 | C1 | CLK10+ | 64 | A1 | ECLTRG0 | 63 | C1 | USER DEF | 64 | A1 | USER DEF |

To use the VXI TTLTRG signals, a custom cable should be used that connects each TTLTRG signal to the desired VME P2 connector signal. The VX402C-64 has a set of eight switches that are set to specify the direction of the trigger signal as shown Figure 6. If the trigger signal is an input to the VME module, the switch should be ON (closed). If the trigger signal is output from the VME module, the switch should be OFF (open).

3.4 SUMBUS CONFIGURATION

The VX402C-64 provides a direct connection of the SUMBUS signal through the pass-through connector to the front connectors. The board also has a prototyping area so that the user can hardwire a custom buffer for the SUMBUS signal.

3.4.1 SUMBUS CUSTOM AREA

The SUMBUS custom area consists of a prototyping grid, $\pm 12V$ supplies, and two jumpers for configuring the signal. The prototyping area is a 10x10 grid of 0.1" spaced through-hole pads which can be used in any way desired. The SUMBUS signal can be wired to the prototyping area using the two pads next to jumpers J21 and J13, and the jumpers must be configured to the proper setting. The location of the custom area can be seen in Figure 9.




Figure 9. SUMBUS Custom Area

3.4.2 SUMBUS JUMPER SETTINGS

In order to use the SUMBUS signal, the jumpers J11 and J12 must be configured properly. The three different settings for the jumpers can be seen in Figure 10. The SUMBUS signal can be connected directly to the front panel (A), connected through the prototyping area (B), or disconnected (C).

The pass-through connector must be installed for the SUMBUS signal to route to the front panel. Also, both jumpers must be configured the same, or the SUMBUS signal will be disconnected.




Figure 10. SUMBUS Jumper Settings

4.0 OPERATING INSTRUCTIONS

While the VX402C-64 is an active carrier, it is designed to be completely transparent to the host interface. For this reason, the VME module can be accessed as if it were plugged directly into the host backplane.

In order to operate the VME module, first set up the hardware configurations on the VX402C-64. Then set the necessary trigger directions using the switches. Ensure the jumpers are set for proper SUMBUS signal routing. Install or remove the pass-through connector cable as desired and replace the shield if necessary.

The unit is now ready to be inserted into the chassis. Next, install the VME module into the front connectors of the VX402C-64. Once power is applied, the VME module can be readily accessed as if it were plugged directly in the backplane.

APPENDIX A - CONNECTORS

| PIN | C | B | A |
|-----|-----------|---------|----------|
| 1 | D08 | - | D00 |
| 2 | D09 | - | D01 |
| 3 | D10 | ACFAIL* | D02 |
| 4 | D11 | BGIN0* | D03 |
| 5 | D12 | BGOUT0* | D04 |
| 6 | D13 | BGIN1* | D05 |
| 7 | D14 | BGOUT1* | D06 |
| 8 | D15 | BGIN2* | D07 |
| 9 | GND | BGOUT2* | GND |
| 10 | SYSFAIL* | BGIN3* | SYSCLK |
| 11 | BERR* | BGOUT3* | GND |
| 12 | SYSRESET* | - | DS1* |
| 13 | LWORD* | - | DS0* |
| 14 | AM5 | - | WRITE* |
| 15 | A23 | - | GND |
| 16 | A22 | AM0 | DTACK* |
| 17 | A21 | AM1 | GND |
| 18 | A20 | AM2 | AS* |
| 19 | A19 | AM3 | GND |
| 20 | A18 | GND | IACK* |
| 21 | A17 | - | IACKIN* |
| 22 | A16 | - | IACKOUT* |
| 23 | A15 | GND | AM4 |
| 24 | A14 | IRQ7* | A07 |
| 25 | A13 | IRQ6* | A06 |
| 26 | A12 | IRQ5* | A05 |
| 27 | A11 | IRQ4* | A04 |
| 28 | A10 | IRQ3* | A03 |
| 29 | A09 | IRQ2* | A02 |
| 30 | A08 | IRQ1* | A01 |
| 31 | +12 V | +5VSTBY | -12 V |
| 32 | +5 V | +5 V | +5 V |

Figure A-1. P1 Pin Configuration

NOTE: BGINx tied directly to BGOUTx

| PIN | C | B | A |
|-----|----------|------|----------|
| 1 | CLK10+ | +5V | ECLTRG0 |
| 2 | CLK10- | GND | -2V |
| 3 | GND | RSV1 | ECLTRG1 |
| 4 | -5.2V | A24 | GND |
| 5 | LBUSC00 | A25 | LBUSA00 |
| 6 | LBUSC01 | A26 | LBUSA01 |
| 7 | GND | A27 | -5.2V |
| 8 | LBUSC02 | A28 | LBUSA02 |
| 9 | LBUSC03 | A29 | LBUSA03 |
| 10 | GND | A30 | GND |
| 11 | LBUSC04 | A31 | LBUSA04 |
| 12 | LBUSC05 | GND | LBUSA05 |
| 13 | -2V | +5V | -5.2V |
| 14 | LBUSC06 | D16 | LBUSA06 |
| 15 | LBUSC07 | D17 | LBUSA07 |
| 16 | GND | D18 | GND |
| 17 | LBUSC08 | D19 | LBUSA08 |
| 18 | LBUSC09 | D20 | LBUSA09 |
| 19 | -5.2V | D21 | -5.2V |
| 20 | LBUSC10 | D22 | LBUSA10 |
| 21 | LBUSC11 | D23 | LBUSA11 |
| 22 | GND | GND | GND |
| 23 | TTLTRG1* | D24 | TTLTRG0* |
| 24 | TTLTRG3* | D25 | TTLTRG2* |
| 25 | GND | D26 | +5V |
| 26 | TTLTRG5* | D27 | TTLTRG4* |
| 27 | TTLTRG7* | D28 | TTLTRG6* |
| 28 | GND | D29 | GND |
| 29 | RSV3 | D30 | RSV2 |
| 30 | GND | D31 | MODID |
| 31 | +24V | GND | GND |
| 32 | -24V | +5V | SUMBUS |

Figure A-2. P2 Pin Configuration

| PIN | D | C | B | A | Z |
|-----|-------|------------|----------|-----------|-----|
| 1 | - | BD08 | - | BD00 | - |
| 2 | GND | BD09 | - | BD01 | GND |
| 3 | - | BD10 | BACFAIL* | BD02 | - |
| 4 | - | BD11 | IN0* | BD03 | GND |
| 5 | - | BD12 | OUT0* | BD04 | - |
| 6 | - | BD13 | IN1* | BD05 | GND |
| 7 | - | BD14 | OUT1* | BD06 | - |
| 8 | - | BD15 | IN2* | BD07 | GND |
| 9 | - | GND | OUT2* | GND | - |
| 10 | - | BSYSFAIL* | IN3* | BSYSCLK | GND |
| 11 | - | BBERR* | OUT3* | GND | - |
| 12 | +3.3V | BSYSRESET* | - | BDS1* | GND |
| 13 | - | BLWORD* | - | BDS0* | - |
| 14 | +3.3V | BAM5 | - | BWRITE* | GND |
| 15 | - | BA23 | - | GND | - |
| 16 | +3.3V | BA22 | BAM0 | BDTACK* | GND |
| 17 | - | BA21 | BAM1 | GND | - |
| 18 | +3.3V | BA20 | BAM2 | BAS* | GND |
| 19 | - | BA19 | BAM3 | GND | - |
| 20 | +3.3V | BA18 | GND | BLACK* | GND |
| 21 | - | BA17 | - | BLACKIN* | - |
| 22 | +3.3V | BA16 | - | BLACKOUT* | GND |
| 23 | - | BA15 | GND | BAM4 | - |
| 24 | +3.3V | BA14 | BIRQ7* | BA07 | GND |
| 25 | - | BA13 | BIRQ6* | BA06 | - |
| 26 | +3.3V | BA12 | BIRQ5* | BA05 | GND |
| 27 | - | BA11 | BIRQ4* | BA04 | - |
| 28 | +3.3V | BA10 | BIRQ3* | BA03 | GND |
| 29 | - | BA09 | BIRQ2* | BA02 | - |
| 30 | +3.3V | BA08 | BIRQ1* | BA01 | GND |
| 31 | GND | +12 V | +5VSTBY | -12 V | - |
| 32 | - | +5 V | +5 V | +5 V | GND |

Figure A-3. J1 Pin Configuration

NOTES:

1. INx tied directly to OUTx.
2. +3.3V supplied on Version -0001 only

| PIN | D | C | B | A | Z |
|-----|-----|-----------|------|-----------|-----|
| 1 | - | CLK10+n | +5V | BECLTRG0 | - |
| 2 | - | CLK10-n | GND | -2V2 | GND |
| 3 | - | GND14 | RSV1 | BECLTRG1 | - |
| 4 | - | -5.2V5 | BA24 | GND13 | GND |
| 5 | - | LBUSC00n | BA25 | LBUSA00n | - |
| 6 | - | LBUSC01n | BA26 | LBUSA01n | GND |
| 7 | - | GND12 | BA27 | -5.2V4 | - |
| 8 | - | LBUSC02n | BA28 | LBUSA02n | GND |
| 9 | - | LBUSC03n | BA29 | LBUSA03n | - |
| 10 | - | GND10 | BA30 | GND11 | GND |
| 11 | - | LBUSC04n | BA31 | LBUSA04n | - |
| 12 | - | LBUSC05n | GND | LBUSA05n | GND |
| 13 | - | -2V1 | +5V | -5.2V3 | - |
| 14 | - | LBUSC06n | BD16 | LBUSA06n | GND |
| 15 | - | LBUSC07n | BD17 | LBUSA07n | - |
| 16 | - | GND08 | BD18 | GND09 | GND |
| 17 | - | LBUSC08n | BD19 | LBUSA08n | - |
| 18 | - | LBUSC09n | BD20 | LBUSA09n | GND |
| 19 | - | -5.2V1 | BD21 | -5.2V2 | - |
| 20 | - | LBUSC10n | BD22 | LBUSA10n | GND |
| 21 | - | LBUSC11n | BD23 | LBUSA11n | - |
| 22 | - | GND06 | GND | GND07 | GND |
| 23 | - | BTTLTRG1* | BD24 | BTTLTRG0* | - |
| 24 | - | BTTLTRG3* | BD25 | BTTLTRG2* | GND |
| 25 | - | GND05 | BD26 | +5Vn | - |
| 26 | - | BTTLTRG5* | BD27 | BTTLTRG4* | GND |
| 27 | - | BTTLTRG7* | BD28 | BTTLTRG6* | - |
| 28 | - | GND03 | BD29 | GND04 | GND |
| 29 | - | RSV3n | BD30 | RSV2n | - |
| 30 | - | GND02 | BD31 | MODIDn | GND |
| 31 | GND | +24Vn | GND | GND01 | - |
| 32 | - | -24Vn | +5V | BSUMBUSn | GND |

Figure A-4. J2 Pin Configuration

NOTES:

1. Signals on Rows A & C are only connected, if the pass-through cable is installed.
2. +3.3V supplied on Version -0001 only

| TO FRONT CONNECTOR J2 | | | |
|-----------------------|------------|-----|------------|
| PIN | | PIN | |
| 1 | -24Vn | 2 | BSUMBUSn |
| 3 | +24Vn | 4 | GND01 |
| 5 | GND02 | 6 | MODIDn |
| 7 | RSV3n | 8 | RSV2n |
| 9 | GND03 | 10 | GND04 |
| 11 | BTTLTRG7*n | 12 | BTTLTRG6*n |
| 13 | BTTLTRG5*n | 14 | BTTLTRG4*n |
| 15 | GND05 | 16 | +5Vn |
| 17 | BTTLTRG3*n | 18 | BTTLTRG2*n |
| 19 | BTTLTRG1*n | 20 | BTTLTRG0*n |
| 21 | GND06 | 22 | GND07 |
| 23 | LBUSC11n | 24 | LBUSA11n |
| 25 | LBUSC10n | 26 | LBUSA10n |
| 27 | -5.2V1 | 28 | -5.2V2 |
| 29 | LBUSC09n | 30 | LBUSA09n |
| 31 | LBUSC08n | 32 | LBUSA08n |
| 33 | GND08 | 34 | GND09 |
| 35 | LBUSC07n | 36 | LBUSA07n |
| 37 | LBUSC06n | 38 | LBUSA06n |
| 39 | -2V1 | 40 | -5.2V3 |
| 41 | LBUSC05n | 42 | LBUSA05n |
| 43 | LBUSC04n | 44 | LBUSA04n |
| 45 | GND10 | 46 | GND11 |
| 47 | LBUSC03n | 48 | LBUSA03n |
| 49 | LBUSC02n | 50 | LBUSA02n |
| 51 | GND12 | 52 | -5.2V4 |
| 53 | LBUSC01n | 54 | LBUSA01n |
| 55 | LBUSC00n | 56 | LBUSA00n |
| 57 | -5.2V5 | 58 | GND13 |
| 59 | GND14 | 60 | BECLTRG1n |
| 61 | CLK10-n | 62 | -2V2 |
| 63 | CLK10+n | 64 | BECLTRG0n |

| TO REAR CONNECTOR P2 | | | |
|----------------------|-----------|-----|-----------|
| PIN | | PIN | |
| 1 | -24V | 2 | BSUMBUS |
| 3 | +24V | 4 | GND |
| 5 | GND | 6 | MODID |
| 7 | RSV3 | 8 | RSV2 |
| 9 | GND | 10 | GND |
| 11 | BTTLTRG7* | 12 | BTTLTRG6* |
| 13 | BTTLTRG5* | 14 | BTTLTRG4* |
| 15 | GND | 16 | +5V |
| 17 | BTTLTRG3* | 18 | BTTLTRG2* |
| 19 | BTTLTRG1* | 20 | BTTLTRG0* |
| 21 | GND | 22 | GND |
| 23 | LBUSC11 | 24 | LBUSA11 |
| 25 | LBUSC10 | 26 | LBUSA10 |
| 27 | -5.2V | 28 | -5.2V |
| 29 | LBUSC09 | 30 | LBUSA09 |
| 31 | LBUSC08 | 32 | LBUSA08 |
| 33 | GND | 34 | GND |
| 35 | LBUSC07 | 36 | LBUSA07 |
| 37 | LBUSC06 | 38 | LBUSA06 |
| 39 | -2V | 40 | -5.2V |
| 41 | LBUSC05 | 42 | LBUSA05 |
| 43 | LBUSC04 | 44 | LBUSA04 |
| 45 | GND | 46 | GND |
| 47 | LBUSC03 | 48 | LBUSA03 |
| 49 | LBUSC02 | 50 | LBUSA02 |
| 51 | GND | 52 | -5.2V |
| 53 | LBUSC01 | 54 | LBUSA01 |
| 55 | LBUSC00 | 56 | LBUSA00 |
| 57 | -5.2V | 58 | GND |
| 59 | GND | 60 | BECLTRG1 |
| 61 | CLK10- | 62 | -2V |
| 63 | CLK10+ | 64 | BECLTRG0 |

Figure A-5. P2 Pin Configuration

NOTES:

C&H Technologies, Inc. <> 445 Round Rock West Drive <> Round Rock, TX 78681 <> www.chtech.com

READER'S COMMENT FORM

Your comments assist us in improving the usefulness of C&H's publications; they are an important part of the inputs used for revision.

C&H Technologies, Inc. may use and distribute any of the information that you supply in any way that it believes to be appropriate without incurring any obligation whatsoever. You may, of course, continue to use the information which you supply.

Please refrain from using this form for technical questions or for requests for additional publications; this will only delay the response. Instead, please direct your technical questions to your authorized C&H representative.

COMMENTS:

Thank you for helping C&H to deliver the best possible product. Your support is appreciated.

Sincerely,

F.R.Harrison
President and CEO

INSTRUCTIONS

In its continuing effort to improve documentation, C&H Technologies, Inc. provides this form for use in submitting any comments or suggestions that the user may have. This form may be detached, folded along the lines indicated, taped along the loose edge (DO NOT STAPLE), and mailed. Please try to be as specific as possible and reference applicable sections of the manual or drawings if appropriate. Also, indicate if you would like an acknowledgment mailed to you stating whether or not your comments were being incorporated.

NOTE: This form may not be used to request copies of documents or to request waivers, deviations, or clarification of specification requirements on current contracts. Comments submitted on this form do not constitute or imply authorization to waive any portion of the referenced document(s) or to amend contractual requirements.

_____ (Fold along this line) _____

_____ (Fold along this line) _____

| |
|------------------------|
| Place Stamp Here |
|------------------------|

C&H Technologies, Inc.
Technical Publications
445 Round Rock West Drive
Round Rock, Texas 78681



Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

*InstraView*SM REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at www.instraview.com ↗

WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. www.artisanng.com/WeBuyEquipment ↗

LOOKING FOR MORE INFORMATION?

Visit us on the web at www.artisanng.com ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

Contact us: (888) 88-SOURCE | sales@artisanng.com | www.artisanng.com