



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)

HARDWARE REFERENCE MANUAL

# PMAC2 PCI Lite

## Preliminary Documentation

PMAC 2 PCI Lite Bus Expansion Card

4XX-603658-xHxx

November 5, 2003



**DELTA TAU**  
Data Systems, Inc.

*NEW IDEAS IN MOTION ...*

*Single Source Machine Control* *Power // Flexibility // Ease of Use*  
21314 Lassen Street Chatsworth, CA 91311 // Tel. (818) 998-2095 Fax. (818) 998-7807 // [www.deltatau.com](http://www.deltatau.com)

## **Copyright Information**

© 2003 Delta Tau Data Systems, Inc. All rights reserved.

This document is furnished for the customers of Delta Tau Data Systems, Inc. Other uses are unauthorized without written permission of Delta Tau Data Systems, Inc. Information contained in this manual may be updated from time-to-time due to product improvements, etc., and may not conform in every respect to former issues.

To report errors or inconsistencies, call or email:

### **Delta Tau Data Systems, Inc. Technical Support**

Phone: (818) 717-5656

Fax: (818) 998-7807

Email: [support@deltatau.com](mailto:support@deltatau.com)

Website: <http://www.deltatau.com>

## **Operating Conditions**

All Delta Tau Data Systems, Inc. motion controller products, accessories, and amplifiers contain static sensitive components that can be damaged by incorrect handling. When installing or handling Delta Tau Data Systems, Inc. products, avoid contact with highly insulated materials. Only qualified personnel should be allowed to handle this equipment.

In the case of industrial applications, we expect our products to be protected from hazardous or conductive materials and/or environments that could cause harm to the controller by damaging components or causing electrical shorts. When our products are used in an industrial environment, install them into an industrial electrical cabinet or industrial PC to protect them from excessive or corrosive moisture, abnormal ambient temperatures, and conductive materials. If Delta Tau Data Systems, Inc. products are directly exposed to hazardous or conductive materials and/or environments, we cannot guarantee their operation.

# Table of Contents

|  |           |
|--|-----------|
| <b>INTRODUCTION .....</b>                              | <b>1</b>  |
| Overview .....   | 1         |
| Board Configuration.....                               | 1         |
| <i>Base Version .....</i>                              | <i>1</i>  |
| <i>Option 2: Dual-Ported RAM.....</i>                  | <i>1</i>  |
| <i>Option 3: USB1.1 Communications Port.....</i>       | <i>2</i>  |
| <i>Option 5: CPU &amp; Memory Configurations.....</i>  | <i>2</i>  |
| <i>Option 6: Extended Servo Algorithm.....</i>         | <i>2</i>  |
| <i>Option 6L: Multi-block Lookahead Firmware.....</i>  | <i>2</i>  |
| <i>Option 7: Plate Mounting.....</i>                   | <i>2</i>  |
| <i>Option 8A: High-Accuracy Clock Crystal.....</i>     | <i>2</i>  |
| <i>Option 10: Firmware Version Specification.....</i>  | <i>2</i>  |
| <i>Option 12: Analog-to-Digital Converters.....</i>    | <i>2</i>  |
| <i>Option 16: Battery-Backed Parameter Memory.....</i> | <i>3</i>  |
| <b>HARDWARE SETUP .....</b>                            | <b>5</b>  |
| <i>Watchdog Timer Jumper.....</i>                      | <i>5</i>  |
| <i>CPU Frequency Control Jumpers.....</i>              | <i>5</i>  |
| <i>Re-Initialization Jumper .....</i>                  | <i>5</i>  |
| <i>Power-Up State Jumpers .....</i>                    | <i>5</i>  |
| <i>Firmware Load Jumper .....</i>                      | <i>5</i>  |
| <i>Flash Memory Bank Select Jumpers.....</i>           | <i>5</i>  |
| <i>Encoder Sample Clock Source Jumpers .....</i>       | <i>5</i>  |
| <i>Serial Port Selection Jumper .....</i>              | <i>6</i>  |
| <i>Output Disable State Jumpers .....</i>              | <i>6</i>  |
| <i>Amplifier Enable / EQU Jumper.....</i>              | <i>6</i>  |
| Resistor Pack Configuration.....                       | 7         |
| <i>Termination Resistors.....</i>                      | <i>7</i>  |
| <i>Pull-Up/Pull-Down Resistors .....</i>               | <i>7</i>  |
| Connections.....                                       | 8         |
| <i>Mounting.....</i>                                   | <i>8</i>  |
| <i>Power Supply Connection.....</i>                    | <i>8</i>  |
| <i>Machine Port Connections .....</i>                  | <i>8</i>  |
| <i>Display Port.....</i>                               | <i>8</i>  |
| <i>Multiplexer Port.....</i>                           | <i>9</i>  |
| <i>I/O Port.....</i>                                   | <i>9</i>  |
| <i>Serial Ports.....</i>                               | <i>9</i>  |
| <i>A/D-Converter Port .....</i>                        | <i>9</i>  |
| <i>Handwheel Port.....</i>                             | <i>9</i>  |
| <b>COMMUNICATIONS SETUP .....</b>                      | <b>11</b> |
| <b>FLEX CPU BOARD JUMPER DESCRIPTIONS.....</b>         | <b>13</b> |
| E1: Watchdog Disable Jumper .....                      | 13        |
| E2: Dual-Ported Ram Port Select .....                  | 13        |
| E4 – E6: Power-Up/Reset Load Source .....              | 13        |
| E7: Firmware Reload Enable .....                       | 13        |
| E10A, B, C: Flash Memory Bank Select.....              | 14        |
| <b>PMAC2-PCI LITE JUMPER DESCRIPTIONS .....</b>        | <b>15</b> |
| E2: CPU Frequency Select .....                         | 15        |
| E3: Normal/Re-Initializing Power-Up/Reset.....         | 15        |
| E4: CPU Frequency Select .....                         | 15        |
| E5 – E6: (Reserved for future use).....                | 16        |
| E13 - E14: Encoder Sample Clock Direction Control..... | 16        |

E17 - E18: Serial Port Type Selection.....16  
E111-118: Command Output Disable State .....17

**PMAC2-PCI LITEMATING CONNECTORS.....19**

CPU Board Connectors .....19  
    *J2 (JEXP)/Expansion*.....19

Baseboard Connectors.....19  
    *J1 (JANA)/Analog (Option 12)* .....19  
    *J2 (JTHW)/Multiplexer Port*.....19  
    *J3 (JIO)/Digital I/O* .....19  
    *J5 (JRS232)/RS-232 Serial Communications*.....19  
    *J5A (JRS422)/RS-422 Serial Communications* .....19  
    *J6 (JDISP)/Display*.....19  
    *J7 (JHW)/Auxiliary Channel*.....20  
    *J8 (JEQU)/Position Compare*.....20  
    *J9 (JMACH1)/Machine Port 1*.....20  
    *J10 (JMACH2)/Machine Port 2*.....20

**PMAC2-PCI LITE BASE BOARD CONNECTOR PINOUTS .....21**

J1 (JANA) Analog Input Port Connector .....21  
J2 (JTHW) Multiplexer Port Connector .....22  
J3 (JI/O) General Input/Output Connector .....23  
J5 (JRS232) Serial Port Connector .....24  
J5A (RS422) Serial Port Connector .....24  
J6 (JDISP) Display Connector .....25  
J7 (JHW) Handwheel Encoder Connector.....25  
J8 (JEQU) Position Compare Output Connector.....26  
J9 (JMACH1) Connector Description .....27  
J10 (JMACH2) Connector Description .....30  
TB1 (2/4-Pin Terminal Block) .....33  
TB2 (3-Pin Terminal Block) .....33

## INTRODUCTION

---

### Overview

---

The PMAC2-PCI Lite is a member of the PMAC2 family of boards optimized for interface to three or four sinewave or direct PWM servo drives and to pulse-and-direction stepper drives. It has four channels of servo interface circuitry, but its software is capable of eight axes of control. It is software compatible with the PMAC2-PC and the Mini-PMAC2.

The PMAC2-PCI Lite is a full-sized PCI-bus expansion card. While the PMAC2-PCI Lite is capable of PCI bus communications, with or without the optional on-board dual-ported RAM, it does not need to be inserted into a PCI expansion slot. Communications can be done through the standard on-board RS-232 serial port; standalone operation is possible.

### Board Configuration

---

#### Base Version

- The base version of the PMAC2-PCI Lite provides a 1-1/2-slot board with:
- 40 MHz DSP563xx CPU
- 128k x 24 zero-wait-state SRAM active memory
- 512k x 8 flash memory for user backup and firmware
- Latest released firmware version (requires V1.17 or newer firmware)
- RS-232/422 serial interface, 33 MHz PCI (PC) bus interface
- Four channels axis interface circuitry, each including:
  - Three output command signal sets, configurable as either:
    - Two serial data streams to external DACs, 1 pulse-and-direction
    - Three PWM top-and-bottom pairs
  - 3-channel differential/single-ended encoder input
  - Nine input flags, two output flags
  - Interface to two external serial ADCs, 8 to 18-bits
- Two channels supplemental interface circuitry, each including:
  - 2-channel differential/single-ended encoder input
  - One output command signal set, configurable as pulse-&-direction or PWM top-and-bottom pair
- Display, muxed I/O, direct I/O interface ports
- Buffered expansion port.
- Clock crystal with  $\pm 100$  ppm accuracy.
- PID/notch/feedforward servo algorithms
- 1-year warranty from date of shipment
- One Manuals CD-ROM per set of one to four PMACs in shipment (Cables, mounting plates, mating connectors not included)

#### Option 2: Dual-Ported RAM

Dual-ported RAM provides a high-speed communications path for bus communications with the host computer through a bank of shared memory. DPRAM is advised if more than 100 data items per second are to be passed between the controller and the host computer in either direction.

Option 2 provides an on-board 8k x 16 bank of dual-ported RAM for PCI or USB. The key component on the board is U1.

### Option 3: USB1.1 Communications Port

If using the PMAC-PCI Lite in a standalone application, use this port because it is faster than the standard RS232/422 communications. Use of this port disables the PCI port.

### Option 5: CPU & Memory Configurations

If the 40 MHz CPU (80 MHz DSP 56002 equivalent) that comes standard does not have sufficient computational power, faster versions are available as options. These options provide a faster CPU IC in U127, and unlike past CPU upgrades, will not require any additional memory chips.

- Option 5CF provides an 80 MHz CPU (160 MHz DSP 56002 equivalent) with zero-wait-state SRAM active memory. Requires V1.17 or newer firmware.
- Option 5EF provides a 160 MHz CPU (320 MHz DSP 56002 equivalent) with zero-wait-state SRAM active memory. Requires V1.17 or newer firmware.

### Option 6: Extended Servo Algorithm

The standard PID servo algorithm with feedforward and notch filter is suitable for most applications. Systems with difficult dynamics, especially with significant flexibility, may require a more powerful servo algorithm, such as the Extended Servo Algorithm (ESA).

- Option 6 provides an Extended (Pole-Placement) Servo Algorithm firmware instead of the regular servo algorithm firmware. This is required only in difficult-to-control systems (resonances, backlash, friction, disturbances, changing dynamics). This option requires a one-time purchase of the ACC-25 program, which is necessary for tuning the Option-6 firmware.

### Option 6L: Multi-block Lookahead Firmware

Option 6L provides a special lookahead firmware for sophisticated acceleration and cornering profiles execution. With the lookahead firmware, PMAC controls the speed along the path automatically (without changing the path) to ensure that axis limits are not violated.

### Option 7: Plate Mounting

If the PMAC2-PCI Lite is used as a PCI bus expansion board, the standard hardware is used for proper mounting of the board in the bus. However, if it is not installed in a PCI expansion slot, other provisions must be made for mounting.

Option 7 provides a mounting plate connected to the PMAC2-PCI Lite with standoffs. It is used to install the PMAC2-PCI Lite in standalone applications.

### Option 8A: High-Accuracy Clock Crystal

The PMAC2-PCI Lite has a clock crystal (component Y1) of nominal frequency 19.6608 MHz (~20 MHz). The standard crystal's accuracy specification is +/-100 ppm. Long-term velocity accuracy is limited by the accuracy of the crystal, unless an external time base is used.

Option 8A provides a nominal 19.6608 MHz crystal with a +/-15 ppm accuracy specification.

### Option 10: Firmware Version Specification

Normally the PMAC2-PCI Lite is provided with the newest released firmware version. A label on the U61 flash memory IC on the CPU board shows the firmware version loaded at the factory.

Option 10 provides for a user-specified firmware version.

### Option 12: Analog-to-Digital Converters

With Option 12, eight or 16 channels of on-board multiplexed analog-to-digital converters can be installed. One or two of these converters are read every phase interrupt. The analog inputs are not optically isolated, and each can have a 0 – 5V input range, or a +/-2.5V input range, individually selectable.

Option 12 provides an 8-channel 12-bit A/D converter. The key components on the board are U28 and connector J1.

Option 12A provides an additional 8-channel 12-bit A/D converter. The key component on the board is U29.

### **Option 16: Battery-Backed Parameter Memory**

The contents of the standard memory are not retained through a power-down or reset unless they have been saved to flash memory first. Option 16 provides supplemental battery-backed RAM for real-time parameter storage that is ideal for holding machine state parameters in case of an unexpected power-down.

Option 16 provides a 16k x 24 bank of battery-backed parameter RAM in components U84, U85, U86, with the battery in BT1.





## HARDWARE SETUP

---

### Watchdog Timer Jumper

Jumper E19 must be OFF for the watchdog timer to operate. This is an important safety feature, so it is vital that this jumper be OFF in normal operation. E19 should be put ON only to debug problems with the watchdog timer circuit.

### CPU Frequency Control Jumpers

If variable I46 is set to the default value of zero, jumpers E2 and E4 on the base PMAC2-PCI Lite board control the frequency at which the CPU will operate (or attempt to operate). Generally, this will be the highest frequency at which the CPU is rated to operate.

- If jumpers E2 and E4 are both OFF, the CPU will operate at a 40MHz frequency.
- If E2 is ON and E4 is OFF, the CPU will operate at a 60MHz frequency.
- If E2 is OFF and E4 is ON, the CPU will operate at an 80MHz frequency.
- If I46 is set to a value greater than zero, E2 and E4 are not used. The CPU frequency is set to 10MHz (I46+1)

### Re-Initialization Jumper

If E3 is off during power-up/reset, the controller will load its last saved set-up parameters from flash memory into active memory. This is the setting for normal operation.

If E3 is on during power-up/reset, the controller will load its factory-default set-up parameters from firmware into active memory. Generally, this is done only if communications cannot be established with the card when it comes up in normal operational mode.

### Power-Up State Jumpers

Jumper E20 must be OFF, jumper E21 must be ON, and jumper E22 must be ON, in order for the CPU to copy the firmware from flash memory into active RAM on power-up/reset. This is necessary for normal operation of the card. (Other settings are for factory use only.)

### Firmware Load Jumper

If jumper E23 is ON during power-up/reset, the board comes up in bootstrap mode which permits the loading of new firmware into the flash-memory IC on the board. When the PMAC Executive program tries to establish communications with a board in this mode, it will detect automatically that the board is in bootstrap mode and ask what file to download as the new firmware.

Jumper E23 must be OFF during power-up/reset for the board to come up in normal operational mode.

### Flash Memory Bank Select Jumpers

The flash-memory IC in location U10 on the Flex CPU board has the capacity for eight separate banks of firmware, only one of which can be used at any given time. The eight combinations of settings for jumpers E10A, E10B, and E10C select which bank of the flash memory is used. In the factory production process, firmware is loaded only into Bank 0 which is selected by having all of these jumpers OFF.

### Encoder Sample Clock Source Jumpers

Jumper E13 controls the source of the SCLK encoder-sampling clock for each servo IC. The default setting, No Jumper Installed, means that the SCLK signal comes from the servo IC and is output on the JMACH connectors. This setting is suitable for all but a few special applications.

## Serial Port Selection Jumper

Jumpers E17 and E18 control which serial-port connector is used. If E17 and E18 connect their pins 1 and 2, the 10-pin RS-232 port connector J5 is used. If E17 and E18 connect their pins 2 and 3, the 26-pin RS-422 port connector J5A is used. The RS-422 port must be used if several cards are to be daisy-chained together on a single multi-drop cable.

## Output Disable State Jumpers

Jumpers E111 through E114 control the hardware state of the digital command output signals for each channel when the amplifier enable signal for that channel is in the disable state (false). Jumper E11 $n$  ( $n = 1$  to 4) controls the output signals for channel  $n$  on the board.

If E11 $n$  is off (default), the command output signals for channel  $n$  are still active when the amplifier enable signal is in the disable state. The Turbo PMAC software should be commanding a net zero command to be output on these signals, and the amplifier-enable signal should be used by the amplifier so that no command output will cause action if it is receiving a disable signal. The Off setting should be used when DAC output format is selected for the channel.

If E11 $n$  is on, the command output signals for channel  $n$  are tri-stated when the amplifier-enable signal is in the disable state. This setting is used only with direct-PWM power-block amplifiers that do not use amplifier enable to gate the PWM signals, and in which the zero-command format of 50% top on-time, and 50% bottom on-time cannot be tolerated in the disable state.

## Amplifier Enable / EQU Jumper

---

### WARNING

The jumper setting must match the type of driver IC, or damage to the IC will result.

---

Jumpers E11 and E12 control the polarity of the AENA and EQU lines. Their default setting is 1 to 2 which applies GND to pin 10 of U93 AENA/EQU $n$  driver IC. This is used for 74ACT563, 74ACT573, and ULN2803 model sinking chips.

To source the AENA and EQU lines, apply +V to pin 10 of U93, jump pin 2 to 3. This is used for UDN2891 model sourcing chip.

---

### Note:

If using ULN2803 or UDN2981 model chips, be sure to plug pin 1 of chip into socket starting at pin 2.

---

## Resistor Pack Configuration

### Termination Resistors

The PMAC2-PCI Lite provides sockets for termination resistors on differential input pairs coming into the board. As shipped, there are no resistor packs in these sockets. If these signals are brought long distances into the PMAC2-PCI Lite board and ringing at signal transitions is a problem, SIP resistor packs may be mounted in these sockets to reduce or eliminate the ringing.

All termination resistor packs have independent resistors (no common connection) with each resistor using two adjacent pins. The following table shows which packs are used to terminate each input device:

| Input     | Pack  | Pack Size | Input       | Pack  | Pack Size |
|-----------|-------|-----------|-------------|-------|-----------|
| Encoder 1 | RP60  | 6-pin     | ADC 1 & 2   | RP60  | 8-pin     |
| Encoder 2 | RP62  | 6-pin     | ADC 3 & 4   | RP61  | 8-pin     |
| Encoder 3 | RP66  | 6-pin     | ADC 5 & 6   | RP121 | 8-pin     |
| Encoder 4 | RP68  | 6-pin     | ADC 7 & 8   | RP122 | 8-pin     |
| Encoder 5 | RP107 | 6-pin     | Fault 1 & 2 | RP63  | 6-pin     |
| Encoder 6 | RP111 | 6-pin     | Fault 3 & 4 | RP64  | 6-pin     |
| Encoder 7 | RP108 | 6-pin     | Fault 5 & 6 | RP124 | 6-pin     |
| Encoder 8 | RP112 | 6-pin     | Fault 7 & 8 | RP125 | 6-pin     |
| SCLK12&34 | RP52  | 6-pin     | SCLK56&78   | RP113 | 6-pin     |

### Pull-Up/Pull-Down Resistors

The differential input signal pairs to the PMAC2-PCI Lite have user-configurable pull-up/pull-down resistor networks to permit the acceptance of either single-ended or differential signals in one setting, or the detection of lost differential signals in another setting.

The ‘+’ inputs of each differential pair each have a hard-wired 1 kohm pull-up resistor to +5V. This cannot be changed.

The ‘-’ inputs of each differential pair each have a hard-wired 2.2 kohm resistor to +5V; each has another 2.2 kohm resistor as part of a socketed resistor pack that can be configured as a pull-up resistor to +5V, or a pull-down resistor to GND.

If this socketed resistor is configured as a pull-down resistor (the default configuration), the combination of pull-up and pull-down resistors on this line acts as a voltage divider, holding the line at +2.5V in the absence of an external signal. This configuration is required for single-ended inputs using the ‘+’ lines alone; it is used for unconnected inputs to prevent the pick-up of spurious noise. It is permissible for differential line-driver inputs.

If this socketed resistor is configured as a pull-up resistor (by reversing the SIP pack in the socket), the two parallel 2.2 kohm resistors act as a single 1.1 kohm pull-up resistor, holding the line at +5V in the absence of an external signal. This configuration is required if encoder-loss detection is desired; or if complementary open-collector drivers are used. It is permissible for differential line-driver inputs even without encoder loss detection.

If Pin 1 of the resistor pack (marked by a dot on the pack) matches Pin 1 of the socket (marked by a wide white line on the front side of the board and a square solder pin on the back side of the board), then the pack is configured as a bank of pull-down resistors. If the pack is reversed in the socket, it is configured as a bank of pull-up resistors.

The following table lists the pull-up/pull-down resistor pack for each input device:

| <b>Device</b> | <b>Resistor Pack</b> | <b>Device</b> | <b>Resistor Pack</b> |
|---------------|----------------------|---------------|----------------------|
| Encoder 1     | RP43                 | ADC/Fault1&2  | RP58                 |
| Encoder 2     | RP48                 | ADC/Fault3&4  | RP59                 |
| Encoder 3     | RP44                 | ADC/Fault5&6  | RP119                |
| Encoder 4     | RP49                 | ADC/Fault7&8  | RP120                |
| Encoder 5     | RP104                | SCLK12&34     | RP62                 |
| Encoder 6     | RP109                | SCLK56&78     | RP123                |
| Encoder 7     | RP105                |               |                      |
| Encoder 8     | RP110                |               |                      |

## Connections

---

### Mounting

The PMAC2-PCI Lite can be mounted in one of two ways: in the PCI bus, or using standoffs.

1. **PCI bus:** To mount in the PCI bus, simply insert the P1 card-edge connector into the PCI socket. If there is a standard PC-style housing, a bracket at the end of the PMAC2-PCI Lite board can be used to screw into the housing to hold the board down firmly.
2. **Standoffs:** At each of the Four Corners of the PMAC2-PCI Lite board, there are mounting holes that can be used to mount the board on standoffs.

### Power Supply Connection

The standard PMAC2-PCI Lite requires only 5V power: 3A in a 4-channel configuration, 4A in an 8-channel configuration (with Option 1). If the Option 12 A/D converters are installed, a –12V supply is also required. In this case, a +12V supply also can be passed through the card and out to the analog devices feeding the A/D converters.

The power can be provided in several ways:

- **Bus connector:** If the PMAC2-PCI Lite is mounted in an electrically active PCI bus slot, it draws its 5V and +/-12V power from the bus automatically.
- **Terminal block:** The TB1 2/4-point terminal block can be used to bring in 5V power, especially in standalone applications. Point 1 is GND; Point 2 is +5V. Points 3 and 4 are needed only if the Option-12 A/D converters are ordered.
- **JMACH connectors:** Up to 2A may be brought in through each 100-pin JMACH connector from an ACC-8 board or its equivalent, provided the cable is 500mm (20 inches) or less in length.

### Machine Port Connections

The PMAC2-PCI Lite has a 100-pin high-density header for each pair of servo interface channels. Through this connector, pass all of the digital signals to and from the amplifier, encoder, and flags for the two channels. Typically, this header is connected with a matching Delta Tau ACC-8 family 2-channel breakout board or equivalent through a provided 100-pin flat cable.

The machine port connectors are:

- J9 (JMACH1)      Board Channels 1 & 2
- J10 (JMACH2)    Board Channels 3 & 4

### Display Port

The J6 (JDISP) display port provides a 14-pin IDC header for connection to the ACC-12 family of displays. Flat cables are provided with each of these displays for direct connection between the display and this port.

## **Multiplexer Port**

The J2 (JTHW) multiplexer port provides eight TTL-compatible 5V CMOS inputs and eight TTL-compatible 5V CMOS outputs on a 26-pin IDC header. These can be used directly as general-purpose digital I/O, or with PMAC2's special M-variable support (TWB, TWD, TWR, and TWS formats). In addition, they can be used to support hundreds, or even thousands of multiplexed I/O points on accessory boards.

Delta Tau provides the following accessory boards that can be connected to the multiplexer port. Each comes with a flat cable for direct connection to the port.

- ACC-8D Option 7 Resolver-to-Digital Converter Board
- ACC-18 Thumbwheel Board
- ACC-34 family of Digital I/O Boards
- ACC-35A & B Extender Boards

## **I/O Port**

The J3 (JIO) I/O port provides 32 TTL-compatible 5V CMOS I/O points on a 40-pin IDC header. Direction is selectable by byte. These are used as general-purpose digital I/O points. ACC-21A provides a convenient connections adapter from this port to OPTO-22 style boards.

## **Serial Ports**

The PMAC2-PCI Lite has two serial-port connectors. Only one of these can be used in an application.

- J5 is a 10-pin IDC header for RS-232 communications. It can be connected to a standard DB9 RS-232 connector on a host computer or terminal via a flat cable such as the ACC-3L. A commercially available DB9-to-DB25 adapter can be added to this flat cable if the host computer or terminal has a DB25 serial connector. Jumpers E17 and E18 on the PMAC2-PCI Lite must connect pins 1 and 2 to use this port.
- J5A is 26-pin IDC header for RS-422 communications. It can be connected to a standard DB25 RS-422 connector on a host computer or terminal via a flat cable such as the ACC-3D. Jumpers E17 and E18 on the PMAC2-PCI Lite must connect pins 2 and 3 to use this port.

## **A/D-Converter Port**

If the Option 12 A/D converters are ordered, the J1 (JANA) analog-input port is provided on the PMAC2 on a 20-pin IDC header. Option 12 provides eight analog inputs at 0 – 5V, or +/-2.5V levels. Option 12A provides eight additional analog inputs at these levels. The +12V and –12V supplies can either be brought in on this connector, or brought out on it for the external analog circuitry, if they have been brought in through TB1 or P1.


## **Handwheel Port**

The J7 (JHW) handwheel port provides two limited supplemental channels, each with a 2-channel encoder input, and a pulse-and-direction or PWM top-and-bottom pair output. All inputs and outputs are digital 5V differential line-driver pairs.




## COMMUNICATIONS SETUP

Delta Tau provides communication tools that take advantage of the PCI bus Plug and Play feature of 32-bits Windows® based computers. Starting with MOTIONEXE.EXE version 10.32.00, which is included in PEWIN32 version 2.32 and newer, a PMAC2-PCI Lite board plugged in a PCI bus slot will be recognized by the operating system when the computer is booted up. The available PCI address, Dual-Ported RAM address and Interrupt lines are set automatically by the operating system and can be checked (but not modified) in the MOTIONEXE.EXE application.



The PMAC2-PCI Lite board may have the optional on-board Dual-Ported RAM circuitry which is ordered through Option-2. If the Dual-Ported RAM circuitry is not on-board, manually disable its automatically assigned use through the setup page of MOTIONEXE:



The MOTIONEXE application will look first for PMAC PCI boards on the PCI bus and will assign device numbers from Device0 to each PMAC PCI sequentially until all the PMAC PCI boards found have a device number assigned. Then, manually add other devices for either ISA bus or Serial port communications.

After each PMAC has a device number assigned to it, communications through the PCI bus are identical to the ISA bus. Any application written for the ISA bus using the Delta Tau provided 32-bits communication libraries provided will not require any further change and the process is transparent.



---


*Note*

For example, if a Device0 for serial RS-232 communications was defined before a PMAC PCI board was installed in the computer, its setup information will be overwritten by the MOTIONEXE application when the PMAC2-PCI Lite board is found. Therefore, it is important to take note of the all the devices and their parameters defined in MOTIONEXE before installing a new PMAC board in the computer.


---

## FLEX CPU BOARD JUMPER DESCRIPTIONS


### E1: Watchdog Disable Jumper

| E Point & Physical Layout   | Description  | Default             |
|---|--|---------------------|
| <p>E1</p>  | <p>Jump pin 1 to 2 to disable Watchdog timer. (For test purposes only.)</p> <p>Remove jumper to enable Watchdog timer.</p> | No jumper installed |


### E2: Dual-Ported Ram Port Select

| E Point & Physical Layout   | Description  | Default             |
|---|--|---------------------|
| <p>E2</p>  | <p>Jump pin 1 to 2 to access DPRAM from baseboard.</p> <p>Jump pin 2 to 3 to access DPRAM through JEXP expansion port.</p> | Pins 1 & 2 jumpered |


### E4 – E6: Power-Up/Reset Load Source

| E Point & Physical Layout   | Description  | Default   |
|---|--|---|
| <p>E6</p>  <p>E4</p> | <p>Remove jumper E4;</p> <p>Jump E5 pin 1 to 2;</p> <p>Jump E6 pin 2 to 3;</p> <p>to read flash IC on power-up/reset.</p> <p>Other combinations are for factory use only; the board will not operate in any other configuration.</p> | <p>No E4 jumper installed;</p> <p>E5 and E6 jump pin 1 to 2</p> |

### E7: Firmware Reload Enable


| E Point & Physical Layout   | Description  | Default             |
|---|--|---------------------|
| <p>E7</p>  | <p>Jump pin 1 to 2 to reload firmware through serial or bus port.</p> <p>Remove jumper for normal operation.</p> | No jumper installed |

## E10A, B, C: Flash Memory Bank Select


| E Point & Physical Layout   | Description  | Default                     |
|---|--|-----------------------------|
| <p><b>E10A</b></p>  <p><b>E10C</b></p> | <p>Remove all three jumpers to select flash memory bank with factory-installed firmware.</p> <p>Use other configuration to select one of the seven other flash memory banks.</p> | <p>No jumpers installed</p> |

## PMAC2-PCI LITE JUMPER DESCRIPTIONS


### E1: Servo and Phase Clock Direction Control

| E Point & Physical Layout  | Location | Description  | Default             |
|--|----------|--|---------------------|
| <p>E1</p>   | C2       | <p>Remove jumper for PMAC2-PCI Lite to use its internally generated servo and phase clock signals and to output these signals on the J5A serial port connector.</p> <p>Jump pins 1 and 2 for PMAC2-PCI Lite to expect to receive its servo and phase clock signals on the J5A serial port connector.</p> | No jumper installed |
| <p><b>Note:</b> If the E1 jumper is ON and the servo and phase clocks are not brought in on the J5A serial port, the watchdog timer will trip immediately.</p> |          |  |                     |


### E2: CPU Frequency Select

| E Point & Physical layout   | Location | Description  | Default  |
|---|----------|--|--|
| <p>E2</p>  | C2       | <p>Remove jumper for 40MHz operation (E4 OFF also) or for 80MHz operation (E4 ON) with I46 = 0.</p> <p>Jump pin 1 to 2 for 60MHz operation (E4 OFF) with I46 = 0.</p> <p>Not used if I46 &gt; 0.</p> | <p>No jumper installed</p> <p>Jumper installed</p> |

### E3: Normal/Re-Initializing Power-Up/Reset



| E Point & Physical Layout   | Location | Description   | Default             |
|---|----------|---|---------------------|
| <p>E3</p>  | C2       | <p>Jump pin 1 to 2 to re-initialize on power-up/reset, loading factory default settings.</p> <p>Remove jumper for normal power-up/reset, loading user-saved settings.</p> | No jumper installed |

### E4: CPU Frequency Select



| E Point & Physical layout   | Location | Description   | Default  |
|---|----------|---|--|
| <p>E4</p>  | C2       | <p>Remove jumper for 40MHz operation (E2 OFF also) or for 60MHz operation (E4 ON) with I46 = 0.</p> <p>Jump pin 1 to 2 for 80MHz operation (E2 OFF) with I46 = 0.</p> <p>Not used if I46 &gt; 0</p> | <p>No jumper installed (standard or Opt 5B)</p> <p>Jumper installed (Opt 5C)</p> |

**E5 – E6: (Reserved for future use)**









**E13 - E14: Encoder Sample Clock Direction Control**

| <b>E Point &amp; Physical layout</b>  | <b>Location</b> | <b>Description</b>   | <b>Default</b>      |
|---|-----------------|--|---------------------|
| <b>E13</b><br> | D1              | Remove jumper to output SCLK generated in first ASIC on SCLK_12 and SCLK_34, or to control direction by software.<br><br>Jump pins 1 to 2 to input SCLK signal for first ASIC on SCLK_34 and output this signal on SCLK_12.<br><br>Jump pins 2 to 3 to input SCLK signal for first ASIC on SCLK_12 and output this signal on SCLK_34.    | No jumper installed |
| <b>E14</b><br> | D2              | Remove jumper to output SCLK generated in second ASIC on SCLK_56 and SCLK_78, or to control direction by software.<br><br>Jump pins 1 to 2 to input SCLK signal for second ASIC on SCLK_78 and output this signal on SCLK_56.<br><br>Jump pins 2 to 3 to input SCLK signal for second ASIC on SCLK_56 and output this signal on SCLK_78. | No jumper installed |
| <b>Note:</b> E14 is installed only if Option 1 has been ordered.                                |                 |  |                     |

**E17 - E18: Serial Port Type Selection**

| <b>E Point &amp; Physical layout</b>   | <b>Location</b> | <b>Description</b>  | <b>Default</b>                   |
|--|-----------------|---|----------------------------------|
| <b>E17</b><br>  | C1              | Connect pins 1 and 2 to use the RS-232 port on the J5 connector.<br><br>Connect pins 2 and 3 to use the RS-422 port on the J5A connector. | Jumper installed in 1-2 position |
| <b>E18</b><br>  | C1              | Connect pins 1 and 2 to use the RS-232 port on the J5 connector.<br><br>Connect pins 2 and 3 to use the RS-422 port on the J5A connector. | Jumper installed in 1-2 position |
| <b>Serial Port Choice:</b> Because both RS-232 and RS-422 ports are always provided, jumpers must be set correctly to use the port of choice. Jumpers E17 and E18 must connect pins 1 and 2 to use the RS-232 port on the J5 connector; to use the RS-422 port on the J5A connector, they must connect pins 2 and 3. |                 |   |                                  |

## E111-118: Command Output Disable State

| E Point & Physical Layout  | Location | Description  | Default             |
|--|----------|--|---------------------|
| E111  | C1       | <p>Jump pin 1 to 2 of E11<math>n</math> for digital servo command output signals of Channel <math>n</math> to tri-state when amplifier-enable signal for Channel <math>n</math> is in disable state.</p> <p>Remove jumper for digital servo command output signals of Channel <math>n</math> to remain active (but typically with zero command value) when amplifier-enable signal for Channel <math>n</math> is in disable state.</p> | No jumper installed |
| E112  |          |  |                     |
| E113  |          |  |                     |
| E114  |          |  |                     |
| E115  |          |  |                     |
| E116  |          |  |                     |
| E117  |          |  |                     |
| E118  |          |  |                     |



## PMAC2-PCI LITEMATING CONNECTORS

---

### CPU Board Connectors

---

#### J2 (JEXP)/Expansion

- Two 50-pin female flat cable connector Delta Tau P/N 014-R00F50-0K0 - T&B Ansley P/N 609-5041
- 171-50 T&B Ansley standard flat cable stranded 50-wire
- Phoenix varioface module type FLKM 50 (male pins) P/N 22 81 08 9

### Baseboard Connectors

---

#### J1 (JANA)/Analog (Option 12)

- Two 14-pin female flat cable connector Delta Tau P/N 014-R00F14-0K0 - T&B Ansley P/N 609-1441
- 171-14 T&B Ansley standard flat cable stranded 14-wire
- Phoenix varioface modules type FLKM14 (male pins) P/N 22 81 02 1

#### J2 (JTHW)/Multiplexer Port

- Two 26-pin female flat cable connector Delta Tau P/N 014-R00F26-0K0 - T&B Ansley P/N 609-2641
- 171-26 T&B Ansley standard flat cable stranded 26-wire
- Phoenix varioface module type FLKM 26 (male pins) P/N 22 81 05 0

#### J3 (JIO)/Digital I/O

- Two 40-pin female flat cable connector Delta Tau P/N 014-R00F40-0K0 - T&B Ansley P/N 609-4041
- 171-40 T&B Ansley standard flat cable stranded 40-wire
- Phoenix varioface module type FLKM 40 (male pins)

#### J5 (JRS232)/RS-232 Serial Communications

- Two 10-pin female flat cable connector Delta Tau P/N 014-R00F10-0K0 - T&B Ansley P/N 609-1041
- 171-10 T&B Ansley standard flat cable stranded 10-wire
- Phoenix varioface module type FLKM 10 (male pins) P/N 22 81 01 8

#### J5A (JRS422)/RS-422 Serial Communications

- Two 26-pin female flat cable connector Delta Tau P/N 014-R00F26-0K0 - T&B Ansley P/N 609-2641
- 171-26 T&B Ansley standard flat cable stranded 26-wire
- Phoenix varioface module type FLKM 26 (male pins) P/N 22 81 05 0

#### J6 (JDISP)/Display

- Two 14-pin female flat cable connector Delta Tau P/N 014-R00F14-0K0 - T&B Ansley P/N 609-1441
- 171-14 T&B Ansley standard flat cable stranded 14-wire



- Phoenix varioface modules type FLKM14 (male pins) P/N 22 81 02 1

### **J7 (JHW)/Auxiliary Channel**

- Two 20-pin female flat cable connector Delta Tau P/N 014-R00F20-0K0 - T&B Ansley P/N 609-2041
- 171-20 T&B Ansley standard flat cable stranded 20-wire
- Phoenix varioface modules type FLKM20 (male pins)

### **J8 (JEQU)/Position Compare**

- Two 10-pin female flat cable connector Delta Tau P/N 014-ROOF10-0K0 - T&B Ansley P/N 609-1041
- 171-10 T&B Ansley standard flat cable stranded 10-wire
- Phoenix varioface module type FLKM 10 (male pins) P/N 22 81 01 8

### **J9 (JMACH1)/Machine Port 1**

- Two 100-pin high-density box header with center key, 0.050" pitch - AMP P/N 1-04068-7, Delta Tau P/N 014-00010-FPB
- High-density flat cable stranded 100-wire

### **J10 (JMACH2)/Machine Port 2**

- Two 100-pin high-density box header with center key, 0.050" pitch - AMP P/N 1-04068-7, Delta Tau P/N 014-00010-FPB
- High-density flat cable stranded 100-wire

## PMAC2-PCI LITE BASE BOARD CONNECTOR PINOUTS

### J1 (JANA) Analog Input Port Connector

This connector is present only if Option 12 is ordered.

| Pin # | Symbol | Function | Description             | Notes                       |
|-------|--------|----------|-------------------------|-----------------------------|
| 1     | ANAI00 | Input    | Analog input 0          | 0-5V or +/-2.5V range       |
| 2     | ANAI01 | Input    | Analog input 1          | 0-5V or +/-2.5V range       |
| 3     | ANAI02 | Input    | Analog input 2          | 0-5V or +/-2.5V range       |
| 4     | ANAI03 | Input    | Analog input 3          | 0-5V or +/-2.5V range       |
| 5     | ANAI04 | Input    | Analog input 4          | 0-5V or +/-2.5V range       |
| 6     | ANAI05 | Input    | Analog input 5          | 0-5V or +/-2.5V range       |
| 7     | ANAI06 | Input    | Analog input 6          | 0-5V or +/-2.5V range       |
| 8     | ANAI07 | Input    | Analog input 7          | 0-5V or +/-2.5V range       |
| 9     | ANAI08 | Input    | Analog input 8          | 0-5V or +/-2.5V range *     |
| 10    | ANAI09 | Input    | Analog input 9          | 0-5V or +/-2.5V range *     |
| 11    | ANAI10 | Input    | Analog input 10         | 0-5V or +/-2.5V range *     |
| 12    | ANAI11 | Input    | Analog input 11         | 0-5V or +/-2.5V range *     |
| 13    | ANAI12 | Input    | Analog input 12         | 0-5V or +/-2.5V range *     |
| 14    | ANAI13 | Input    | Analog input 13         | 0-5V or +/-2.5V range *     |
| 15    | ANAI14 | Input    | Analog input 14         | 0-5V or +/-2.5V range *     |
| 16    | ANAI15 | Input    | Analog input 15         | 0-5V or +/-2.5V range *     |
| 17    | GND    | Common   | PMAC common             | Not isolated from digital   |
| 18    | +12V   | Output   | Positive supply voltage | To power external circuitry |
| 19    | GND    | Common   | PMAC common             | Not isolated from digital   |
| 20    | -12V   | Output   | Negative supply voltage | To power external circuitry |

\*This signal is present only if Option-12A is ordered.

The JANA connector provides the inputs for the 8 or 16 optional analog inputs on the PMAC2.

## J2 (JTHW) Multiplexer Port Connector

| Pin # | Symbol | Function      | Description     | Notes  |
|-------|--------|---------------|-----------------|--|
| 1     | GND    | Common        | PMAC common     |  |
| 2     | GND    | Common        | PMAC common     |  |
| 3     | DAT0   | Input         | Data-0 input    | Data input from MUX port accessories         |
| 4     | SEL0   | Output        | Select-0 output | Address/data output for MUX port accessories |
| 5     | DAT1   | Input         | Data-1 input    | Data input from MUX port accessories         |
| 6     | SEL1   | Output        | Select-1 output | Address/data output for MUX port accessories |
| 7     | DAT2   | Input         | Data-2 input    | Data input from MUX port accessories         |
| 8     | SEL2   | Output        | Select-2 output | Address/data output for MUX port accessories |
| 9     | DAT3   | Input         | Data-3 input    | Data input from MUX port accessories         |
| 10    | SEL3   | Output        | Select-3 output | Address/data output for MUX port accessories |
| 11    | DAT4   | Input         | Data-4 input    | Data input from MUX port accessories         |
| 12    | SEL4   | Output        | Select-4 output | Address/data output for MUX port accessories |
| 13    | DAT5   | Input         | Data-5 input    | Data input from MUX port accessories         |
| 14    | SEL5   | Output        | Select-5 output | Address/data output for MUX port accessories |
| 15    | DAT6   | Input         | Data-6 input    | Data input from MUX port accessories         |
| 16    | SEL6   | Output        | Select-6 output | Address/data output for MUX port accessories |
| 17    | DAT7   | Input         | Data-7 input    | Data input from MUX port accessories         |
| 18    | SEL7   | Output        | Select-7 output | Address/data output for MUX port accessories |
| 19    | N.C.   | No Connection | No connection   |  |
| 20    | GND    | Common        | PMAC common     |  |
| 21    | BRLD/  | Output        | Buffer request  | Low is buffer required                       |
| 22    | GND    | Common        | PMAC common     |  |
| 23    | IPLD/  | Output        | In position     | Low is in position                           |
| 24    | GND    | Common        | PMAC common     |  |
| 25    | +5V    | Output        | +5Vdc supply    | Power supply out                             |
| 26    | INIT/  | Input         | PMAC reset      | Low is reset                                 |

## J3 (JI/O) General Input/Output Connector

| Pin # | Symbol | Function | Description       | Notes                       |
|-------|--------|----------|-------------------|-----------------------------|
| 1     | I/O00  | In/Out   | Digital I/O 0     | Software direction ctrl.    |
| 2     | I/O01  | In/Out   | Digital I/O 1     | Software direction ctrl.    |
| 3     | I/O02  | In/Out   | Digital I/O 2     | Software direction ctrl.    |
| 4     | I/O03  | In/Out   | Digital I/O 3     | Software direction ctrl.    |
| 5     | I/O04  | In/Out   | Digital I/O 4     | Software direction ctrl.    |
| 6     | I/O05  | In/Out   | Digital I/O 5     | Software direction ctrl.    |
| 7     | I/O06  | In/Out   | Digital I/O 6     | Software direction ctrl.    |
| 8     | I/O07  | In/Out   | Digital I/O 7     | Software direction ctrl.    |
| 9     | I/O08  | In/Out   | Digital I/O 8     | Software direction ctrl.    |
| 10    | I/O09  | In/Out   | Digital I/O 9     | Software direction ctrl.    |
| 11    | I/O10  | In/Out   | Digital I/O 10    | Software direction ctrl.    |
| 12    | I/O11  | In/Out   | Digital I/O 11    | Software direction ctrl.    |
| 13    | I/O12  | In/Out   | Digital I/O 12    | Software direction ctrl.    |
| 14    | I/O13  | In/Out   | Digital I/O 13    | Software direction ctrl.    |
| 15    | I/O14  | In/Out   | Digital I/O 14    | Software direction ctrl.    |
| 16    | I/O15  | In/Out   | Digital I/O 15    | Software direction ctrl.    |
| 17    | I/O16  | In/Out   | Digital I/O 16    | Software direction ctrl.    |
| 18    | I/O17  | In/Out   | Digital I/O 17    | Software direction ctrl.    |
| 19    | I/O18  | In/Out   | Digital I/O 18    | Software direction ctrl.    |
| 20    | I/O19  | In/Out   | Digital I/O 19    | Software direction ctrl.    |
| 21    | I/O20  | In/Out   | Digital I/O 20    | Software direction ctrl.    |
| 22    | I/O21  | In/Out   | Digital I/O 21    | Software direction ctrl.    |
| 23    | I/O22  | In/Out   | Digital I/O 22    | Software direction ctrl.    |
| 24    | I/O23  | In/Out   | Digital I/O 23    | Software direction ctrl.    |
| 25    | I/O24  | In/Out   | Digital I/O 24    | Software direction ctrl.    |
| 26    | I/O25  | In/Out   | Digital I/O 25    | Software direction ctrl.    |
| 27    | I/O26  | In/Out   | Digital I/O 26    | Software direction ctrl.    |
| 28    | I/O27  | In/Out   | Digital I/O 27    | Software direction ctrl.    |
| 29    | I/O28  | In/Out   | Digital I/O 28    | Software direction ctrl.    |
| 30    | I/O29  | In/Out   | Digital I/O 29    | Software direction ctrl.    |
| 31    | I/O30  | In/Out   | Digital I/O 30    | Software direction ctrl.    |
| 32    | I/O31  | In/Out   | Digital I/O 31    | Software direction ctrl.    |
| 33    | GND    | Common   | Reference voltage |                             |
| 34    | GND    | Common   | Reference voltage |                             |
| 35    | PHASE/ | Output   | Phase clock       | For latching data           |
| 36    | SERVO/ | Output   | Servo clock       | For latching data           |
| 37    | GND    | Common   | Reference voltage |                             |
| 38    | GND    | Common   | Reference voltage |                             |
| 39    | +5V    | Output   | Supply voltage    | To power external circuitry |
| 40    | +5V    | Output   | Supply voltage    | To power external circuitry |

The JI/O connector provides 32 input/output pins at TTL levels. Direction can be controlled in byte-wide groups.


## J5 (JRS232) Serial Port Connector

| Pin # | Symbol | Function | Description         | Notes              |
|-------|--------|----------|---------------------|--------------------|
| 1     | PHASE  | Output   | Phasing clock       |                    |
| 2     | DTR    | Bidirect | Data terminal ready | Tied to DSR        |
| DSR   | TXD/   | Input    | Receive data        | Host transmit data |
| 4     | CTS    | Input    | Clear to send       | Host ready bit     |
| 5     | RXD/   | Output   | Send data           | Host receives data |
| 6     | RTS    | Output   | Req. to send        | PMAC ready bit     |
| 7     | DSR    | Bidirect | Data set ready      | Tied to DTR        |
| 8     | SERVO  | Output   | Servo clock         |                    |
| 9     | GND    | Common   | PMAC common         |                    |
| 10    | +5V    | Output   | +5Vdc supply        | Power supply out   |

The JRS232 connector provides the PMAC2-PC with the ability to communicate serially with an RS232 port. This connector cannot be used for daisy-chain interconnection of multiple PMACs. The J5A RS-422 port must be used for daisy-chaining.

E17 and E18 must connect pins 1 and 2 to use the RS-232 port for serial communications.

## J5A (RS422) Serial Port Connector

| JRS422 (26-PIN Connector) |        |          | <br>Front View |                     |
|---------------------------|--------|----------|--|---------------------|
| Pin #                     | Symbol | Function | Description  | Notes               |
| 1                         | CHASSI | Common   | PMAC common  |                     |
| 2                         | S+5V   | Output   | +5Vdc supply   |                     |
| 3                         | RD-    | Input    | Receive data   | Diff. I/O low true  |
| 4                         | RD+    | Input    | Receive data   | Diff. I/O high true |
| 5                         | SD-    | Output   | Send data  | Diff. I/O low true  |
| 6                         | SD+    | Output   | Send data  | Diff. I/O high true |
| 7                         | CS+    | Input    | Clear to send  | Diff I/O high true  |
| 8                         | CS-    | Input    | Clear to send  | Diff. I/O low true  |
| 9                         | RS+    | Output   | Req. to send   | Diff. I/O high true |
| 10                        | RS-    | Output   | Req. to send   | Diff I/O low true   |
| 11                        | DTR    | Bidirect | Data term read   | Tied to DSR         |
| 12                        | INIT/  | Input    | PMAC reset   | Low is "reset"      |
| 13                        | GND    | Common   | PMAC common  |                     |
| 14                        | DSR    | Bidirect | Data set ready   | Tied to DTR         |
| 15                        | SDIO-  | Bidirect | Special data   | Diff. I/O low true  |
| 16                        | SDIO+  | Bidirect | Special data   | Diff. I/O high true |
| 17                        | SCIO-  | Bidirect | Special ctrl.  | Diff I/O low true   |
| 18                        | SCIO+  | Bidirect | Special ctrl.  | Diff. I/O high true |
| 19                        | SCK-   | Bidirect | Special clock  | Diff. I/O low true  |
| 20                        | SCK+   | Bidirect | Special clock  | Diff. I/O high true |
| 21                        | SERVO- | Bidirect | Servo clock  | Diff. I/O low true  |
| 22                        | SERVO+ | Bidirect | Servo clock  | Diff. I/O high true |
| 23                        | PHASE- | Bidirect | Phase clock  | Diff. I/O low true  |
| 24                        | PHASE+ | Bidirect | Phase clock  | Diff. I/O high true |
| 25                        | GND    | Common   | PMAC common  |                     |
| 26                        | +5V    | Output   | +5Vdc supply   | Power supply out    |

E17 and E18 must connect pins 2 and 3 to use the RS-422 port for serial communications. This connector could be also used to daisychain interconnect multiple PMACs for synchronized operation.

## J6 (JDISP) Display Connector

| Pin # | Symbol | Function | Description          | Notes            |
|-------|--------|----------|----------------------|------------------|
| 1     | VDD    | Output   | +5V power            | Power supply out |
| 2     | VSS    | Common   | PMAC common          |                  |
| 3     | RS     | Output   | Read strobe          | TTL signal out   |
| 4     | VEE    | Output   | Contrast adjust. VEE | 0 to +5 Vdc *    |
| 5     | E      | Output   | Display enable       | High is enable   |
| 6     | R/W    | Output   | Read or write        | TTL signal out   |
| 7     | DB1    | Output   | Display data1        |                  |
| 8     | DB0    | Output   | Display data0        |                  |
| 9     | DB3    | Output   | Display data3        |                  |
| 10    | DB2    | Output   | Display data2        |                  |
| 11    | DB5    | Output   | Display data5        |                  |
| 12    | DB4    | Output   | Display data4        |                  |
| 13    | DB7    | Output   | Display data7        |                  |
| 14    | DB6    | Output   | Display data6        |                  |

The JDISP connector is used to drive the 2-line x 24 character (ACC-12), 2 x 40 (ACC-12A) LCD, or the 2 x 40 vacuum fluorescent (ACC 12C) display unit. The **DISPLAY** command may be used to send messages and values to the display.

## J7 (JHW) Handwheel Encoder Connector

| Pin # | Symbol | Function | Description           | Notes                       |
|-------|--------|----------|-----------------------|-----------------------------|
| 1     | GND    | Common   | Reference voltage     |                             |
| 2     | +5V    | Output   | Supply voltage        | To power external circuitry |
| 3     | HWA1+  | Input    | HW positive A channel | Also pulse input            |
| 4     | HWA1-  | Input    | HW negative A channel | Also pulse input            |
| 5     | HWB1+  | Input    | HW positive B channel | Also direction input        |
| 6     | HWB1-  | Input    | HW negative B channel | Also direction input        |
| 7     | HWA2+  | Input    | HW positive A channel | Also pulse input            |
| 8     | HWA2-  | Input    | HW negative A channel | Also pulse input            |
| 9     | HWB2+  | Input    | HW positive B channel | Also direction input        |
| 10    | HWB2-  | Input    | HW negative B channel | Also direction input        |
| 11    | PUL1+  | Output   | PFM positive pulse    | Also PWM bottom output      |
| 12    | PUL1-  | Output   | PFM negative pulse    | Also PWM bottom output      |
| 13    | DIR1+  | Output   | PFM positive dir out  | Also PWM top output         |
| 14    | DIR1-  | Output   | PFM negative dir out  | Also PWM top output         |
| 15    | PUL2+  | Output   | PFM positive pulse    | Also PWM bottom output      |
| 16    | PUL2-  | Output   | PFM negative pulse    | Also PWM bottom output      |
| 17    | DIR2+  | Output   | PFM positive dir. out | Also PWM top output         |
| 18    | DIR2-  | Output   | PFM negative dir out  | Also PWM top output         |
| 19    | GND    | Common   | Reference voltage     |                             |
| 20    | +5V    | Output   | Supply voltage        | To power external circuitry |


The VHW connector provides for two 2-channel encoder inputs and two sets of pulse outputs.

## J8 (JEQU) Position Compare Output Connector

| Pin # | Symbol | Function | Description       | Notes               |
|-------|--------|----------|-------------------|---------------------|
| 1     | EQU1/  | Output   | Encoder 1 comp-Eq | Programmed polarity |
| 2     | EQU2/  | Output   | Encoder 2 comp-Eq | Programmed polarity |
| 3     | EQU3/  | Output   | Encoder 3 comp-Eq | Programmed polarity |
| 4     | EQU4/  | Output   | Encoder 4 comp-Eq | Programmed polarity |
| 5     | EQU5/  | Output   | Encoder 5 comp-Eq | Programmed polarity |
| 6     | EQU6/  | Output   | Encoder 6 comp-Eq | Programmed polarity |
| 7     | EQU7/  | Output   | Encoder 7 comp-Eq | Programmed polarity |
| 8     | EQU8/  | Output   | Encoder 8 comp-Eq | Programmed polarity |
| 9     | +V     | Supply   | Positive supply   | +5V                 |
| 10    | GND    | Common   | Digital ground    |                     |

This connector provides the position-compare outputs for the eight encoder channels.

## J9 (JMACH1) Connector Description

| J9 JMACH1 Connector |                        |                | <br>Front View |  |
|---------------------|------------------------|----------------|--|--|
| Pin#                | Symbol                 | Function       | Description  | Notes  |
| 1                   | +5V                    | Output / Input | +5V power  | For external circuit or from external supply |
| 2                   | +5V                    | Output / Input | +5V power  | For external circuit or from external supply |
| 3                   | GND                    | Common         | Reference voltage  |  |
| 4                   | GND                    | Common         | Reference voltage  |  |
| 5                   | CHA1+                  | Input          | Encoder 1 positive A channel   | Also pulse input                             |
| 6                   | CHA1-                  | Input          | Encoder 1 negative A channel   | Also pulse input                             |
| 7                   | CHB1+                  | Input          | Encoder 1 positive B channel   | Also direction input                         |
| 8                   | CHB1-                  | Input          | Encoder 1 negative B channel   | Also direction input                         |
| 9                   | CHC1+                  | Input          | Encoder 1 positive C channel   | Index channel                                |
| 10                  | CHC1-                  | Input          | Encoder 1 negative C channel   | Index channel                                |
| 11                  | CHU1                   | Input          | Channel 1 U flag   | Hall effect, fault code, or sub-count        |
| 12                  | CHV1                   | Input          | Channel 1 V flag   | Hall effect, fault code, or sub-count        |
| 13                  | CHW1                   | Input          | Channel 1 W flag   | Hall effect, fault code, or sub-count        |
| 14                  | CHT1                   | Input          | Channel 1 T flag   | Fault code, or sub-count                     |
| 15                  | USER1                  | Input          | General purpose user flag  | Hardware capture flag, or sub-count          |
| 16                  | PLIM1                  | Input          | Positive overtravel limit  | Hardware capture flag                        |
| 17                  | MLIM1                  | Input          | Negative overtravel limit  | Hardware capture flag                        |
| 18                  | HOME1                  | Input          | Home switch input  | Hardware capture flag                        |
| 19                  | ACCFLT1                | Input          | Accessory fault flag   | For loss of ACC supply voltage               |
| 20                  | WD0/                   | Output         | Watchdog output  | Low is PMAC watchdog fault                   |
| 21                  | SCLK12+                | Input / Output | Encoder sample clock   | Direction controlled by PMAC2 jumper         |
| 22                  | SCLK12-                | Input / Output | Encoder sample clock   | Direction controlled by PMAC2 jumper         |
| 23                  | ADC_CLK1+              | Output         | A/D converter clock  | Programmable frequency                       |
| 24                  | ADC_CLK1-              | Output         | A/D converter clock  | Programmable frequency                       |
| 25                  | ADC_STB1+              | Output         | A/D converter strobe   | Programmable sequence                        |
| 26                  | ADC_STB1-              | Output         | A/D converter strobe   | Programmable sequence                        |
| 27                  | ADC_DAA1+              | Input          | Channel A ADC serial data  | MSB first                                    |
| 28                  | ADC_DAA1-              | Input          | Channel A ADC serial data  | MSB first                                    |
| 29                  | ADC_DAB1+              | Input          | Channel B ADC serial data  | MSB first                                    |
| 30                  | ADC_DAB1-              | Input          | Channel B ADC serial data  | MSB first                                    |
| 31                  | AENA1+                 | Output         | Amplifier enable   | High is enable                               |
| 32                  | AENA1-                 | Output         | Amplifier enable   | Low is enable                                |
| 33                  | FAULT1+                | Input          | Amplifier fault  | Programmable polarity                        |
| 34                  | FAULT1-                | Input          | Amplifier fault  | Programmable polarity                        |
| 35                  | PWMATOP1+<br>DAC_CLK1+ | Output         | Phase A Top CMD or DAC clock   | Programmable function control                |
| 36                  | PWMATOP1-<br>DAC_CLK1- | Output         | Phase A Top CMD or DAC clock   | Programmable function control                |




|    |                        |                |  |   |
|----|------------------------|----------------|--|---|
| 37 | PWMABOT1+<br>DAC1A+    | Output         | Phase A Bottom CMD or<br>DAC A serial data | Programmable function control                   |
| 38 | PWMABOT1-<br>DAC1A-    | Output         | Phase A Bottom CMD or<br>DAC A serial data | Programmable function control                   |
| 39 | PWMBTOP1+<br>DAC_STB1+ | Output         | Phase B Top CMD or DAC<br>strobe           | Programmable function control                   |
| 40 | PWMBTOP1-<br>DAC_STB1- | Output         | Phase B Top CMD or DAC<br>strobe           | Programmable function control                   |
| 41 | PWMBBOT1+<br>DAC1B+    | Output         | Phase B Bottom CMD or<br>DAC B serial data | Programmable function control                   |
| 42 | PWMBBOT1-<br>DAC1B-    | Output         | Phase B Bottom CMD or<br>DAC B serial data | Programmable function control                   |
| 43 | PWMCTOP1+<br>DIR1+     | Output         | Phase B Top CMD or PFM<br>direction        | Programmable function control                   |
| 44 | PWMCTOP1-<br>DIR1-     | Output         | Phase B Top CMD or PFM<br>direction        | Programmable function control                   |
| 45 | PWMCBOT1+<br>PULSE1+   | Output         | Phase B Bottom CMD or<br>PFM pulse         | Programmable function control                   |
| 46 | PWMCBOT1-<br>PULSE1-   | Output         | Phase B Bottom CMD or<br>PFM pulse         | Programmable function control                   |
| 47 | GND                    | Common         | Reference voltage                          |   |
| 48 | GND                    | Common         | Reference voltage                          |   |
| 49 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 50 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 51 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 52 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 53 | GND                    | Common         | Reference voltage                          |   |
| 54 | GND                    | Common         | Reference voltage                          |   |
| 55 | CHA2+                  | Input          | Encoder 2 positive A channel               | Also pulse input                                |
| 56 | CHA2-                  | Input          | Encoder 2 negative A channel               | Also pulse input                                |
| 57 | CHB2+                  | Input          | Encoder 2 positive B channel               | Also direction input                            |
| 58 | CHB2-                  | Input          | Encoder 2 negative B channel               | Also direction input                            |
| 59 | CHC2+                  | Input          | Encoder 2 positive C channel               | Index channel                                   |
| 60 | CHC2-                  | Input          | Encoder 2 negative C channel               | Index channel                                   |
| 61 | CHU2                   | Input          | Channel 2 U flag                           | Hall effect, fault code, or sub-<br>count       |
| 62 | CHV2                   | Input          | Channel 2 V flag                           | Hall effect, fault code, or sub-<br>count       |
| 63 | CHW2                   | Input          | Channel 2 W flag                           | Hall effect, fault code, or sub-<br>count       |
| 64 | CHT2                   | Input          | Channel 2 T flag                           | Fault code, or sub-count                        |
| 65 | USER2                  | Input          | General purpose user flag                  | Hardware capture flag, or sub-<br>count         |
| 66 | PLIM2                  | Input          | Positive overtravel limit                  | Hardware capture flag                           |
| 67 | MLIM2                  | Input          | Negative overtravel limit                  | Hardware capture flag                           |
| 68 | HOME2                  | Input          | Home switch input                          | Hardware capture flag                           |
| 69 | ACCFLT2                | Input          | Accessory fault flag                       | For loss of ACC supply voltage                  |
| 70 | WD0/                   | Output         | Watchdog output                            | Low is PMAC watchdog fault                      |

|     |                        |                |   |  |
|-----|------------------------|----------------|---|--|
| 71  | SCLK12+                | Input / Output | Encoder sample clock                    | Direction controlled by PMAC2 jumper         |
| 72  | SCLK12-                | Input / Output | Encoder sample clock                    | Direction controlled by PMAC2 jumper         |
| 73  | ADC_CLK2+              | Output         | A/D converter clock                     | Programmable frequency                       |
| 74  | ADC_CLK2-              | Output         | A/D converter clock                     | Programmable frequency                       |
| 75  | ADC_STB2+              | Output         | A/D converter strobe                    | Programmable sequence                        |
| 76  | ADC_STB2-              | Output         | A/D converter strobe                    | Programmable sequence                        |
| 77  | ADC_DAA2+              | Input          | Channel A ADC serial data               | MSB first                                    |
| 78  | ADC_DAA2-              | Input          | Channel A ADC serial data               | MSB first                                    |
| 79  | ADC_DAB2+              | Input          | Channel B ADC serial data               | MSB first                                    |
| 80  | ADC_DAB2-              | Input          | Channel B ADC serial data               | MSB first                                    |
| 81  | AENA2+                 | Output         | Amplifier enable                        | High is enable                               |
| 82  | AENA2-                 | Output         | Amplifier enable                        | Low is enable                                |
| 83  | FAULT2+                | Input          | Amplifier fault                         | Programmable polarity                        |
| 84  | FAULT2-                | Input          | Amplifier fault                         | Programmable polarity                        |
| 85  | PWMATOP2+<br>DAC_CLK2+ | Output         | Phase A Top CMD or DAC clock            | Programmable function control                |
| 86  | PWMATOP2-<br>DAC_CLK2- | Output         | Phase A Top CMD or DAC clock            | Programmable function control                |
| 87  | PWMABOT2+<br>DAC2A+    | Output         | Phase A Bottom CMD or DAC A serial data | Programmable function control                |
| 88  | PWMABOT2-<br>DAC2A-    | Output         | Phase A Bottom CMD or DAC A serial data | Programmable function control                |
| 89  | PWMBTOP2+<br>DAC_STB2+ | Output         | Phase B Top CMD or DAC strobe           | Programmable function control                |
| 90  | PWMBTOP2-<br>DAC_STB2- | Output         | Phase B Top CMD or DAC strobe           | Programmable function control                |
| 91  | PWMBBOT2+<br>DAC2B+    | Output         | Phase B Bottom CMD or DAC B serial data | Programmable function control                |
| 92  | PWMBBOT2-<br>DAC2B-    | Output         | Phase B Bottom CMD or DAC B serial data | Programmable function control                |
| 93  | PWMCTOP2+<br>DIR2+     | Output         | Phase B Top CMD or PFM direction        | Programmable function control                |
| 94  | PWMCTOP2-<br>DIR2-     | Output         | Phase B Top CMD or PFM direction        | Programmable function control                |
| 95  | PWMCBOT2+<br>PULSE2+   | Output         | Phase B Bottom CMD or PFM pulse         | Programmable function control                |
| 96  | PWMCBOT2-<br>PULSE2-   | Output         | Phase B Bottom CMD or PFM pulse         | Programmable function control                |
| 97  | GND                    | Common         | Reference voltage                       |  |
| 98  | GND                    | Common         | Reference voltage                       |  |
| 99  | +5V                    | Output / Input | +5V power                               | For external circuit or from external supply |
| 100 | +5V                    | Output / Input | +5V power                               | For external circuit or from external supply |

The JMACH1 connector provides the interface pins for channels 1 and 2. Usually, it is connected to a breakout board, such as one of the ACC-8x family of boards, or an application-specific interface board.

## J10 (JMACH2) Connector Description

| J10 JMACH2 Connector |                        |                | <br>Front View |  |
|----------------------|------------------------|----------------|--|--|
| Pin#                 | Symbol                 | Function       | Description  | Notes  |
| 1                    | +5V                    | Output / Input | +5V power  | For external circuit or from external supply |
| 2                    | +5V                    | Output / Input | +5V power  | For external circuit or from external supply |
| 3                    | GND                    | Common         | Reference voltage  |  |
| 4                    | GND                    | Common         | Reference voltage  |  |
| 5                    | CHA3+                  | Input          | Encoder 3 positive A channel   | Also pulse input                             |
| 6                    | CHA3-                  | Input          | Encoder 3 negative A channel   | Also pulse input                             |
| 7                    | CHB3+                  | Input          | Encoder 3 positive B channel   | Also direction input                         |
| 8                    | CHB3-                  | Input          | Encoder 3 negative B channel   | Also direction input                         |
| 9                    | CHC3+                  | Input          | Encoder 3 positive C channel   | Index channel                                |
| 10                   | CHC3-                  | Input          | Encoder 3 negative C channel   | Index channel                                |
| 11                   | CHU3                   | Input          | Channel 3 U flag   | Hall effect, fault code, or sub-count        |
| 12                   | CHV3                   | Input          | Channel 3 V flag   | Hall effect, fault code, or sub-count        |
| 13                   | CHW3                   | Input          | Channel 3 W flag   | Hall effect, fault code, or sub-count        |
| 14                   | CHT3                   | Input          | Channel 3 T flag   | Fault code, or sub-count                     |
| 15                   | USER3                  | Input          | General purpose user flag  | Hardware capture flag, or sub-count          |
| 16                   | PLIM3                  | Input          | Positive overtravel limit  | Hardware capture flag                        |
| 17                   | MLIM3                  | Input          | Negative overtravel limit  | Hardware capture flag                        |
| 18                   | HOME3                  | Input          | Home switch input  | Hardware capture flag                        |
| 19                   | ACCFLT3                | Input          | Accessory fault flag   | For loss of acc supply voltage               |
| 20                   | WD0/                   | Output         | Watchdog output  | Low is PMAC watchdog fault                   |
| 21                   | SCLK34+                | Input / Output | Encoder sample clock   | Direction controlled by PMAC2 jumper         |
| 22                   | SCLK34-                | Input / Output | Encoder sample clock   | Direction controlled by PMAC2 jumper         |
| 23                   | ADC_CLK3+              | Output         | A/D converter clock  | Programmable frequency                       |
| 24                   | ADC_CLK3-              | Output         | A/D converter clock  | Programmable frequency                       |
| 25                   | ADC_STB3+              | Output         | A/D converter strobe   | Programmable sequence                        |
| 26                   | ADC_STB3-              | Output         | A/D converter strobe   | Programmable sequence                        |
| 27                   | ADC_DAA3+              | Input          | Channel A ADC serial data  | MSB first                                    |
| 28                   | ADC_DAA3-              | Input          | Channel A ADC serial data  | MSB first                                    |
| 29                   | ADC_DAB3+              | Input          | Channel B ADC serial data  | MSB first                                    |
| 30                   | ADC_DAB3-              | Input          | Channel B ADC serial data  | MSB first                                    |
| 31                   | AENA3+                 | Output         | Amplifier enable   | High is enable                               |
| 32                   | AENA3-                 | Output         | Amplifier enable   | Low is enable                                |
| 33                   | FAULT3+                | Input          | Amplifier fault  | Programmable polarity                        |
| 34                   | FAULT3-                | Input          | Amplifier fault  | Programmable polarity                        |
| 35                   | PWMATOP3+<br>DAC_CLK3+ | Output         | Phase A Top CMD or DAC clock   | Programmable function control                |
| 36                   | PWMATOP3-<br>DAC_CLK3- | Output         | Phase A Top CMD or DAC clock   | Programmable function control                |

|    |                        |                |  |   |
|----|------------------------|----------------|--|---|
| 37 | PWMABOT3+<br>DAC3A+    | Output         | Phase A Bottom CMD or<br>DAC A serial data | Programmable function<br>control                |
| 38 | PWMABOT3-<br>DAC3A-    | Output         | Phase A Bottom CMD or<br>DAC A serial data | Programmable function<br>control                |
| 39 | PWMBTOP3+<br>DAC_STB3+ | Output         | Phase B Top CMD or DAC<br>strobe           | Programmable function<br>control                |
| 40 | PWMBTOP3-<br>DAC_STB3- | Output         | Phase B Top CMD or DAC<br>strobe           | Programmable function<br>control                |
| 41 | PWMBBOT3+<br>DAC3B+    | Output         | Phase B Bottom CMD or<br>DAC B serial data | Programmable function<br>control                |
| 42 | PWMBBOT3-<br>DAC3B-    | Output         | Phase B Bottom CMD or<br>DAC B serial data | Programmable function<br>control                |
| 43 | PWMCTOP3+<br>DIR3+     | Output         | Phase B Top CMD or PFM<br>direction        | Programmable function<br>control                |
| 44 | PWMCTOP3-<br>DIR3-     | Output         | Phase B Top CMD or PFM<br>direction        | Programmable function<br>control                |
| 45 | PWMCBOT3+<br>PULSE3+   | Output         | Phase B Bottom CMD or<br>PFM pulse         | Programmable function<br>control                |
| 46 | PWMCBOT3-<br>PULSE3-   | Output         | Phase B Bottom CMD or<br>PFM pulse         | Programmable function<br>control                |
| 47 | GND                    | Common         | Reference voltage                          |   |
| 48 | GND                    | Common         | Reference voltage                          |   |
| 49 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 50 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 51 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 52 | +5V                    | Output / Input | +5V power                                  | For external circuit or from<br>external supply |
| 53 | GND                    | Common         | Reference voltage                          |   |
| 54 | GND                    | Common         | Reference voltage                          |   |
| 55 | CHA4+                  | Input          | Encoder 4 positive A channel               | Also pulse input                                |
| 56 | CHA4-                  | Input          | Encoder 4 negative A channel               | Also pulse input                                |
| 57 | CHB4+                  | Input          | Encoder 4 positive B channel               | Also direction input                            |
| 58 | CHB4-                  | Input          | Encoder 4 negative B channel               | Also direction input                            |
| 59 | CHC4+                  | Input          | Encoder 4 positive C channel               | Index channel                                   |
| 60 | CHC4-                  | Input          | Encoder 4 negative C channel               | Index channel                                   |
| 61 | CHU4                   | Input          | Channel 4 U flag                           | Hall effect, fault code, or sub-<br>count       |
| 62 | CHV4                   | Input          | Channel 4 V flag                           | Hall effect, fault code, or sub-<br>count       |
| 63 | CHW4                   | Input          | Channel 4 W flag                           | Hall effect, fault code, or sub-<br>count       |
| 64 | CHT4                   | Input          | Channel 4 T flag                           | Fault code, or sub-count                        |
| 65 | USER4                  | Input          | General purpose user flag                  | Hardware capture flag, or<br>sub-count          |
| 66 | PLIM4                  | Input          | Positive overtravel limit                  | Hardware capture flag                           |
| 67 | MLIM4                  | Input          | Negative overtravel limit                  | Hardware capture flag                           |
| 68 | HOME4                  | Input          | Home switch input                          | Hardware capture flag                           |
| 69 | ACCFLT4                | Input          | Accessory fault flag                       | For loss of ACC supply<br>voltage               |
| 70 | WD0/                   | Output         | Watchdog output                            | Low is PMAC watchdog fault                      |

|  |                        |                |   |  |
|--|------------------------|----------------|---|--|
| 71   | SCLK34+                | Input / Output | Encoder sample clock                    | Direction controlled by PMAC2 jumper         |
| 72   | SCLK34-                | Input / Output | Encoder sample clock                    | Direction controlled by PMAC2 jumper         |
| 73   | ADC_CLK4+              | Output         | A/D converter clock                     | Programmable frequency                       |
| 74   | ADC_CLK4-              | Output         | A/D converter clock                     | Programmable frequency                       |
| 75   | ADC_STB4+              | Output         | A/D converter strobe                    | Programmable sequence                        |
| 76   | ADC_STB4-              | Output         | A/D converter strobe                    | Programmable sequence                        |
| 77   | ADC_DAA4+              | Input          | Channel A ADC serial data               | MSB first                                    |
| 78   | ADC_DAA4-              | Input          | Channel A ADC serial data               | MSB first                                    |
| 79   | ADC_DAB4+              | Input          | Channel B ADC serial data               | MSB first                                    |
| 80   | ADC_DAB4-              | Input          | Channel B ADC serial data               | MSB first                                    |
| 81   | AENA4+                 | Output         | Amplifier enable                        | High is enable                               |
| 82   | AENA4-                 | Output         | Amplifier enable                        | Low is enable                                |
| 83   | FAULT4+                | Input          | Amplifier fault                         | Programmable polarity                        |
| 84   | FAULT4-                | Input          | Amplifier fault                         | Programmable polarity                        |
| 85   | PWMATOP4+<br>DAC_CLK4+ | Output         | Phase A Top CMD or DAC clock            | Programmable function control                |
| 86   | PWMATOP4-<br>DAC_CLK4- | Output         | Phase A Top CMD or DAC clock            | Programmable function control                |
| 87   | PWMBOT4+<br>DAC4A+     | Output         | Phase A Bottom CMD or DAC A serial data | Programmable function control                |
| 88   | PWMBOT4-<br>DAC4A-     | Output         | Phase A Bottom CMD or DAC A serial data | Programmable function control                |
| 89   | PWMBTOP4+<br>DAC_STB4+ | Output         | Phase B Top CMD or DAC strobe           | Programmable function control                |
| 90   | PWMBTOP4-<br>DAC_STB4- | Output         | Phase B Top CMD or DAC strobe           | Programmable function control                |
| 91   | PWMBBOT4+<br>DAC4B+    | Output         | Phase B Bottom CMD or DAC B serial data | Programmable function control                |
| 92   | PWMBBOT4-<br>DAC4B-    | Output         | Phase B Bottom CMD or DAC B serial data | Programmable function control                |
| 93   | PWMCOT4+<br>DIR4+      | Output         | Phase B Top CMD or PFM direction        | Programmable function control                |
| 94   | PWMCOT4-<br>DIR4-      | Output         | Phase B Top CMD or PFM direction        | Programmable function control                |
| 95   | PWMCBOT4+<br>PULSE4+   | Output         | Phase B Bottom CMD or PFM pulse         | Programmable function control                |
| 96   | PWMCBOT4-<br>PULSE4-   | Output         | Phase B Bottom CMD or PFM pulse         | Programmable function control                |
| 97   | GND                    | Common         | Reference voltage                       |  |
| 98   | GND                    | Common         | Reference voltage                       |  |
| 99   | +5V                    | Output / Input | +5V power                               | For external circuit or from external supply |
| 100  | +5V                    | Output / Input | +5V power                               | For external circuit or from external supply |
| The JMACH2 connector provides the interface pins for channels 3 and 4. Usually, it is connected to a breakout board, such as one of the ACC-8x family of boards, or an application-specific interface board. |                        |                |   |  |

## TB1 (2/4-Pin Terminal Block)

This terminal block can be used to provide the input for the power supply for the circuits on the PMAC2 board when it is not in a bus configuration. When the PMAC2 Lite is in a bus configuration, these supplies come through the bus connector from the bus power supply automatically; in this case, this terminal block should not be used.

| Pin#  | Symbol | Function | Description             | Notes  |
|---|--------|----------|-------------------------|--|
| 1   | GND    | Common   | Reference voltage       |  |
| 2   | +5V    | Input    | Positive supply voltage | Supplies all PMAC digital circuits   |
| 3   | +12V   | Input    | Positive supply voltage | +12v to +15v; not required on-board; used on J1 to supply analog inputs    |
| 4   | -12V   | Input    | Negative supply voltage | -12v to -15v; required for opt-12 ADCs; used on J1 to supply analog inputs |
| <b>Note:</b> Unless Option 12 (Analog-to-Digital Converters) is included on the board, only pins 1 and 2 will be provided on this terminal block. |        |          |                         |  |

## TB2 (3-Pin Terminal Block)

This terminal block provides the output for PMAC2's watchdog timer relay, both normally open and normally closed contacts.

| Pin#   | Symbol | Function | Description        | Notes           |
|--|--------|----------|--------------------|-----------------|
| 1  | WD_NC  | Output   | Watchdog relay out | Normally closed |
| 2  | COM    | Input    | Watchdog return    | +V or 0V        |
| 3  | WD_NO  | Output   | Watchdog relay out | Normally open   |
| <b>Note:</b> The normally closed relay contact is open while PMAC2 Lite is operating properly — it has power and the watchdog timer is not tripped. This contact is closed when the PMAC2 Lite is not operating properly (either the PMAC has lost power or the watchdog timer has tripped). The normally open relay contact is closed while PMAC2 is operating properly, and open when PMAC2 is not operating properly. |        |          |                    |                 |



## Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

### SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

### *InstraView*<sup>SM</sup> REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at [www.instraview.com](http://www.instraview.com) ↗

### WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. [www.artisanng.com/WeBuyEquipment](http://www.artisanng.com/WeBuyEquipment) ↗

### LOOKING FOR MORE INFORMATION?

Visit us on the web at [www.artisanng.com](http://www.artisanng.com) ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

**Contact us:** (888) 88-SOURCE | [sales@artisanng.com](mailto:sales@artisanng.com) | [www.artisanng.com](http://www.artisanng.com)