



Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

*InstraView*SM REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at www.instraview.com ↗

WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. www.artisanng.com/WeBuyEquipment ↗

LOOKING FOR MORE INFORMATION?

Visit us on the web at www.artisanng.com ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

Contact us: (888) 88-SOURCE | sales@artisanng.com | www.artisanng.com

MODEL 8901A
CAMAC-TO-GPIB INTERFACE



(FAN 2016)



Corporate Headquarters

700 Chestnut Ridge Road
Chestnut Ridge, NY 10977-6499
Tel: (914) 578-6013 Fax: (914) 578-5985
E-mail: lrs_sales@lecroy.com
lrs_support@lecroy.com

Copyright© July 1997. LeCroy™ is a registered trademark of
LeCroy Corporation. All rights reserved. Information in this
publication supersedes all earlier versions.

CE CONFORMITY

CONDITIONS FOR CE CONFORMITY

Since this product is a subassembly, it is the responsibility of the end user, acting as the system integrator, to ensure that the overall system is CE compliant. This product was demonstrated to meet CE conformity using a CE compliant crate housed in an EMI/RFI shielded enclosure. It is strongly recommended that the system integrator establish these same conditions.



CAUTION

INSTALLATION

Crate power should be turned off during insertion or removal of modules to avoid possible damage caused by momentary misalignment of contacts.

SPECIFICATIONS

The information contained in this manual is subject to change without notice. The reference for product specification is the Technical Data Sheet effective at the time of purchase.



TABLE OF CONTENTS

1. General Information	
Purpose	9
Unpacking and Inspection	9
Warranty	9
Product Assistance	9
Maintenance Agreements	9
Documentation Discrepancies	10
Service Procedures	10
2. Product Description	
The 8901A and the CAMAC Standard	11
Upgrade Notes	11
Specifications	11
Internal Registers and Byte Descriptions	11
CAMAC Cycle Execution	12
CLEAR, INITIALIZE and INHIBIT	12
Block Transfer Mode	12
Service Requests (SRQ)	12
Serial Poll	12
Front Panel LEDs	12
GPIB Device Address Switch	13
General	13
3. Installation	
Setup of Jumpers and Mechanical Switches	15
GPIB Address	15
Byte Order Jumpers	15
Installation in Mainframe	15
4. Operating Instructions	
Introduction	17
Instrument Drivers and Example Source Code	17
Command Types	17
8901A Setup Command Information	17
Transfer Mode Commands	17
SRQ Setup Commands and Responses	18
CAMAC Commands	19
The C, Z and I Commands	19
Commands to Individual Modules	20
Programming the 8901A and Other CAMAC Modules	20
General	20
LISTEN, TALK, UNLISTEN: GPIB Bus Actions	20
Uploading Command Byte(s) to the 8901A	21
Procedure for 8901A Setup Commands	21
Procedure for C, Z, and I Commands	21
Procedure for Commands Sent to Individual Modules	22
Procedure for Readout of Data into Computer	23
Programming Example: Sample Source Code	24
5. Theory Of Operation	
General	31
GPIB Command Decoder	31
Acceptor Handshake	32
LISTEN Mode	32
Global CAMAC Commands	32

F,A,N CAMAC Commands	32
Transfer Mode	32
Serial Poll Mode	33
TALK Mode	33
Source Handshake	33
CAMAC Cycle Timing	33
Read Data	33
X and Q Response	33
LAM Lines	34
SRQ Generation	34
6. Appendix	
AN-33 "An Introduction to CAMAC"	35
7. Index	45

GENERAL INFORMATION

PURPOSE	<p>This manual is intended to provide instruction regarding the setup and operation of the covered instruments. In addition, it describes the theory of operation and presents other information regarding its functioning and application.</p>
UNPACKING AND INSPECTION	<p>It is recommended that the shipment be thoroughly inspected immediately upon delivery. All material in the container should be checked against the enclosed Packing List and shortages reported promptly. If the shipment is damaged in any way, please notify the Customer Service Department or the local field service office. If the damage is due to mishandling during shipment, you may be requested to assist in contacting the carrier in filing a damage claim.</p>
WARRANTY	<p>LeCroy warrants its instrument products to operate within specifications under normal use and service for a period of one year from the date of shipment. Component products, replacement parts, and repairs are warranted for 90 days. This warranty extends only to the original purchaser. Software is thoroughly tested, but is supplied "as is" with no warranty of any kind covering detailed performance. Accessory products not manufactured by LeCroy are covered by the original equipment manufacturers' warranty only.</p> <p>In exercising this warranty, LeCroy will repair or, at its option, replace any product returned to the Customer Service Department or an authorized service facility within the warranty period, provided that the warrantor's examination discloses that the product is defective due to workmanship or materials and has not been caused by misuse, neglect, accident or abnormal conditions or operations.</p> <p>The purchaser is responsible for the transportation and insurance charges arising from the return of products to the servicing facility. LeCroy will return all in-warranty products with transportation prepaid.</p> <p>This warranty is in lieu of all other warranties, express or implied, including but not limited to any implied warranty of merchantability, fitness, or adequacy for any particular purpose or use. LeCroy shall not be liable for any special, incidental, or consequential damages, whether in contract, or otherwise.</p>
PRODUCT ASSISTANCE	<p>Answers to questions concerning installation, calibration, and use of LeCroy equipment are available from the Customer Service Department, 700 Chestnut Ridge Road, Chestnut Ridge, New York, 10977-6499, (914) 578-6030.</p>
MAINTENANCE AGREEMENTS	<p>LeCroy offers a selection of customer support services. For example, Maintenance Agreements provide extended warranty that allows the customer to budget maintenance costs after the initial warranty has expired. Other services such as installation, training, on-site repair, and addition of engineering improvements are available through specific Supplemental Support Agreements. Please contact the Customer Service Department for more information.</p>

**DOCUMENTATION
DISCREPANCIES**

LeCroy is committed to providing state-of-the-art instrumentation and is continually refining and improving the performance of its products. While physical modifications can be implemented quite rapidly, the corrected documentation frequently requires more time to produce. Consequently, this manual may not agree in every detail with the accompanying product and the schematics in the Service Documentation. There may be small discrepancies in the values of components for the purposes of pulse shape, timing, offset, etc., and, occasionally, minor logic changes. Where any such inconsistencies exist, please be assured that the unit is correct and incorporates the most up-to-date circuitry.

SERVICE PROCEDURE

Products requiring maintenance should be returned to the Customer Service Department or authorized service facility. If under warranty, LeCroy will repair or replace the product at no charge. The purchaser is only responsible for the transportation charges arising from return of the goods to the service facility. For all LeCroy products in need of repair after the warranty period, the customer must provide a Purchase Order Number before any inoperative equipment can be repaired or replaced. The customer will be billed for the parts and labor for the repair as well as for shipping. All products returned for repair should be identified by the model and serial numbers and include a description of the defect or failure, name and phone number of the user. In the case of products returned, a Return Authorization Number is required and may be obtained by contacting the Customer Service Department at (914) 578-6030.

PRODUCT DESCRIPTION

THE 8901A and the CAMAC STANDARD

The Model 8901A is a CAMAC module which provides GPIB access to a CAMAC mainframe.

CAMAC is an international standard for modularized instrumentation as defined by the ESONE Committee and the IEEE (Standard 583). Its function is to provide a means by which a wide range of modular instruments can be powered in a multi-receptacle crate and interfaced to a computer. The LeCroy Model 8901A CAMAC to GPIB (IEEE 488) interface allows the CAMAC system configuration to be used with GPIB computer controllers.

Simple program instructions via the GPIB to registers in the Model 8901A select an individual instrument module within the CAMAC mainframe, select any subaddress within that module, and establish the function (read, write, control). This allows the user to handle the entire CAMAC mainframe of up to 23 individual instrument modules in the same manner as any ordinary single device connected to the IEEE-488 bus. It is possible to interconnect up to 15 different CAMAC mainframes in this way.

The 8901A can be programmed to do a block transfer of all data within a CAMAC module to a GPIB Listener without additional intermediate commands. In this mode, the 8901A will alternately transfer one, two or three 8-bit bytes (as programmed) as fast as the Listener can accept them (at rates approaching 500 kilobytes/sec) and then initiate a new CAMAC acquisition cycle. Not all CAMAC modules, however, support Block Read readout.

UPGRADE NOTES

The Model 8901A is a direct replacement for both the LeCroy Model 8901 and 8901/100 (Mod 100). In addition to all of the 8901-8901/100 features, the "A" version includes the generation of the GPIB EOI signal at the end of valid data, a jumper to select the order in which data bytes are sent to the GPIB controller, and a "slow" block mode transfer for instruments that cannot be read out at full CAMAC speed.

SPECIFICATIONS

Internal Registers and Byte Descriptions

Registers in the 8901A Interface are sequentially loaded with data after it has been commanded to enter the LISTEN mode by the GPIB System Controller. These registers store all the information necessary (F, A, N, W, C, Z, I) to generate standard CAMAC cycles (see Table 1).

The first byte received by the interface after it has entered the LISTEN mode contains either the CAMAC Function (F Code) or 8901A Setup information. The second and sequential bytes accept, respectively, the CAMAC subaddress (A Code), station number (N Code) and three bytes of data.

Once these registers have been loaded, the information will be retained until modified or power is turned off. The loading process can be terminated (and re-initialized) after any number of bytes have been transferred by issuing a TALK, LISTEN, Unlisten or IFC command. Again, note that the 8901A must be placed in LISTEN mode before it will receive any information.

Table 1: Register Descriptions

Register Name	Register Description
F	Contains Function code OR Setup Command
A	Module Subaddress
N	CAMAC station (slot) number
D1	Low data byte (bits W1-W8 on CAMAC Dataway)
D2	Middle data byte (bits W9-W16)
D3	High data byte (bits W17-W24)

CAMAC Cycle Execution

A CAMAC cycle is executed every time the 8901A is commanded to enter the TALK mode and a Service Request is not pending. At the completion of the CAMAC cycle a DAV (Data Valid) will be asserted. Every time a byte is accepted a new byte is made available. When no more data is available, the 8901A asserts End of Identity (EOI).

CLEAR, INITIALIZE and INHIBIT

The 8901A can be programmed to generate CLEAR (C), INITIALIZE (Z), or INHIBIT (I) signals on the dataway when a CAMAC cycle is executed. The C and Z registers are cleared after the completion of the next CAMAC cycle. The INHIBIT register will remain set until it is programmed off.

Block Transfer Mode

The 8901A can be programmed to do a high speed block transfer of 8-, 16-, or 24-bit words from CAMAC modules with read and increment capability. Following module addressing and the appropriate control byte, (see Operating Instructions) a TALK command will start the 8901A to read one, two, or three bytes of data and automatically initiate another CAMAC cycle. Approximately 2 μ sec later (a programmable 40 μ sec delay can be used for slow modules) new data is available to be read. CAMAC cycles will continue to be executed until a Q=0 (end of memory) condition causes the 8901A to stop executing CAMAC cycles and exit the transfer mode.

Service Requests (SRQ)

The 8901A can be programmed to operate in SRQ mode. In this mode, a Service Request will be issued after a specific condition occurs on the CAMAC dataway, involving the dataway LAM, Q and X lines.

Serial Poll

After issuing a service request, a Serial Poll must be performed. The 8901A will send the status of the individual LAM, X and Q lines, terminating the Service Request after the controller reads the status byte. Note: For a LAM-generated Service Request, the LAM must be cleared or disabled before the poll is taken, or else another service request will immediately be issued.

Front Panel LEDs

TALK: indicates when 8901A is a GPIB Talker.

LISTEN: indicates when 8901A is a GPIB Listener.

SRQ Enable: indicates when 8901A is enabled to carry out Service Requests.

X Response: indicates a valid command was accepted by the addressed module.

Q Response: indicates a valid data transfer or valid test within the mainframe.

Look-at-Me: indicates when any CAMAC modules sets "LAM" line (often used to generate a Service Request).

INHIBIT: indicates when CAMAC dataway is inhibited. (Note: the INHIBIT LED turns on when the appropriate control byte is uploaded. A TALK must still be executed for before other modules can be Inhibited.

**GPIB Device
Address Switch**

Sets the GPIB Address of the 8901A. See Figure 1 on page 15.

General

The 8901A resides in the two slots furthest right in a CAMAC mainframe and generates all CAMAC dataway signals in response to commands from a GPIB controller. A standard GPIB connector on the front panel permits interconnection to any GPIB system. This allows any GPIB controller to program settings, read from or write to any standard CAMAC modules.

Packaging: is in conformance with CAMAC standard, RF-shielded 2 module.

Power Required: is 1.2 A at +6 V.



INSTALLATION

SETUP OF JUMPERS AND MECHANICAL SWITCHES

Before installation in a mainframe, set the GPIB Address and Byte Order jumpers as described in this section.

GPIB Address

Each device connected to the GPIB must have a unique address which the system controller uses to communicate with it. The address of the Model 8901A is set by a DIP switch located under the GPIB connector on the front panel. The switches are labeled A0, A1, A2, A3, A4 (representing values of 1, 2, 4, 8, 16 respectively). Valid GPIB address are 0 to 31. Figure 1 shows an address setting of 9 as an example.




Figure 1

Byte Order Jumpers

On the side panel of the Model 8901A are two pair of jumpers labeled "NORMAL" and "REVERSE". These jumpers determine the order in which the data bytes are read out. When the jumpers are set to normal, the least significant byte of data is read out first in multi-byte transfers. When in the reverse byte position, a 16-bit word is read out, most significant byte first, followed by the least significant byte. If 24-bit transfer is selected, the order is middle byte, least significant byte and then most significant byte. It is recommended that the reverse byte option only be used when the computer expects the MSB before the LSB in a 16-bit word. *Caution* - this jumper only controls the byte order for reading out of the 8901A. It does not effect the data bytes uploaded to the dataway "Write" lines.

NORMAL setting byte readback order: Byte #1, Byte #2, Byte #3

REVERSE setting byte readback order: Byte #2, Byte #1, Byte #3

INSTALLATION IN MAINFRAME

The 8901A is compatible with any standard CAMAC mainframe.

With the power off, insert the 8901A into the Control Station location (the two rightmost locations in the mainframe). Modules may become damaged if inserted with power on, due to momentary misalignment of the contacts.

Note: CAMAC mainframes with an embedded controller, like the Model DDC3000, may not contain a Control Station.

Connect a GPIB cable from the 8901A to the GPIB interface associated with your computer.

Always ensure that the mainframe has sufficient clearance at the top to permit adequate airflow. For example, when using the 8901A in the 8013A benchtop instrument mainframe, air-blocking baffles (Models BFP-1 and BFP-2) should be used to ensure proper cooling. Do not obstruct ventilation by placing papers or other objects on the top of the mainframe.

OPERATING INSTRUCTIONS

INTRODUCTION

The 8901A provides GPIB control of all instruments in a CAMAC mainframe by transferring data uploaded via GPIB to the CAMAC dataway, and by controlling the execution of CAMAC cycles.

Instrument Drivers and Example Source Code

Current versions of instrument drivers for the LabVIEW™ and LabWindows™ packages are available from the LeCroy WWW and FTP sites, as well as some sample source code and control programs. All 8901A sample software is not protected under the 8901A warranty.

Please also refer to the next chapter "Programming CAMAC Modules" for information on uploading and executing commands described in this section.

Command Types

The GPIB controller may send the 8901A two basic types of commands:

1. **8901A Setup Commands:** These commands program the 8901A, and do not involve the CAMAC dataway or other CAMAC modules.
2. **CAMAC Commands:** These commands are communicated through the CAMAC dataway for programming and operation of other instruments in the mainframe.

8901A SETUP COMMAND INFORMATION

There are two categories of Setup Commands:

- Transfer Mode Commands
- SRQ (Service Request) Configuration Commands

These are all single byte commands. Please see the section "Programming the 8901A and other CAMAC Modules" for programming instructions.

Transfer Mode Commands

By sending the appropriate command byte (see Table 3), the 8901A can be programmed to return 8, 16, or 24-bit data words in either single or block word transfers over the GPIB bus. In the case of multiple byte transfers, data is sent based on the Byte Order Jumper setting. When the byte order is set to NORMAL the least significant byte is sent first followed by the middle and high bytes.

In "normal" transfer modes (not to be confused with the NORMAL jumper setting mentioned above), the 1, 2, or 3 data bytes are followed by a status byte containing the X response (least significant bit) and the Q response (bit 2), along with the GPIB EOI status line, which is asserted to indicate end of the data transfer. When programmed for normal transfers, the 8901A will await further commands after data is transferred.

Table 3 - Transfer Mode Commands

	Normal Transfer		Block Read		High Speed Block Read	
8-bit read	97	(61)	121	(79)	105	(69)
16-bit read	98	(62)	122	(7A)	106	(6A)
24-bit read	100	(64)	124	(7C)	108	(6C)

Single byte commands - values specified in decimal with hex value given in ()

In block read modes, the 8901A will transfer a block of data. The 8901A will automatically initiate additional CAMAC cycles after downloading the current data word(s). CAMAC cycles will continue to be executed until the Q status line goes to 0, or until the GPIB controller terminates the transfer.

There are two basic types of block read modes in the 8901A. The first one, "normal block read" is provided for modules which cannot read out at full CAMAC speed (1 MHz). In this mode, a 35 µsec delay (plus GPIB overhead) is added between each CAMAC cycle to slow down the transfer rate. The other mode, "high speed block read" runs as fast as the data is read out over the GPIB, up to 2 µsec per cycle.

When block mode transfers are terminated by Q=0, two additional bytes are sent to the GPIB controller. A status byte with the X and Q data, followed by a zero byte and EOI.

Note: If the GPIB controller terminates the transfer before Q=0, one additional cycle will be executed and the data will be left in the 8901A's registers. To access this data, it is necessary to send the CAMAC command F(0) A(0) and N(24) (see next section), and then readout the data word. This is required since the 8901A is initiating the CAMAC cycles in block mode transfers.

At the end of each block transfer, the 8901A is reset to the corresponding normal transfer mode.

SRQ Setup Commands and Responses

A service request (SRQ) is a mechanism by which a GPIB compatible instrument can communicate to a computer that a particular condition exists, without requiring the computer to readout any data. There are three conditions occurring on the CAMAC bus which can be employed to cause the Model 8901A to issue a service request to the GPIB controller:

1. When any individual LAM line is set
2. When Q is set
3. When X is set

Table 4 lists the commands to send to the 8901A to set it up to generate a SRQ on the proper condition(s).

Table 4 - Service Request Response Commands

Disable SRQ	64 (40)
Enable SRQ on occurrence of LAM	65 (41)
Enable SRQ on occurrence of Q=0	66 (42)
Enable SRQ on occurrence of LAM or Q=0	67 (43)
Enable SRQ on occurrence of X=0	68 (44)
Enable SRQ on occurrence of LAM or X=0	69 (45)
Enable SRQ on occurrence of Q=0 or X = 0	70 (46)
Enable SRQ on occurrence of LAM, Q=0 or X=0	71 (47)

NOTE: All of these commands de-assert INHIBIT.

Single byte commands - values specified in decimal with hex value given in ()

The GPIB controller must perform a serial poll of all devices after receiving a service request. When the 8901A is polled, it sends up to 5 bytes of information to the GPIB controller. The first byte is a status byte which contains the current state of X and Q in bits 1 (LSB) and 2 respectively and bit 7 indicating whether or not the currently addressed 8901A was the device which requested service. If bit 7 is equal to one, the 8901A generated the request. The next four bytes indicate the state of the LAM lines. They are encoded as follows:

Byte #	Description
1	Status byte, with X and Q on bits 1 and 2 respectively
2	LAM for slots 1 through 6 (Slot 1 LAM is least significant bit)
3	LAM for slots 7 through 12
4	LAM for slots 13 through 18
5	LAM for slots 19 through 23

A service request by the 8901A will be cleared after the controller reads the status byte. However, if the request was caused by a LAM, a service request will immediately be issued again unless SRQ on LAM is disabled in the 8901A or the LAM is cleared in the instrument(s) asserting it. It is important to note that the 8901A cannot transfer any CAMAC commands to the dataway while any service request is pending.

CAMAC COMMANDS

CAMAC commands are communicated through the CAMAC dataway, for programming and operation of other instruments in the mainframe. There are two basic types.

The C, Z, and I Commands

The 8901A can be programmed to generate CLEAR (C), INITIALIZE (Z), or INHIBIT (I) signals on the dataway when a CAMAC cycle is executed. These commands are visible to all instruments in the mainframe. C, Z, and I are all single byte commands; please see the section "Programming the 8901A and other CAMAC Modules" for programming instructions. CAMAC modules may have different responses to these commands; please check the user manual for information specific to your modules. The "Introduction to CAMAC" Application Note (AN-33 included at the end of this manual) contains further information regarding standard use of the C, I and Z lines.

The CLEAR and INITIALIZE signals will be turned on only during the first CAMAC cycle executed after the 8901A received that command. The INHIBIT line will remain asserted until the 8901A is programmed to de-assert it. *Caution* - changing the INHIBIT line will affect the state of the service request response programming.

Send INITIALIZE (Z)	33	(21)
Send CLEAR (C)	34	(22)
Send CLEAR and INITIALIZE	35	(23)
Assert INHIBIT (I)	72	(48)
De-assert INHIBIT (also disables SRQ)	64	(40)

Single byte commands - values specified in decimal with hex value given in ()

Commands to Individual Modules

The 8901A transfers Function, Subaddress, Station (or slot) number, and up to three bytes of data to the CAMAC dataway when sending a CAMAC command. These commands are often referred to as "FAN", "FNA" or "Function code" commands.

Table 7 - Acceptable Values for FAN Commands

Command Component	Abbreviation	Range of Values
Function code	F	0 - 31
Subaddress	A	0 - 15
Station Number	N	1 - 25 (Normal stations typically occupy slots 1-23)
Data bytes	D1, D2, D3	0 - 255 each

PROGRAMMING THE 8901A AND OTHER CAMAC MODULES

General

The programming of the two types of commands described in the last section (SETUP COMMANDS and CAMAC COMMANDS) must be handled in slightly different manners. This section outlines the mechanics and examples necessary to upload and execute these commands.

LISTEN, TALK, UNLISTEN: GPIB Bus Actions

Proper programming of the 8901A requires an understanding of these modes. To place the 8901A into LISTEN or TALK mode, or to make it UNTALK or UNLISTEN, GPIB level commands must be executed, typically by the host computer. Please refer to the manual for your GPIB controller card for information on setting GPIB devices to be listeners, talkers, etc. Steps 1 and 3 in this section are of this type.

The C function for this operation when using NI-488 GPIB board-level commands is **ibcmd**. This function sends command bytes to the GPIB controller. The bytes contain information about the devices attached to the GPIB bus, and specifies through the use of device addresses if they are to be placed in TALK or LISTEN mode, or to UNTALK or UNLISTEN. These bytes are also referred to as "Interface Messages".

Here are the correct byte assignments for the "command byte" parameter used with **ibcmd**:

Table 8 - Byte values of GPIB Interface Messages

Action	Decimal Value of Command Byte
Make 8901A LISTEN	32 + (8901A device address)
Make 8901A TALK	64 + (8901A device address)
Make Computer a GPIB LISTENER	32
Make Computer a GPIB TALKER	64
Send UNLISTEN	63
Send UNTALK	95

A typical assignment of the 8901A address (set via the front panel dip switches is simply "1". Thus, the 8901A LISTEN and 8901A TALK bytes would become 33 and 64 respectively.

Note: All of the bytes above happen to have ASCII text equivalents, e.g., decimal 32 is the space character; decimal 65 is the letter "Capital A".

ibcmd can send multiple bytes, so it is convenient to make the 8901A LISTEN in at the same time as making the Computer a TALKER.

The 8901A must be placed in LISTEN mode to receive any information. Placing the 8901A into TALK mode will execute a CAMAC cycle.

Lastly, and importantly, the UNLISTEN action is used to latch data in the 8901A without executing a CAMAC cycle. This is necessary for the execution of 8901A SETUP COMMANDS.

Uploading Command Byte(s) to the 8901A

Step 2 of the examples below require the transfer of appropriate data to the 8901A. In the NI-488 board level command language, this is implemented using the **ibwrt** function. This function sends a stream of data to the 8901A. This data, of up to 6 bytes, is typically packed into either an array of characters (C programming language) or is packed into a String variable (Basic programming languages). The conversion of from INTEGER decimal value into a character is often accomplished using the **chr** function.

See "Procedures for Commands Sent to Individual Modules" below for more instruction.

Procedure for 8901A Setup Commands

The following steps should be used to upload and execute 8901A setup commands. All of these commands are defined by a single byte, and consist of the Transfer Mode and SRQ commands listed in Tables 3 and 4.

1. Place 8901A in LISTEN mode (this step will cause the LISTEN lamp to illuminate).
2. Upload command byte (ex. Decimal 106 to set the 8901A in 16 bit Normal Transfer mode).
3. Make 8901A UNLISTEN (turns off LISTEN lamp and latches the command byte).

Procedure for C, Z, and I Commands

The following steps should be used to upload and execute the C, Z, and I commands.

Note: When uploading the INHIBIT command in step 2 above, the INHIBIT lamp will illuminate. The CAMAC crate, however, does not receive this information until step 3 is completed.

1. Place 8901A in LISTEN mode (this step will cause the LISTEN lamp to illuminate).
2. Upload command byte (ex. Decimal 34 to upload the CLEAR byte command).
3. Make 8901A TALK (turns off LISTEN lamp, illuminates TALK light, executes CAMAC cycle).

Procedure for Commands Sent to Individual Modules

These commands do the work to program, initialize, readout, etc., all of your CAMAC plug-ins. These commands are often referred to as "FAN", "FNA" and "Function code" commands. The following steps should be used to upload and execute these commands:

1. Place 8901A in LISTEN mode (this step will cause the LISTEN lamp to illuminate).
2. Upload byte stream (see below for example).
3. Make 8901A TALK (turns off LISTEN lamp, illuminates TALK light, executes CAMAC cycle).

When assembling the byte stream, pack the bytes, in the following order, into a buffer.

Table 9 - Byte order for Uploading CAMAC Function Commands

Byte #	Byte Name	Byte Description
1	F	Function Code Number
2	A	Module Subaddress
3	N	CAMAC Station (or slot) Number
4	D1	Low Data Byte (bits W1-W8)
5	D2	Middle Data Byte (bits W9-W16)
6	D3	High Data Byte (bits W17-W24)

The command loading procedure may be halted after any number of these bytes have been uploaded. This is useful when only the function or Subaddress is changing as a program executes. For example, if the user plans to send an F(25) A(0) N(5) command followed by F(2) A(0) N(5) command, only one byte of information needs to be uploaded (the F(2) data). Thus the F(2) A(0) N(5) command may be executed without uploading the A and N information immediately prior to executing the CAMAC cycle with a TALK command.

Procedure for Readout of Data into Computer

To readback data placed on the dataway by a CAMAC module (typically after an F(0) or F(2) is uploaded and executed), follow the following procedure. This is simply an extension of the last section, "Procedure for Commands to Individual Modules":

1. Place 8901A in LISTEN mode (this step will cause the LISTEN lamp to illuminate).
2. Upload byte stream (ex. F(2) A(0) command string).
3. Make 8901A TALK (turns off LISTEN lamp, illuminates TALK light, executes CAMAC cycle).
4. Issue Read command (e.g. **ibrd** for NI-488).

Step 4 will return data appropriate to the Transfer Mode previously programmed. (See Transfer Mode section, including Table 3.)

PROGRAMMING EXAMPLE: SAMPLE SOURCE CODE

```
/* _____ CAMGPIB.C _____ */  
/*  
/TEXT
```

Purpose: Functions to control the CAMAC bus via an 8901A or 6010,
from an IBM PC using National Instruments PC-II GPIB Card.

Language: C

Note: These functions were created for a novice user, although they assume
the basic knowledge of 'C', GPIB, and CAMAC.

They are not optimized for speed but for ease of understanding.

MUST link the National Instruments gpib.obj file, Microsoft 'C'
versions are labeled MCIBx.OBJ file, (x=C,S,M,L).

```
/CODE  
*/  
/* _____ */
```

```
#include "camgpib.h"
```

```
extern int ibfind(char *);  
extern int ibonl(int,int);  
extern int ibtmo(int,int);  
extern int ibsic(int);  
extern int ibcmd(int,char *,int);  
extern int ibwrt(int,char *,int);  
extern int ibrd(int,char *,int);
```

```
extern int ibsta;      /* status word      */  
extern int iberr;     /* GPIB error code  */  
extern int ibcnt;     /* number of bytes sent */
```

```
int gpibBd = -1;      /* device descriptor for the controller board */  
char pcTalk[] = "@!"; /* Talk 0 List 1 */  
char pcList[] = "A"; /* List 0 Talk 1 */  
int ccType = 0;      /* Type of controller, 8901 or 6010 */  
int qxRet;           /* status last camac command */
```

```
#define DEF6010 "DUMB ON;CDMA OFF;CFMT OFF;WORD,BINARY;CORD LOFIRST;CAMAC 2"  
#define DEFCNT 59
```

```
/* _____ */  
/*  
/TEXT
```

Function: void caminit(addr, type)

Purpose: Initialize the GPIB routines and the camac controller.

Input: int addr - GPIB Address of controller
int type - C8901 or C6010

Notes: This function MUST be performed to setup CAMAC access!

If GPIB board cannot be opened this function will exit(1)
your program.

```
/CODE  
*/  
void caminit(addr, type)
```

```

int addr, type;
{
    /* if gpib board was never opened, open it */
    if(gpibBd < 0)
    {
        if((gpibBd = ibfind("GPIB0")) < 0)
            return;
    }

    if(addr > 0 && addr < 29)
    {
        pcTalk[1] = 0x20 + addr;
        pcList[1] = 0x40 + addr;
    }

    /* do an interface clear */
    ibsic(gpibBd);

    /* set timeout, 3 sec */
    ibtmo(gpibBd, 12);

    /* set type of controller */
    ccType = type;

    if(type == 6010)
    {
        /* address 6010 to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send command string to the 6010 */
        ibwrt(gpibBd, DEF6010, DEFCNT);
    }
}

/* ----- */
/*
/TEXT

Function: void camo(n, f, a, d)

Purpose: Do a 24 bit camac write cycle, W1-W24.

Input: int n - slot number of module
       int f - funtion code
       int a - address code
       long d - data value to send

/COE
*/

void camo(n, f, a, d)
int n, f, a;
long d;
{
    char rw[40];

    /* init qxResp return value */
    qxRet = 0;

    if(ccType == 8901)
    {
        /* address 8901 to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send 24 bit normal mode command to 8901A (decimal 100) */
        ibwrt(gpibBd, "d", 1);

        /* MUST make the 8901A unlisten, send unlisten & untalk */

```

```

ibcmd(gpibBd, "?_", 2);

/* build command string with 3 bytes of data (CAMAC W1-W24) */
rw[0] = (char)f;
rw[1] = (char)a;
rw[2] = (char)n;
rw[3] = (char)(d & 0xFFL);
rw[4] = (char)((d & 0xFF00L) >> 8);
rw[5] = (char)((d & 0xFF0000L) >> 16);

/* address 8901A to listen */
ibcmd(gpibBd, pcTalk, 2);

/* send command string to the 8901A (F, A, N, D1, D2, D3) */
ibwrt(gpibBd, rw, 6);

/* address 8901A to talk to execute the CAMAC cycle */
ibcmd(gpibBd, pcList, 2);

/* read data from the 8901A to update the Q and X status */
ibrd(gpibBd, rw, 10);

/* 1st byte=R1-R8, 2nd byte=R9-R16, 3rd byte=R17-R24, 4th byte=Q&X */
if(ibcnt == 4)
    qxRet = (int)(rw[3] & 3);
}
else if(ccType == 6010)
{
/* build command string with 3 bytes of data (CAMAC W1-W24) */
sprintf(rw, "n=%2d;f=%2d;a=%2d;w=%10ld;rqx", n, f, a, d);

/* address 6010 to listen */
ibcmd(gpibBd, pcTalk, 2);

/* send command string to the 6010 */
ibwrt(gpibBd, rw, 31);

/* address 6010 to talk */
ibcmd(gpibBd, pcList, 2);

/* read data from the 6010 to update the Q and X status */
ibrd(gpibBd, rw, 10);

/* 1st byte=R1-R8, 2nd byte=R9-R16, 3rd byte=R17-R24, 4th byte=Q&X */
if(ibcnt == 4)
    qxRet = (int)(rw[3] & 3);
}
}

/* _____ */
/*
/TEXT

Function: long cami(n, f, a)

Purpose: Do a 24 bit camac read cycle.

Input: int n - slot number of module
       int f - funtion code
       int a - address code

Returns: long (R1-R24) value of data read.

/CODE
*/

long cami(n, f, a)

```

```

int n, f, a;
{
    long d, d1, d2, d3;
    char rw[40];

    /* init return data value and qxResp return value */
    d = 0L;
    qxRet = 0;

    if(ccType == 8901)
    {
        /* address 8901 to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send 24 bit normal mode command to 8901A (decimal 100) */
        ibwrt(gpibBd, "d", 1);

        /* MUST make the 8901A unlisten, send unlisten & untalk */
        ibcmd(gpibBd, "?_", 2);

        /* build command string with 3 bytes of data (CAMAC W1-W24) */
        rw[0] = (char)f;
        rw[1] = (char)a;
        rw[2] = (char)n;
        rw[3] = (char)0;
        rw[4] = (char)0;
        rw[5] = (char)0;

        /* address 8901A to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send command string to the 8901A (F, A, N, D1, D2, D3) */
        ibwrt(gpibBd, rw, 6);

        /* address 8901A to talk to execute the CAMAC cycle */
        ibcmd(gpibBd, pcList, 2);

        /* read data from the 8901A to update the Q and X status */
        ibrd(gpibBd, rw, 10);

        /* 1st byte=R1-R8, 2nd byte=R9-R16, 3rd byte=R17-R24, 4th byte=Q&X */
        if(ibcnt == 4)
        {
            d3 = (long)rw[2];
            d3 = d3 & 0xFF;

            d2 = (long)rw[1];
            d2 = d2 & 0xFF;

            d1 = (long)rw[0];
            d1 = d1 & 0xFF;

            d = (d3 << 16) + (d2 << 8) + d1;

            qxRet = (int)(rw[3] & 3);
        }
    }
    else if(ccType == 6010)
    {
        /* build command string with 0 data (CAMAC W1-W24) */
        sprintf(rw, "n=%2d;f=%2d;a=%2d;w=0;rx", n, f, a);

        /* address 6010 to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send command string to the 6010 */
    }
}

```

```

        ibwrt(gpibBd, rw, 22);

        /* address 6010 to talk */
        ibcmd(gpibBd, pcList, 2);

        /* read data from the 6010 to update the Q and X status */
        ibrd(gpibBd, rw, 10);

        /* 1st byte=R1-R8, 2nd byte=R9-R16, 3rd byte=R17-R24, 4th byte=Q&X */
        if(ibcnt == 4)
        {
            d3 = (long)rw[2];
            d3 = d3 & 0xFF;

            d2 = (long)rw[1];
            d2 = d2 & 0xFF;

            d1 = (long)rw[0];
            d1 = d1 & 0xFF;

            d = (d3 << 16) + (d2 << 8) + d1;

            qxRet = (int)(rw[3] & 3);
        }
    }
    return(d);
}
/* _____ */
/*
/TEXT

```

Function: int camibk16(n, f, a, count, buffer)

Purpose: Do a 16 bit block read cycle.

Input: int n - slot number of module
 int f - function code
 int a - address code
 int count - number of data values to read

Output: int *buffer - array to store data into

Return: number of data values read.

```

/CODE
*/

```

```

int camibk16(n, f, a, count, buffer)
int n, f, a, count, *buffer;
{
    int retval;
    char rw[40];

    /* init return data count value */
    retval = 0;

    /* block xfer mode is set in bytes */
    count = count * 2;

    if(ccType == 8901)
    {
        /* address 8901 to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send 16 bit high speed mode command to 8901A (decimal 106) */
    }
}

```

```

        ibwrt(gpibBd, "j", 1);

        /* MUST make the 8901A unlisten, send unlisten & untalk */
        ibcmd(gpibBd, "?_", 2);

        /* build command string with 3 bytes of data (CAMAC W1-W24) */
        rw[0] = (char)f;
        rw[1] = (char)a;
        rw[2] = (char)n;
        rw[3] = (char)0;
        rw[4] = (char)0;
        rw[5] = (char)0;

        /* address 8901A to listen */
        ibcmd(gpibBd, pcTalk, 2);

        /* send command string to the 8901A (F, A, N, D1, D2, D3) */
        ibwrt(gpibBd, rw, 6);

        /* address 8901A to talk to execute the CAMAC cycle */
        ibcmd(gpibBd, pcList, 2);

        /* read a block of data from the 8901A */
        ibrd(gpibBd, (char *)buffer, count);

        /* number of 16 bit values read */
        retval = ibcnt / 2;
    }
else if(ccType == 6010)
{
    /* 6010 max of 8192 bytes it can block transfer */
    if(count > 8192)
        count = 8192;

    /* build command string to perform block read (CAMAC W1-W16) */
    sprintf(rw, "n=%2d;f=%2d;a=%2d;cbls=%4d;rb", n, f, a, count);

    /* address 6010 to listen */
    ibcmd(gpibBd, pcTalk, 2);

    /* send command string to the 6010 */
    ibwrt(gpibBd, rw, 27);

    /* address 6010 to talk */
    ibcmd(gpibBd, pcList, 2);

    /* read a block of data from the 6010 */
    ibrd(gpibBd, (char *)buffer, count);

    /* number of 16 bit values read */
    retval = ibcnt / 2;
}

return(retval);
}

/* _____ */
/*
/TEXT

Function: int qxResp()

Purpose: Returns the CAMAC Q and X response from the last camo or
        caml functions.

Returns: Q response in bit 1, X response in bit 0

/COE

```

```
*/  
  
int qxResp()  
{  
    return(qxRet);  
}  
  
/* _____ end of file _____ */  
  
  
/* _____ CAMGPIB.H _____ */  
/*  
/TEXT  
  
    Purpose: Header file for all files that use functions from camgpib.c  
  
    Language: C  
  
/CODE  
*/  
/* _____ */  
  
extern void caminit(int addr, int type);  
extern void camo(int n, int f, int a, long d);  
extern long cami(int n, int f, int a);  
extern int camibk16(int n, int f, int a, int count, int *buffer);  
extern int qxResp(void);  
  
/* _____ end of file _____ */
```

THEORY OF OPERATION

GENERAL


The Model 8901A is a GPIB to CAMAC interface which is composed of two circuit boards. The first board plugs into the control (rightmost) slot of the CAMAC mainframe and interfaces to the CAMAC station number (N) lines and LAM lines. This board also contains the GPIB interface circuitry. The second board provides the interface to the CAMAC Dataway. It has registers to store the CAMAC commands sent by the GPIB controller and drive the function (F), address (A), and write data (W) lines of the Dataway during a CAMAC cycle. It also has the circuit to generate the CAMAC cycle timing and latch the read data (R) lines.

The 8901A circuitry can be broken down into logical subsections as shown in the block diagram. The operation of each of these subsections is discussed here.

GPIB COMMAND DECODER

At the heart of the 8901A is the GPIB command decoder. When a command is put on the GPIB bus it must be interpreted by the 8901A and a decision must be made as to how (if at all) to respond to it. The 8901A will respond to any of the following GPIB commands: interface clear (IFC), serial poll enable (SPE), serial poll disable (SPD), my TALK address (MTA), my LISTEN address (MLA), Unlisten (UNL), and Untalk (UNT).

The 8901A has four basic states: Idle, TALK mode, LISTEN mode, Serial poll mode. These states are entered and exited as a result of one of the above GPIB commands. The following table lists each of the commands and describes its effect on the 8901A's state.



8901A Functional Block Diagram

IFC: Resets all registers in the 8901A and places it in the Idle state regardless of its current state.

SPE: Causes the 8901A to enter Serial Poll mode.

SPD: If the 8901A is in Serial Poll mode, this command returns it to the Idle state. It also clears a pending service request (SRQ).

MTA: If in Serial Poll mode, the 8901A will output its SRQ status upon receiving its TALK address. If not in Serial Poll mode, receipt of MTA will cause a CAMAC cycle to be executed and TALK mode to be entered.

UNT: Takes the 8901A out of TALK mode if it is active MLA - Causes the 8901A to enter LISTEN mode so that it may accept CAMAC or setup commands.

UNL: Places the 8901A into the Idle state if currently in LISTEN mode.

ACCEPTOR HANDSHAKE

The GPIB protocol provides a handshake for all data transfers. When a GPIB command is sent or the 8901A is in LISTEN mode, the 8901A must indicate that it is ready to receive a transfer by asserting the RFD line. The GPIB controller must then assert DAV when valid data is on the bus. The 8901A can then read in the data. It then asserts the DAC line to say the transfer is complete.

LISTEN MODE

Bits 6 and 7 of the first byte the 8901A receives from the GPIB Talker after entering LISTEN mode is used to determine whether the byte is a command for the 8901A itself, a "global" CAMAC command or a CAMAC command for a specific module. Bits 1-5 are then latched in the appropriate registers. If it is a CAMAC F command for a particular instrument, a sequencer is used to latch additional bytes in the following order: A, N, W1-8, W9-16, W10-24.

GLOBAL CAMAC COMMANDS

There are three global CAMAC commands: C, Z, and I. For each of these commands there is a corresponding line on the CAMAC Dataway which is driven by the 8901A whenever a CAMAC cycle is executed. The command is asserted if its latched value is a 1. At the end of the CAMAC cycle the C and Z latch is reset to zero.

F, A, N CAMAC COMMANDS

As described above, the values for F, A, N, and the Write data are latched when the information is sent from the GPIB controller. When a CAMAC cycle is executed, all of these lines are driven for the entire length of the cycle (while Busy is asserted). The latched values will not change until they are overwritten by a new command from the GPIB controller.

TRANSFER MODE

The commands for the 8901A determine how many bytes are to be read back, whether a new CAMAC cycle should be executed when data is read out (block mode), and what conditions (if any) should cause SRQ to be asserted by the 8901A. The latches for this information are cleared if an IFC is sent. The block transfer enable flip flop also is cleared when a Q = 0 is read in.

SERIAL POLL MODE

Serial poll is used by the GPIB controller to determine which device asserted SRQ. Upon decoding the serial poll enable command, the SPAS flip flop is set true, putting the 8901A in serial poll mode. When the controller then addresses the 8901A to TALK, the serial poll status bytes are sent instead of data and CAMAC cycles are inhibited. Bit 7 of the status bytes indicates the state of the SRQ line while bits 1-6 are used for data. The first byte contains X and Q, while the next 4 bytes contain the LAM status (six slots/byte) starting with slot 1. The SRQ is cleared when all of the status is read out or when the 8901A receives a serial poll disable command.

TALK MODE

When the 8901A is addressed to TALK (and serial poll mode is not active) two things occur. First, the 8901A enters the Talker active state. This causes the direction of the GPIB buffers to be reversed, since the 8901A must now drive the GPIB bus and it must disable the acceptor handshake circuit and enable the source handshake circuit. Secondly, the 8901A starts the execution of a CAMAC cycle. Upon completion of the cycle the appropriate number of data bytes are sent to the GPIB Listener followed by the X and Q response byte which is sent with the EOI signal asserted.

SOURCE HANDSHAKE

Since the 8901A is in TALK mode, the GPIB handshaking protocol reverses. That is, the 8901A is now the one to indicate when data is valid. Three conditions must be met before it can assert DAV. First, it must be in TALK mode and ATN must be set false by the GPIB controller. Also it must wait for the GPIB controller (or Listener) to assert RFD. The last condition is that the CAMAC data must be latched into the 8901A during the CAMAC cycle. When all of these conditions have been met, the 8901A waits an additional 200 nsec before asserting DAV to allow time for the data to become stable on the GPIB bus. When the listening device asserts DAC, DAV is cleared and a sequencer is clocked to output the next byte. This byte may be another data byte, or a status byte. If in block mode the status byte is suppressed, and a new CAMAC cycle is initiated instead.

CAMAC CYCLE TIMING

The CAMAC cycle starts when the 8901A is addressed to TALK or, if it is in block mode transfer, when the last data byte is read out. The 8901A asserts the Busy line and enables the F,A,N,W,C,Z and I drivers. Approximately 500 nsec later, S1 is asserted for 250 nsec. At the end of S1, all 24 bits of the CAMAC data lines, X, and Q are latched in the 8901A. S2 is asserted 125 nsec later for 250 nsec. The cycle is terminated 125 nsec after S2 goes away, Busy is cleared and all drivers are disabled.

READ DATA

The sequencer described above determines which data byte is to read out. The order of the first two bytes may be reversed by side-panel jumpers. The data is latched in the 8901A on every CAMAC cycle and generally read out immediately after the cycle completes. However, a special command (F(0), A(0), N(24)) is provided to allow readout of the latched data (the CAMAC cycle is inhibited) at a later time.

X AND Q RESPONSES

The X and Q responses are latched in the 8901A during the CAMAC cycle and read out in the response byte. They are also used in the generation of SRQs and termination of block mode transfers.

LAM LINES

The LAM lines are used by the SRQ generation circuit and can be read by the GPIB controller when it's conducting a serial poll.

SRQ GENERATION

A service request (SRQ) may be generated (depending on how the 8901A is programmed) on any of the following conditions: a LAM is set by one of the CAMAC instruments, or a X = 0 or Q =0 response is detected during the execution of a CAMAC cycle. When a service request is pending, CAMAC cycles are inhibited until a serial poll is performed and the SRQ cleared. However, if the SRQ was caused by a LAM, unless the LAM is cleared or the 8901A is disabled to generate SRQs on LAM before the serial poll is taken, another SRQ will be issued immediately.

INDEX

A		M	
Acceptor Handshake	32	Maintenance Agreements	9
Address Switch	13		
B		P	
Block Transfer	12	Programming Examples	24
Byte Order Jumpers	15		
C		Q	
CAMAC Commands	19, 32	Q Response	33
CAMAC Cycles	12		
CAMAC Standard	11		
Clear, Initialize and Inhibit	12, 19, 21		
Customer Service	9		
D		R	
Data Readout	23, 33	Registers	11
F		S	
FAN Commands	20, 32	Serial Poll	12, 33
		Service Procedure	10
		Service Request	12, 18
		Setup Commands	17, 21
		Source Handshake	33
		Specifications	11
		SRQ Generation	34
		SRQ Setup Commands	18
G		T	
GPIB Address	13, 15	Talk Mode	20, 33
GPIB Command	31	Transfer Mode	17
I		U	
Installation	15	Unlisten	20
Instrument Drivers	17	Uploading Command	21
J		W	
Jumpers	15	Warranty	9
L		X	
Listen	20	X Response	33
Listen Mode	23, 32		





Artisan Technology Group is your source for quality new and certified-used/pre-owned equipment

- FAST SHIPPING AND DELIVERY
- TENS OF THOUSANDS OF IN-STOCK ITEMS
- EQUIPMENT DEMOS
- HUNDREDS OF MANUFACTURERS SUPPORTED
- LEASING/MONTHLY RENTALS
- ITAR CERTIFIED SECURE ASSET SOLUTIONS

SERVICE CENTER REPAIRS

Experienced engineers and technicians on staff at our full-service, in-house repair center

*InstraView*SM REMOTE INSPECTION

Remotely inspect equipment before purchasing with our interactive website at www.instraview.com ↗

WE BUY USED EQUIPMENT

Sell your excess, underutilized, and idle used equipment. We also offer credit for buy-backs and trade-ins. www.artisanng.com/WeBuyEquipment ↗

LOOKING FOR MORE INFORMATION?

Visit us on the web at www.artisanng.com ↗ for more information on price quotations, drivers, technical specifications, manuals, and documentation

Contact us: (888) 88-SOURCE | sales@artisanng.com | www.artisanng.com