

ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

**Artisan Technology Group**
(217) 352-9330 | sales@artisantg.com | artisantg.com

**Full-service, independent repair center**
with experienced engineers and technicians on staff.

**We buy your excess, underutilized, and idle equipment**
along with credit for buybacks and trade-ins.

**Custom engineering**
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

**Expert team | Trust guarantee | 100% satisfaction**

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

**Visit our website - *Click HERE***

# 53/63 SMART HARDWARE SYSTEM

## GETTING STARTED


Introduction . . . . . Page 1

53/63-ACX . . . . . Page 2

53/63-IBX . . . . . Page 4

53/63-MPX . . . . . Page 6

53/63-CCX . . . . . Page 9

53/63-PCX . . . . . Page 10

53/63-RSX . . . . . Page 12

53/63-HAX . . . . . Page 14

53/63-PIX . . . . . Page 16

# INTRODUCTION

The Getting Started Manual contains a separate section for each of the various 53/63 series configured systems. The purpose of this Manual is to provide the first time user of a CDS System with an orderly procedure for bringing up the system. The procedures provided will enable the user to quickly assemble the various parts of the system and begin sending commands to the instrument function cards installed in the system.

Following the Getting Started section, are manual sections for each of the parts of a 53/63 Series System. These manual sections contain detailed specifications and operating instructions for each component of a 53/63 Series System.

Also supplied in a separate set of binders are service manuals on each component of a 53/63 Series System.

To familiarize yourself with the ACX operation, it is recommended that the ACX first be operated in Unbuffered Mode using a CRT or other RS-232 keyboard/printer. The following represents an orderly procedure for bringing the System up:

1. Install the various Function Cards ordered into the blue card cage slots. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is installed. Consult individual Function Card Operating Manuals for correct orientation of cards in the Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See the 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. The 53A-130 Communications Card should be installed next in the green card slot. Before installing the Communications Card, the various switches controlling data baud rate, data format, etc. must be set (See the ACX Operating Manual, Hardware Description section for switch locations and settings).

   A. Set the Communications Configuration Switch on the 53A-130 Communications Card to agree with the options selected on your CRT. (See Table 2 in the ACX Operating Manual).

   B. Set the User-Interface Configuration Switch for system address 0, ACX Self-Test disabled, Expansion RAM Self-Test disabled, Carrier Override disabled, BASIC Mode non-buffered and User IFC to SD0.

   C. Make sure that the RS-232C/RS-422 switch has all rockers closed in order to place the serial port in RS-232C mode.

   D. Set the Option Switch Bank to Echo ON and Bubble/Disk Interface to the position indicated in the ACX Manual.

   E. Your terminal will be hooked up to Serial Device 0.

4. Using either a 53A-761 Data Cable or a 53A-780 Hooded Connector, connect the following signal lines between the 53A-122 Communications Card and your terminal.

| Signal Name | 53A-130 Front Edge Connector Pin Number | Connect to Terminal |
|---|---|---|
| XMIT Data from ACX | Y | REC |
| REC Data into ACX | W | XMIT |
| Ground | 24 | Ground |

The wire colors associated with the various signals available at the user end of the 53A-761 Data Cable are given in the 53A-761 Operating Manual.

Your CRT may also require additional connections in the CRT connector, such as:

Pin 4 to Pin 5 (CLEAR TO SEND tied to REQUEST TO SEND), and, Pin 8 to Pin 20 (CARRIER DETECT tied to DATA TERMINAL READY).

5. Use 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed in your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

6. If one or more chained card cages (53/63-CCX's) are to be used with your ACX System, use the 53A-743 Chaining Cable to connect either the 53A-145 Chaining Card or the 53A-143 Bubble Disk Chaining Card or a 53A-758 Chaining Cable to connect the 53A-144 Disk Interface Chaining Card in your ACX Card Cage to the 53A-123 Communications Card in your first chained card cage.

7. Place your terminal in the Full Duplex Mode of operation. (Failure to do so will result in double characters being printed on the terminal).

8. Power-up the ACX System and any chained card cages. The ACX system will then give you a configuration message which describes the hardware environment of your system, the XYBASIC sign-on message and an available memory message followed by the XYBASIC prompt 'READY'. At this point the system is ready for operation. i.e. you may begin entering XYBASIC commands or a program.

   Note: All character strings sent to the ACX from your terminal keyboard must be terminated by a Carriage-Return or a line-feed or both.

9. Now that you have the ACX up and running, consult the 53A-130 Operating Manual for information on XYBASIC programming of the ACX and individual function card manuals for the programming commands needed to operate specific function cards. The example BASIC program below shows how a 53A-522 DMM Card would be programmed to DC volts, autorange; followed by taking a voltage reading from channel 4 of a 53A-332 Scanner Card. The example assumes that the address switch on the 53A-171 Control Card has been set to 0 and that the addresses of the DMM and Scanner Cards are 1 and 2 respectively.

```
10 PRINT @BPI, "@024"          :REM CLOSE RELAY 4 ON 331 SCANNER CARD
20 PRINT @BPI, "@03F1A"        :REM SET 522 DMM FOR DC VOLTS, AUTORANGE
30 PRINT @BPI, "T"             :REM TRIGGER DMM MEASUREMENT
40 INPUT @BPI, RESULTS$        :REM FETCH RESULTS FROM 522 DMM CARD
50 PRINT RESULTS$              :REM PRINT THE RESULTS TO THE SCREEN
RUN
```

The following represents an orderly procedure for bringing your 53/63-IBX System up:

1. Install the various Function Cards ordered into the blue card cage slots of the 53/63-IBX Card Cage. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is installed. Consult individual Function Card Operating Manuals for correct orientation of cards in the Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See the 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. Next install the 53A-128 Communications Card in the green card slot. Before installing the Communications Card, use the four-position, Rocker Switch on the card to set the IEEE-488 bus TALK/LISTEN address of your IBX System. See the 53A-128 Manual for details on setting the Address Select Switch. If you plan to use the serial polling capability of your IBX System, set the Serial Polling Response Switch as per the 53A-128 Operating Manual.

4. Use the CDS-supplied 53A-713, 716, or 717 Cable to connect the Front Edge Connector of the 53A-128 Communications Card to your IEEE-488 bus controller. Route the cable to the rear of the Card Cage using the Card Cage cable tray.

5. Use 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed in your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

6. If one or more chained card cages (53/63-CCX's) are to be used with your IBX system, consult the 53/63-CCX section of this manual for instructions on interconnecting the card cages.

7. The System is now ready for operation. If the 53A-171 Card is set to Address 0 and the System contained a 53A-351 Relay Switching Card with Address 3, sending @03C5 from your system controller to the IBX System would cause Relay 5 on the 53A-351 Card to close.

8. When the characters @03C5 are sent to the IBX System, the LEDs on the 53A-128, 171, and 351 Cards will go to the following known states:

53A-128 Communications Card

LISTEN LED - lit, the 128 Card is addressed to LISTEN.
POWER LED - flashes each time data is sent or received.

53A-171 Control Card

POWER LED - extinguished, the Control Card is addressed.

53A-351 Relay Switching Card

POWER LED - extinguished, the Relay Card is addressed.
RELAY LED 5 - lit, Relay 5 is closed.

9. Consult individual Function Card Operating Manuals for a complete description of the commands used to program each card and the functions of the various LED indicators on each card.

10. After power is applied to the System, the 53A-128 Communications Card will generate a service request (SRQ). The service request is caused by the power-up interrupt generated by the 53A-171 Control Card. The power-up interrupt is generated so that a user's system controller can easily determine if the IBX System has had an AC power failure since the last time the system controller communicated with it. The method used to clear the IBX power-up SRQ will depend on the setting of the SRQ Clear Switch on the 53A-128 Communications Card. See the manual sections entitled SRQ Clear Switch and Service Request Line in the 53A-128 Operating Manual for specific software programming details.

To familiarize yourself with the MPX operation, it is recommended that the MPX first be operated in Local Mode using a CRT or other RS-232 keyboard/printer. The following represents an orderly procedure for bringing the System up:

1. Install the various Function Cards ordered into the blue card cage slots. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is in- stalled. Consult individual Function Card Operating Manuals for correct orientation of cards in Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See the 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. The 53A-122 Communications Card should be installed next in the green card slot. Before installing the Communications Card, the various switches controlling data baud rate, data format, etc. must be set (See the 53A-122 Operating Manual, Switch Layout, for a diagram depicting switch locations.):

   A. Set the Communications Option Switch on the 53A-122 Communications Card to agree with the options selected on your terminal. (See 53A-181 Firmware Operating Manual, Table VI.)

   B. Set the Address Option Switch on the 53A-122 to address 0, Local Mode. (See 53A-181 Firmware Operating Manual, Table V.)

   C. Set the A and B Mode Switches to Pos. 1 - Closed, 2 and 3 - Open. (See 53A-122 Communications Card Operating Manual, Mode Switches.)

   D. Your terminal will be hooked up to I/O port 0; therefore, the A Baud Rate Switch must be set to agree with the Baud Rate selected on your CRT. Use the X16 ratio when setting the Baud Rate. (See 53A-122 Communications Card Operating Manual, Baud Rate Switches.)

4. Using either a 53A-750 Data Cable or a 53A-780 Hooded Connector, connect the following signal lines between the 53A-122 Communications Card and your terminal.

| Signal Name | 53A-122 Front Edge Connector Pin Number | Connect to Terminal |
|---|---|---|
| XMIT Data from MPX | 2 | REC |
| REC Data into MPX | 8 | XMIT |
| Ground | 6 | Ground |

In order to allow the 53A-122 Card to transmit data, you must jumper together the following three signals:

| Signal Name | 53A-122 Front Edge Connector Pin Number |
|---|---|
| Data Terminal Ready | 1 |
| Clear to Send | 11 |
| Data Carrier Detect | 13 |

A detailed description of all 53A-122 Communications Card Input and Output signals is given in the 53A-122 Operating Manual Section entitled Interfacing to the MPU Communications Card. The wire colors associated with the various signals available at the user end of the 53A-750 Data Cable are given in the 53A-750 Operating Manual.

Your terminal may also require additional connections, such as: Pin 4 to Pin 5 (CLEAR TO SEND tied to REQUEST TO SEND), and, Pin 8 to Pin 20 (CARRIER DETECT tied to DATA TERMINAL READY).

5. Use 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed in your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

6. If one or more chained card cages (53/63-CCX's) are to be used with your MPX System, use the 53A-743 Chaining Cable to connect the 53A-142 Chaining Card in your MPX Card Cage and the 53A-123 Communications Card in your first chained card cage.

7. Place your terminal in the Half Duplex Mode of operation. (The 122 character echo feature was disabled in Step 3 when the Mode Switch was set.)

8. Power-up the MPX System and any chained card cages. Send the characters !0 followed by a CARRIAGE-RETURN from your terminal. The MPX will respond with 0*, indicating that it is now addressed and in the Executive Mode. The DS0 and DS1 LEDs will be lit on the 53A-122 Communications Card (See 53A-181 Firmware Operating Manual, Table VII for a further description of the DS LEDs.) Each time a character is sent from the terminal to the MPX, the large Power LED on the 53A-122 Communications Card will blink indicating data is being received from the terminal.

   Note: All character strings sent to the MPX from your terminal keyboard must be terminated by a Carriage-Return.

9. To self-test the MPX System, send the word TEST to the MPX while it is still in the Executive Mode. The test results will be shown on your terminal per the TEST Command described in the 53A-181 Firmware Operating Manual.

10. To transfer the MPX to BASIC so that you can enter a BASIC program and run it, send the command BASIC to the MPX. The MPX will respond with READY. To return to the Executive Mode from BASIC, send !0.

11. To connect your terminal directly to the CDS Backplane in order to send commands to the System Cards without running a BASIC program, use the DIO Command. For example, return to the Executive Mode by sending !0, then send DIO#2.

    If the 53A-171 Card is set to address 0 and the MPX contains a 53A-351 Card with address 3, sending @03C5 to the MPX would cause Relay 5 on the 53A-351 Card to close. To exit the DIO Mode, again send !0. See the DIO Command in 53A-181 Firmware Operating Manual for a further explanation of DIO.

12. Now that you have the MPX up and running, consult the 53A-181 Firmware Operating Manual for information on BASIC programming of the MPX and individual function card manuals for the programming commands needed to operate specific function cards.

## 53/63-CCX

The following represents an orderly procedure for bringing your 53/63-CCX System up:

1. Install the various Function Cards ordered into the blue card cage slots. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is in- stalled. Consult individual Function Card Operating Manuals for correct orientation of cards in Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. Each 53A-171 Control Card must have a unique address from all other 53A-171 Control Cards in a system. As an addressing convention, it is recommended that the control card in the first mainframe (IBX, MPX, RSX, PIX, ACX, or HAX) have its control card's Address Select Switch set to an address of 0, the first CCX mainframe have its control card's address set to 1, the second CCX to 2, etc. See the 53A-171 Operating Manual for instructions on setting the Address Select Switch and insuring that the STEP/NORMAL Switch is in the normal position.

3. Next install the 53A-123 Communications Card in the green card slot.

4. To chain the CCX mainframe to either an IBX, RSX, PCX, PIX, or HAX System, insert the 53A-145 Chaining Card in the red card cage slot of the IBX, RSX, PCX, PIX, or HAX System. In the case of an MPX System, the 53A-142 Memory/Chaining Card supplied with the MPX provides the chaining interface to the first CCX System. In the case of an ACX System, the 53A-143 Bubble Disk Chaining Card, the 53A-144 Disk Interface Chaining Card or the 53A-145 Chaining Card provide the chaining interface to the first CCX System.

5. Depending on the chaining card installed, use either the 53A-743 Chaining Cable (53A-145/142/143 Chaining Cards) or 53A-758 Chaining Cable (53A-144 Chaining Card) as the connection between the chaining card in the ACX, MPX, IBX, RSX, PCX, PIX, or HAX mainframe and the 53A-123 Communications Card in the first CCX Mainframe.

6. If additional CCX Mainframes are to be chained from the first CCX Mainframe, insert the supplied 53A-145 Chaining Card in the red slot of the first CCX mainframe, and use the 53A-743 Chaining Cable as the connection between the 53A-145 Chaining Card in the first CCX Mainframe and the 53A-123 Communications Card in the second CCX Mainframe. Up to a total of 9 CCX Mainframes can be chained together in this fashion.

7. The CCX Mainframe(s) are now ready for operation.

The following represents an orderly procedure for bringing your 53/63-PIX System up:

1. Install the various Function Cards ordered into the blue card cage slots of the 53/63-PCX Card Cage. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is installed. Consult individual Function Card Operating Manuals for correct orientation of cards in the Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See the 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. Next install the 53A-128 Communications Card in the green card slot. Before installing the Communications Card, use the four-position, Rocker Switch on the card to set the IEEE-488 bus TALK/LISTEN address of your PCX System. In order to use the standard 53A-183 PC Software supplied with the PCX System, the address of the 53A-128 Communications Card must be set to decimal 24 (the factory-shipped address). See the 53A-128 Manual for details on setting the TALK/LISTEN Address Switch. If you plan to use the serial polling capability of your PCX System, set the Serial Polling Response Switch and the SRQ Clear Switch as described in the 53A-128 Operating Manual.

4. The 53A-903 I/O Card must be installed in the rear of your IBM PC or IBM PC-compatible computer. See the INSTALLATION Section of the 53A-903 Operating Manual for detailed instructions on how to install the 53A-903 Card.

5. Use the CDS-supplied 53A-713, 716, or 717 Cable to connect the Front Edge Connector of the 53A-128 Communications Card to the 53A-903 I/O Card installed in your PC. Route the cable out the rear of the Card Cage using the Card Cage cable tray.

6. Use 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed in your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

7. If one or more chained card cages (53/63-CCX's) are to be used with your PCX system, consult the 53/63-CCX section of this manual for instructions on interconnecting the card cages.

8. The System is now ready for operation. Again consult the INSTALLATION Section of the 53A-903 I/O Card Operating Manual for details on how to install and use the CDS-supplied 53A-183 software to control your PCX System.

If the 53A-171 Card is set to Address 0 and the System contained a 53A-351 Relay

Switching Card with Address 3, sending @03C5 from your system controller to the PCX System would cause Relay 5 on the 53A-351 Card to close.

When the characters @03C5 are sent to the PCX System, the LEDs on the 53A-128, 171, and 351 Cards will go to the following known states:

53A-128 Communications Card
LISTEN LED - lit, the 128 Card is addressed to LISTEN.
POWER LED - flashes each time data is sent or received.

53A-171 Control Card
POWER LED - extinguished, the Control Card is addressed.

53A-351 Relay Switching Card
POWER LED - extinguished, the Relay Card is addressed.
RELAY LED 5 - lit, Relay 5 is closed.

9. Consult individual Function Card Operating Manuals for a complete description of the commands used to program each card and the functions of the various LED indicators on each card.

10. After power is applied to the System, the 53A-128 Communications Card will generate a service request (SRQ). The service request is caused by the power-up interrupt generated by the 53A-171 Control Card. The power-up interrupt is generated so that a user's system controller can easily determine if the PCX System has had an AC power failure since the last time the system controller communicated with it. The method used to clear the PCX power-up SRQ will depend on the setting of the SRQ Clear Switch on the 53A-128 Communications Card. See the manual sections entitled SRQ Clear Switch and Service Request Line in the 53A-128 Operating Manual for specific software programming details.

## 53/63-RSX

The following represents an orderly procedure for bringing your 53/63-RSX System up:

1. Install the various Function Cards ordered into the blue card cage slots of the 53/63-RSX Card Cage. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is installed. Consult individual Function Card Operating Manuals for correct orientation of cards in Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. The 53A-121 Communications Card should be installed next in the green card slot. Before installing the Communications Card, the various switches controlling data baud rate, data format, etc. and the RIC and RIL characters must be set (See the 53A-121 Operating Manual for switch locations, functions and settings).

   A. Set the Parity, Format, Baud Rate and Echo Switches on the 53A-121 Communications Card to agree with the options selected on the RS-232 device being used to control the 53/63-RSX System.

   B. After reading the Switches For Command Characters (RIC & RIL) paragraphs in the Description section of the 53A-121 Operating Manual, set the RIC and RIL switches to ASCII appropriate for your application.

4. Use the 53A-738 Data Cable to connect the required signal lines from the 53A-121 Communications Card to the RS-232 device that will control the 53/63-RSX System. Route the cable out the rear of the Card Cage using the Card Cage cable tray. At a minimum the following signal lines must be connected:

| 53A-121 Signal Name | 53A-121 Front Edge Connector Pin Number | Connect To Controlling Device Signal |
|---|---|---|
| RS-232 Input Data | 20 | RS-232 Output Data |
| RS-232 Output Data | 19 | RS-232 Input Data |
| Signal Ground | X | Signal Ground |
| RS-232 53/63 System Busy | 17 | Data Set Ready (input to controlling device) |
| RS-232 System Controller Busy | 21 | Clear To Send (output from Controlling device) |

The wire colors associated with the various signals available at the user end of the 53A-738 Data Cable are given in the Signal Connections section of the 53A-121 Operating Manual.

5. Use the 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

6. If one or more chained card cages (53/63-CCX's) are to be used with your RSX System, consult the 53/63-CCX section of this manual for instructions on interconnecting the card cages.

7. The System is now ready for operation. If the 53A-171 Card is set to Address 0 and the System contained a 53A-351 Relay Switching Card with Address 3, sending @03C5 from your system controller to the RSX System would cause Relay 5 on the 53A-351 Card to close.

   When the characters @03C5 are sent to the RSX System, the LEDs on the 53A-121, 171, and 351 Cards will go to the following known states:

   53A-121 Communications Card

   INPUT/OUTPUT LED - out, the 121 Card is receiving output from the system controller.
   CONTROLLER BUSY - Out
   SYSTEM BUSY - Flashes when data is sent to the 53A-121.

   POWER LED - flashes each time data is sent or received.

   53A-171 Control Card
   POWER LED - extinguished, the Control Card is addressed.

   53A-351 Relay Switching Card
   POWER LED - extinguished, the Relay Card is addressed.
   RELAY LED 5 - lit, Relay 5 is closed.

8. Consult individual Function Card Operating Manuals for a complete description of the commands used to program each card and the functions of the various LED indicators on each card.

## 53/63-HAX

The following represents an orderly procedure for bringing your 53A/63A-HAX System up:

1. Install the various Function Cards ordered into the blue card cage slots of the 53/63-HAX Card Cage. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is installed. Consult individual Function Card Operating Manuals for correct orientation of cards in Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. Next install the 53A-123 Communications Card in the green card slot.

4. The 53A-902 I/O Card should next be installed in an I/O slot of the Hewlett Packard 1000 (21MX or 2100) computer. Before installing the card, set the Line Feed, Stop Character Enable and Stop Character Select switches per the instructions given in the 53A-902 Operating Manual.

5. Use the CDS-supplied 53A-741 Cable to connect the Front Edge Connector of the 53A-123 Communications Card to the Front Edge Connector of the 53A-902 I/O Card. Route the cable out the rear of the Card Cage using the Card Cage cable tray.

6. Use 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed in your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

7. Using HP 1000 Documentation, a system generation must be done in order to configure an HP teletype driver into the HP 1000 Operating System for control of data transmission to and from the 53A-902 I/O Card. In an HP RTE operating system environment, driver DVR000 is normally used. If the standard HP teletype driver is to be modified, or a custom driver is to be written, see the section in the 53A-902 Operating Manual entitled Assembly Language Instructions.

8. The System is now ready for operation. If the 53A-171 Card is set to Address 0 and the System contained a 53A-351 Relay Switching Card with Address 3, sending @03C5 from your system controller to the HAX System would cause Relay 5 on the 53A-351 Card to close.

   When the characters @03C5 are sent to the HAX System, the LEDs on the 53A-121, 171, and 351 Cards will go to the following known states:

53A-123 Communications Card

I/O LED - out, the 123 Card is receiving data from the HP 1000.
POWER LED - flashes each time data is sent or received.

53A-171 Control Card

POWER LED - extinguished, the Control Card is addressed.

53A-351 Relay Switching Card

POWER LED - extinguished, the Relay Card is addressed.
RELAY LED 5 - lit, Relay 5 is closed.

9. Consult individual Function Card Operating Manuals for a complete description of the commands used to program each card and the functions of the various LED indicators on each card.

## 53/63-PIX

The following represents an orderly procedure for bringing your 53/63-PIX System up:

1. Install the various Function Cards ordered into the blue card cage slots of the 53/63-PIX Card Cage. As an addressing convention, it is recommended that the Address Select Switch on each card be set to the slot number in which the card is installed. Consult individual Function Card Operating Manuals for correct orientation of cards in Mainframe and for the settings of the various other switches on each card.

2. Install the 53A-171 Control Card in the black card cage slot after setting its Address Select Switch. See the 53A-171 Operating Manual for instructions on setting the Address Select Switch. Insure that the STEP/NORMAL Switch is in the normal position.

3. The 53A-129 Communications Card should next be installed next in the green card slot.

4. Use the 53A-742 Data Cable to connect the required signal lines from the 53A-129 Communications Card to the TTL I/O port on your system controller. Route the cable out the rear of the Card Cage using the Card Cage cable tray.

   Consult the 53A-129 Communications Card Operating Manual for information on the required interface signals between the 53A-129 Communications Card and your controllers TTL I/O port.

5. Use 53A-780 Hooded Connectors or pre-wired CDS data cables to route signals in and out of the various function cards installed your system.

NOTE: If cables are being installed in a 63 Series System, consult the Cable Installation section of the Card Cage Operating Manual for instructions on removing the card cage top cover.

6. If one or more chained card cages (53/63-CCX's) are to be used with your PIX System, consult the 53/63-CCX section of this manual for instructions on interconnecting the card cages.

7. The System is now ready for operation. If the 53A-171 Card is set to Address 0 and the System contained a 53A-351 Relay Switching Card with Address 3, sending @03C5 from your system controller to the PIX System would cause Relay 5 on the 53A-351 Card to close.

   When the characters @03C5 are sent to the RSX System, the LEDs on the 53A-129, 171, and 351 Cards will go to the following known states:

   53A-129 Communications Card
   INPUT/OUTPUT LED - out, the 129 Card is receiving output from the system controller.
   POWER LED - flashes each time data is sent or received.

53A-171 Control Card
POWER LED - extinguished, the Control Card is addressed.

53A-351 Relay Switching Card
POWER LED - extinguished, the Relay Card is addressed.
RELAY LED 5 - lit, Relay 5 is closed.

8. Consult individual Function Card Operating Manuals for a complete description of the commands used to program each card and the functions of the various LED indicators on each card.

**Artisan Technology Group** is an independent supplier of quality pre-owned equipment

## Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

## We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

## Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP