ARTISAN®
TECHNOLOGY GROUP

Your **definitive** source for quality pre-owned equipment.

Artisan Technology Group
(217) 352-9330 | sales@artisantg.com | artisantg.com

Full-service, independent repair center
with experienced engineers and technicians on staff.

We buy your excess, underutilized, and idle equipment
along with credit for buybacks and trade-ins.

Custom engineering
so your equipment works exactly as you specify.

- Critical and expedited services
- In stock / Ready-to-ship
- Leasing / Rentals / Demos
- ITAR-certified secure asset solutions

Expert team | Trust guarantee | 100% satisfaction

All trademarks, brand names, and brands appearing herein are the property of their respective owners.

Find the *Thermo / Forma Scientific 3860* at our website: ***Click HERE***

Thermo Forma

Models:

3033 and 3035
3860 and 3862

Steri-Cult Incubators

Operating and Maintenance Manual

Manual No: 7073033 Rev. 6

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Read This Instruction Manual.

Failure to read, understand and follow the instructions in this manual may result in damage to the unit, injury to operating personnel, and poor equipment performance.



CAUTION! All internal adjustments and maintenance must be performed by qualified service personnel.

Refer to the serial tag on the back of this manual.

The material in this manual is for information purposes only. The contents and the product it describes are subject to change without notice. Thermo Forma makes no representations or warranties with respect to this manual. In no event shall Thermo Forma be held liable for any damages, direct or incidental, arising out of or related to the use of this manual.

MANUAL NUMBER 7073033

REV	ECR/ECN	DATE	DESCRIPTION	By
6	20122/IN-2948	6/18/01	Updated electrical schematics to meet EMC standards	ccs
5	Updates from 2	4/16/01	Updated Accessories list (caster dollies)	ccs
4	19588/SI-8132	12/21/00	Changed power switch P/N 360146 to 363033 (elec. schematics)	aks
3	--	5/19/00	Quark format	ccs
2	18501/SI-7634	8/17/99	Added securing bracket in Section 2	ccs

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



Important operating and/or maintenance instructions. Read the accompanying text carefully.

Ce symbole attire l'attention de l'utilisateur sur des instructions importantes de fonctionnement et/ou d'entretien. Il peut être utilisé seul ou avec d'autres symboles de sécurité. Lire attentivement le texte d'accompagnement.

Wichtige Betriebs- und/oder Wartungshinweise. Lesen Sie den nachfolgenden Text sorgfältig.

Importante instruccions de operacion y/o mantenimiento. Lea el texto acompanante cuidadosamente.



Potential electrical hazards. Only qualified persons should perform procedures associated with this symbol.

Ce symbole attire l'attention de l'utilisateur sur des risques électriques potentiels. Seules des personnes qualifiées doivent appliquer les instructions et les procédures associées à ce symbole.

Gefahr von Stromschlägen. Nur qualifizierte Personen sollten die Tätigkeiten ausführen, die mit diesem Symbol bezeichnet sind.

Potencial de riesgos electricos. Solo personas das capacitadadas deben ejecutar los procedimientos asociadas con este simbulo.



Equipment being maintained or serviced must be turned off and locked off to prevent possible injury.

Risques potentiels liés à l'énergie. L'équipement en entretien ou en maintenance doit être éteint et mis sous clé pour éviter des blessures possibles.

Geräte, an denen Wartungs- oder Servicearbeiten durchgeführt werden, müssen abgeschaltet und abgeschlossen werden, um Verletzungen zu vermeiden.

El equipo recibiendo servicio o mantenimiento debe ser apagado y segurado para prevenir danos.

√ Always use the proper protective equipment (clothing, gloves, goggles, etc.)
√ Always dissipate extreme cold or heat and wear protective clothing.
√ Always follow good hygiene practices.
√ Each individual is responsible for his or her own safety.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Do You Need Information or Assistance on Thermo Forma Products?

If you do, please contact us 8:00 a.m. to 7:00 p.m. (Eastern Time) at:

1-740-373-4763	Direct
1-888-213-1790	Toll Free, U.S. and Canada
1-740-373-4189	FAX
http://www.thermoforma.com	Internet Worldwide Web Home Page
service@thermoforma.com	Service E-Mail Address

Our **Sales Support** staff can provide information on pricing and give you quotations. We can take your order and provide delivery information on major equipment items or make arrangements to have your local sales representative contact you. Our products are listed on the Internet and we can be contacted through our Internet home page.

Our **Service Support** staff can supply technical information about proper setup, operation or troubleshooting of your equipment. We can fill your needs for spare or replacement parts or provide you with on-site service. We can also provide you with a quotation on our Extended Warranty for your Thermo Forma products.

Whatever Thermo Forma products you need or use, we will be happy to discuss your applications. If you are experiencing technical problems, working together, we will help you locate the problem and, chances are, correct it yourself...over the telephone without a service call.

When more extensive service is necessary, we will assist you with direct factory trained technicians or a qualified service organization for on-the-spot repair. If your service need is covered by the warranty, we will arrange for the unit to be repaired at our expense and to your satisfaction.

Regardless of your needs, our professional telephone technicians are available to assist you Monday through Friday from 8:00 a.m. to 7:00 p.m. Eastern Time. Please contact us by telephone or fax. If you wish to write, our mailing address is:

Thermo Forma
Millcreek Road, PO Box 649
Marietta, OH 45750

International customers please contact your local Thermo Forma distributor.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Table of Contents

Section 1 - Receiving . . . . . .2 - 1
1.1 Preliminary Inspection . . . . . .2 - 1
1.2 Visible Loss or Damage . . . . . .2 - 1
1.3 Responsibility for Shipping Damage . . . . . .2 - 1

Section 2 - Installation and Start-up . . . . . .2 - 1
2.1 Location . . . . . .2 - 1
2.2 Securing the Unit . . . . . .2 - 1
2.3 Leveling . . . . . .2 - 2
2.4 Connecting to Power . . . . . .2 - 2
2.5 Connecting the Water Drain Line . . . . . .2 - 2
2.6 Preliminary Disinfecting . . . . . .2 - 2
2.7 Installing the Diffuser Pans and Pilasters . . . . . .2 - 2
2.8 Installing the Shelves . . . . . .2 - 2
2.9 Connecting the CO2 Supply . . . . . .2 - 3
a. To connect the CO2 supply: . . . . . .2 - 3
2.10 Connecting the Temp/Alarm Back-Up Battery . . .2 - 3
2.11 Filling the Humidity Reservoir . . . . . .2 - 4
2.12 Setting the Over/Under Temperature Safety . . . . .2 - 4
2.13 Setting the CO2 . . . . . .2 - 5
2.14 Setting the Relative Humidity . . . . . .2 - 5
2.15 Setting the Chamber Temperature . . . . . .2 - 5
2.16 Connecting to the Recorder Jack . . . . . .2 - 5
2.17 Connecting to the Remote Alarm Contacts . . . . . .2 - 6
2.18 Convenience/Accessory Outlet . . . . . .2 - 6

Section 3 - Operation . . . . . .3 - 1
3.1 Description . . . . . .3 - 1
3.2 Power Control Panel . . . . . .3 - 1
a. Main Power Switch . . . . . .3 - 1
b. Program/Run Key Switch . . . . . .3 - 1
c. Door Ajar Light . . . . . .3 - 1
d. Sample Port . . . . . .3 - 1
3.3 Temperature Alarm/Monitor . . . . . .3 - 2
a. LED Temp Display . . . . . .3 - 2
b. High and Low Temp Limit Switch . . . . . .3 - 2
c. Temp Alarm Lights, Audible Alarm, Normal/Standby Switch . . . . . .3 - 2
3.4 CO2 Control Panel . . . . . .3 - 2
a. CO2 LCD Display . . . . . .3 - 2
b. CO2 Inject Light . . . . . .3 - 2
c. CO2 Alarm Light and Audible Alarm . . . . . .3 - 2
3.5 Auto Zero Function . . . . . .3 - 2
3.6 Auto Zero Alarm . . . . . .3 - 3
3.7 RH Control Panel . . . . . .3 - 3
a. Relative Humidity Liquid Crystal Display . . . . .3 - 3
b. Humidity Indicator Light . . . . . .3 - 3
3.8 Temperature Control Panel . . . . . .3 - 3
a. Temperature LCD Display . . . . . .3 - 3
b. Heat Indicator Light . . . . . .3 - 3

Section 4 - Routine Maintenance . . . . . .4 - 1
4.1 Disinfecting the Incubator Interior . . . . . .4 - 1
4.2 Cleaning the Cabinet Exterior . . . . . .4 - 1
4.3 Cleaning Stainless Steel . . . . . .4 - 1
4.4 Draining the Humidity Reservoir . . . . . .4 - 1

Section 5 - Service . . . . . .5 - 1
5.1 Fuses . . . . . .5 - 1
5.2 Calibration . . . . . .5 - 1
a. CO2 Calibration . . . . . .5 - 1
b. RH Calibration . . . . . .5 - 2
c. Temperature Calibration . . . . . .5 - 2
5.3 Changing the CO2 Filter . . . . . .5 - 3
5.4 Changing the Zero Sample Filter . . . . . .5 - 3
5.5 Changing the Microbiological Filter . . . . . .5 - 3
5.6 Changing the Air Pump . . . . . .5 - 4
5.7 Changing the Inline Water Filter . . . . . .5 - 4
5.8 Changing the Blower Motor . . . . . .5 - 4
5.9 Replacing the IR Sensor . . . . . .5 - 5
5.10 Silencing the Audible Alarm . . . . . .5 - 5
5.11 Service Calibration Guide . . . . . .5 - 5
a. Set-up . . . . . .5 - 5
b. Functional checks . . . . . .5 - 5
c. Has the cabinet defaulted? . . . . . .5 - 5
5.12 Temperature Alarm/Monitor Calibration . . . . . .5 - 6
5.13 Reheat Calibration . . . . . .5 - 6
5.14 RH Calibration . . . . . .5 - 6
5.15 Temperature Offset Adjustment . . . . . .5 - 6
5.16 CO2 Calibration Procedure . . . . . .5 - 6
5.17 Returning the Cabinet from Total Default . . . . . .5 - 7
5.18 Drying out the Humidity Reservoir . . . . . .5 - 8

Section 6 - Specifications . . . . . .6 - 1
a. Electrical Requirements . . . . . .6 - 1
b. Dimensions . . . . . .6 - 1
c. Temperature Control . . . . . .6 - 1
d. Temperature Alarm . . . . . .6 - 1
e. CO2 . . . . . .6 - 1
f. Fittings . . . . . .6 - 1
g. Capacity . . . . . .6 - 1
h. Shelves . . . . . .6 - 1
i. Certification . . . . . .6 - 2
j. Weight . . . . . .6 - 2
k. Environmental Conditions . . . . . .6 - 2

Section 7 - Accessories . . . . . .7 - 1
7.1 Incubator Accessories . . . . . .7 - 1
7.2 General Accessories . . . . . .7 - 1

Section 8 - Parts List . . . . . .8 - 1

Section 9 - Electrical Schematics . . . . . .9 - 1

Section 10 - Warranty Information . . . . . .10 - 1

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 1 - Receiving

1.1 Preliminary Inspection

This unit was thoroughly inspected and carefully packed prior to shipment and all necessary precautions were taken to ensure safe arrival. Immediately upon receipt, before the unit is moved from the receiving area, carefully examine the shipment for loss or damage. Unpack the shipment and inspect both interior and exterior for any in-transit damage.

1.2 Visible Loss or Damage

If any loss or damage is discovered, note any discrepancies on the delivery receipt and call the delivering carrier and request that their representative perform an inspection. Do not discard any of the packing material and do not move the shipment from the receiving area.

1.3 Responsibility for Shipping Damage

For products shipped F.O.B. Marietta, Ohio, the responsibility of Thermo Forma ends when the merchandise is loaded onto the carrier's vehicle.

On F.O.B. Destination shipments, Thermo Forma and the carrier's responsibility ends when your Receiving Department personnel sign a free and clear delivery receipt.

Whenever possible, Thermo Forma will assist in settling claims for loss or in-transit damage.

Section 2 - Installation and Start-up

2.1 Location

Locate the incubator in a draft-free area away from doors, windows, and air conditioning or heating ductwork. To help prevent microbial contamination, the incubator should also be removed from areas of high personnel traffic.


Place the unit on a firm, level surface capable of supporting the unit with humidity reservoir water (Approximate weight with water = 278 lbs or 125 kg).

Allow enough clearance on the left side of the unit for easy access to view the reservoir water level, the filters and electrical components. Adequate space is also required behind the incubator for electrical and gas connections.

2.2 Securing the Unit

Shipped with the shelf channels is a securing bracket and mounting hardware. Retain these for future use, if not required at this time.

All 3033/3860 Series units require a securing bracket, with the exception of a single unit standing on the floor. All incubators must be secured to each other if stacked, and/or to the caster dolly when used. The securing brackets mount to the back of the unit, using holes already drilled. See the illustrations below. The screws in these locations can be discarded and the screws and flatwashers included with the bracket installed in their place.



Units stacked on floor

Units stacked on a dolly

Single unit on a dolly

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2.3 Leveling

Before filling the humidity system, check the level of the unit by placing a bubble-type level on one of the shelves. Turning the leveling feet counterclockwise lengthens them, clockwise shortens them. Level the unit front-to-back and left-to-right.

To prevent injury to personnel and/or damage to equipment, lock the inner glass door and secure outer door before tipping unit to adjust leveling feet.
Do not attempt to tilt the incubator without assistance.

2.4 Connecting to Power

See the serial tag on the left side panel of the unit for electrical specifications.

Connect the incubator to a grounded dedicated circuit only.
The power switch is the mains disconnect device for the incubator.

Plug the power cord provided into the power connector and into a grounded dedicated circuit. See Figure 2-1.

2.5 Connecting the Water Drain Line

A barb-type fitting on the back of the incubator (beneath and to the left of the power cord) is the drain connection for the humidity reservoir. (Refer to Figure 2-1.)




Figure 2-1

Connect one end of the 1/4" tubing supplied with the incubator to the barb fitting. Place the other end of the tubing into a container capable of holding at least 1.5 gallons of water or route the tubing to a suitable drain.

2.6 Preliminary Disinfecting

Disinfect all interior surfaces, including both door gaskets, by washing with an appropriate laboratory disinfectant. Rinse the surfaces with sterile distilled water. Repeat rinsing until all of the disinfectant-detergent has been removed.

Remove the protective plastic film from the shelf brackets. Wash the shelf brackets, diffuser pans, pilasters and shelves with the laboratory disinfectant and rinse with sterile distilled water.

It is recommended that the incubator run for 24 hours to assure removal of all trace vapors.

2.7 Installing the Diffuser Pans and Pilasters

1. Install the boots onto the top and bottom diffuser pans. The diffuser pans are the flat, metal shelf-type assemblies that form the top and bottom of the incubator chamber. (Refer to Figure 2-2).
2. The diffuser pans must be installed with the feather gasket contacting the chamber top or bottom and the boots matching the holes in the chamber wall.
3. Place the bottom diffuser pan into the incubator chamber by positioning the left side first to align the boot with the hole in the chamber wall.
4. Place the left and right pilasters into the chamber with the vertical keyholes at the front (Figure 2-3). Allow the top of the right pilaster to lay diagonally across the chamber, resting upon the left pilaster. Pilasters are the assemblies that hold the shelves inside the incubator chamber.
5. Place top diffuser pan into the incubator chamber. While supporting the top diffuser pan, raise the right pilaster up until it is vertical.
6. Lock the retainers on the pilasters into place.
7. Remove the protective cap from the gas inlet tube located on the bottom of the top diffuser pan. (Figure 2-2).
8. Connect the incoming CO_2 tubing to the gas inlet tube. The CO_2 tubing is routed through the stopper in the back wall of the incubator chamber.

2.8 Installing the Shelves

The shelves are easily installed and removed for cleaning.

1. Slide the rivets on the shelf channel into the keyholes on the pilasters.
2. Slide the shelf into the channel.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 2-2




Figure 2-3

2.9 Connecting the CO_2 Supply

A main supply of liquid CO_2 is recommended. The liquid CO_2 should be supplied from tanks without siphon tubes to ensure that only CO_2 gas enters the incubator injection system. It is also recommended that a two-stage pressure regulator with indicating gauges be installed at the supply cylinder outlet.

The high pressure gauge should have an indicating range of 0 to 2000 PSIG to monitor tank pressure and the low pressure gauge should have an indicating range of 0 to 30 PSIG to monitor the input pressure to the incubator injection system. A suitable two-stage pressure regulator is available from Forma, Stock #965010.

The CO_2 source must be regulated at a pressure level of 5 to 10 PSIG. Higher pressure levels may damage the CO_2 system. Pressure levels lower than 5 PSI will not affect the operation of the incubator, but will increase the CO_2 recovery time.

a. To connect the CO2 supply:

The CO_2 supply fitting (labeled CO2 inlet) is located on the back of the incubator. Securely attach the vinyl CO_2 line to the barbed fitting and check the connection for leaks.

2.10 Connecting the Temp/Alarm Back-Up Battery

The temperature alarm back-up battery has been disconnected to prevent it from discharging during shipment. To connect the battery:

1. Turn the incubator off. Remove the Temperature Alarm module.


2. Locate the 9-volt battery and its connector on the back of the module (Figure 2-4).

3. Snap the battery connector onto the battery terminals and reinstall the module.

Note: If the alarm sounds, turn the alarm switch to the Standby position until the incubator is turned on.

Replace batteries with a rechargeable type only. Dispose of the old battery in an environmentally safe manner.

Figure 2-4



Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2.11 Filling the Humidity Reservoir

For best operation of the incubator, sterilized distilled, demineralized or de-ionized water should be used in the humidity reservoir. Water purity should be in the resistance range of 50K to 1M Ohm/cm, or a conductivity range of 20.0 to 1.0 uS/cm. Refer to ASTM Standard D5391-93 or D4195-88 for measuring water purity.

Distillation systems, as well as some types of reverse osmosis water purity systems, can produce water in the quality range specified. Tap water is not recommended as it may contain chlorine, which can deteriorate the stainless steel. Tap water may also have a high mineral content, which would produce a build-up of scale in the reservoir. High purity, ultra pure or milli-q water is not recommended as it is an extremely aggressive solvent and will deteriorate the stainless steel. High purity water has a resistance of above 1M Ohm to 18M Ohm/cm. Even high purity water can contain bacteria and organic contaminants. Water should always be sterilized or treated with a decontaminant, safe for use with stainless steel as well as safe for the product, prior to being introduced into the humidity reservoir.

Distilled or de-ionized water used in the humidity reservoir must be within a water quality resistance range of 50K to 1M Ohm/cm to protect and prolong the life of the stainless steel. Use of water outside the specified range will decrease the operating life of the unit and may void the warranty.

The humidity reservoir fill port fitting is located on the upper left side of the incubator. A viewing window built into the side panel allows the reservoir bottle water level to be seen.

1. Remove the brass plug from the fill port using a 1/4" Allen wrench.
2. Attach the threaded fitting, tubing and funnel to the fill port.
3. Add 3 liters of sterile distilled water to the reservoir. If the humidity reservoir is overfilled, water will escape through the overflow drain.

Note: With the power switch ON, the Add Water alarm may activate if the reservoir is not filled within 10 minutes. Silence the alarm by pressing any "sensi-touch" key.


No modification to the Add Water system should be made, such as attaching to a pressurized supply, without first consulting the Forma Service department. The water valve is rated to 5 PSIG. Pressure in excess of this may damage or override the valve and cause flooding of the incubator chamber.

2.12 Setting the Over/Under Temperature Safety (Refer to Figure 2-5)

The over/under temperature safety settings are made on the Temperature Alarm/Monitor control panel. Power to the incubator must be turned on.

To make these adjustments, a screwdriver is provided. Pull on the black knob located to the right of the sample port on the power control panel. The knob is the handle of the screwdriver.

Refer to the control panel illustration in Figure 2-5 and look for this screwdriver symbol:



To set the overtemperature safety limit:

1. Slide the Set Hi/Actual/Set Low switch on the Temperature Alarm Monitor to the Set Hi position.
2. Using the screwdriver turn the adjustment screw labeled Set Hi until the desired high limit temperature is displayed.

Note: The incubator will likely overshoot 2 or 3°C on initial start-up. The Set Hi should be set to allow for this. It may later be set closer to the setpoint.

To set the under temperature safety limit:

1. Slide the switch to the Set Lo position and turn the Set Lo adjustment screw until the desired low limit temperature is displayed on the LCD display.

Note: On initial start-up, the Set Lo should be set below ambient to avoid an alarm condition. When the incubator has stabilized, the Set Lo may be adjusted closer to setpoint temperature. the high and low setpoint temperature limits should not be set within 0.2°C of the desired temperature to avoid nuisance alarms.

2. Return the slide switch to the center Actual position to display the chamber temperature.




Figure 2-5

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2.13 Setting the CO_2

When setting the CO_2, the incubator power must be on and the key switch set to Program. Refer to the power control module illustration in Figure 2-6 and the CO_2 control module illustration, Figure 2-7.

1. With the Program/Run key switch turned to Program, press the inverted Y touch button on the CO_2 control panel until the word SET appears on the left side of the CO_2 display.
2. Using the up arrow or down arrow touch buttons, set the CO_2 concentration percentage. The CO_2 may be set in 0.1% increments within a range of 0% to 20%.
3. When the CO_2 concentration has been selected, press the inverted Y button again to return to the display mode. (SET will disappear from the window).
4. When programming is complete, turn the Program/Run key switch to Run and remove the key to secure the setpoints.




Figure 2-6




Figure 2-7

2.14 Setting the Relative Humidity

1. With the Program/Run key switch turned to Program, press the inverted Y touch button on the RH Control panel until the word SET appears on the left side of the display.
2. Using the arrow keys, increase or decrease the setpoint until the desired humidity percentage appears. The RH may be set in 1% increments from 5% above ambient to 98%.
3. When the RH level has been selected, press the inverted Y button. (SET will disappear from the window).
4. When programming is complete, return the Program/Run key switch to Run and remove the key to protect the setpoints from unauthorized tampering.

Note: The incubator will not attempt to control the RH until the chamber temperature is within 1°C of setpoint. During this time the value displayed in the RH control panel will be "—". The RH recorder output will be the RH setpoint value.




Figure 2-8




Figure 2-9

2.15 Setting the Chamber Temperature (Refer to Figure 2-9)

Note: The Temperature Control panel displays the temperature setpoint. The Temperature Alarm/Monitor displays the actual chamber temperature.

1. Turn the Program/Run key switch to Program and press the arrow keys to increase or decrease the temperature setpoint.

Note: The temperature may be set in 0.1°C increments within a range of 4°C above ambient to +45°C.

2. When the temperature setpoint has been selected, return the key switch to Run and remove the key to secure the setpoints.

2.16 Connecting to the Recorder Jack

A recorder jack, capable of an input signal from 0 to 999mV, is provided for connecting electronic recorders. The TEMP/RH/CO_2 jack is located on the back panel of the incubator. Refer to Figure 2-1 for the jack location and Figure 2-10 for the pin descriptions.




Figure 2-10

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

2.17 Connecting to the Remote Alarm Contacts

An internal DPDT relay is provided on the Temperature Alarm/Monitor to monitor alarms and is connected to an RJ-11 (telephone style) jack on the back of the cabinet. Figure 2-10 identifies the pin contacts, Figure 2-1 shows the location of the Remote Alarm Connector.




Figure 2-11

IMPORTANT USER INFORMATION

Caution! Stored product should be protected by an activated alarm system capable of initiating a timely response 24 hours/day. Forma Alarms provide interconnect for centralized monitoring.

The remote contacts are “dry” contacts, rated at 30V, 1A maximum.

A modular to modular cable (Forma Stock No. 190388) and an RJ-11 telephone style terminal converter (Stock No. 190392) or equivalent may be used to convert the remote alarm output to a screw terminal connection. Refer to Figure 2-12.

2.18 Convenience/Accessory Outlet

An electrical outlet is located on the back of the incubator, providing 115VAC 0.35A max for lights and accessories. The maximum allowable leakage current for the product plugged into the outlet is 3 mA. The outlet is protected by an adjacent fuse 0.5 amp, 250V, T (time-lag), Forma P/N 230120. Refer to the electrical schematic in Section 9 of this manual.




Figure 2-12

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 3 - Operation

3.1 Description

The Steri-Cult Series CO_2 incubator provides perfect culture conditions in a state-of-the-art, microprocessor controlled incubator. During operation, the chamber air is drawn through the top diffuser pan and into the chamber outlet duct where it passes over a temperature probe. The temperature controller then cycles the heaters which surround the incubator chamber.

Next, the air passes through the blower and onto a microbiological filter. The filter scrubs the circulating air, trapping spores and other airborne contaminants. The "scrubbed" air exits the filter and continues along the sensing/conditioning path. A sample of this air is routed through the infrared CO_2 sensing unit where precise CO_2 levels are monitored.

Periodically, the Air Inject solenoid opens, allowing filtered outside air to pass across the IR sensor. This serves as an Auto-Zero to eliminate possible sensor or electrical component drift. During this time, the CO_2 inject solenoid will not cycle. Signals from the IR sensor are sent to the CPU Board where they are compared to the CO_2 setpoint. If a difference exists between the actual value and the setpoint, the microprocessor computes the appropriate solenoid on/off times. This creates a proportional CO_2 controller when the actual value is within 1% of setpoint.

The recirculated chamber air continues into the humidity reservoir. The air passes below the water level and is humidified as it bubbles through the water. The microprocessor looks at the air temperature and selected humidity level and calculates the necessary water temperature required to obtain the desired RH. Water in the reservoir is heated by an external heater and the temperature is monitored by an immersed temperature probe.

Note: The Steri-Cult incubators are designed to minimize the amount of condensation on the glass door. However, the units are not condensate-free, specifically if the chamber interior is operated above an absolute RH average of 85%. It is normal to have a small amount of condensate form across the bottom and in the corners of the glass door if the RH setpoint is equal to or greater than 90% RH.

No attempt to control RH will occur until the chamber temperature is within 1°C of setpoint. During this time the value displayed in the RH Control module will be "—". The RH recorder output will be the RH setpoint value.

The humidified and CO_2 enhanced air then passes across another heater which is controlled by a third temperature probe. The purpose of this heater is to restore lost heat to the air before entering the chamber.

Air enters the chamber beneath the bottom diffuser pan and is forced up through the holes into the chamber.

When the outer door is opened, power to the heaters, CO_2 inject solenoid and humidity reservoir is interrupted. When the outer door is closed, power is restored.

3.2 Power Control Panel (Figure 3-1)

The Power Control Panel houses the Main Power switch, Program/Run key switch, Door Ajar light (red), Sample Port and Adjustment Screwdriver.

a. Main Power Switch

The Main Power switch controls all electrical power to the incubator. The switch must be on for any of the incubator systems to be functional.

b. Program/Run Key Switch

The Program/Run key switch determines the operating mode of the incubator.

When the switch is set to Program, the operator may set the chamber temperature, relative humidity and CO_2.

When the switch is set to Run, the programmed setpoints are locked. The setpoints may be viewed but not changed.

c. Door Ajar Light

The red Door Ajar light warns that the outer door is open or has not been securely closed.

When the Door Ajar light is on, power to the heaters and the CO_2 injection solenoid is interrupted.

d. Sample Port

The Sample Port is used to draw a sample of chamber atmosphere so CO_2 content may be measured by an independent source.



For proper operation and to prevent CO_2 loss, the sample port must be capped when not in use.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

3.3 Temperature Alarm/Monitor

The Temperature Alarm/Monitor contains a liquid crystal display (LCD), red Overtemp and red UnderTemp lights, a Normal/Standby alarm switch, Set Hi and Set Lo adjustment screws and a three-position selector switch.

a. LED Temp Display

The LCD display will show actual chamber temperature, high alarm limit or low alarm limit, depending upon the position of the three position switch.

b. High and Low Temp Limit Switch

The High and Low temperature limits are set by placing the three position switch to Set Hi or Set Lo and turning the proper adjustment screw until the desired temperature appears in the LCD window. When the switch is returned to Actual the LCD displays the actual chamber temperature.

c. Temp Alarm Lights, Audible Alarm and Normal/Standby Switch

If the chamber temperature exceeds the programmed high or low limits, the appropriate red LED lights and an audible alarm will sound.




Figure 3-1

The audible alarm is silenced by turning the Normal/Standby switch to the Standby position. The red LED will remain lit until the alarm condition has been corrected.

Note: The alarm will ring back when the alarm condition has been corrected as a reminder to turn the Normal/Standby switch to the Normal position.

3.4 CO_2 Control Panel

The CO_2 Control Panel contains an amber LED inject light, a red alarm light, an LCD readout and three "Sensi-Touch" touch pad buttons.

a. CO_2 LCD Display

The LCD readout displays either the actual chamber CO_2 content or the CO_2 setpoint. Touching the inverted Y button selects the mode of the display.

When the unit is in the Set mode the word SET appears on the left side of the display. With the key switch turned to Program, the CO_2 setpoint is set by pressing the up arrow or down arrow buttons. Touching the inverted Y button again will change the display to read the actual chamber CO_2.

b. CO_2 Inject Light

When CO_2 is being injected, the amber Inject light will be lit.

c. CO_2 Alarm Light and Audible Alarm

If the incubator CO_2 concentration deviates from the setpoint by +/- 1% (nominal) for more than 30 minutes, the red LED alarm light will be activated and a pulsing audible alarm will sound.

Pressing any of the nine Sensi-Touch buttons on the control panel will silence the alarm and turn off the red alarm light.

If the alarm is not silenced, and the actual CO_2 concentration returns to within +/- 1% of the setpoint, the audible alarm will turn off, but the alarm light will stay lit until a touch pad button is pressed.

A CO_2 setpoint of 00.0 will disable the deviation alarm.

3.5 Auto Zero Function

The CO_2 Auto Zero Function compensates for any drift in the CO_2 sensing system.

The Auto Zero solenoid activates approximately every four hours to allow room air supplied by the air pump to enter the CO_2 sensor cell. (The reading from the room air is considered to be 0% CO_2.) The calibration value is automatically adjusted to make the actual reading 0%.

Note: The "%" indicator in the %CO2 display is turned off during the Auto Zero cycle, which takes 3-4 minutes.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

3.6 Auto Zero Alarm

If the calibration correction value is larger than that of a typical instrument drift, it is considered an error and the calibration value will not be changed.



This indicates a problem such as elevated ambient, CO_2 component failure, plugged lines, electrical noise, etc. Therefore, the incubator will continue to use the last correct zero value.

Four consecutive errors are considered an alarm condition. The %CO2 in the CO_2 display will then flash and the audible alarm will sound.

Note: If a subsequent auto zero calibration value is within the range, the alarms will be turned off.

A CO_2 setpoint of 00.0 will disable the Auto Zero alarm.

3.7 RH Control Panel

The Relative Humidity (RH) Control Panel contains an amber LED, an LCD readout and three Sensi-Touch buttons.

a. Relative Humidity Liquid Crystal (LCD) Display

The LCD readout displays either the actual chamber RH or the RH setpoint. Touching the inverted Y button selects the display mode.

When the inverted Y button is pressed, the word SET appears on the left side of the LCD window. With the key switch turned to Program, the RH level can be set by touching the up arrow or the down arrow. Pressing the inverted Y button again changes the display to read the chamber humidity.

If the humidity reservoir runs low on water a steady audible alarm will sound and the symbol H_2O will flash in the LCD window. Pressing any of the nine Sensi-Touch buttons on the control panel will silence the alarm for 10 minutes.

When a low water alarm occurs, add 3 liters of sterile distilled water to the humidity reservoir. Follow the instructions in Section 2.10.

Note: No humidification will take place until the chamber temperature is within 1° of the temperature setpoint. During this time, the LCD reading will default to two dashes ("—"), and the RH recorder output will be the RH setpoint value.

If no humidity control is desired, a 00.0 setpoint should be selected. This will cause the display to show "—" and will also defeat the H_20 alarm.

b. Humidity Indicator Light

The amber LED will light as the unit calls for more moisture to maintain the humidity setpoint.

3.8 Temperature Control Panel

The Temperature Control Panel contains an amber LED, an LCD and three Sensi-Touch buttons.

a. Temperature LCD Display

The LCD readout displays the selected temperature setpoint.

Note: On this module the inverted y button performs no function.

With the key switch turned to Program, the temperature is set by pressing the up arrow or down arrow buttons.

Note: This module displays setpoint - not actual temperature.

b. Heat Indicator Light

The amber Heat LED lights when the temperature controller calls for more heat in the chamber.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Thermo Forma

PREVENTIVE MAINTENANCE

Incubators

Your Thermo Forma equipment has been thoroughly tested and calibrated before shipment. Regular preventive maintenance is important to keep your unit functioning properly. The operator should perform routine cleaning and maintenance on a regular basis. For maximum performance and efficiency, it is recommended the unit be checked and calibrated periodically by a qualified service technician.

The following is a condensed list of preventive maintenance requirements. See the specified section of the instruction manual for further details.

Thermo Forma has qualified service technicians, using NIST traceable instruments, available in many areas. For more information on Preventive Maintenance or Extended Warranties, please contact us at the number listed below.

Cleaning and calibration adjustment intervals are dependent upon use, environmental conditions and accuracy required.

Tips for all incubators:

- Do NOT use bleach or any disinfectant that has high chloros
- Use sterile, distilled or demineralized water.
- Avoid spraying cleaner on the CO_2 sensor.
- Do not use powdered gloves for tissue cultures.

Millcreek Road, Box 649 Marietta, Ohio 45750 USA 740-373-4763
USA and Canada 888-213-1790 Telefax: 740-373-4189 http://www.fservice@forma.com

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Preventive Maintenance for 3033 and 3860 Series Incubators

Refer to Manual Section	Action	Daily	Weekly	Yearly	Every 2 Years
--	Check CO_2 tank levels.	✓			
--	Inspect door latch, hinges and door gasket seal.			✓	
5.2	* Verify and document CO_2, temperature and humidity calibration			✓	
5.16	* Verify and document Auto Zero, at the minimum.			✓	
4.1, 4.4	Perform a complete decontamination procedure. Wipe down interior, shelves and side panels with disinfectant. Drain the water reservoir bottle and rinse with disinfectant. Rinse all well with sterile distilled water.	Between experiments *More frequent decontamination may be required, depending on use and environmental conditions*			
5.5	* Change HEPA, gas, water and air filters, as applicable		✓ *More frequent changes may be required, depending on use and environmental conditions*		

* Qualified service technicians only

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 4 - Routine Maintenance

4.1 Disinfecting the Incubator Interior

The incubator can be disinfected in about 30 minutes using an appropriate disinfectant diluted with sterile distilled water (50K to 1M Ohm/cm) per manufacturer's instructions.

Do not use strong alkaline or caustic agents. Stainless steel is corrosion resistant, not corrosion proof. do not use solutions of sodium hypochlorite (bleach), as they may cause pitting and rust.

1. Turn the power switch off.
2. Remove the shelves, pilasters and diffuser pans and clean all interior surfaces with disinfectant solution.
3. Rinse surfaces at least twice with sterile distilled water, or until all of the disinfectant-detergent has been removed.
4. Thoroughly clean the inner door gasket.
5. Clean the inside of the glass door with disinfectant solution and rinse with sterile distilled water.
6. Wash the shelves and rinse with sterile distilled water.
7. Reinstall the diffuser pans, pilasters and shelves. (See Sections 2.6 and 2.7 if necessary.)
8. Turn the power switch on.

After decontamination, operate the unit for 24 hours to remove trace vapors from the incubator chamber.

4.2 Cleaning the Cabinet Exterior

The incubator exterior may be cleaned with a general-use laboratory disinfectant.

4.3 Cleaning Stainless Steel

Use the mildest cleaning procedure that will do the job effectively. To insure maximum effectiveness and to avoid marring the surface, always rub in the direction of the finish polish lines. Rinse the surface thoroughly and wipe the surface dry.

The use of aromatic solvents is not recommended for cleaning cabinet interiors as residues could cause contamination of the cabinet environment.


Do not use strong alkaline or caustic agents. Stainless steel is corrosion-resistant, not corrosion-proof. Do not use solutions of sodium hypochlorite (bleach) as they may cause pitting and rust.

4.4 Draining the Humidity Reservoir

A drain valve has been provided for draining of the humidity system.

1. Verify that there is a hose connected to the drain fitting on the back of the incubator. Route the line to a large container or suitable drain.
2. Turn the incubator on.
3. Remove the humidity reservoir fill port plug located on the upper left side of the incubator using a 1/4" Allen wrench. (Refer to Figure 4-1)

Figure 4-1



4. Remove the cover plate located directly beneath the Temperature Control Module. The cover is released by pulling the two black plastic locking pins. (Refer to Figure 4-2)




Figure 4-2
Drain Valve Access Panel

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

5. Reach through the opening and open the drain valve by rotating it 90° counterclockwise so the handle is parallel with the drain line. (Figure 4-3) This will drain the entire humidity system.
6. Close the drain and replace the access panel.




Figure 4-3

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 5 - Service

CAUTION
Contains Parts and Assemblies Susceptible to Damage by Electrostatic Discharge (ESD)

Servicing must be performed by qualified service personnel only!

5.1 Fuses

Two North American UL and/or CSA 250VAC time-lag fuses are located behind the side access panel on the component mount. (See Figure 8-1) To gain access to the fuses, remove the cabinet side panel. Replace the fuses with fuses of the same type and rating.

The following chart identifies the fuses in the unit and their characteristics.

Incubator Model	Fuse Stock #	Amp/Size/Rating	Rupture Speed	IEC Letter Code
3033, 3860	(main) 230066	250V, 10 Amp	Time-Lag	T
3035, 3862	(main) 230093	250V, 5 Amp	Time-Lag	T
All Models	(power supply) 230103	250V, 0.75 Amp	Time-Lag	T
All Models	(accessory) 230120	250V, 0.5 Amp	Time-Lag	T

5.2 Calibration

Frequency of calibration is dependent upon use, environmental conditions and accuracy required. Thermo Forma recommends calibration every three to four months.

All incubators are factory calibrated. However, the incubator should be run and checked for proper operation prior to being put into use. Before making any calibrations or adjustments to the unit, it is imperative that all reference instruments be in good repair and properly calibrated.

a. CO_2 Calibration

Equipment required: Fyrite or another independent method of CO_2 measurement.

1. With the CO_2 supply connected, adjust the CO_2 to the desired level.
2. If the unit is already operating, allow 30 minutes to stabilize. If the unit is being started up and is cold, allow two hours for stabilization.
3. When the incubator has stabilized, turn the Program/Run key switch to Program.
4. Turn the incubator power switch off.
5. Press and hold the inverted Y button on the CO_2 module while turning the Power switch on. Continue to press the inverted Y button until the "beeping" stops.

Note: When entering the calibration mode, the temperature display will read 00.0 and the RH display will show the CO_2 sensor output voltage in millivolts. (This value can be used for diagnostic purposes by service personnel.)

6. Press the inverted Y touch button on the CO_2 module so that the word SET appears in the LCD window. This puts the module into the Span Adjust mode.
7. Remove the cap from the Sample Port on the front of the control panel and read the CO_2 concentration with the Fyrite. Two readings should be taken.
8. Using the up or down arrow buttons, change the CO_2 display to match the Fyrite reading.
9. Disconnect the reference instrument and replace the Sample Port cap.

For proper operation and to prevent CO_2 loss, the sample port must be capped when not in use.

10. Turn the incubator power switch off, then back on without pressing any buttons.
11. Return the Program/Run key switch to Run.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

b. RH Calibration

Equipment required: Humidity sensing instrument of known accuracy.

1. Place the reference humidity instrument in the center of the chamber.
2. Allow the incubator to run at the desired humidity level for at least an hour after it has stabilized.
3. Record the humidity level shown by the reference instrument and the humidity level displayed on the RH Control module.
4. Turn the Program/Run key switch to Program.
5. Turn the incubator off.
6. Press and hold the inverted Y button on the RH module and turn the power switch on. Press the inverted Y key until the beeping stops.

The incubator RH is ready for calibration when the temperature display and CO_2 displays read 00.0. If the word SET appears in the LCD window, press the inverted y button to remove it.

When in the RH Calibration mode, the display shows the temperature (°C) of the water in the humidity reservoir, not the RH concentration.

7a. Using the arrow touch buttons, adjust the display upward or downward. If the RH reading was lower than the reference instrument, increase the display by 0.2°C for each percent that the (RH) incubator reading was low.

Example: If the RH display reads 85% and the reference instrument reads 87%, increase the display reading by 0.4°C.

7b. If the RH Control reading was higher than the reference instrument, decrease the display by 0.2°C for each percent that the (RH) incubator reading was high.

Example: If the RH display reads 87% and the reference instrument reads 85%, decrease display by 0.4°C.

8. Turn the incubator off, then back on without pressing any buttons.
9. Return the Program/Run key switch to Run.

c. Temperature Calibration

Any change in temperature calibration will require adjustments to the temperature alarm/monitor, RH control and temperature control. Failure to make these adjustments will result in incorrect humidity control, poor temperature uniformity, or both.

Equipment Required: a thermometer of known accuracy.

1. Place the reference thermometer in the center of the chamber.
2. Close both incubator doors and allow the incubator temperature to stabilize for about one hour.
3. Record the temperature indicated on the thermometer and the temperature readout on the Temperature Alarm/Monitor Module.
4. Carefully swing open the control panel and identify the Temperature Alarm module.
5. Locate the adjustment potentiometer labeled Zero. Refer to the illustration at the right.
6. Using the adjustment screwdriver, turn the Zero pot until the displayed temperature agrees with the reference thermometer.
7. Close the control panel, taking care not to pinch the ribbon wires inside the compartment.




Figure 5-1

8. Turn the Program/Run key switch to Program.
9. Turn the incubator off.
10. Press and hold the inverted Y touch button on the RH module while turning the power switch on. Press the inverted Y button until the beeping stops. When the unit is ready for calibration, the temperature display and the CO_2 display will read 00.0.

Note: If the word SET appears in the lcd window, momentarily press the inverted Y button to remove it.

11. Using the up or down arrow buttons, change the display by an amount equal to the amount the Temperature Alarm/Monitor display was changed.

Example: If the reference instrument reads 37.5 and the Temperature Alarm/Monitor reads 37.0, the display would have been increased 0.5. Therefore, the RH Control display must also be increased 0.5.

12. Turn the incubator off.
13. Press and hold the inverted Y touch button on the Temperature Module while turning the incubator on.

Note: Continue to press the inverted Y button until the beeping stops. when the unit is ready for calibration, the RH display and the CO_2 display will read 00.0. If the word Set appears in the display window, press the inverted Y button to remove it.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 5-2

14. Using the arrow buttons, change the displayed value by an amount equal to the amount the Temperature Alarm/Monitor display was changed.

Example: If the reference instrument reads 37.5 and the Temperature Alarm/Monitor reads 37.0, the display should be increased 0.5. Therefore, the Temperature Control display must also be increased 0.5.

15. Turn incubator off, then back on without pressing any keys.
16. Return the Program/Run key switch to Run.

5.3 Changing the CO_2 Filter P/N 770001

Note: Under normal use, the CO_2 filter should be serviceable for about two years. If the CO_2 filter becomes clogged, replace it with Thermo Forma stock #770001.

1. Turn the incubator off and unplug it.
2. Remove the screws securing the left side access panel.
3. Remove the panel by lifting it up and out. Set it aside.
4. Locate the CO_2 filter about halfway up the left side. (It will be connected to the hose leading to the CO_2 gas fitting on the back of the incubator. (See Figure 5-2.)
5. Remove and replace the filter by forcing the plastic hose clamps open or cutting them.
6. Install the new filter and refasten the plastic hose clamps or install new clamps.
7. Dispose of the old filter following approved biological safety procedures.

5.4 Changing the Zero Sample Filter P/N 770001

Note: Under normal use, the service life of the Zero Sample filter is about two years. If the filter becomes clogged, replace it with Thermo Forma stock #770001.

1. Turn the incubator off and unplug it.
2. Remove the screws securing the side access panel.
3. Remove the panel by lifting it up and out. Set it aside.
4. Locate the Zero Sampler Filter installed in the clear vinyl tubing connected between the upper solenoid valve and the air pump located beneath the reservoir bottle. See Figure 5-2.
5. Remove and replace the filter by forcing the plastic hose clamps open, or cutting them.
6. Install the new filter and refasten the plastic hose clamps, or install new clamps.
7. Dispose of the old filter following approved biological safety procedures.

5.5 Changing the Microbiological Filter P/N 760043

Note: Under normal usage, the service life of the microbiological filter is about two years. Replace the filter with Thermo Forma stock #760043.

1. Turn the incubator off and unplug it.
2. Remove the screws securing the side access panel.
3. Remove the panel by lifting it up and out and set it aside.
4. Locate the cover plate in the upper left corner and remove it.
5. Remove the fiber insulation to expose the filter. Refer to Figure 5-2.
6. Cut the small plastic tie wrap which secures the solenoid valve to the one inch plastic tubing.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

7. Loosen the metal hose clamp below the filter's 90° elbow.
8. Loosen the metal hose clamp on the end of the filter connected to the blower motor.
9. Slide the filter out and replace it, reversing Steps 1 through 9. Make sure the airflow direction is from the blower through the filter and downward through the one-inch tubing. Look for the flow direction arrow on the body of the filter.
10. Dispose of the old filter following approved biological safety procedures.

5.6 Changing the Air Pump

1. Turn the incubator off and unplug it.
2. Remove the screws securing the side access panel.
3. Remove the panel by lifting it up and out and set it aside.
4. The air pump is located in a foam-lined metal enclosure attached to the bottom of the reservoir bottle platform.
5. Cut and remove the two outermost tie wraps which secure the enclosure to the base of the platform. The tie wraps are fed through rubber grommets. (Figure 5-3)
6. Tip the enclosure downward, pivoting on the two rear grommet/tie wraps.
7. Cut the two tie wraps which hold the air pump to the bottom of the enclosure. The tie wraps may be cut from inside the enclosure or at where they exit from the bottom of the enclosure.
8. Lift the air pump out and remove the vinyl hose by pulling it off of the pump fitting.
9. Trace the two black air pump wires to the two yellow wire nuts. Remove the wire nuts and disconnect the pump wires from the wiring harness.
10. Install the new air pump by reversing Steps 1 through 9.

Note: If there is a vibration with the air pump, creating an undesirable noise or shelf vibration, remove all four of the tie wraps on the outer corners of the enclosure (Refer to Figure 5-3).

5.7 Changing the Inline Water Filter P/N 780266




Figure 5-3

1. Turn the incubator off and pull the plug.
2. Remove the screws securing the left side access panel.
3. Remove the side access panel by lifting it straight up and set it aside.
4. Locate the inline water filter. (Refer to Figures 5-3 and 5-4)
5. Remove and replace the filter by pushing the tubing onto the ends of the filter.

5.8 Changing the Blower Motor P/N 900078

1. Turn the incubator off and pull the plug.
2. Remove the screws securing the left side access panel.
3. Remove the side access panel by lifting it straight up and set it aside.
4. Remove the cover panel from the enclosed section in the upper left corner.
5. Remove the loose fiber insulation.
6. Loosen or remove the metal hose clamp securing the blower motor to the microbiological filter. (Refer to Figure 5-4).
7. Remove or cut the white snapper hose clamp which secures the rubber boot from the blower motor to the stainless steel elbow (air intake line).
8. Locate the two black blower motor connecting wires, unscrew the wire nuts and remove the wires from the harness.
9. Remove the screws from the four corners of the blower mounting plate. This plate is the top panel on the back of the incubator cabinet. Do not remove the two screws in the center of the mounting plate. These screws secure the blower motor to the blower bracket.
10. Remove the blower and mounting plate from the incubator.




Figure 5-4

11. Replace the blower motor on its mounting bracket and install the assembly by reversing Steps 1-10.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

5.9 Replacing the IR Sensor

1. Turn the incubator off and pull the plug.
2. Remove the screws securing the left side access panel.
3. Remove the side access panel by lifting it straight up and set it aside.
4. Remove the cover panel from the enclosed section in the upper left corner.
5. Remove the loose fiber insulation.
6. Locate sensor board and unplug the electrical connector.
7. Remove the tubing from the IR sensor.
8. Remove the sensor board from the (4) nylon support mounts. (Push in on each small tab, and pull board forward)
9. Install the new board over the (4) nylon support mounts.
10. Remove the top piece (plug-in part with screws) of the electrical connector on new board.
11. Reconnect the original electrical connector.
12. Reconnect the tubing to the IR sensor.
13. Replace the insulation and cover panels.

5.10 Silencing the Audible Alarm

To turn OFF the audible alarm on the Microprocessor Board:

1. Swing open the control panel.
2. Locate the red, surface-mounted switch in the upper right corner of the microprocessor board. (Refer to Illustration 5-5.)
3. Using a small screwdriver or your fingernail, move the switch from on to off. The audible alarm will silence.

Note: Turning this switch off will eliminate CO_2 and RH alarms. It will also silence the key tones.




Figure 5-5

5.11 Service Calibration Guide

This service guide supplement is designed to be used in direct conjunction with Sections 4 and 6. All calibration functions are to be performed with the word "Set" removed from the LCD displays except when calibrating CO_2 span.

a. Set-up

1. Check that the battery in the Temperature Alarm/Monitor is connected.
2. Check that High and Low alarm points are set properly.
3. Check that the alarm enable microboard DIP switches are all On (down).

b. Functional checks

1. With the power switch off, plug the unit in.
2. Turn the key switch to Program.
3. Turn the unit on. The green LED and LCD displays will light. Verify that the chamber blower is operating.
4. Check the water bottle level. The bottle should be full.
5. Verify that water is flowing through the Fill solenoid and into the humidity reservoir.
6. Place unit in the Run mode and confirm that the setpoints of RH, CO_2 and temperature cannot be changed.
7. Return key switch to Program.
8. Check the operation of the overtemp and undertemp including the alarm contacts on the Temperature Alarm/Monitor board. (Refer to Figure 5-6.)
9. Open and close the outer door to verify the Door Ajar switch operation.
10. Check for default of cabinet.

c. Has the cabinet defaulted?

This is indicated if setpoints have changed and are:

(20°C) = Temp, (0%) = RH, (0%) = CO_2.

If there is no evidence of default, proceed to Section: Reheat Calibration.

If default is evident, then zero and span both Reheat and RH. (See "Procedure for Returning the Cabinet from Total Default").

0°C= (1000) Ohm resistor

60°C= (1232) Ohm resistor.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

The Reheat terminals on the microboard for resistor hook-up are 14 and 15.

The RH terminals on the microboard for resistor hook-up are 11 and 12.

Note: Do not leave any inputs to the microboard disconnected during zero and span phase, or errors will occur. Proceed to the Reheat Calibration procedure.




Figure 5-6

5.12 Temperature Alarm/Monitor Calibration

Note: Allow a minimum of 6 hours for stabilization from a cold start up to 37°C.

Place a thermometer in the center of the chamber and adjust the zero trim pot on the Temperature Alarm/Monitor board to match. (Refer to Section 6.1.c.)

5.13 Reheat Calibration

Place the Temperature Control module in the calibration mode using the inverted Y key.

Check the LCD display to ensure that the word Set does not appear. If it does, depress the inverted Y key to remove it. The module is now in the Zero mode.

Place the Reheat probe, located in the outlet tube of the humidity reservoir (not in the reservoir itself) in a beaker with the same thermocouple or thermometer used to calibrate the monitor module.

Using the up arrow and down arrow, adjust the display to match.

Put thermal compound on the tip of the probe and insert it fully into the sheath. Seal it with silastic.

5.14 RH Calibration

1. Read the RH in the cabinet with a reliable humidity indicating device. Note the difference between the indicating device and the LCD readout.
2. Put incubator in calibrate mode using inverted Y key. Next press the inverted Y key until the word Set disappears from the window. You are now in the RH Zero mode. Using the up and down arrow keys, adjust the display (0.2°C) for each percent difference in the LCD readout compared to the indicating device.

Example: If the indicating device is 95% and the LCD readout is 90%, with the RH module in the Calibration mode, raise the displayed temperature (0.2°C) for each percent of difference, or (0.2) x 5% = 1.0. Raise the displayed temperature 1.0°C.

3. Return the incubator to the Run mode by turning the power off, then on.

5.15 Temperature Offset Adjustment

1. Make sure unit is stable before proceeding.
2. Place the Temperature Control module in the Calibration mode, EXCEPT depress the up arrow instead of the inverted Y key. Use the inverted Y to remove the word Set.
3. Use the up arrow and down arrow keys to adjust the Temperature Control to match the Temperature Alarm/Monitor module.
4. Return incubator to Operation mode.

5.16 CO_2 Calibration Procedure

Equipment required: Fyrite, or another independent method of CO_2 measurement.

1. Put the Run/Program key switch on control panel in Program mode.
2. Change the CO_2 setpoint to 1.0%.
3. Default CO_2 values by depressing the up arrow key on the CO_2 module and turning the main power switch off, and then back on.
4. Check CO_2 setpoint. If it now reads 0.0%, the default was successful. If not, then repeat Step 3.
5. Locate “hidden” key to the right of the down arrow key on the CO2 module. (This is a touch-tone key like the other keys).
6. While depressing the “hidden” key on the CO_2 module, turn the incubator power switch “OFF” and back “ON”. Continue holding the “hidden” key until the high audible tone stops.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

7. The incubator is now in Calibration mode with "Auto-Zero" activated.

Note: RH display will show the CO_2 sensor output voltage in millivolts and the temp control will be "00.0" if Calibration mode has been successfully entered. If the attempt was unsuccessful, repeat Steps 5 and 6.

8. Remove the cover plate directly beneath the Temperature Control module and locate the labeled "CO2 Zero Adjustment" pot. Adjust this pot so that the RH display reads 000 (+/- 20). Turning this pot counterclockwise will decrease the display reading and clockwise will increase it.

Note: There will be several seconds of delay between each pot adjustment and the voltmeter reaction to that adjustment. In addition, the voltage will tend to "wander" by 10 millivolts or so. This is normal.

9. Using the up and down arrows on the CO_2 module, adjust the CO_2 display so that it reads "00.0".

Note: Make sure the word "Set" is not in the CO_2 window before making adjustment.

10. Turn the incubator power switch Off , then On, to take the unit out of Calibration mode.
11. Connect CO_2 to the incubator and adjust the CO_2 setpoint to the desired level.
12. Wait at least 10 minutes after the incubator has reached proper control level.
13. Turn the incubator OFF.
14. While holding down the inverted Y key on the CO_2 module, turn the incubator on. Continue holding the inverted Y key until the the high audible tone stops.
15. Check to see that the Temp Set display reads "00.0". (This indicates that you are in the Calibration mode).
16. Momentarily depress the inverted Y key so that the word Set appears in the LCD window. (This puts the unit in span adjust mode).
17. Read the CO_2 concentration on the independent test instrument.
18. Using the up and down arrow keys on the CO_2 module, adjust the CO_2 display to agree with actual CO_2 content in cabinet.
19. Turn the incubator off.
20. Close the control panel door and secure it.
21. Open and close (or fan) the chamber door to release the CO_2.
22. Turn the incubator on and adjust the setpoints as desired. Return the incubator to normal operation.
23. Allow the unit to stabilize about 1 hour.
24. Initiate an Auto-Zero cycle by placing the Program/Run switch in Program and the CO_2 module in Set mode (press the inverted "Y" key) and press the "hidden" key.
25. Wait about 30 minutes after the Auto-Zero cycle completes and read the CO_2 concentration on the independent test instrument.
26. If the CO_2 display does not match the independent instrument reading, repeat Steps 13 through 22.

5.17 Returning the Cabinet from Total Default

1. Turn the key switch to Program.

Note: All adjustments will be made on the RH module.

2. Place the RH module in the calibrate mode by pressing the inverted Y key while turning the power on.
3. Remove the sensor leads from terminals 11 and 12 on the micro-board.
4. Install a 1000 Ohm resistor across terminals 11 and 12.
5. Remove the word "Set" by momentarily depressing the inverted Y key.
6. Adjust the display to read "00.0" by using the up and down arrow keys.
7. Remove the 1000 Ohm resistor and replace it with a 1232 Ohm resistor.
8. Momentarily depress the inverted Y key to bring the word "Set" into the LCD window.
9. Adjust the display to read "60.0" by using the up and down arrow keys.
10. Repeat steps 4 through 9 until no changes are necessary.
11. Turn the incubator off.
12. Remove the resistor from terminals 11 and 12 and reinstall the sensor wires.

Note: The adjustments which follow will be made on the Temperature module.

13. Remove the reheat sensor wires from terminals 14 and 15.
14. Place the Temperature module in Calibrate mode by pressing the inverted Y key while turning the incubator on.
15. Install a 1000 Ohm resistor across terminals 14 and 15.
16. Remove the word "Set" by momentarily depressing the inverted Y key.
17. Adjust the display to read "00.0" by using the up and down arrow keys.
18. Remove the 1000 Ohm resistor and replace it with a 1232 Ohm resistor.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

19. Momentarily press the inverted Y key so that the word "Set" appears in the LCD window.
20. Adjust the display to read "60.0" by using the up and down arrow keys.
21. Repeat steps 15 to 20, as necessary.
22. Turn the incubator off.
23. Remove the resistor from terminals 14 and 15 and reinstall the sensor wires.
24. Hold down the fourth unmarked key on the CO_2 module and turn the main power on. Hold the key depressed until the high audible tone stops.
25. Remove the word "Set" from the LCD window by momentarily pressing the inverted Y key. Wait two minutes.
26. Adjust display to read "00.0" by using the up and down arrow keys.
27. Turn the incubator off.
28. Place an accurate thermometer and RH indicating device in the middle of the chamber.
29. Turn the incubator on and set the CO_2 setpoint for 05.0%. Set the temperature for 37.0°. Set the RH for 80%. Set the overtemp safety for 45.0°. Allow the incubator to stabilize for 6 hours.
30. Proceed with calibration of temperature, RH and CO_2 as outlined in the beginning of this section.

5.18 Drying out the Humidity Reservoir

Servicing must be performed by qualified service personnel only!

1. Drain the humidity reservoir (refer to Section 4.4).
2. Turn off and remove the cap from the barbed drain fitting on the back of the cabinet.
3. Open the incubator's outer and inner doors.
4. Swing open the control panel and remove the vinyl fill tubing from the side of the humidity reservoir. (The white plastic hose clamp is easily broken by twisting it).
5. Remove the access panel on the left side of the incubator (four screws) and jumper pin #4 of the humidity control relay to ground. (See Figure 5-7).




Figure 5-7

6. Turn the power to the unit on and leave it on for 45 minutes.
7. Turn the unit off and remove the jumper wire.
8. Replace the fill tubing onto the humidity reservoir and clamp it.
9. Close the control panel and replace the side access cover.
10. The unit is ready to be returned to service.

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 6 - Specifications

a. Electrical Requirements

Model 3033:
90-130VAC, 60 Hz, 1 Phase, 7 FLA Nominal

Model 3035:
180-260VAC, 50/60 Hz, 1 Phase, 4 FLA Nominal

Model 3860:
90-130VAC, 60 Hz, 1 Phase, 6.5 FLA Nominal

Model 3862:
180-260VAC, 50/60 Hz, 1 Phase, 3.7 FLA Nominal

Power Switch: 2 Pole
Main Control: Microprocessor
Data Output: 10 M/V Temperature, Humidity & CO_2
Installation Category: Overvoltage Category II
Pollution Degree 2

b. Dimensions

Model 3033/3035
Exterior: 40.25”W x 39.50”H x 26.75”F-B
102.2cm x 100.33cm x 67.95cm
Interior: 27.20”W x 32.95”H x 20.25”F-B
69.09cm x 83.69cm x 51.44cm

Model 3860/3862
Exterior: 32.50”W x 39.50”H x 26.75”F-B
82.55cm x 100.33cm x 67.95cm
Interior: 19.20”W x 32.95”H x 20.25”F-B
48.77cm x 83.69cm x 51.44cm

c. Temperature Control (+/- 0.05°C at 37°C)

Range: +4°C Above Ambient to +45°C
Sensor: Platinum Probe
Controller: Microprocessor
Display: Digital LCD
Readability: 0.1°C
Setability: 0.1°C

d. Temperature Alarm

Sensor: Platinum Probe
Display: Audio/Visual
Readability: 0.1°C
Setability: 0.1°C

e. CO_2

Inlet Pressure: 10 PSIG
Sensor: Infrared
Controller: Microprocessor
Display: Digital LCD
Readability: 0.1%
Setability: 0.1%
Alarm Differential and Delay: +/- 1% (nominal)

f. Fittings

Drain Port: 1/4” FPT Barbed Fitting
Access Port: 1.18” Removable Plug
CO2 Inlet: 1/4” Barbed Fitting
Fill Port: 1/4” FPT

g. Capacity

Humidity Reservoir: 1.0 gal., 50K to 1M Ohm/cm (3.75 L)

h. Shelves

Model 3033/3035
Standard: 6 Provided
Maximum: 26
Dimensions: 25.57” x 19.69” (64.95 cm x 50.01 cm)
Construction: Stainless Steel, Perforated

Surface Area:
Per Shelf: 3.5 sq. ft. (0.32 sq. m.)
Maximum Per Chamber: 91 sq. ft. (8.4 sq. m.)
Clearance: Adjustable on 1.0” centers (2.54cm)

Model 3860/3862
Standard: 5 Provided
Maximum: 26
Dimensions: 17.75” x 17.75” (45.1 cm x 45.1cm)
Construction: Stainless Steel, Perforated, Electropolished

Surface Area:
Per Shelf: 2.2 sq. ft. (0.2 sq. m.)
Maximum Per Chamber: 57 sq. ft. (5.3 sq. m.)
Clearance: Adjustable on 1.0” centers (2.54cm)

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

i. Certification

CSA: Standard 151
UL: Standard 1262 (Model 3033, 3860 Only)
EN61010-1, IEC 1010-1, IEC 1010-2-010
EN55011, Group 1 Class B
EN50082-1

j. Weight

Model 3033/3035
Approximate Net Weight: 380 lbs. (172 Kg)

Shipping:
Motor: 430 lbs. (195 Kg)
Air: 460 lbs. (209 Kg)
Ocean: 500 lbs. (227 Kg)

Model 3860/3862
Approximate Net Weight, 270 lbs. (122 Kg)

Shipping:
Motor: 350 lbs. (159 Kg)
Air: 380 lbs. (172 Kg)
Ocean: 430 lbs. (195 Kg)

k. Environmental Conditions (Indoor Use only)

Ambient Conditions: 5°C to 40°C
Relative Humidity: 80% up to 31°C, then decreasing linearly to 50% at 40°C
Altitude: Up to 2000 meters above sea level

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 7 - Accessories

7.1 Incubator Accessories

		Model Numbers			
Stock No.	**Description**	**3033**	**3035**	**3860**	**3862**
1900024	Caster Dolly	X	X		
1900026	Caster Dolly			X	X
224136	Stainless Steel Shelf Kit	X	X		
224144	Copper Shelf			X	X
224145	Electropolished Stainless Steel Shelf Kit			X	X
224159	Electropolished Stainless Steel Shelf Kit	X	X		
190035	Duplex Outlet Kit 115V (factory installed)	X		X	
190036	Duplex Outlet Kit 220V (factory installed)		X		X
523028	Floor Stand (for stacked units)	X	X	X	X
760045	Disposable HEPA Filter (99.97%) Assembly	X	X	X	X
770001	Disposable Microbiological Gas Filter (99.97%)	X	X	X	X
6003033	Installation/Operation Qualification Protocol	X	X	X	X

7.2 General Accessories

Stock No.	**Description**
155021	CO_2 Fyrite Analyzer Kit 0-20%
220051	Replacement Fluid for CO_2 Analyzer (three bottles per carton)
965010	Two-Stage Regulator, CO_2
285722	Glass Thermometer, 0°C to 100°C

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Section 8 - Parts List

Model 3033/3035/3860/3862 Parts

Qty	Stock	# Description
1	900078	Blower motor kit
1	130625	Tubeaxial fan, 115V
1	760045	Disposable HEPA filter 99.97
1	770001	Disposable gas filter 99.97
1	780266	Inline water filter
1	290042	Platinum probe (1000 Ohm sensor)
1	190253	CO_2 sensor with p.c. board
1	400051	Power supply board
1	190867	Temp alarm/monitor board
1	250049	S.S. solenoid valve (humidity)
1	250052	3-way solenoid valve (auto-zero)
1	250085	Solenoid valve (CO_2)
1	184058	Mini vac/pressure pump-1/4 l/m (for auto-zero solenoid)
1	190211	Frequency control board (3035/3862)
1	230103	Glass fuse, .75A, time delay
2	230066	Ceramic fuse, 10A, time delay (3033/3860)
2	230093	Ceramic fuse, 5A, time delay (3035/3862)
1	230120	Fuse, (for convenience outlet) .5A, time delay
1	430108	Line cord set (3033/3860)
1		* Line cord set (3035/3862)

* Country dependent, consult factory

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Figure 8-1

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com






Figure 8-2

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



Electrical Schematic
Model:
3033 and 3035
Steri-Cult Incubator

3033-70-0-D REV.32
Page 2 of 3

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



WIRE REFERENCE CHART

WIRE NO	GA	COLOR	WIRE NO	GA	COLOR	WIRE NO	GA	COLOR
1	16	BRN	21	24/2	BLK	48	20	ORG
2	16	BLU	22	24/2	WHT or CLR	49	20	BRN
3	16	GRN/YEL	23	24/2	BLK	50	20	PUR
4	16	BLK	24	24/2	WHT or CLR	51	20	PUR
5	20	WHT	25	NOT USED		52	20	ORG
5A	10	WHT	26	NOT USED		53	20	BRN
5B	24	WHT	27	24/2	WHT or CLR	54	20	BLK
6	10	GRY	28	24/2	BLK	55	20	BLU
6A	16	BLU	29	20	YEL	56	20	BLU
7	16	BRN	30	20	GRN	57	20	PUR
7A	16	BRN	31	20	BLK	58	20	YEL
8	16	BLU	32	20	RED	59	20	RED
8A	16	BLU	33	22/3	BLK	60	20	ORG
9	20	BLK	34	22/3	WHT	61	24/2	BLK
9A	16	BLK	35	22/3	RED	62	24/2	WHT or CLR
9B	24	BLK	36	20	BLU	63	NOT USED	
10	20	PUR	37	HEATER LEAD		64	22/3	BLK
11	20	BRN	38	HEATER LEAD		65	22/3	RED
12	NOT USED		39	HEATER LEAD		66	22/3	WHT or CLR
13	NOT USED		40	HEATER LEAD		67	NOT USED	
14	NOT USED		41	20	YEL	68	22/3	RED
15	NOT USED		42	20	RED	69	NOT USED	
16	NOT USED		43	20	ORG	70	16	GRN
17	NOT USED		44	20	BRN	71	20	RED
18	22/3	RED	45	NOT USED		72	20	BLK
19	22/3	BLK	46	NOT USED		73	20	BLK
20	22/3	WHT or CLR	47	NOT USED				

NOTES:

⊛	Denotes Terminal Strip Connection	Parts List Reference Number	
N/A	Last Relay Number	○	Assembly
N/A	Last Terminal Number	⬠	Panel
73	Last Wire Number	⬡	Refrigeration
		□	Wiring

CUSTOMER APPROVAL/REFERENCE
APPROVED BY _____
APPROVING FIRM _____
DATE OF APPROVAL _____

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND SUCH INFORMATION IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM THERMO FORMA

REV	ECR NO.	DATE	BY	CAD	APPD	DESCRIPTION OF REVISION
32	IN-2948	06-05-01	GLM	KDG	LDN	INLET 460123 TO 480160 & ADD FERRITE
31	SI-8132	12-18-00	JAS	KDG	LDN	CHG. 360146 POWER SWITCH TO 363033
30	SI-6940	03-26-98	CBG	KDG	LDN	CHG. WIRES 5B & 9B 22 GA. TO 24 GA.
29	SI-6743	10-20-97	CBG	KDG	LDN	CLARIFY WIRING ON XFORMER INPUT
28	IN-2308	07-29-97	GJG	GJG	LDN	CHANGED AIR PUMP STOCK NUMBER

DATE 8-10-94 | DWN RET | CAD N/A | APPD LDN | SCALE NTS

CUSTOMER

JOB TITLE 3033/3035 STERI-CULT 200 INCUBATOR

DWG TITLE ELECTRICAL SCHEMATIC


LOCATION INCUBATR01 | JOB NUMBER | DRAWING NUMBER 3033-70-0-D

ThermoForma
ROI 649, MARIETTA, OHIO 45750


Electrical Schematic
Model:
3033 and 3035
Steri-Cult Incubator

3033-70-0-D REV.32
Page 3 of 3

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com




Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



Electrical Schematic
Model:
3860 and 3862
Steri-Cult Incubator

3860-70-0-D REV.16
Page 2 of 3

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com



WIRE REFERENCE CHART

WIRE NO	GA	COLOR	WIRE NO	GA	COLOR	WIRE NO	GA	COLOR
1	16	BRN	21	24/2	BLK	48	20	ORG
2	16	BLU	22	24/2	WHT or CLR	49	20	BRN
3	16	GRN/YEL	23	24/2	BLK	50	20	PUR
4	16	BLK	24	24/2	WHT or CLR	51	20	PUR
5	20	WHT	25	NOT USED		52	20	ORG
5A	16	WHT	26	NOT USED		53	20	BRN
5B	22	WHT	27	24/2	WHT or CLR	54	20	BLK
6	16	GRY	28	24/2	BLK	55	20	BLU
6A	16	BLU	29	20	YEL	56	20	BLU
7	16	BRN	30	20	GRN	57	20	PUR
7A	16	BRN	31	20	BLK	58	20	YEL
8	16	BLU	32	20	RED	59	20	RED
8A	16	BLU	33	22/3	BLK	60	20	ORG
9	20	BLK	34	22/3	WHT	61	24/2	BLK
9A	16	BLK	35	22/3	RED	62	24/2	WHT or CLR
9B	22	BLK	36	20	BLU	63	NOT USED	
10	20	PUR	37	HEATER LEAD		64	22/3	BLK
11	20	BRN	38	HEATER LEAD		65	22/3	RED
12	NOT USED		39	HEATER LEAD		66	22/3	WHT or CLR
13	NOT USED		40	HEATER LEAD		67	NOT USED	
14	NOT USED		41	20	YEL	68	22/3	RED
15	NOT USED		42	20	RED	69	NOT USED	
16	NOT USED		43	20	ORG	70	16	GRN
17	NOT USED		44	20	BRN	71	20	RED
18	22/3	RED	45	NOT USED		72	20	BLK
19	22/3	BLK	46	NOT USED		73	20	BLK
20	22/3	WHT or CLR	47	NOT USED				

NOTES.

⊛	Denotes Terminal Strip Connection	Parts List Reference Number	
N/A	Last Relay Number	⬠	Assembly
N/A	Last Terminal Number	⬠	Panel
73	Last Wire Number	⬡	Refrigeration
		□	Wiring

CUSTOMER APPROVAL/REFERENCE
APPROVED BY _____
APPROVING FIRM _____
DATE OF APPROVAL _____

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION AND SUCH INFORMATION IS NOT TO BE DISCLOSED TO OTHERS FOR ANY PURPOSE NOR USED FOR MANUFACTURING PURPOSES WITHOUT WRITTEN PERMISSION FROM THERMO FORMA

REV	ECR NO.	DATE	BY	CAD	APPD	DESCRIPTION OF REVISION
J6	IN-2948	06-05-01	GLM	KDG	LDN	INLET 460129 TO 460180 & ADD FERRITE
J5	SI-8132	12-18-00	JAS	KDG	LDN	CHG. 360146 POWER SWITCH TO 363033
J4	SI-6743	10-20-97	CBG	KDG	LDN	CLARIFY WIRING ON XFORMER INPUT
J3	IN-2308	07-29-97	GJG	GJG	LDN	CHANGE AIR PUMP STOCK NUMBER
J2	IN-2294	08-30-97	JAS	KDG	LDN	DELETED FREQUENCY BOARD OUTPUT CABLE

DATE 8-14-89	DWN RTT	CAD N/A	APPD LDN	SCALE NTS
CUSTOMER			
JOB TITLE 3860/3862 HEPA FILTERED IR INCUBATOR			
DWG TITLE ELECTRICAL SCHEMATIC			
LOCATION INCUBATR01	JOB NUMBER	DRAWING NUMBER 3860-70-0-D	

Thermo Forma
BOX 649, MARIETTA, OHIO 45750

Electrical Schematic
Model:
3860 and 3862
Steri-Cult Incubator

3860-70-0-D REV.16
Page 3 of 3

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Thermo Forma
Millcreek Road, P.O. Box 649
Marietta, Ohio 45750
U.S.A.

Telephone (740) 373-4763
Telefax (740) 373-4189

Artisan Technology Group - Quality Instrumentation ... Guaranteed | (888) 88-SOURCE | www.artisantg.com

Artisan Technology Group is an independent supplier of quality pre-owned equipment

Gold-standard solutions

Extend the life of your critical industrial, commercial, and military systems with our superior service and support.

We buy equipment

Planning to upgrade your current equipment? Have surplus equipment taking up shelf space? We'll give it a new home.

Learn more!

Visit us at **artisantg.com** for more info on price quotes, drivers, technical specifications, manuals, and documentation.

Artisan Scientific Corporation dba Artisan Technology Group is not an affiliate, representative, or authorized distributor for any manufacturer listed herein.

We're here to make your life easier. How can we help you today?

(217) 352-9330 | sales@artisantg.com | artisantg.com

ARTISAN® TECHNOLOGY GROUP